



STORMSHIELD



GUIDE

STORMSHIELD NETWORK SECURITY

CLI SERVERD COMMANDS REFERENCE GUIDE

Version 4.3.29 LTSB

Document last updated: July 22, 2024

Reference: sns-en-cli_serverd_commands_reference_guide-v4.3-LTSB



Table of contents

Introduction	4
Changelog of serverd commands between SNS v4.2 and SNS v4.3	5
Changelog of serverd commands between SNS v4.1 and SNS v4.2	13
Changelog of serverd commands between SNS v4.0 and SNS v4.1	16
Changelog of serverd commands between SNS v3.11 and SNS v4.0	20
AUTH	24
CHPWD	25
CONFIG	26
CONFIG ACTIVATE	26
CONFIG ANTISPAM	26
CONFIG ANTIVIRUS	33
CONFIG AUTH	38
CONFIG AUTOBACKUP	61
CONFIG AUTOUPDATE	64
CONFIG BACKUP	67
CONFIG BIRD	68
CONFIG CHECKDB	70
CONFIG	
COMMUNICATION	71
CONFIG CONSOLE	82
CONFIG CRYPTO	86
CONFIG DDNSCLIENT	86
CONFIG DHCP	90
CONFIG DNS	111
CONFIG DOWNLOAD	116
CONFIG FILTER	116
CONFIG FWADMIN	124
CONFIG GLOBAL	127
CONFIG HA	156
CONFIG HOSTREP	161
CONFIG IPSEC	165
CONFIG KEY	195
CONFIG LCD	196
CONFIG LDAP	197
CONFIG LOG	206
CONFIG MAILFILTERING	219
CONFIG MODEM	224
CONFIG NETWORK	226
CONFIG NTP	260
CONFIG OBJECT	264
CONFIG OPENVPN	313
CONFIG	
PASSWDPOLICY	316
CONFIG PPTP	318
CONFIG PROTOCOL	322
CONFIG PVM	703
CONFIG RAID	715
CONFIG REPORT	716
CONFIG RESTORE	718
CONFIG SANDBOXING	719
CONFIG SECURE	721
CONFIG	
SECURITYINSPECTION	726
CONFIG SLOT	738
CONFIG SMCROUTING	742
CONFIG SNMP	747
CONFIG SSH	756
CONFIG SSLFILTERING	759
CONFIG STATUS	763
CONFIG SYSEVENT	765
CONFIG TELEMETRY	767
CONFIG UPLOAD	768
CONFIG URLD	769
CONFIG URLFILTERING	771
CONFIG WEBADMIN	777
CONFIG WIFI	783
CONFIG XVPN	785
GLOBALADMIN	797
GLOBALADMIN	
GETINFOS	797
GLOBALADMIN	
GETSTATUS	797
HA	798
HA CHECKSYNC	798
HA CLUSTER	798
HA HALT	801
HA INFO	801
HA REBOOT	803
HA REMOTE	803
HA SETMODE	804
HA SYNC	804
HA TPMSYNC	805
HELP	806
LIST	807
LOG	808
LOG CLEAR	808
LOG DATETOLINE	808
LOG DOWNLIMIT	809
LOG DOWNLOAD	809
LOG INFO	810
LOG PROPERTY	810
LOG SEARCH	811
MODIFY	814
MONITOR	815
MONITOR ADDRESSLIST	815
MONITOR AGG	816
MONITOR ALARM	817
MONITOR ANTIVIRUS	817
MONITOR ASSOCIATION	818
MONITOR AUTOBACKUP	819
MONITOR AUTOUPDATE	819
MONITOR BYPASS	820
MONITOR CERT	820
MONITOR CRL	820
MONITOR CRYPTOCARD	821
MONITOR DHCP	822
MONITOR DISK	822
MONITOR ETHER	823
MONITOR FAN	823
MONITOR FILTER	824
MONITOR FILTERTABLE	824
MONITOR FLUSH	825
MONITOR FWADMIN	828
MONITOR GETIKESA	828
MONITOR GETSA	829
MONITOR GETSPD	830
MONITOR GPRS	831
MONITOR HEALTH	831
MONITOR HOST	832
MONITOR HOSTREP	833
MONITOR INTERFACE	833
MONITOR IPGEOLOC	834
MONITOR IPREP	834
MONITOR LOG	835
MONITOR MISC	835
MONITOR OPENVPN	836
MONITOR POLICY	837
MONITOR POWER	838
MONITOR PROXYCACHE	838
MONITOR PVM	839



MONITOR QOS	850	SYSTEM IDENT	897
MONITOR RADIUS	850	SYSTEM INFormatiON	898
MONITOR RAID	850	SYSTEM INITIALIZE	898
MONITOR REVRT	851	SYSTEM LANGUAGE	899
MONITOR ROUTE	852	SYSTEM LED	899
MONITOR ROUTER	852	SYSTEM LICENCE	900
MONITOR		SYSTEM LOGDISK	903
SANDBOXING	853	SYSTEM NSLOOKUP	904
MONITOR SERVICES	854	SYSTEM PCAP	905
MONITOR SMART	854	SYSTEM PING	907
MONITOR SSOAGENT	854	SYSTEM PROPERTY	907
MONITOR STAT	855	SYSTEM REBOOT	909
MONITOR SYSLOG	855	SYSTEM REGISTER	909
MONITOR SYSTEM	856	SYSTEM RIGHT	910
MONITOR THIND	856	SYSTEM SESSION	914
MONITOR TPM	857	SYSTEM SETBOOT	914
MONITOR USER	857	SYSTEM SETBRANCH	915
NOP	859	SYSTEM STATUS	915
PKI	860	SYSTEM TPM	915
PKI ACTIVATE	860	SYSTEM TIMEZONE	918
PKI CA	860	SYSTEM TRACEROUTE	920
PKI CERTIFICATE	869	SYSTEM UPDATE	920
PKI CONFIG	873	SYSTEM WATCHDOG	923
PKI CRL	874	USER	924
PKI EST	876	USER ACCESS	924
PKI IMPORT	878	USER CERTIFICATE	930
PKI REQUEST	878	USER CHECK	930
PKI SCEP	881	USER CREATE	931
PKI SEARCH	886	USER GROUP	931
QUIT	887	USER LIST	936
REPORT	888	USER PASSWORD	937
REPORT GET	888	USER REMOVE	937
REPORT RESET	891	USER REQUEST	938
SYSTEM	892	USER SEARCH	942
SYSTEM BACKUP	892	USER SHOW	942
SYSTEM BYPASS	892	USER UPDATE	943
SYSTEM CHECKCRL	893	USER VOUCHER	944
SYSTEM CLONE	894	VERSION	948
SYSTEM			
CHECKVERSION	894		
SYSTEM DATE	895		
SYSTEM			
DEFAULTCONFIG	895		
SYSTEM ETHERCOUNT	896		
SYSTEM FWADMIN	896		
SYSTEM HALT	897		



Introduction

This document details all the Stormshield Network CLI / Serverd commands of the IPS-Firewall for the release 4.3.29 LTSB.

These commands can be executed in the *CLI console* module in web administration, with an administration client connected port 1300 (NSRPC) or by making use of the [SNS-PYTHON-API](#).

These commands can be used from version 4.3.29 LTSB of Stormshield Network firmware. To check their validity in earlier versions, please refer to the *History* category of the description of these commands.



Changelog of serverd commands between SNS v4.2 and SNS v4.3

Removed commands

Commands replaced by another one

Commands with the same name that change behavior

CONFIG AUTH SHOW

- Before:

```
[radius]
state          : status of this method
host           : radius server hostname
port          : radius port
pencoding      : radius server charset encoding
bhost         : radius backup server hostname
bport         : radius backup port
bencoding      : radius backup server charset encoding
presharedkey   : key used for encrypting exchanges between the firewall and
the RADIUS server
bpresharedkey  : key used for encrypting exchanges between the firewall and
the Backup RADIUS server
```

[...]

```
[agent]
State          : activate or not the agent
Mscontroller   : object name of the Microsoft domain controller
MsbackupController : object name of the second Microsoft domain controller
Directory      : name of the LDAP directory to use
MaxLogonTime   : maximum time in seconds for the authentication
Probe         : activate or not the user logout probing
ProbeMethod    : comma separated list of probing methods (arp, icmp,
nbstat, registry, ...)
ProbeTimeout   : maximum time in seconds for not responding stations
BindAddr       : the IP address of the source connection
BindPort       : the port of the source connection
AgentAddr      : the IP address of the agent
AgentPort      : the port of the agent
AgentPassword  : the password of the agent
BackupAddr     : the IP address of the backup agent
BackupPort     : the port of the backup agent
BackupPassword : the password of the backup agent
DomainName     : the filter to be applied on logon events
```

- After:

```
[radius]
state          : status of this method
host           : radius server hostname
port          : radius port
pencoding      : radius server charset encoding
bhost         : radius backup server hostname
```



```
bport          : radius backup port
bencoding      : radius backup server charset encoding
presharedkey   : key used for encrypting exchanges between the firewall and
the RADIUS server
bpresharedkey  : key used for encrypting exchanges between the firewall and
the Backup RADIUS server
timeout       : timeout in milliseconds when authenticating on the RADIUS server
btimeout       : timeout in milliseconds when authenticating on the backup RADIUS
server
retry: number of retries when authenticating on the RADIUS server
bretry: number of retries when authenticating on the backup RADIUS server
VSAusergroup: 1 if user group VSA support is enabled, 0 otherwise
```

```
[...]
```

```
[agent]
```

```
State          : activate or not the agent
Mscontroller   : object name of the Microsoft domain controller
MsbackupController : object name of the second Microsoft domain controller
Directory      : name of the LDAP directory to use
MaxLogonTime   : maximum time in seconds for the authentication
Probe          : activate or not the user logout probing
ProbeMethod    : comma separated list of probing methods (arp, icmp,
nbstat, registry, ...)
ProbeTimeout   : maximum time in seconds for not responding stations
BindAddr       : the IP address of the source connection
AgentAddr      : the IP address of the agent
AgentPort      : the port of the agent
AgentPassword  : the password of the agent
BackupAddr     : the IP address of the backup agent
BackupPort     : the port of the backup agent
BackupPassword : the password of the backup agent
DomainName     : the filter to be applied on logon events
```

CONFIG NETWORK ROUTE SHOW

- Before:

```
[StaticRoutes]
Remote=mynet Address=172.168.100.0/24 Interface=out Gateway=10.2.0.1
Color=000c0a Protected=0 State=0 Comment=""
Remote=192.168.100.0/255.255.255.0 Interface=in Gateway=10.2.2.1
Color=0a0c0a Protected=1 State=1 Comment="test route"
```

- After:

```
[StaticRoutes]
Remote=mynet Address=172.168.100.0/24 Interface=out Gateway=10.2.0.1
Color=000c0a GatewayHasLB=0 Protected=0 State=0 Comment=""
Remote=192.168.100.0/255.255.255.0 Interface=in Gateway=10.2.2.1
Color=0a0c0a GatewayHasLB=0 Protected=1 State=1 Comment="test route"
Remote=mynet Address=10.3.0.0/16 Interface=in Gateway=myrouter Color=0a0c0a
GatewayHasLB=1 Protected=1 State=1 Comment=""
```

CONFIG NETWORK ROUTE ADD

The token **interface** is now optional if there is value for **gateway** token.

CONFIG NETWORK ROUTE IPV6 ADD

The token **interface** is now optional if there is value for **gateway** token.



MONITOR HEALTH

- Before:

```
[&lt;serial>]
hamode=(none|active|passive)
cpu=(n/a|unknown|good|minor|major)
cpu_temp=(n/a|unknown|good|minor|major)
disk=(n/a|unknown|good|minor|major)
fans=(n/a|unknown|good|minor|major)
mem=(n/a|unknown|good|minor|major)
powerstatus=(n/a|unknown|good|minor|major)
raid=(n/a|unknown|good|minor|major)
cert=(n/a|unknown|good|minor|major)
crl=(n/a|unknown|good|minor|major)
passwd=(n/a|unknown|good|minor|major)
[MAIN]
status=(unknown|good|minor|major)
```

- After:

```
[&lt;serial>]
hamode=(none|active|passive)
cpu=(n/a|unknown|good|minor|major)
cpu_temp=(n/a|unknown|good|minor|major)
disk=(n/a|unknown|good|minor|major)
fans=(n/a|unknown|good|minor|major)
mem=(n/a|unknown|good|minor|major)
powerstatus=(n/a|unknown|good|minor|major)
raid=(n/a|unknown|good|minor|major)
cert=(n/a|unknown|good|minor|major)
crl=(n/a|unknown|good|minor|major)
passwd=(n/a|unknown|good|minor|major)
router=(n/a|unknown|good|minor|major)
[MAIN]
status=(unknown|good|minor|major)
```

CONFIG HA SHOW

- Before:

```
[Global]
State=0|1                : Is HA activated?
Initialized=0|1          : HA initialization
SendARP=0|1              : SendARP state
SendARPPeriod=           : delay (sec) between 2 ARPs
Secure=0|1               : Crypto state on the HA link
InterfacesFlipFlop=<0-20000> : How long, in milliseconds, non-HA interfaces
must go down when the firewall becomes passive (0=disabled)
LACPWhenPassive=1        : Maintain LACP negotiations while being
passive
DelayConnUpd=10           : Connections living less than this value (in
seconds) won't be synchronized
LACPMembersHaveWeight=1   : Include LACP members in quality computation
```

- After:

```
[Global]
State=0|1                : Is HA activated?
Initialized=0|1          : HA initialization
SendARP=0|1              : SendARP state
SendARPPeriod=           : delay (sec) between 2 ARPs
```



```
Secure=0|1 : Crypto state on the HA link
InterfacesFlipFlop=<0-20000> : How long, in milliseconds, non-HA interfaces
must go down when the firewall becomes passive (0=disabled)
LACPWhenPassive=1 : Maintain LACP negotiations while being
passive
DelayConnUpd=10 : Connections living less than this value (in
seconds) won't be synchronized
LACPMembersHaveWeight=1 : Include LACP members in quality computation
FailoverMembersHaveWeight=1 : Include Failover members in quality
computation
```

CONFIG OBJECT ROUTER SHOW

- Before:

```
[Config]
name=myrouter
comment="nice comment"
gatewaythreshold=1
activateallbackup=0
frequency=15
tries=3
wait=2
loadbalancing=connhash
onfailpolicy=Pass

[PrincipalGateway]
pos=1 host=host1 check=www.google.com comment="First router"
pos=2 host=host2 check=www.google.com comment="Second router"

[BackupGateway]
pos=1 host=host3 check=www.google.com comment=""
```

- After:

```
[Config]
name=myrouter
monitor=TCP_PROBE
port=tcp_service
comment="nice comment"
gatewaythreshold=1
activateallbackup=0
frequency=15
tries=3
triesup=0
wait=2
loadbalancing=connhash
onfailpolicy=Pass
slause=0
slalatency=
slajitter=
slalossrate=
slaunreachablerate=

[PrincipalGateway]
pos=1 host=host1 check=www.google.com comment="First router"
pos=2 host=host2 check=www.google.com comment="Second router"

[BackupGateway]
pos=1 host=host3 check=www.google.com comment=""
```




CONFIG OBJECT GET

- Before:

```
[Object]
[...]
type=router global=0 modify=<0|1> name= comment= gatewaythreshold=
activateallbackup=<0|1> frequency= wait= tries= loadbalancing=
onfailpolicy=
[...]
```

- After:

```
[Object]
[...]
type=router global=0 modify=<0|1> name= comment= gatewaythreshold=
activateallbackup=<0|1> frequency= wait= tries= triesup= loadbalancing=
onfailpolicy=
[...]
```

CONFIG OBJECT LIST

- Before:

```
[Object]
[...]
type=router global=0 modify=<0|1> name= comment= gatewaythreshold=
activateallbackup=<0|1> frequency= wait= tries= loadbalancing=
onfailpolicy= used=<0|1>
[...]
```

- After:

```
[Object]
[...]
type=router global=0 modify=<0|1> name= comment= gatewaythreshold=
activateallbackup=<0|1> frequency= wait= tries= triesup= loadbalancing=
onfailpolicy= used=<0|1>
[...]
```

Commands with new mandatory parameters

Commands with new optional parameters

CONFIG AUTH RADIUS

- timeout [no default value]
- btimeout [no default value]
- retry [no default value]
- bretry [no default value]
- VSAusergroup [no default value]



CONFIG FILTER RULE UPDATE

- ackqosid {no default value}

CONFIG NETWORK INTERFACE CREATE

- Laggmode {default: lacp}
- LaggFailoverMaster {no default value}

CONFIG NETWORK INTERFACE UPDATE

- Laggmode {default: lacp}
- LaggFailoverMaster {no default value}

CONFIG NETWORK INTERFACE AGGREGATE

- Laggmode {default: lacp}

MONITOR QOS

- ifname {default: all interfaces will be displayed}

MONITOR CONNECTION

- ackqidname {default: no default value}
- rtstate {default: no default value}

MONITOR FLUSH STATE

- rtstate {default: no default value}

CONFIG HA CREATE

- FailoverMembersHaveWeight {default: 0}

CONFIG HA UPDATE

- FailoverMembersHaveWeight {default: 0}

CONFIG SSH UPDATE

- CLIShell {default: no default value}
- LogAdmin {default: no default value}



CONFIG OBJECT ROUTER NEW

- monitor {default: no default value}
- triesup {default: no default value}
- slause {default: no default value}
- slajitter {default: no default value}
- slalency {default: no default value}
- slalossrate {default: no default value}
- slaunreachablerate {default: no default value}

CONFIG GLOBAL OBJECT ROUTER NEW

- monitor {default: no default value}
- triesup {default: no default value}
- slause {default: no default value}
- slajitter {default: no default value}
- slalency {default: no default value}
- slalossrate {default: no default value}
- slaunreachablerate {default: no default value}

CONFIG IPSEC UPDATE

- UsedInterface {default: no default value}

CONFIG IPSEC PEER NEW

- mobike {default: no default value}

CONFIG IPSEC PEER UPDATE

- mobike {default: no default value}

CONFIG OBJECT QOS QID ADD

- lengthrev {default: 0 if update=1}

CONFIG OBJECT QOS QID LIST

- useclone {default: 0}

CONFIG PROTOCOL PROFILE ALARM UPDATE

- ackqid {default: no default value}



CONFIG PROTOCOL SSL COMMON PROXY SSLPROTOCOL

- TLSv1_3 [default: no default value]

PKI CERTIFICATE CREATE

- force [default: 0]

CONFIG PROTOCOL TCPUDP COMMON IPS CONNECTION

- UseAutoFastRoute [default: 1]



Changelog of serverd commands between SNS v4.1 and SNS v4.2

Removed commands

Commands replaced by another one

CONFIG CONSOLE SSH

- Replaced by: CONFIG SSH UPDATE

CONFIG CONSOLE GETHOSTKEY

- Replaced by: CONFIG SSH GETHOSTKEY

CONFIG CONSOLE GETKEY

- Replaced by: CONFIG SSH GETKEY

CONFIG IPSEC PROFILE PHASE1 ADDPROP

- Replaced by: CONFIG IPSEC PROFILE PHASE1 PROPOSALS ADD

CONFIG IPSEC PROFILE PHASE1 REMOVEPROP

- Replaced by: CONFIG IPSEC PROFILE PHASE1 PROPOSALS REMOVE

CONFIG IPSEC PROFILE PHASE1 MOVEPROP

- Replaced by: CONFIG IPSEC PROFILE PHASE1 PROPOSALS MOVE

Commands with the same name that change behavior

MONITOR GETSA

- Before:

```
101 begin
src=10.2.0.1 dst=10.2.0.2 type="esp" mode="tunnel" spi=6599678
peerspi=106673664 reqid=16385 enc="rijndael-cbc" auth="hmac-sha1"
state="mature" lifetime=465 bytes=101552 maxlifetime=600 maxbytes=0
```

- After:

```
101 begin
rulename="ba6c3194672da4df9590d7ff827384b4" ikerulename="Site_fw_vm_2"
src=192.168.10.1 srcname=Firewall_in dst=192.168.11.1 dstname=fw_vm_2
type="esp" mode="tunnel" encap=0 esn=0 reqid=1 spiout=3439867777
```



```
spiin=3485712767 enc=AES_CBC/256 auth=HMAC_SHA2_256_128 state=INSTALLED  
bytesin=0 bytesout=864 packetsin=0 packetsout=8 lifetime=134  
maxlifetime=3601
```

MONITOR GETSPD

- Before:

```
101 begin  
src=127.0.0.0 srcmask=8 srcname=Network_loopback dst=127.0.0.0 dstmask=8  
dstname=Network_loopback dir=in policy=none spid=13 seq=3 pid=56555
```

- After:

```
101 begin  
rulename="Site_fw_vm_2" src=192.168.74.4 srcmask=32 srcname=vm_base  
dst=0.0.0.0 dstmask=0 dstname=any srcgw=192.168.10.1 srcgwname=Firewall_in  
dstgw=192.168.11.1 dstgwname=fw_vm_2 localid="lid" peerid="pid" ike=2  
enc="esp" policy="TUNNEL" maxlifetime=2880
```

Commands with new mandatory parameters

Commands with new optional parameters

CONFIG WEBADMIN IDLE

- ServerTimeout <60-3600> [no default value]
- ClientMaxTimeout <0-3600> [no default value]

CONFIG IPSEC PROFILE PHASE1 LIST

- useclone [default: off]

CONFIG IPSEC PROFILE PHASE1 SHOW

- useclone [default: off]

CONFIG IPSEC PROFILE PHASE2 LIST

- useclone [default: off]

CONFIG IPSEC PROFILE PHASE2 SHOW

- useclone [default: off]

CONFIG IPSEC POLICY GATEWAY ADD

- rulename
- tfc



CONFIG IPSEC POLICY GATEWAY UPDATE

- tfc

CONFIG IPSEC POLICY MOBILE ADD

- rulename
- tfc

CONFIG IPSEC POLICY MOBILE UPDATE

- tfc

PKI EST QUERY

- force {on|off}

PKI SCEP QUERY

- force {on|off}



Changelog of serverd commands between SNS v4.0 and SNS v4.1

Removed commands

SYSTEM REGISTER

Commands replaced by another one

Commands with the same name that change behavior

HA INFO

- Before:

```
[&lt;serial>]  
Reply=  
Model=  
Version=  
Supervisor=  
AsqDumpVersion=  
ConnSyncVersion=  
ClusterBalancingVersion=  
Forced=  
Mode=  
Licence=  
ConnectedOn=  
BackupActive=  
BackupVersion=  
BackupDate=  
Quality=  
Priority=  
Boot=  
LastConfigSync=  
LastModeChange=  
State=  
Ip=  
Link=  
LinkStatusChanged=  
BackupIp=  
BackupLink=  
BackupLinkStatusChanged=  
FwadminRevision=
```

- After:

```
[<serial>]  
Reply=  
Model=  
Version=  
Supervisor=  
AsqDumpVersion=  
ConnSyncVersion=  
ClusterBalancingVersion=  
Forced=
```




```
Mode=  
Licence=  
ConnectedOn=  
BackupActive=  
BackupVersion=  
BackupDate=  
Quality=  
Priority=  
Boot=  
LastConfigSync=  
LastModeChange=  
State=  
Ip=  
Link=  
LinkStatusChanged=  
BackupIp=  
BackupLink=  
BackupLinkStatusChanged=  
FwadminRevision=  
SystemNodeName=
```

SYSTEM IDENT

- Before:

```
SystemName=  
SystemAccess=  
SystemFqdn=
```

- After:

```
SystemName=  
SystemAccess=  
SystemFqdn=  
SystemNodeName=
```

CONFIG IPSEC LDAPLOOKUP LIST

- Before:

```
[ldap]  
domain=ldap_entry_1, ldap_entry_2
```

- After:

```
[ldap]  
pos=0 domain=ldap_entry_1  
pos=1 domain=ldap_entry_2
```

PKI IMPORT

- force behavior changed: now, if the certificate already exists in the PKI, it will not be imported with a different name if force=0.

Commands with new mandatory parameters

CONFIG CONSOLE SETPASSPHRASE

- oldpassword



CONFIG IPSEC LDAPLOOKUP UPDATE

- pos

Commands with new optional parameters

CONFIG AUTH AGENT

- SyslogBackupAddr (<object>|any)

CONFIG NETWORK INTERFACE ADDRESS ADD

- DHCPVendorClassId (no default value)
- DHCPUserClass (no default value)
- DHCPAuthsend (no default value)

SYSTEM IDENT

- SystemNodeName (no default value)

CONFIG OBJECT HOST NEW

- beginmac (no default value)
- endmac (no default value)

CONFIG IPSEC PSK ADD

- identifier (replaces id)

CONFIG IPSEC PSK LIST

- identifier (replaces id)

CONFIG IPSEC PSK REMOVE

- identifier (replaces id)

PKI CA CONFIG SHOW

- scope (local|global|both)

PKI CA CONFIG CRLDP SHOW

- scope (local|global|both)



PKI CA SHOW

- scope {local|global|both}

PKI CERTIFICATE SHOW

- scope {local|global|both}

CONFIG NETWORK INTERFACE CREATE

- MigrateArp {on|off}

CONFIG NETWORK INTERFACE UPDATE

- MigrateArp {on|off}

CONFIG WEBADMIN IDLE

- ServerTimeout <60-3600> {no default value}
- ClientMaxTimeout <0-3600> {no default value}

PKI CONFIG UPDATE

- checkcrlbindaddr



Changelog of serverd commands between SNS v3.11 and SNS v4.0

Removed commands

CONFIG SECURE

- CONFIG SECURE LIST
- CONFIG SECURE ADD
- CONFIG SECURE REMOVE
- CONFIG SECURE SYNC
- CONFIG SECURE STATE
- CONFIG SECURE SHOW
- CONFIG SECURE INITIALIZE
- CONFIG SECURE LOAD
- CONFIG SECURE BACKUP
- CONFIG SECURE RESTORE

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID

- CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID SHOW
- CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID INSERT
- CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID REMOVE
- CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID UPDATE

CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID

- CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID SHOW
- CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID INSERT
- CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID REMOVE
- CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID UPDATE

CONFIG PROTOCOL NB-SSN PROFILE IPS UUID

- CONFIG PROTOCOL NB-SSN PROFILE IPS UUID SHOW
- CONFIG PROTOCOL NB-SSN PROFILE IPS UUID INSERT
- CONFIG PROTOCOL NB-SSN PROFILE IPS UUID REMOVE
- CONFIG PROTOCOL NB-SSN PROFILE IPS UUID UPDATE



Commands replaced by another one

Commands with the same name that change behavior

CONFIG NETWORK ACTIVATE

Example: create a VLAN interface without physical interface attached

- Before:

```
SRPClient> CONFIG NETWORK ACTIVATE
100 code=00a00100 msg="Ok"
```

- After:

```
SRPClient> CONFIG NETWORK ACTIVATE
101CONFIG.NETWORK.INTERFACE.ADDRESS.ADD code=00a01000 msg="Begin"
format="section_line"
[Check]
type=error code=6 interface=vlan0 msg="This VLAN has no physical interface"
200 code=02a0a300 msg="The network configuration has errors, it cannot be
saved nor activated"
```

Checks are now done before activating the network configuration.

MONITOR HEALTH

- Before:

```
[<serial>]
hamode=
cpu=
disk=
fans=
mem=
powerstatus=
raid=
cert=
crl=
passwd=
[MAIN]
status=
```

- After:

```
[<serial>]
hamode=
cpu=
cpu_temp=
disk=
fans=
mem=
powerstatus=
raid=
cert=
crl=
passwd=
[MAIN]
status=
```



CONFIG HA SHOW

- Before:

```
[Global]
State=
Initialized=
Forward=
SendARP=
SendARPPeriod=
Secure=
InterfacesFlipFlop=
LACPWhenPassive=
ConnOlderThan=
LACPMembersHaveWeight=
[Communication]
ifname=
ifname2=
[ICMP]
NbPing=
[Corosync]
TokenTimeout=
MulticastAddr=
```

- After:

```
[Global]
State=
Initialized=
SendARP=
SendARPPeriod=
Secure=
InterfacesFlipFlop=
LACPWhenPassive=
DelayConnUpd=
LACPMembersHaveWeight=
[Communication]
ifname=
ifname2=
[ICMP]
NbPing=
[Corosync]
TokenTimeout=
MulticastAddr=
```

Commands with new mandatory parameters

Commands with new optional parameters

CONFIG FILTER RULE UPDATE

- nohasync {on|off} [no default value]
- etherproto {auto|none|<transport protocol name>} [no default value]

CONFIG NETWORK INTERFACE SHOW

- useclone {on|off} [default: off]



CONFIG NETWORK INTERFACE UPDATE

- name {no default value}
- PARAMETERS FOR ETHERNET, AGG, VLAN, GREYAP AND BRIDGE INTERFACES**
- DHCPLeaseTime {no default value}
 - DHCPHostName {no default value}
 - DHCPVendorClassId {no default value}
 - DHCPUserClass {no default value}
 - DHCPAuthsend {no default value}
 - RequestDNS {on|off}

CONFIG NETWORK INTERFACE IPV6 ADDRESS UPDATE

- refaddress {no default value}

CONFIG NETWORK INTERFACE IPV6 ROUTERADV PREFIX UPDATE

- refaddress {no default value}

CONFIG HA CREATE

- DelayConnUpd {replaces ConnOlderThan}

CONFIG HA UPDATE

- DelayConnUpd {replaces ConnOlderThan}

PKI SEARCH

- scope {local|global|both}
 - Before: local
 - After: both by default



AUTH

History

Format appears in Netasq 9.0.0 impersonate id appears in Netasq 9.0.0

Description

User authentication.

Returns

The authentication result.

Format

raw

Usage

<administrator id> [<random value> | <impersonate id>]

Example

AUTH admin



CHPWD

Description

Indicate if the password must be updated.

Returns

UpdatePasswd=1 if factory password, =0 if the password has already been changed.

Example

CHPWD

UpdatePasswd=0



CONFIG

Level

base

Description

Firewall configuration functions.

CONFIG ACTIVATE

Level

base,modify

Description

Activate a file, or cancel all pending changes when given argument is cancelall

Usage

<filename>|cancelall

Remark

Additionnal rights may be needed to activate some files

ExampleCONFIG ACTIVATE network
CONFIG ACTIVATE cancelall

CONFIG ANTISPAM

Level

base

History

Appears in Netasq 6.0.0

Description

Anti-SPAM configuration

CONFIG ANTISPAM ACTIVATE

Level

contentfilter,modify

History

Appears in Netasq 6.2.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Apply AntiSPAM configuration CACHE_CATEGORY antispanm_whitelist,antispanm_blacklist



CONFIG ANTISPAM BLACKLIST

Level

base

History

Appears in Netasq 9.0.0

Description

Domain blacklist

CONFIG ANTISPAM BLACKLIST ADD

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Add a wildcard domain to blacklist

Usage

<domain>

Returns

Error code

Example

```
CONFIG ANTISPAM BLACKLIST ADD *stormshield*.eu CACHE_CATEGORY antispam_blacklist
```

CONFIG ANTISPAM BLACKLIST LIST

Level

base

History

Appears in Netasq 9.0.0

Description

List domains wildcard

Usage

```
[start=<int> [limit=<int>] [dir={ASC|DESC}] [search=<pattern>] [sort=<token>] [refresh=  
[0|1]]]
```

Returns

List of domains

Format

list

Example

```
CONFIG ANTISPAM BLACKLIST LIST 101 code=00a01000 msg="Begin" *stormshield*.eu 100  
code=00a00100 msg="Ok" CACHE_CATEGORY antispam_blacklist
```



CONFIG ANTISPAM BLACKLIST REMOVE

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Remove a wildcard domain from the blacklist

Usage

<domain>

Returns

Error code

Example

```
CONFIG ANTISPAM BLACKLIST REMOVE *stormshield*.eu CACHE_CATEGORY antispam_blacklist
```

CONFIG ANTISPAM DNSBL

Level

base

History

Appears in Netasq 6.0.0

Description

Anti-SPAM DNS-based Blacklists

CONFIG ANTISPAM DNSBL ADD

Level

contentfilter,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Define a new blacklist

Usage

```
Name=<name> DNSTarget=<dnstarget> SpamLevel=<1..3> [Desc=<description>]
```

Example

```
CONFIG ANTISPAM DNSBL ADD name=SPAMHAUSSBL dnstarget=sbl.spamhaus.org spamlevel=3
```

CONFIG ANTISPAM DNSBL EDIT

Level

contentfilter,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

**Description**

Modify a user-defined blacklist

Usage

Name=<name> DNSTarget=<dnstarget> SpamLevel=<level> [Desc=<description>]

CONFIG ANTISPAM DNSBL LIST**Level**

base

History

Appears in Netasq 6.0.0

Description

List (user-)defined blacklists

Usage

Type=<User|Factory>

Example

CONFIG ANTISPAM DNSBL LIST TYPE=User

CONFIG ANTISPAM DNSBL REMOVE**Level**

contentfilter,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Remove a user-defined blacklist

Usage

Name=<name>

CONFIG ANTISPAM DNSBL SET**Level**

contentfilter,modify

History

Appears in Netasq 6.0.0

whitelist deprecated in 6.1.2

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Set DNSBL parameters

Usage

[state=0|1] [active=<list>] [trusted=<trusted server>]

Example

CONFIG ANTISPAM DNSBL SET active=list1,list2,list3

CONFIG ANTISPAM DNSBL SET trusted="relais.stormshield.eu"



CONFIG ANTISPAM DNSBL SHOW

Level

base

History

Appears in Netasq 6.0.0

Description

Get DNSBL configuration

Example

```
CONFIG ANTISPAM DNSBL SHOW
```

CONFIG ANTISPAM SET

Level

contentfilter,modify

History

Appears in 6.1.2

headers Appears in 6.1.4

whitelist disAppears in Netasq 9.0.0

warningads appears in Netasq 9.1.0

stateads appears in Netasq 9.1.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Global Anti-SPAM settings

Usage

```
warning=<string with a *> warningads=<string without *> stateads=1|0 maxfile=<size>
```

```
headers=1|0 deletethreshold=<spamlevel>
```

Example

```
CONFIG ANTISPAM SET warning="{SPAM *}" maxfile=65534 headers=on deletethreshold=3
```

```
CONFIG ANTISPAM SET warningads="{ADS}" stateads=1 maxfile=50000 headers=on
```

CONFIG ANTISPAM SHOW

Level

base

History

Appears in 6.1.2

Description

Global Anti-SPAM settings

CONFIG ANTISPAM VR

Proxy/SpamVendor

Level

base

**History**

Appears in 6.1.2

licence check Appears in Netasq 6.2.0

Description

Vade Retro settings

CONFIG ANTISPAM VR SET**Level**

contentfilter,modify

History

Appears in 6.1.2

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

AllowCJK and AllowRussian appear in 9.1.2

Description

Vade Retro settings

Usage

[State=0|1] [Threshold=<0-150>] [AllowCJK=0|1] [AllowRussian=0|1]

CONFIG ANTISPAM VR SHOW**Level**

base

History

Appears in 6.1.2

Description

Vade Retro settings

CONFIG ANTISPAM WHITELIST**Level**

base

History

Appears in Netasq 9.0.0

Description

Domain whitelist

CONFIG ANTISPAM WHITELIST ADD**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Add a wildcard domain to whitelist

**Usage**

<domain>

Returns

Error code

Example

```
CONFIG ANTISPAM WHITELIST ADD *stormshield*.eu CACHE_CATEGORY antispam_whitelist
```

CONFIG ANTISPAM WHITELIST LIST**Level**

base

History

Appears in Netasq 9.0.0

Description

List domains wildcard

Usage

```
[start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>] [sort=<token>]  
[refresh=<0|1>]]
```

Returns

List of domains

Format

list

Example

```
CONFIG ANTISPAM WHITELIST LIST 101 code=00a01000 msg="Begin" *stormshield*.eu 100  
code=00a00100 msg="Ok" CACHE_CATEGORY antispam_whitelist
```

CONFIG ANTISPAM WHITELIST REMOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Remove a wildcard domain from the whitelist

Usage

<domain>

Returns

Error code

Example

```
CONFIG ANTISPAM WHITELIST REMOVE *stormshield*.eu CACHE_CATEGORY antispam_whitelist
```




CONFIG ANTIVIRUS

Level

base

History

Appears in Netasq 6.1.0

Description

AntiVirus configuration

CONFIG ANTIVIRUS ACTIVATE

Level

contentfilter,modify

History

Appears in Netasq 6.1.0

level maintenance deprecated in 6.1.4

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Reload antivirus configuration

Returns

Error code

CONFIG ANTIVIRUS CLEANUP

Level

contentfilter,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Remove antivirus database

Usage

[config=<config_index>]

Returns

Error code

Example

CONFIG ANTIVIRUS CLEANUP

CONFIG ANTIVIRUS ERASEAV

Level

contentfilter,modify

History



Appears in 4.6.0

Description

Remove all advanced antivirus binaries, provided advanced antivirus is not the active solution. Controls can be overridden with the force option.

Usage

[force=<1|0>]

Returns

Error code

Example

CONFIG ANTIVIRUS ERASEAV force=1

CONFIG ANTIVIRUS LICENCE

Level

contentfilter,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Antivirus license

Usage

[config=<config_index>]

Returns

[License]

Date

[VendorLicense]

Required : Notify if a vendorLicense is required

Status : status (Ok / NotFound / Expired / Invalid)

Expdate : expiration date

CONFIG ANTIVIRUS LIMITS

Level

contentfilter,modify

History

Appears in 3.10.0

Description

Scanner limit options

Usage

[config=<config_index>] [MaxProcTime=<int>]

config : configuration index

MaxProcTime : Max duration of a scan in seconds (default is 120)

**Returns**

Error code

CONFIG ANTIVIRUS LIST**Level**

base

History

Appears in Netasq 6.1.0

Description

List installed antivirus

Returns

Name and last modification date of each config

Example

```
101 code=00a01000 msg="Begin"
[00]
name="clamav"
lastmod="2006-05-11 16:51:31"
[01]
name="AdvancedAV"
lastmod="2006-01-10 11:28:40"
100 code=00a00100 msg="Ok"
```

CONFIG ANTIVIRUS OBJECTS**Level**

contentfilter,modify

History

Appears in Netasq 6.1.0

ScanOLE disappears in Netasq 9.0.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

HeuristicAnalysis appears in Netasq 9.0.1

Description

Scanner options

Usage

```
[config=<config_index>] [ScanArchives={on|off}] [ScanPacked={on|off}] [BlockEncrypted=
{on|off}] [BlockUnsupported={on|off}] [HeuristicAnalysis={on|off}]
```

Returns

Error code

CONFIG ANTIVIRUS SELECT**Level**

base

History



Appears in Netasq 7.0.0

Description

Switch the active antivirus if possible and starts the download of the new database.

Usage

config=<config_index>

Returns

Error code.

Remark

Contentfilter and Modify levels needed to switch antivirus

Example

CONFIG ANTIVIRUS SELECT config=00

CONFIG ANTIVIRUS SERVICES

Level

base

History

Appears in Netasq 6.1.0

Description

Antivirus Services

CONFIG ANTIVIRUS SERVICES FTP

Level

contentfilter,modify

History

Appears in Netasq 8.0.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Configure FTP service

Usage

VirusCode=<integer> VirusMsg=<message>

Returns

Error code

Remark

Ftp VirusCode restricted to the set [100;600[

Ftp VirusMsg is limited to 2048 characters

CONFIG ANTIVIRUS SERVICES POP3

Level

contentfilter,modify

History



Appears in Netasq 6.1.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Configure POP3 service

Usage

MailAdvisory=<message>

Returns

Error code

Remark

Pop3 Mail advisory is limited to 1000 characters

CONFIG ANTIVIRUS SERVICES SHOW**Level**

base

History

Appears in Netasq 6.1.0

Description

Show antivirus services

Returns

[Smtp]

VirusCode : smtp error code

VirusMsg : viruscode error message

[Pop3]

MailAdvisory : virus notification message

CONFIG ANTIVIRUS SERVICES SMTP**Level**

contentfilter,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to contentfilter,modify in Netasq 9.0.0

Description

Configure SMTP service

Usage

[VirusCode=<integer>] [VirusMsg=<message>]

Returns

Error code

Remark

Smtp Viruscode restricted to the set [400;600[

Smtp VirusMsg is limited to 1000 characters



CONFIG ANTIVIRUS SHOW

Level

base

History

Appears in Netasq 6.1.0

Added MaxProcTime in 3.10.0

Description

Dump antivirus config

Usage

[config=<config_index>]

Returns

[Config]

State : Antivirus status

Selected : Selected antivirus

Name : Antivirus name

[Base]

Date : Date of the antiviral database

[Objects]

ScanArchives_Capa : scanarchives capacity

ScanArchives : extracting engine status

ScanPacked_Capa : scanpacked capacity

ScanPacked : unpacking engine status

BlockEncrypted_Capa : blockencrypted capacity

BlockEncrypted : block encrypted files

BlockUnsupported_Capa : blockunsupported capacity

BlockUnsupported : block unsupported formats

HeuristicAnalysis_Capa : heuristicanalysis capacity

HeuristicAnalysis : heuristic analysis

[Limits]

MaxProcTime_Capa : MaxProcTime capacity

MaxProcTime : Maximum scan time in seconds

CONFIG AUTH

Level

base

Description

Authentication related functions.

CONFIG AUTH ACTIVATE

Level

user,modify

**History**

CANCEL appears in Netasq 6.0.0

NEXTBOOT appears in Netasq 6.0.0

level changes from other,modify to user,modify in Netasq 9.0.0

Description

Reload authentication daemon with latest configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG AUTH ACTIVATE

CONFIG AUTH ADVANCED**Level**

user,modify

History

anonymised appears in Netasq 6.0.0

realbind appears in Netasq 6.0.0

userpriority appears in Netasq 6.1.0

http deprecated in Netasq 6.1.0

UpdPwd deprecated in Netasq 6.1.0

level changes from other,modify to user,modify in Netasq 9.0.0

continueonerror appears in Netasq 9.1.0

userpriority deprecated in Netasq 9.1.0

httpport appears in 1.0.0

httpsport appears in 1.0.0

bruteforcestate appears in 2.1.0

nbattempt appears in 2.1.0

timeoutbanned appears in 2.1.0

triestime appears in 2.1.0

defaultprofile appears in 3.0.0

usedns disappears in 3.0.0

realbind disappears in 3.0.0

authMethod appears in 3.2.0

nbBruteforceEntries appears in 3.5.0

BindMethodExternal appears in 4.7.0

Description

Advanced parameters configuration.

Usage

[anonymised=on|off] [continueonerror=on|off] [httpport=<port>] [httpsport=<port>]
[bruteforcestate=on|off] [nbattempt=<nb attempt before being banned>]
[nbBruteforceEntries=<nb of ip addresses bruteforce detection can track>]
[timeoutbanned=<ban time (in s) for each new attempt>] [triestime=<time between 2



```
attempts to reset counter>]  
[defaultprofile=<00-09>][authMethod=Default|MultiLdapLook] [BindMethodExternal=<host>]
```

Returns

Error Code

Remark

anonymised : show/hide the logo in authentication page
continueonerror : If an error was issued during authentication process, try the next one
httpport : http port for authentication
httpsport : https port for authentication
bruteforcestate : bruteforce protection state on/off
nbattempt : Number of attempts before bruteforce detection
nbBruteforceEntries : Number of IP addresses bruteforce detection can track
timeoutbanned : Ban time for bruteforce protection
triestime : Minimum time before retry once is banned
defaultprofile : Default profile when no mapping is defined
BindMethodExternal : Host IP to use for external authentication (radius & kerberos)

Example

```
CONFIG AUTH ADVANCED anonymised=on defaultprofile=01
```

CONFIG AUTH AGENT

Level

user,modify

History

Appears in 9.1.0
SyslogState appears in 3.10.0
SyslogAddr appears in 3.10.0
SyslogPort appears in 3.10.0
SyslogAddrPattern appears in 3.10.0
SyslogUserPattern appears in 3.10.0
SyslogMsgPattern appears in 3.10.0
SyslogBackupAddr appears in 4.1.0

Description

Configure the authentication agent.
Issue an error if state is activated but no agent ip/password or controller is defined.
The domainName parameter sets an optional filter on received logon events. If a domain is provided, only users on this domain are logged in.

Remark

Remember to activate the configuration.

Usage

```
slot=<0-4>  
[State=<on|off>]  
[Mscontroller=<host,host,host>]  
[MaxLogonTime=<seconds (60-86400)>]  
[GroupRefresh=<seconds (0=disable 120-2592000)>]  
[Probe=<on|off>]  
[ProbeMethod=<ping|registry>]  
[ProbeTimeout=<seconds (60-3600)>]
```




```
[agentAddr=<object>]
[agentPort=<object>]
[agentPassword=<password>]
[backupAddr=<object>]
[backupPort=<object>]
[backupPassword=<password>]
[domainName=<NetBIOS Domain>]
[DnsEnabled=<on|off>]
[NetbiosName=<NetBIOS Name>]
[SyslogState=<on|off>]
[SyslogAddr=<object|any>]
[SyslogPort=<object>]
[SyslogBackupAddr=<object|any>]
[SyslogAddrPattern=<address pattern>]
[SyslogUserPattern=<user pattern>]
[SyslogMsgPattern=<login status pattern>]
```

Example

```
CONFIG AUTH AGENT
```

CONFIG AUTH AGENTIGNORE**Level**

base

History

Appears in Netasq 9.1.0

Description

Configure SSOAgent uid ignore list.

CONFIG AUTH AGENTIGNORE ADD**Level**

user,modify

History

Appears in Netasq 9.1.0

Description

Add an UID to the list.

Usage

slot=<0-4>

uid=<uid>

Example

```
CONFIG AUTH AGENTIGNORE ADD uid=test
```

CONFIG AUTH AGENTIGNORE REMOVE**Level**

user,modify

History



Appears in Netasq 9.1.0

Description

Remove an UID from the list.

Usage

slot=<0-4>

uid=<uid>

Example

```
CONFIG AUTH AGENTIGNORE REMOVE uid=test
```

CONFIG AUTH AGENTIGNORE SHOW**Level**

base

History

Appears in Netasq 9.1.0

level changes from user to user,base in 1.0.0

Usage

slot=<0-4>

Format

list

Description

Display the list of ignored UID.

Example

```
CONFIG AUTH AGENTIGNORE SHOW
```

CONFIG AUTH DEFAULT**Level**

user,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to user,modify in Netasq 9.0.0

Description

Restore authentication default configuration.

Returns

Error Code

Remark

Remember to activate the configuration

Example

```
CONFIG AUTH default
```



CONFIG AUTH GUEST

Level

user,modify

History

Appears in 1.0.0

PortalPage appears in 3.0.0

Description

Configure GUEST authentication method.

Usage

```
[state=<0|1>] [logontime=<seconds>] [disclaimertime=<seconds>] [portaliface=<iface>]
[[form=<field>] [label=<field>] [default=<field>]] | [removeform=<field>]] [listforms=<iface>]
```

Example

```
CONFIG AUTH GUEST state=1 logontime=600 disclaimertime=86400
```

```
CONFIG AUTH GUEST portalpage=em1 form="fieldName" label="label1" default="defaultValue"
```

```
CONFIG AUTH GUEST listforms=em1
```

CONFIG AUTH HTTPS

Level

user,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to user,modify in Netasq 9.0.0

sslparanoiac appears in Netasq 9.1.0

tlsv13 appears in 4.2.0

Description

Advanced SSL parameters configuration.

Usage

```
[certificate=<name of privkey object>] [cipherlist=<supported cipher list>]
[sslparanoiac=<0|1>] [tlsv13=<0|1>]
```

Returns

Error Code

Remark

Those values are also used by the SSL VPN. All lists use the coma separator.

certificate : private key and certificate used by the server for SSL

ca_custom : ca certificate sent to client and 'ca_verify' used to trust client certificate

cipherlist : list of supported ciphers

sslparanoiac : Paranoiac mode on ssl connection

tlsv13 : TLS 1.3 available on ssl connection

Example

```
CONFIG AUTH HTTPS certificate=mycertificate cipherlist="AES256-SHA,RC4-MD5"
```



CONFIG AUTH INTERFACE

Level

base

History

Appears in Netasq 6.1.0

Description

Interface authentication related functions.

CONFIG AUTH INTERFACE ADVANCED

Level

user,modify

History

Appears in Netasq 6.1.0

wpad appears in Netasq 8.0.0

level changes from other,modify to user,modify in Netasq 9.0.0

disclaimertime appears in 1.0.0

redirectLogin appears in 3.5.0

keepalive appears in 4.3.0

Description

Interface related configuration options.

Usage

[config=<config index>] : Profile to configure (0 if not provided)

[http=on|off] : Activate HTTP access (not secure)

[onlyonelogin=on|off] : User can authenticate at one one place

[usecookie=None|Session|Time] : Cookie to use

[wpad=on|off] : Allow access to WPAD file

[disclaimer=on|off] : Activate disclaimer

[disclaimertime=<900-31536000>] : Number of times the disclaimer must be re-shown

[autocomp=on|off] : Allow auto-completion

[SecondUser=kick|reject] : What to do when a new user come over existing one (kick previous or reject new)

[VPNSSLMultiuser=on|off] : Allow the auto-promote of the user IP to Multiuser if VPN access is granted

[DefaultDomain=<domain>] : Default domain to use. (see profile mapping)

[form1=<form1_name>] : Custom disclaimer form field 1

[form1default=<form1_value>] : Custom disclaimer form field 1 default value

[form2=<form2_name>] : Custom disclaimer form field 2

[form2default=<form2_value>] : Custom disclaimer form field 2 default value

[form3=<form3_name>] : Custom disclaimer form field 3

[form3default=<form3_value>] : Custom disclaimer form field 3 default value

[SponsorEnabled=<on|off>] : Allow SPONSOR method

[redirectLogin=<on|off>] : Redirect web page to a new tab and open a logout page

[RedirectKeepalive=<30-300>] : Interval in seconds between keepalive on the logout page

Returns

Error Code

Remark



config index : if not specified, default value is 0
http : start/stop the authentication daemon in HTTP
onlyonelogin : force only one login per user at the same time
usecookie : enable cookies
wpad : enable access to WPAD file
disclaimer : enable captive portal disclaimer
disclaimertime : Do not show the disclaimer until many seconds. (15 minutes to 1 year)
autocomp : enable autocompletion by the browser
SecondUser : Kick previous logged user or reject new user
VPNSSLMultiuser : Promote IP to multiuser if SSLVPN access can be made

Example

CONFIG AUTH INTERFACE ADVANCED config=0

CONFIG AUTH INTERFACE ENROLMENT**Level**

user,modify

History

Appears in Netasq 6.1.0

use mailgroup in Netasq 7.0.0

level changes from other,modify to user,modify in Netasq 9.0.0

Description

Managing LDAP/PKI web enrollment.

Usage

[config=<config_index>] [type=<ldap|pki|none>] [mailgroup=<mail_group_name>|none]

Returns

Error Code

Remark

config index : if not specified, default value is 0

type : enable LDAP or LDAP/PKI enrollment form

mailgroup : using mailgroup to report new enrollment requests

Example

CONFIG AUTH INTERFACE ENROLMENT config=0 type=pki mailgroup=none

CONFIG AUTH INTERFACE ENROLMENT type=pki mailgroup=Administrators

CONFIG AUTH INTERFACE LIST**Level**

base

History

Appears in Netasq 6.1.0

level changes from other,modify to base in Netasq 9.0.0

Description

List authentication interface configurations.

Returns

101 code=00a01000 msg="Begin"
[00]



```
name="Internal"
lastmod="2006-04-05 03:18:24"
[01]
name="External"
lastmod="2006-04-05 03:18:24"
[02]
name="default02"
lastmod="2006-01-03 10:03:10"
[03]
name="default03"
lastmod="2006-01-03 10:03:10"
100 code=00a00100 msg="Ok"
```

Example

CONFIG AUTH INTERFACE LIST

CONFIG AUTH INTERFACE METHOD**Level**

user,modify

History

Appears in Netasq 6.1.0

option srp for default appears in Netasq 6.2.3

option plain for default appears in Netasq 6.2.3

option default removed in Netasq 9.0.0

level changes from other,modify to user,modify in Netasq 9.0.0

deprecated in Netasq 9.1.0

CONFIG AUTH INTERFACE PASSWORD**Level**

user,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to user,modify in Netasq 9.0.0

Description

Specify password related values period in seconds.

Usage

[config=<config_index>] [updpwd=No|Can|Must] [pwdexpire=<passwordexpirationtime>]

Returns

Error Code

Remark

config index : if not specified, default value is 0

updpwd : update password

pwdexpire : password validity in days

Change period combo in the authentication web page

When not defined, transparent authentication methods use maxtime.

Example

CONFIG AUTH INTERFACE PASSWORD config=0 updpwd=Must pwdexpire=60



CONFIG AUTH INTERFACE RENAME

Level

user,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to user,modify in Netasq 9.0.0

Description

Rename an authentication configuration.

Usage

index=<config_index> name=<config name>

Returns

Error Code

Remark

config index : needs to be specified

name : name of the configuration slot

Example

CONFIG AUTH INTERFACE rename index=1 name=backup

CONFIG AUTH INTERFACE SHOW

Level

base

History

Appears in Netasq 6.1.0

Description

Show authentication configuration.

Usage

[config=<index>]

Returns

[config]

state : authentication daemon state

HttpState : activate http daemon

EnrolFormType : enrollment form (none, user, pki)

EnrolFormMail : using mail to report new enrollment requests

updpwd : update password

UseCookie : authentication cookies state

PswdExpire : password expiration time

min : Minimum authentication period

max : Minimum authentication period

ssotime : Authentication period for transparent methods (spnego and ssl)

proxyredirect : method to redirect in transparent proxy mode

Seconduser : What to do when a second user come from a single user IP.

VPNSSLMultiuser : Auto-promote IP to multiuser is sslvpn can be used



CONFIG AUTH INTERFACE STATE

Level

base

History

Appears in Netasq 6.1.0

Description

Get/Set the status of the authentication server.

Usage

[config=<config_index>] [state=on|off]

Returns

Error Code

Remark

config index : if not specified, default value is 0
Changing state requires user and modify levels

Example

CONFIG AUTH INTERFACE STATE state=on

CONFIG AUTH INTERFACE TIME

Level

user,modify

History

Appears in Netasq 6.1.0
level changes from other,modify to user,modify in Netasq 9.0.0

Description

Specify authentication period in seconds.

Usage

[config=<config_index>] min=<MinTime> max=<MaxTime>
[ssotime=<transparentmethodstime>]

Returns

Error Code

Remark

config index : if not specified, default value is 0
Change period combo in the authentication web page
When not defined, transparent authentication methods use maxtime

Example

CONFIG AUTH INTERFACE TIME config=0 mintime=900 maxtime=7200 ssotime=2400

CONFIG AUTH INTERFACE TIMERANGE

Level

user,modify

History



Appears in Netasq 6.1.0
Deprecated in Netasq 9.0.0

Description

Manage authentication timeranges.

Usage

[config=<config_index>] [action=<pass|block>] | [action=default defaultcal=<calendarid>]

Returns

Error Code

Remark

config index : if not specified, default value is 0
action : action to be taken when user calendar is not defined
calendarid : authd default calendar in LDAP

Example

CONFIG AUTH INTERFACE TIMERANGE config=1 action=pass

CONFIG AUTH KERBEROS

Level

user,modify

History

level changes from other,modify to user,modify in Netasq 9.0.0
status Appears in Netasq 9.1.0

Description

Configure kerberos authentication.

Usage

[domain=<host domain name> host=<kdc hostname> [port=<kdc port>] [bhost=<backup kdc hostname> [bport=<backup kdc port>]]] | [state=<0|1>]

Returns

Error Code

Remark

default value for kdc_port is 88

Example

CONFIG AUTH KERBEROS host=10.0.0.125 domain="DOMAIN.LOCAL"

CONFIG AUTH LDAP

Level

base

Description

Manage voucher user LDAP configuration.

Usage

voucher

**Returns**

Error code

Example**CONFIG AUTH LDAP VOUCHER****Level**

base

Description

Manage voucher user LDAP configuration

Usage

create | show | shrink | status

Returns

Error code

Example**CONFIG AUTH LDAP VOUCHER ACTIVATE****Level**

user,modify

Description

Activate the voucher LDAP configuration

Usage**Returns**

Error code

Example

CONFIG AUTH LDAP VOUCHER activate

CONFIG AUTH LDAP VOUCHER SHOW**Level**

base

Description

Show voucher LDAP configuration.

Usage**Returns**

Error code

Example

CONFIG AUTH LDAP VOUCHER SHOW

CONFIG AUTH LDAP VOUCHER SHRINK**Level**

user,modify

Description



Shrink user database.

Usage**Returns**

Error code

Example

```
CONFIG AUTH LDAP VOUCHER SHRINK
```

CONFIG AUTH LDAP VOUCHER STATE**Level**

user,modify

Description

Start or stop LDAP server.

Usage

```
[state=<1|0>] [PERIOD=<int>]
```

Returns

Error code

Example

```
CONFIG AUTH LDAP VOUCHER STATE state=1 period=5  
CONFIG AUTH LDAP VOUCHER STATE state=0
```

CONFIG AUTH LDAP VOUCHER STATUS**Level**

base

Description

Returns voucher LDAP server status

Usage**Returns**

Error code

Example

```
CONFIG AUTH LDAP VOUCHER status
```

CONFIG AUTH MAP**Level**

base

History

Appears in 3.0.0

Description

Manage authentication profile mapping on interface.

CONFIG AUTH MAP ADD**Level**



user,modify

History

Appears in 3.0.0

Usage

interface=<ifname> config=<00-09>

Example

CONFIG AUTH MAP ADD interface=in config=00

Description

Create a new mapping or modify an existing one.

CONFIG AUTH MAP CLEAR**Level**

user,modify

History

Appears in 3.0.0

Example

CONFIG AUTH MAP CLEAR

Description

Remove all the mappings and use only default profile.

CONFIG AUTH MAP LIST**Level**

base

History

Appears in 3.0.0

Format

section_line

Description

Display authentication profile mapping.

CONFIG AUTH MAP REMOVE**Level**

user,modify

History

Appears in 3.0.0

Usage

interface=<ifname>

Example

CONFIG AUTH MAP REMOVE interface=in

Description



Remove the mapping on given interface.

CONFIG AUTH MULTIUSER

Level

base

History

Appears in Netasq 9.1.0

Description

Manage object as multiple user one

CONFIG AUTH MULTIUSER ADD

Level

user,modify

History

Appears in Netasq 9.1.0

Description

Add an object at the end of the list. keyword 'any' is granted.

Usage

object=<name>

Returns

Error code

Example

```
CONFIG AUTH MULTIUSER ADD object='host'
```

CONFIG AUTH MULTIUSER LIST

Level

base

History

Appears in Netasq 9.1.0

Description

List the object marked as multiple user with the type of the object.

Format

list

Returns

```
[Result] host='host1'  
host_2='host2'  
range='range1'  
network='network1'  
interface='interface1'  
group='group1'  
internet='internet'
```

**Example**

CONFIG AUTH MULTIUSER LIST

CONFIG AUTH MULTIUSER REMOVE**Level**

user,modify

History

Appears in Netasq 9.1.0

Description

Remove an object from the list.

Returns

Error code

Usage

object=<name>

Example

CONFIG AUTH MULTIUSER REMOVE object="host"

CONFIG AUTH RADIUS**Level**

user,modify

History

bport appears in Netasq 6.1.0

bhost appears in Netasq 6.1.0

level changes from other,modify to user,modify in Netasq 9.0.0

status appears in Netasq 9.1.0

pencoding and bencoding appear in 2.0.0

timeout, btimeout, retry, bretry and VSAusergroup appear in 4.3.0

Description

Configure radius authentication.

Usage

[state=<0|1>] | [host=<host> [port=<service>] key=<sharedkey> [pencoding=<encoding>]
[timeout=<timeout>] [retry=<retry>]] [bhost=<host> [bport=<service>] bkey=<sharedkey>
[bencoding=<encoding>] [btimeout=<timeout>] [bretry=<retry>] [VSAusergroup=<0|1>]]

Returns

Error Code

Remark

Authentication with radius can be used with unknown users (default method).

default value for port is 1812

Microsoft RADIUS server uses ISO-8859-1 charset

timeouts are in milliseconds

The total timeout must be lower than or equal to 120 seconds: (timeout * (retry + 1)) +
(btimeout * (bretry + 1)) <= 120000

Example



```
CONFIG AUTH RADIUS host=10.2.0.100 port=1812 key="shared secret"  
CONFIG AUTH RADIUS host=radiusrv port=radius key="shared secret" pencoding=ISO-8859-1  
timeout=1000 retry=2 bhost=radiusrv bport=radius bkey="other shared secret"  
bencoding=UTF-8 btimeout=500 bretry=0 VSAusergroup=1
```

CONFIG AUTH SHOW

Level

base

History

guest authentication appears in 1.0.0
realbind disappears in 3.0.0
timeout, btimeout, retry, bretry and VSAusergroup appear in 4.3.0

Description

Show authentication configuration.

Returns

[config]

anonymised : show/hide the logo in the authentication page
SslCertificate : refer key/certificate entry on 'key' file
internal : internal interface configuration
external : external interface configuration

[CAVerifyList]

Number=0

[radius]

state : status of this method
host : radius server hostname
port : radius port
pencoding : radius server charset encoding
bhost : radius backup server hostname
bport : radius backup port
bencoding : radius backup server charset encoding
presharedkey : key used for encrypting exchanges between the firewall and the RADIUS server
bpresharedkey : key used for encrypting exchanges between the firewall and the Backup RADIUS server
timeout : timeout in milliseconds when authenticating on the RADIUS server
btimeout : timeout in milliseconds when authenticating on the backup RADIUS server
retry: number of retries when authenticating on the RADIUS server
bretry: number of retries when authenticating on the backup RADIUS server
VSAusergroup: 1 if user group VSA support is enabled, 0 otherwise

[ssl]

state : status of this method
CertificateIdentifier : field in certificate to match
LdapIdentifier : field in LDAP to match

[kerberos]

state : status of this method
domain : Kerberos realm (domain) name
pkdc_host : Primary KDC host address



pkdc_port : Primary KDC port (default 88)
bkdc_host : Backup KDC host address
bkdc_port : Backup KDC port (default 88)

[spnego]

state : status of this method
domain : Windows domain name
principal : Principal service name

[agent]

State : activate or not the agent
Mscontroller : object name of the Microsoft domain controller
MsbbackupController : object name of the second Microsoft domain controller
Directory : name of the LDAP directory to use
MaxLogonTime : maximum time in seconds for the authentication
Probe : activate or not the user logout probing
ProbeMethod : comma separated list of probing methods (arp, icmp, nbstat, registry, ...)
ProbeTimeout : maximum time in seconds for not responding stations
BindAddr : the IP address of the source connection
AgentAddr : the IP address of the agent
AgentPort : the port of the agent
AgentPassword : the password of the agent
BackupAddr : the IP address of the backup agent
BackupPort : the port of the backup agent
BackupPassword : the password of the backup agent
DomainName : the filter to be applied on logon events

[guest]

state : activate or not the guest method
LogonTime : Time in seconds for re-authentication
Disclaimertime : Time in seconds for disclaimer revalidation

CONFIG AUTH SPNEGO

Level

user,modify

History

Appears in Netasq 6.0.0
level changes from other,modify to user,modify in Netasq 9.0.0
status appears in Netasq 9.1.0

Description

Configure SPNEGO authentication.

Usage

[principal=<service name> domain=<host domain name>] | [state=<0|1>]

Returns

Error code 100

Example

```
CONFIG AUTH SPNEGO principal="HTTP/myfirewall" domain="DOMAIN.LOCAL"  
CONFIG AUTH SPNEGO state=1
```




CONFIG AUTH SPONSOR

Level

user,modify

History

Appears in 3.0.0

Description

Configure SPONSOR authentication method.

Usage

[state=<0|1>]

[mintime=<seconds>] : Minimum authentication period (limited to 1 minute)

[maxtime=<seconds>] : Maximum authentication period (limited to 36 hours)

Example

CONFIG AUTH SPONSOR state=1 mintime=60 maxtime=129600

CONFIG AUTH SSL

Level

base

History

ca_verify appears in Netasq 6.1.0

Description

Configure SSL authentication.

CONFIG AUTH SSL CAVERIFY

Level

user

History

ca_verify appears in Netasq 9.0.0

Description

Configure SSL authority for authentication.

CONFIG AUTH SSL CAVERIFY ADD

Level

user,modify

History

caverify add appears in Netasq 9.0.0

Description

Add an authority to the list of authentication authorities.

Returns

Error Code

Usage



caname: name of the authority

Example

```
CONFIG AUTH SSL CAVERIFY ADD caname=<authority name>
```

CONFIG AUTH SSL CAVERIFY REMOVE**Level**

user,modify

History

caverify remove appears in Netasq 9.0.0

Description

Remove an authority from the list.

Returns

Error Code

Usage

id: id of the list

Example

```
CONFIG AUTH SSL CAVERIFY REMOVE id=1
```

CONFIG AUTH SSL CERTIDENTIFIER**Level**

user,modify

History

appears in Netasq 9.0.1

Description

Set the certificate identifier field in common name.

WARNING: the value is case sensitive. Do not write emailaddress but emailAddress

Returns

Error Code

Usage

name : the name of the field

Example

```
CONFIG AUTH SSL CERTIDENTIFIER name="emailAddress"
```

CONFIG AUTH SSL LDAPIDENTIFIER**Level**

user,modify

History

appears in Netasq 9.0.1

Description

Set the LDAP identifier field to match the certificate field.

Returns



Error Code

Usage

name : the name of the field

Example

```
CONFIG AUTH SSL LDAPIDENTIFIER name="Mail"
```

CONFIG AUTH SSL LDAPLOOKUP**Level**

base

History

Appears in 3.3.0

Description

Configure the LDAP lookup order.

CONFIG AUTH SSL LDAPLOOKUP ADD**Level**

user,modify

History

Appears in 3.3.0

Description

Add an SSL LDAP lookup entry.

Usage

[index=number]

field=<commonName, countryName, localityName, stateOrProvinceName, organizationName, organizationalUnitName, emailAddress, unstructuredName, challengePassword, unstructuredAddress, givenName, surname, initials, firendlyName, name, dnQualifier, domainComponent, rfc822MailBox>

pattern=<a_matching_regex> domainName=<ldap_1, ldap_2, ...>

Example

```
CONFIG IPSEC LDAPLOOKUP ADD field=commonName pattern="%s@domain.eu"
```

```
domainName=ldap1
```

```
CONFIG IPSEC LDAPLOOKUP ADD index=2 field=organizationName pattern="domain.eu"
```

```
domainName=ldap1
```

CONFIG AUTH SSL LDAPLOOKUP LIST**Level**

base

History

Appears in 3.3.0

Description

List the SSL LDAP lookup pattern matching entries.

Example

```
CONFIG AUTH SSL LDAPLOOKUP LIST [ldap] domain=ldap_entry_1, ldap_entry_2
```

**CONFIG AUTH SSL LDAPLOOKUP METHOD****Level**

user,modify

History

Appears in 3.3.0

Description

Configure the LDAP lookup method.

Usage

lookup=<default|multildap_lookup>

Example

CONFIG AUTH SSL LDAPLOOKUP METHOD lookup=default

CONFIG AUTH SSL LDAPLOOKUP MOVE**Level**

user,modify

History

Appears in 3.3.0

Description

Swap two SSL LDAP lookup pattern matching entries.

Usage

index=number to=number

Example

CONFIG AUTH SSL LDAPLOOKUP MOVE index=3 to=1

CONFIG AUTH SSL LDAPLOOKUP REMOVE**Level**

user,modify

History

Appears in 3.3.0

Description

Remove an SSL LDAP lookup entry.

Usage

index=number

Example

CONFIG AUTH SSL LDAPLOOKUP REMOVE index=3

CONFIG AUTH SSL LDAPLOOKUP SHOW**Level**

base

History

Appears in 3.3.0

Description



Display the LDAP lookup method.

Usage**Example**

```
CONFIG AUTH SSL LDAPLOOKUP SHOW
```

CONFIG AUTH SSL UPDATE**Level**

user,modify

History

Appears in Netasq 9.1.0

Description

Update the configuration of SSL method.
state is the status of the method.

Returns

Error Code

Usage

```
[state=<0|1>]
```

Example

```
CONFIG AUTH SSL UPDATE state=1
```

CONFIG AUTOBACKUP**Level**

base

History

Appears in 1.0.0

Description

Autobackup configuration

CONFIG AUTOBACKUP ACTIVATE**Level**

modify,maintenance

History

Appears in 1.0.0

Description

Copy all clones in real profiles.

Usage

```
[CANCEL]
```

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

**Returns**

Error code

Example

```
CONFIG AUTOBACKUP ACTIVATE  
CONFIG AUTOBACKUP ACTIVATE CANCEL
```

CONFIG AUTOBACKUP LAUNCH

Level

modify,maintenance

History

Appears in 1.0.0

Description

Launch autobackup manually.

Returns

Error code

Example

```
CONFIG AUTOBACKUP LAUNCH
```

CONFIG AUTOBACKUP RESTORE

Level

modify,maintenance

History

Appears in 1.0.0
fwserial deprecated in 3.5.0

Description

Restore last full configuration launched by autobackup.

Usage

```
[backuppassword=<backup password>] [refresh=0|1]  
- refresh : when set to 1, refresh all (except network) firewall configuration, and does not  
require user to reboot if services successfully restarted.
```

Returns

Error code

Remark

Autobackup must be enable and functional.

Example

```
CONFIG AUTOBACKUP RESTORE
```

CONFIG AUTOBACKUP SET

Level



modify,maintenance

History

Appears in 1.0.0

backupid appears in 2.3.0

IgnoreProxy appears in 3.10.2

StartTime, StartMDay and StartWDay appear in 4.3.24

Description

Set autobackup configuration.

Usage

```
[state=<0|1>] [distantbackup=<0|1|2>] [period=<period as string>] [starttime=*[HH[:MM]
[startmday=1-31|startwday=1-7]] [backuppassword=<backup password>]
[backupid=<alphanum str>]
[server=<server obj>] [port=<server port obj>] [path=<path>] [protocol=(http|https)] [mode=
(basic|digest|post)]
[authusername=<authentication username>] [authpassword=<authentication password>]
[controlname=<http control name>]
[servercertificate=<ca:cert>] [clientcertificate=<ca:cert>] [IgnoreProxy=<0|1>]
- period : time + unit {s,m,h,d,w};
- starttime : \"*\"/>

```

- period : time + unit {s,m,h,d,w};
- starttime : \"*\
- startmday : month day {1-31}. First autobackup startup day. starttime mandatory, startwday forbidden;
- startwday : week day {1-7}. First autobackup startup day. starttime mandatory, startmday forbidden;
- distantbackup : localbackup only {0}, cloud stormshield {1}, custom server {2};
- backupid : used in backup filename (default is serial number) - protocol : protocol used (http,https);
- mode : webdav mode with authentication (basic,digest) or post request;
- controlname : name also used with html form (only with post mode);
- authusername : authentication username (only with basic and digest webdav modes);
- authpassword : authentication password (only with basic and digest webdav modes);
- path : path on the server;
- servercertificate : server certificate reference;
- clientcertificate : client certificate;

Returns

Error code

Remark

Protocol http and mode post are incompatible

Example

```
CONFIG AUTOBACKUP SET state=1 server=backupserver port=http controlname=myfile
path=/action.php period=10h password=mypassword
```

CONFIG AUTOBACKUP SHOW

Level

base

History

Appears in 1.0.0

**Description**

Show the autobackup config.

Returns

```
[AUTOBACKUP]
State=<state>
DistantBackup=<distant backup enabled>
Server=<server obj name>
Port=<server port obj name>
Path=<path>
Period=<period>
BackupId=<str>
BackupPassword=<backup password>
IgnoreProxy=<0|1>
Protocol=<protocol used>
Mode=<mode used>
AuthUsername=<authentication username>
AuthPassword=<authentication password>
ControlName=<http control name>
servercertificate=<reference server certificate>
clientcertificate=<server client>
```

Example

```
CONFIG AUTOBACKUP SHOW
```

CONFIG AUTOUPDATE

Level

base

History

Appears in Netasq 6.0.0

Description

Autoupdate (Content-Filtering Update)

CONFIG AUTOUPDATE ACTIVATE

Level

modify,maintenance

History

Appears in Netasq 6.1.0

level changes from modify,other to modify,maintenance in Netasq 9.0.0

Description

Reload AutoUpdate configuration

Returns

Error code

Example

```
CONFIG AUTOUPDATE ACTIVATE
```




CONFIG AUTOUPDATE LIST

Level

base

History

Appears in Netasq 6.1.0

Description

List all available update

Returns

List=<list of available update comma separated>

Example

CONFIG AUTOUPDATE LIST

CONFIG AUTOUPDATE SERVER

Level

modify,maintenance

History

Appears in Netasq 6.0.0

state Appears in Netasq 6.1.0

update Appears in Netasq 6.1.0

secure Appears in 6.1.5

update options AdvancedAV,Clamav,URLFiltering,Antispam-Vaderetro Appears in Netasq 6.2.0

start Appears in Netasq 7.0.0

update option Pvm Appears in Netasq 7.0.0

start Appears in Netasq 7.0.0

level changes from modify,other to modify,maintenance in Netasq 9.0.0

update option RootCertificates Appears in Netasq 9.1.0

ca Appears in Stormshield 4.1.0

bindaddr Appears in Stormshield 4.3.0

Description

Set autoupdate parameters. If the update token is not specified, all services will be modified. The url token can take a maximum of 8 URL, separated by comma. retries=0 means no retry limit.

If https protocol is used, ca token must contains a number of CA equal to the number of given URL, separated by comma.

The bindaddr token set an object which represents a local IP address of the firewall, and clears the setting if set empty.

Usage

```
[url=<url> [ca=<url>]] [start=<time>] [period=<period>] [retries=<n>] [state={on|off|1|0}]  
[secure={on|off|0|1}] [bindaddr=<firewall_ip_object>] [update=  
[Antispam|Patterns|CustomPatterns|AdvancedAV|Clamav|URLFiltering|Vaderetro|Pvm|RootCertificates|IPData]]
```

Returns

Error code

Example



```
CONFIG AUTOUPDATE SERVER url="http://www.stormshield.eu/autoupdate"  
CONFIG AUTOUPDATE SERVER  
url="https://www.mywebsite.com/autoupdate,http://www2.mywebsite.com/autoupdate,https://  
www3.mywebsite.com/autoupdate" ca="mywebsiteauthority,,mywebsiteauthority"  
CONFIG AUTOUPDATE SERVER url="https://update1-sns.stormshieldcs.eu/1"  
ca="/data/CloudServices/cert/bundle.crt"  
CONFIG AUTOUPDATE SERVER period=00M00w01d00h00m00s retries=3  
CONFIG AUTOUPDATE SERVER start="10:00:00"  
CONFIG AUTOUPDATE SERVER bindaddr=Firewall_in update=Clamav
```

CONFIG AUTOUPDATE SHOW

Level

base

History

Appears in Netasq 6.0.0

Description

Dump the autoupdate config. The Run token represents the state of the last update (0=never started ; 1=up to date ; 2=failed ; 3=running ; 4=not available) and can be obtained by MONITOR AUTOUPDATE too. The update begins at 'start' time and will be repeated after each 'period'.

Returns

[Global]

Version=<autoupdate version>

[<available_update>]

Secure={0|1} : check sign

State={0|1} : update active or not

URL=<url> : url to retrieve update

Period=<period> : period to perform update

Retries=<int> : number of retry

Run=<int> : state of the last update (0=never started ; 1=up to date ; 2=failed ; 3=running ; 4=not available). These information can be obtained by MONITOR AUTOUPDATE

Start=<time> : time of the first update

BindAddr=<ip_object> : binding local IP

Example

```
CONFIG AUTOUPDATE SHOW
```

CONFIG AUTOUPDATE STATE

Level

modify,maintenance

History

update Appears in Netasq 6.1.0

level changes from modify,other to modify,maintenance in Netasq 9.0.0

Description

Activate/Deactivate the autoupdate subsystem

Usage

```
state=<on|off> [update=<available_update>]
```

**Returns**

Error code

Remark

all available update are given by CONFIG AUTOUPDATE LIST

Example

CONFIG AUTOUPDATE STATE state=on

CONFIG BACKUP

Level

maintenance

History

level maintenance Appears in Netasq 6.0.0
level other deprecated in Netasq 6.0.0
option global for list Appears in Netasq 6.0.0
option urlgroup for list Appears in 6.0.2
option pattern for list Appears in 6.0.2
usb Appears in Netasq 6.1.0
option secure for list Appears in Netasq 6.2.0
option autoupdate for list Appears in Netasq 6.2.0
option proxies for list Appears in Netasq 6.2.0
option services for list Appears in Netasq 6.2.0
format appears in Netasq 9.0.0
global_vpn appears in 2.5.0
global_cert appears in 3.0.0
ttmpassword appears in 3.10.0
usb disappears in 4.0.0
option secure for list disappears in 4.0.0 privkeys appears in 3.10.0
ondiskprotect appears in 3.10.0

Description

Backups full or partial configuration (complete list of available items is provided by SYSTEM BACKUP command)

Usage

list=<all|network|global|object|global_object|filter|filterslotxx|global_filter|global_filterslotxx|vpn|global_vpn|ldap|urlfiltering|sslfiltering|urlgroup|global|pattern|autoupdate|services|mailfiltering|dhcp|ntp|dns|snmp|pvm|cert|global_cert|securityinspection|vpn-ssl|vpn-pptp|event-rules|qos|auth|webadmin|statusweight|log|route|sysevent|bird|antispam|mailgroup|communication|system|serverd|reports|access_tickets|monitor> [password=<string>] [comment=<string>] [ttmpassword=<string>] [privkeys=all|none] [ondiskprotect=0|1]
A TPM password is required if it protects some private keys.
All private keys are included by default, but this can be avoided with option \"privkeys=none\".
Ondisk protected keys are backedup unprotected by default, but they can remain protected with option \"ondiskprotect=1\".

Format

raw

Returns



Error code

Example

```
CONFIG BACKUP list=all comment="sauvegarde tout" password=mypassword  
CONFIG BACKUP list="pattern,network,global,network"
```

CONFIG BIRD

Level

base

History

Appears in 2.0.0

Description

Commands related to BIRD configuration

CONFIG BIRD ACTIVATE

Level

network,modify

History

Appears in 2.0.0

Description

Apply BIRD configuration

Usage

[CANCEL] : changes are discarded

Returns

Error code

CONFIG BIRD SHOW

Level

base

History

Appears in 2.0.0

RestartOnHAAActive appears in 2.5.0

SupportProtAddrIPv4 appears in 3.2.0

SupportExclusionRangesIPv4 appears in 3.2.0

SupportProtAddrIPv6 appears in 3.2.0

SupportExclusionRangesIPv6 appears in 3.2.0

Description

Display BIRD state

Returns

[BIRD]

IPv4=0|1

IPv6=0|1

**Example**

```
[BIRD]
IPv4=1
IPv6=0
RestartOnHAAActive=1
SupportProtAddrIPv4=1
SupportExclusionRangesIPv4=1
SupportProtAddrIPv6=1
SupportExclusionRangesIPv6=1
```

CONFIG BIRD STATE**Level**

network,modify

History

Appears in 2.0.0

Description

Configure BIRD state

Usage

```
[ipv4=0|1] [ipv6=0|1]
```

Returns

Error code

Example

```
CONFIG BIRD STATE ipv4=1 ipv6=0
```

CONFIG BIRD UPDATE**Level**

network,modify

History

Appears in 2.5.0 RestartOnHAAActive appears in 2.5.0

SupportProtAddrIPv4 appears in 3.2.0

SupportExclusionRangesIPv4 appears in 3.2.0

SupportProtAddrIPv6 appears in 3.2.0

SupportExclusionRangesIPv6 appears in 3.2.0

Description

Configure advanced parameters of BIRD

Usage

```
RestartOnHAAActive={0|1}
```

```
SupportProtAddrIPv4={0|1}
```

```
SupportExclusionRangesIPv4={0|1}
```

```
SupportProtAddrIPv6={0|1}
```

```
SupportExclusionRangesIPv6={0|1}
```

Returns

Error code



CONFIG CHECKDB

Level

base

History

Appears in 4.3.25

Description

CheckDB configuration functions

CONFIG CHECKDB ACTIVATE

Level

base,modify

History

Appears in 4.3.25

Description

Update checkdb configuration file

Example

CONFIG CHECKDB ACTIVATE

CONFIG CHECKDB SHOW

Level

base

History

Appears in 4.3.25

Description

Display checkdb configuration

Returns

[Config]
State=<0|1>
Period=<str>

Example

CONFIG CHECKDB SHOW

CONFIG CHECKDB UPDATE

Level

base,modify

History

Appears in 4.3.25

Description



Update checkdb configuration

Usage

[state=<0|1>]
[period=<period>]

Remark

Period must be between 5 minutes and 1 week

Example

```
CONFIG CHECKDB UPDATE state=1 period=3d12h30m30s
```

CONFIG COMMUNICATION

Level

base

Description

Configure external communication.

CONFIG COMMUNICATION ACTIVATE

Level

base,modify

History

CANCEL/NEXTBOOT appears in Netasq 9.0.0

Description

Activate/cancel modifications of communication and email groups.

Usage

[CANCEL|NEXTBOOT]
- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

```
CONFIG COMMUNICATION ACTIVATE  
CONFIG COMMUNICATION ACTIVATE cancel
```

CONFIG COMMUNICATION EMAIL

Level

base

Description

Manage email groups and templates.



CONFIG COMMUNICATION EMAIL GROUP

Level

base

Description

Manage email groups.

CONFIG COMMUNICATION EMAIL GROUP ACTIVATE

Level

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Activate or cancel the latest changes in email groups configuration.

Usage

[CANCEL]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

Example

CONFIG COMMUNICATION EMAIL GROUP ACTIVATE

CONFIG COMMUNICATION EMAIL GROUP ADDRECIPIENT

Level

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Add a new recipient to an email group.

Usage

mailgroup=<mail_group_name> [mail=<mail_addr> | dn=<user|usergroup>]

Example

CONFIG COMMUNICATION EMAIL GROUP ADDRECIPIENT mailgroup=Administrators
dn=james@nowhere.net

CONFIG COMMUNICATION EMAIL GROUP CHECK

Level

log

History

Appears in Netasq 7.0.0

level changes from other to log in Netasq 9.0.0

Format Appears in Netasq 9.0.0

**Description**

Check an email group.

Usage

mailgroup=<mail_group_name>

Format

section_line

Example

CONFIG COMMUNICATION EMAIL GROUP CHECK mailgroup=Administrators

CONFIG COMMUNICATION EMAIL GROUP CREATE**Level**

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Create a new email group.

Usage

mailgroup=<mail_group_name> [comment=string]

Example

CONFIG COMMUNICATION EMAIL GROUP CREATE mailgroup=Administrators comment="here is a comment!"

CONFIG COMMUNICATION EMAIL GROUP DELRECIPIENT**Level**

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Delete a recipient from an email group.

Usage

mailgroup=<mail_group_name> {mail=<mail_addr> | dn=<user|usergroup>}

Example

CONFIG COMMUNICATION EMAIL GROUP DELRECIPIENT mailgroup=Administrators
mail=james@nowhere.net

CONFIG COMMUNICATION EMAIL GROUP EDIT**Level**

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

**Description**

Modify an email group.

Usage

mailgroup=<mail_group_name> comment=string

Example

CONFIG COMMUNICATION EMAIL GROUP EDIT mailgroup=Administrators comment="here is a comment!"

CONFIG COMMUNICATION EMAIL GROUP LIST**Level**

base

History

Appears in Netasq 7.0.0
level changes from other to base in Netasq 9.0.0

Description

Dump the email groups.

Returns

[MailGroup1]
comment=this is a comment
email=a@b.com
email=c@b.com
cn=user
[MailGroup2]
...

Example

CONFIG COMMUNICATION EMAIL GROUP LIST

CONFIG COMMUNICATION EMAIL GROUP REMOVE**Level**

log,modify

History

Appears in Netasq 7.0.0
level changes from other,modify to log,modify in Netasq 9.0.0

Description

Delete an email group.

Usage

mailgroup=<mail_group_name>

Example

CONFIG COMMUNICATION EMAIL GROUP REMOVE mailgroup=Administrators

CONFIG COMMUNICATION EMAIL GROUP RENAME**Level**

log,modify

History



Appears in Netasq 9.0.0

Description

rename an email group.

Usage

oldname=<mail_group_name> newname=<mail_group_name>

Example

CONFIG COMMUNICATION EMAIL GROUP RENAME oldname=Administrators newname=Admins

CONFIG COMMUNICATION EMAIL TEMPLATE**Level**

base

History

Appears in Netasq 7.0.0

Description

Manage email templates.

CONFIG COMMUNICATION EMAIL TEMPLATE DEFAULT**Level**

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Reset an email template to default.

Usage

<template_id>

Returns

Reset the requested template to its default.

Remark

Additional rights may be needed to write some templates.

Example

CONFIG COMMUNICATION EMAIL TEMPLATE DEFAULT pvm_detailed

CONFIG COMMUNICATION EMAIL TEMPLATE DOWNLOAD**Level**

log

History

Appears in Netasq 7.0.0

default arg appears in Netasq 9.0.0

level changes from other to log in Netasq 9.0.0

Format appears in Netasq 9.0.0

Description



Download an email template.

Usage

<template_id> [default=<0|1>]

Returns

The requested template

if default=1, return the default value of the requested template

Remark

If no default parameter is specified, the default value is 0.

Additional rights may be needed to read some templates.

Format

raw

Example

CONFIG COMMUNICATION EMAIL TEMPLATE DOWNLOAD pvm_detailed

CONFIG COMMUNICATION EMAIL TEMPLATE LIST**Level**

log

History

Appears in Netasq 7.0.0

level changes from other to log in Netasq 9.0.0

Format appears in Netasq 9.0.0

Description

List all email templates.

Returns

[Result]

id=pvm_detailed type=pvm name="Detailed Vulnerability Mail"

id=pvm_summary type=pvm name="Summary Vulnerability Mail"

id=app_cert_req type=cert_req name="Accept the certificate request"

id=rej_cert_req type=cert_req name="Reject the certificate request"

Format

section_line

Example

CONFIG COMMUNICATION EMAIL TEMPLATE LIST

101 code=00a01000 msg="Début"

[Result]

id=pvm_detailed type=pvm name="Detailed Vulnerability Mail"

id=pvm_summary type=pvm name="Summary Vulnerability Mail"

id=app_cert_req type=cert_req name="Accept the certificate request"

id=rej_cert_req type=cert_req name="Reject the certificate request"

100 code=00a00100 msg="Ok"

CONFIG COMMUNICATION EMAIL TEMPLATE UPLOAD**Level**

log,modify

History



Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Upload an email template.

Usage

<template_id>

Returns

Upload the requested template.

Remark

Additional rights may be needed to write some templates.

Example

CONFIG COMMUNICATION EMAIL TEMPLATE UPLOAD pvm_detailed

CONFIG COMMUNICATION HTTPPROXY

Level

network,modify

History

level changes from other,modify to network,modify in Netasq 9.0.0

Description

Configure HTTP proxy.

Usage

[host=<host_object> port=<obj_port>] [user=<string> auth=<string>] [exclude=<host_object_list>]

Returns

Error code

Example

CONFIG COMMUNICATION HTTPPROXY host=myproxy.stormshield.eu port=http user=username
auth=authpassword exclude=myserver.stormshield.eu,intranet

CONFIG COMMUNICATION IPFIX

Level

base

History

Appears in 3.0.0

Description

Configure IPFIX.

CONFIG COMMUNICATION IPFIX SHOW

Level

base

**History**

Appears in 3.0.0

Description

Show IPFIX configuration.

Returns

[IPFIX]

State : State

Collector : IPFIX collector

Port : Port used to communicate with the collector

BindAddr : Firewall local IP to use to connect to the collector

BackupServer: Backup collector to send IPFIX messages to

BackupPort : Port used with BackupServer

Refresh : Timeout before resending the IPFIX templates

Transport : Transport protocol used to communicate with the collector

Example

CONFIG COMMUNICATION IPFIX SHOW

CONFIG COMMUNICATION IPFIX UPDATE**Level**

log,modify

History

Appears in 3.0.0

Description

Configure IPFIX.

Usage

State=[1|0] [Collector=<host object>] [Port=<service object>|<integer>] [BindAddr=[<firewall_ip object>|""]] [Transport=tcp|udp] [Backup=<host object>] [BackupPort=<service object>|<integer>] [Refresh=<integer>]

where:

- BindAddr: Object which represents a local IP address of the firewall
- Transport: Transport protocol to be used for IPFIX
- Backup and BackupPort: Backup collector when the 1st one is unreachable - TCP only
- Refresh: Time to wait before resending the IPFIX templates to the collector - UDP only

Returns

Error code

Example

CONFIG COMMUNICATION IPFIX State=1 collector=Ipfix_collector Port=4739 BindAddr=Firewall_in
Refresh=900

CONFIG COMMUNICATION IPFIX State=0

CONFIG COMMUNICATION SHOW**Level**

base

Description



Dump the communication configuration.

Usage

[smtp|httpproxy]: Dump smtp or httpproxy configuration, or both if no argument is specified.

Returns

[SMTP]

State : State

Server : Smtplib server

Domain : Domain name

Delay : Delay

Example

CONFIG COMMUNICATION SHOW

CONFIG COMMUNICATION SMTP

Level

log,modify

History

port appears in Netasq 6.0.0

option service_object for port appears in Netasq 6.1.0

option State appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

options username and password appear in Netasq 9.0.2

option domain is replaced by emailAddress in 3.3.0

Description

Configure SMTP for mail notifications.

Usage

state={0|1} [server=<host object>] [emailAddress=<user@domain>] [mandatory if state=1]
[port=<service_object|int>] [delay=<int>] [username=<string>] [password=<string>]

Returns

Error code

Example

CONFIG COMMUNICATION SMTP state=1 server=smtp_server

emailAddress=user@stormshield.local delay=900

CONFIG COMMUNICATION SMTP state=0

CONFIG COMMUNICATION SYSLOG

Level

base

History

Command becomes a tree in 3.0.0

Description

Configure Syslog.



CONFIG COMMUNICATION SYSLOG PROFILE

Level

base

History

Appears in 3.0.0

Description

Commands to configure Syslog profiles.

CONFIG COMMUNICATION SYSLOG PROFILE SHOW

Level

base

History

Appears in 3.0.0

Description

Show the specified Syslog profile. If the profile is not specified, then list all profiles.

Usage

[index=<profile_idx>]

Returns

[index]

State : State

Name : Syslog profile name

Comment : Description of the profile

Server : Syslog server to send the log messages to

Port : Syslog port

BackupServer: Backup Syslog server to send log to

BackupPort : Backup Syslog port

Protocol : Transport to use {UDP|TCP|TLS}

SyslogProtocol : Syslog protocol to use {Legacy|Legacy_long|RFC5424}

CAServer : The trusted CA which issued the server certificate

CertServer : The server certificate

CertClient : The client certificate

BindAddr : Firewall local IP to use to connect to the Syslog server

Facility : Facility number

LogtypePos : Indicates if the logtype token should appear after starttime token

LogAlarm : Indicates if this profile should send alarm logs to the Syslog server

LogConnection Indicates if this profile should send connection logs to the Syslog server

LogFilter : Indicates if this profile should send filter logs to the Syslog server

LogWeb : Indicates if this profile should send web logs to the Syslog server

LogSmtp : Indicates if this profile should send smtp logs to the Syslog server

LogDate : Indicates if this profile should send date logs to the Syslog server

LogFtp : Indicates if this profile should send ftp logs to the Syslog server

LogSystem : Indicates if this profile should send system logs to the Syslog server

LogPlugin : Indicates if this profile should send plugin logs to the Syslog server

LogVPN : Indicates if this profile should send VPN logs to the Syslog server

LogAuth : Indicates if this profile should send auth logs to the Syslog server

LogServer : Indicates if this profile should send Server logs to the Syslog server

LogPop3 : Indicates if this profile should send POP3 logs to the Syslog server

LogXvpn : Indicates if this profile should send Xvpn logs to the Syslog server

LogMonitor : Indicates if this profile should send Monitor logs to the Syslog server



LogPvm : Indicates if this profile should send Pvm logs to the Syslog server
 LogCount : Indicates if this profile should send Count logs to the Syslog server
 LogFilterstat: Indicates if this profile should send FilterStat logs to the Syslog server
 LogSsl : Indicates if this profile should send SSL logs to the Syslog server
 LogSandboxing: Indicates if this profile should send Sandboxing logs to the Syslog server

Example

```
CONFIG COMMUNICATION SHOW index=0
```

CONFIG COMMUNICATION SYSLOG PROFILE UPDATE**Level**

log,modify

History

Appears in 3.0.0

Description

Configure Syslog.

Usage

```
Index=<profile_idx> [State={1|0}] [Name=<Profile name>] [Comment=<comment>|""]  
[Server=<host_object>|""] [Port=<service_object|integer>] [BackupServer=<host_object>|""]  
[BackupPort=<service_object|integer>]  
[BindAddr={<firewall_ip_object>|""}]  
[Protocol={UDP|TCP|TLS}] [SyslogProtocol={Legacy|Legacy_long|RFC5424}]  
[CAsServer=<ca>|""] [CertServer=<cert>|""] [CertClient=<cert>|""]  
[Facility={0-8}] [LogtypePos={0|1}]  
[LogAlarm={0|1}] [LogConnection={0|1}] [LogFilter={0|1}] [LogWeb={0|1}] [LogSntp={0|1}]  
[LogDate={0|1}] [LogFtp={0|1}] [LogSystem={0|1}]  
[LogPlugin={0|1}] [LogVPN={0|1}] [LogAuth={0|1}] [LogServer={0|1}] [LogPop3={0|1}]  
[Log=Xvpn{0|1}] [LogMonitor={0|1}]  
[LogPvm={0|1}] [LogCount={0|1}] [LogFilterstat={0|1}] [LogSsl={0|1}] [LogSandboxing=  
{0|1}]
```

where:

- LogtypePos=1 means that logtype token appears after starttime token.
- BindAddr must be an object which represents a local IP address of the firewall.

Returns

Error code

Example

```
CONFIG COMMUNICATION SYSLOG State=1 Server=Syslog_Server Port=512 BindAddr=Firewall_in  
ClearText=1 Facility=1  
CONFIG COMMUNICATION SYSLOG State=0
```

CONFIG COMMUNICATION TEST**Level**

base

History

Appears in 3.5.0

Description

Test external communication configuration.



CONFIG COMMUNICATION TEST SMTP

Level

log

History

Appears in 3.5.0

Description

Try to send an email using SMTP configuration for email notifications.

Usage

To=<email>

Returns

Error code

Example

CONFIG COMMUNICATION TEST SMTP To=user@domain.tld

CONFIG CONSOLE

Level

base

Description

Console configuration

CONFIG CONSOLE BRUTEFORCE

Level

base

History

Appears in 3.10.0

Description

bruteforce configuration

CONFIG CONSOLE BRUTEFORCE SHOW

Level

base

History

Appears in 3.10.0

Description

Show bruteforce tokens

Usage

None

Returns

Error code

**Example**

CONFIG CONSOLE BRUTEFORCE SHOW

CONFIG CONSOLE BRUTEFORCE UPDATE**Level**

admin,modify

History

Appears in 3.10.0

Description

Configure bruteforce

Usage

BruteforceState=<id> NbAttempt=<token> NbBruteForceEntries=<value>
TimeoutBanned=<value> TriesTime=<value>

Returns

Error code

Example

CONFIG CONSOLE BRUTEFORCE UPDATE State=1 CONFIG CONSOLE BRUTEFORCE UPDATE State=1
NbAttempt=1

CONFIG CONSOLE GETHOSTKEY**Level**

base

History

Format Appears in Netasq 9.0.0
Moved to CONFIG SSH GETHOSTKEY in 4.2.0

Description

Get firewall public key

Returns

the ssh firewall public key

Format

raw

Example

CONFIG CONSOLE GETHOSTKEY

CONFIG CONSOLE GETKEY**Level**

admin

History

Format Appears in Netasq 9.0.0
Moved to CONFIG SSH GETKEY in 4.2.0

**Description**

Get admin account private key

Returns

the ssh private key of admin

Format

raw

Example

CONFIG CONSOLE GETKEY

CONFIG CONSOLE REMOTEADMIN**Level**

admin,modify

History

Appears in Netasq 9.0.0

Description

Authorized or not connection for 'admin' from remote IP

Usage

[on|off]

Returns

current status

Example

CONFIG CONSOLE REMOTEADMIN
CONFIG CONSOLE REMOTEADMIN off

CONFIG CONSOLE SERVERDLOOPBACK**Level**

maintenance

History

Appears in 4.1.0

Description

Force serverd to listen only the loopback interface

Usage

[state=0|1]

Returns

Error code or current value if no parameter :

[global]

ForceLoopback= : current state

Example

CONFIG CONSOLE SERVERDLOOPBACK
[global] ForceLoopback=0



```
CONFIG CONSOLE SERVERDLOOPBACK state=1  
100 code=00a00100 msg="Ok"
```

CONFIG CONSOLE SETPASSPHRASE

Level

admin,modify

History

Oldpassword Appears in SNS 4.1.0

Description

Generate and set admin key passphrase

Usage

```
oldpassword=<oldpassword> newpassword=<newpassword>
```

Returns

Error code

Example

```
CONFIG CONSOLE SETPASSPHRASE oldpassword=<CurrentAdminPwd>  
newpassword=<NewAdminPwd>
```

CONFIG CONSOLE SSH

Level

admin,modify

History

Userpass Appears in Netasq 6.0.0

Password deprecated in Netasq 6.0.0

Port Appears in Netasq 6.1.0

Moved to CONFIG SSH UPDATE in 4.2.0

Description

Enable/disable SSH console access

Usage

```
State=[0|1] Userpass=[0|1] Port=[number|object]
```

Returns

Error code (if parameter) or :

State= : state of service

Userpass= : specify if password mode is on/off

Port= : port used by service

Remark

Admin and Modify levels are required to update configuration

Example

```
CONFIG CONSOLE SSH State=1 Userpass=1 Port=gopher
```



CONFIG CRYPTO

Level

maintenance, modify

History

Appears in 2.0.0

ClientTLSv12 & ClientTLSv13 appear in 4.2.0

SSLParanoiac appears in 4.2.2

Description

Configure cryptographic parameters.

Usage

```
[Cryptodr=0|1] [ClientTLSv12=0|1] [ClientTLSv13=0|1] [SSLParanoiac=0|1]
```

where:

- Cryptodr: Disable/Enable ANSSI DR mode.
- ClientTLSv12: Disable/Enable TLS 1.2 for client application.
- ClientTLSv13: Disable/Enable TLS 1.3 for client application.
- SSLParanoiac: Disable/Enable SSL paranoiac mode

Returns

Error code

Example

```
CONFIG CRYPTO Cryptodr=1
```

```
CONFIG CRYPTO ClientTLSv12=0 ClientTLSv13=1
```

```
CONFIG CRYPTO SSLParanoiac=1
```

CONFIG DDNSCLIENT

Level

base

History

Appears in Netasq 6.0.0

Description

Dynamic DNS client administration

CONFIG DDNSCLIENT ACTIVATE

Level

network, modify

History

Appears in Netasq 9.0.0

Description

Activate/cancel modifications of DDNSCLIENT configuration

Usage

```
[CANCEL|NEXTBOOT]
```

- no argument: changes are activated immediately;



- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG DDNSCLIENT ACTIVATE

CONFIG DDNSCLIENT DELETE**Level**

network,modify

History

Appears in Netasq 6.0.0

Description

Delete an existing dynamic DNS client configuration

Usage

name=<name of configuration to be deleted>

Returns

Error code

Example

CONFIG DDNSCLIENT DELETE name=DynamicDNS

CONFIG DDNSCLIENT LIST**Level**

base

History

Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0

Description

List Dynamic DNS client configurations

Returns

list of Dynamic DNS client configurations

Format

list

Example

CONFIG DDNSCLIENT LIST
DynamicDNS

CONFIG DDNSCLIENT NEW**Level**



network,modify

History

Appears in Netasq 6.0.0

Added noip in Netasq 9.1.0

Description

Create a new dynamic DNS client configuration

Usage

name=<confname> provider=<dyndns|noip>

Returns

Error code

Example

CONFIG DDNSCLIENT NEW name=DynamicDNS provider=dyndns

CONFIG DDNSCLIENT RESETEVENT

Level

network,modify

History

Appears in Netasq 6.0.0

Description

Remove all event entry and set offline

Usage

name=<conf name>

Returns

Error code

Example

CONFIG DDNSCLIENT RESETEVENT name=DynamicDNS

CONFIG DDNSCLIENT SET

Level

network,modify

History

Appears in Netasq 6.0.0

NAT appears in 3.0.0

Description

Set a global or a configuration parameter

Usage

name=<conf name> [state=<0|1> | service=<provider service name> | server=<host object> |
user=<username> | password=<pass> | hostname=<dns name> | protocol=<HTTP|HTTPS> |
WildcardOption=<0|1> | OfflineOption=<0|1> | RenewInterval=<time in sec> | NAT=<0|1>]

Returns



Error code

Example

```
CONFIG DDNSCLIENT SET name=DynamicDNS state=1
```

CONFIG DDNSCLIENT SHOW**Level**

base

History

Appears in Netasq 6.0.0

Description

Show all or specific dynamic DNS client configuration

Usage

```
[name=<name of configuration>]
```

Returns

```
[Config]
```

```
Verbosity={0|1}
```

```
[DynamicDNS]
```

```
State={On|Off}
```

```
Provider=type of provider
```

```
Service=name of service
```

```
User=user name to login
```

```
Password=password to login
```

```
Hostname=registred hostname
```

```
Server=server of service
```

```
protocol={HTTP|HTTPS}
```

```
WildcardOption={0|1} : wilcard redirection
```

```
OfflineOption={0|1} : offline redirection
```

```
RenewInterval=maximum interval between renewal
```

```
NAT={0|1} : 0 uses interface address, 1 uses public address
```

Remark

optional parameter "name" to show only one configuration

Example

```
CONFIG DDNSCLIENT SHOW
```

```
[Config]
```

```
Verbosity=0
```

```
[DynamicDNS]
```

```
State=On
```

```
Provider=dyndns
```

```
Service=dyndns
```

```
User=ddns_user
```

```
Password=ddns_passwd
```

```
Hostname=my_ddns.dnsalias.net
```

```
Server=members.dyndns.org
```

```
protocol=HTTP
```

```
WildcardOption=1
```



OfflineOption=0
RenewInterval=2419200

CONFIG DDNSCLIENT UNSET

Level

network,modify

History

Appears in Netasq 6.0.0

Description

Unset a global or a configuration parameter (restore default value)

Usage

name=<conf name> param=
[state|service|server|user|password|hostname|protocol|RenewInterval|OfflineOption|WildcardO
ption|NAT]

Returns

Error code

Example

CONFIG DDNSCLIENT UNSET name=DynamicDNS param=state

CONFIG DHCP

Service/DHCP

Level

base

Description

Command to manage DHCP server.

CONFIG DHCP ACTIVATE

Level

network,modify

History

CANCEL appears in Netasq 6.0.0

NEXTBOOT appears in Netasq 6.0.0

level changes from other,modify to network,modify in Netasq 9.0.0

Description

Activate DHCP configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next reboot.

Returns



Error code

Example

```
CONFIG DHCP ACTIVATE
```

CONFIG DHCP HOST**Level**

base

Description

Configure DHCP hosts

CONFIG DHCP HOST ADD**Level**

network,modify

History

macaddr deprecated in Netasq 6.0.0

level changes from other,modify to network,modify in Netasq 9.0.0

dns1, dns2, domain appear in 2.0.0

Description

Add a host to DHCP server configuration.

Usage

```
name=<hostname> [gate=<gateway>] [dns1=objhost] [dns2=objhost] [domain=str]
```

Returns

Error code

Example

```
CONFIG DHCP HOST ADD name=host1
```

```
CONFIG DHCP HOST ADD name=host2 gate=gw1
```

CONFIG DHCP HOST LIST**Level**

base

History

level base appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

Format appears in Netasq 9.0.0

Description

List DHCP server hosts

Returns

list of hosts in the form :

```
pos=num host=obj_host macaddr=ethernet_address [gate=objhost] [dns1=objhost]  
[dns2=objhost] [domain=str]
```

Format

section_line

**Example**

```
CONFIG DHCP HOST LIST
```

```
pos=1 host=host1 macaddr=00:00:AA:BB:88:22 gate=gw1
```

CONFIG DHCP HOST REMOVE**Level**

network,modify

History

pos deprecated in Netasq 6.0.0

level changes from other,modify to network,modify in Netasq 9.0.0

Description

Remove a host from DHCP server configuration.

Usage

name=<hostname>

Returns

Error code

Example

```
CONFIG DHCP HOST REMOVE name=host1
```

CONFIG DHCP PARAMETERS**Level**

base

Description

Configure DHCP server global parameters.

CONFIG DHCP PARAMETERS ADD**Level**

network,modify

History

custom-option1 appears in Netasq 6.1.0

custom-option2 appears in Netasq 6.1.0

default-ltime deprecated in Netasq 6.1.0

iparray option for custom-option2 appears in Netasq 6.1.3

hostgroup name option for custom-option2 appears in Netasq 6.1.3

level changes from other,modify to network,modify in Netasq 9.0.0

filename appears in 3.9.0

Description

Add a global parameter to DHCP server.

Usage

```
domain-name=<name> | dns-update=Off|On | default-ltime=<seconds> | max-ltime=<seconds>  
| min-ltime=<seconds> | wpad=Off|On | custom-option1=<name>,<id>,{str|ip|iparray},  
{<string>|<host name>|<hostgroup name>} | custom-option2=<name>,<id>,{str|ip|iparray},  
{<string>|<host name>|<hostgroup name>} | filename=<string>
```

**Returns**

Error code

Example

```
CONFIG DHCP PARAMETERS ADD domain-name=my.domain.com
```

CONFIG DHCP PARAMETERS LIST**Level**

network

History

level changes from other to network in Netasq 9.0.0
filename appears in 3.9.0

Description

List DHCP server global parameters and options.

Returns

[Parameters]

domain-name=domain name for clients
dns-update=Off|On : dynamic dns update
default-ltime=default lease time for clients
min-ltime=minimum lease time for clients
max-ltime=maximum lease time for clients

Example

```
CONFIG DHCP PARAMETERS LIST  
[Parameters]  
domain-name=my.domain.com
```

CONFIG DHCP PARAMETERS REMOVE**Level**

network,modify

History

level changes from other,modify to network,modify in Netasq 9.0.0
filename appears in 3.9.0

Description

Remove a global parameter from DHCP server.

Usage

domain-name
dns-update
default-ltime
min-ltime
max-ltime
wpad
filename

Returns

Error code

Example



CONFIG DHCP PARAMETERS REMOVE domain-name

CONFIG DHCP RANGE

Level

base

Description

Configure ranges of IP addresses.

CONFIG DHCP RANGE ADD

Level

network,modify

History

begin deprecated in Netasq 6.0.0

end deprecated in Netasq 6.0.0

name appears in Netasq 6.0.0

level changes from other,modify to network,modify in Netasq 9.0.0

dns1, dns2, domain appear in 2.0.0

Description

Add a range.

Usage

name=<objrange> [gate=<objhost>] [dns1=objhost] [dns2=objhost] [domain=str]

Returns

Error code

Example

CONFIG DHCP RANGE ADD name=dhcp_range

CONFIG DHCP RANGE LIST

Level

base

History

level base appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

name appears in Netasq 6.0.0

Format appears in Netasq 9.0.0

Description

List ranges.

Returns

list of ranges in the form:

pos=num name=[<object name>|None] begin=ip end=ip [gate=<objhost>|ip] [dns1=objhost]
[dns2=objhost] [domain=str]

Format

section_line

**Example**

```
CONFIG DHCP RANGE LIST  
pos=1 name="dhcp_range" begin=10.2.20.21 end=10.2.20.254 gate=gw1
```

CONFIG DHCP RANGE REMOVE**Level**

network,modify

History

pos deprecated in Netasq 6.0.0
name appears in Netasq 6.0.0
level changes from other,modify to network,modify in Netasq 9.0.0

Description

Delete a DHCP range.

Usage

name=<object name> | begin=<ip address> only if name=None

Returns

Error code

Example

```
CONFIG DHCP RANGE REMOVE name=dhcp_range
```

CONFIG DHCP RELAY**Level**

base

Description

Configure DHCP relay.

CONFIG DHCP RELAY ADVANCED**Level**

network,modify

History

Appears in 1.0.0

Description

Set advanced settings: bindaddr.

Usage

```
[BindAddr={<firewall_ip_object>|""}]
```

Remark

BindAddr must be an object which represents a local IPv4 address of the firewall.

Returns

Error code

Example

```
CONFIG DHCP RELAY ADVANCED BindAddr=Firewall_in
```



CONFIG DHCP RELAY INTERFACE

Level

base

Description

Configure interfaces involved in DHCP relay.

CONFIG DHCP RELAY INTERFACE ADD

Level

network,modify

History

Appears in Netasq 9.0.0

Description

Add an interface involved in DHCP traffic relaying.

Usage

name=<Interface Name>

Returns

Error code

Example

CONFIG DHCP RELAY INTERFACE ADD name=out

CONFIG DHCP RELAY INTERFACE ALL

Level

network,modify

History

Appears in Netasq 9.0.0

Description

Configure DHCP relay to listen on all the interfaces or listen only on interfaces explicitly configured.

Usage

state={0|1|On|Off}

Returns

Error code

Example

CONFIG DHCP RELAY INTERFACE ALL state=1

CONFIG DHCP RELAY INTERFACE LIST

Level

base

History

Appears in Netasq 9.0.0

Description

List configured interfaces involved in DHCP traffic relaying.

**Returns**

list all the interfaces involved in DHCP traffic relaying

Format

list

Example

CONFIG DHCP RELAY INTERFACE LIST

In

Out

CONFIG DHCP RELAY INTERFACE REMOVE**Level**

network,modify

History

Appears in Netasq 9.0.0

Description

Remove an interface involved in DHCP traffic relaying.

Usage

name=<Interface Name>

Returns

Error code

Example

CONFIG DHCP RELAY INTERFACE REMOVE name=out

CONFIG DHCP RELAY SERVER**Level**

network,modify

History

Appears in Netasq 9.0.0

Description

Set the DHCP server(s) to which the dhcp requests will be forwarded.

Usage

name=<host|range|hostgroup|"">

Returns

Error code

Example

CONFIG DHCP RELAY SERVER name=myhost

CONFIG DHCP RELAY SHOW**Level**

base

History



Appears in Netasq 9.0.0
BindAddr appears in 1.0.0

Description

Show DHCP relay configuration.

Returns

```
[Config]
State={On|Off} # DHCP relay State
Server={host|range|network|hostgroup}
InterfaceAll={0|1}
BindAddr=<host>
```

Example

```
CONFIG DHCP RELAY SHOW
[Config]
State=On
Server=myhost
InterfaceAll=0
BindAddr=Firewall_in
```

CONFIG DHCP RELAY STATE**Level**

base

History

Appears in Netasq 9.0.0

Description

Get/set DHCP relay state.

Usage

```
[On|Off]
```

Returns

```
State={on|off}
```

Remark

Network and Modify level are required to update the state value.

Example

```
CONFIG DHCP RELAY STATE On
CONFIG DHCP RELAY STATE Off
```

CONFIG DHCP SERVERS**Level**

base

Description

Configure various servers for DHCP clients.

CONFIG DHCP SERVERS ADD**Level**



network,modify

History

Appears in Netasq 6.2.0

level changes from other,modify to network,modify in Netasq 9.0.0

www appears in 2.0.0

next-server appears in 3.9.0

Description

Add a server.

Usage

```
defaultgateway=<hostname> | dns1=<hostname> | dns2=<hostname> | news=<hostname> |  
ntp=<hostname> | pop=<hostname> | smtp=<hostname> | tftp=<hostname> |  
wins=<hostname> | www=<hostname> | next-server=<hostname>
```

Returns

Error code

Example

```
CONFIG DHCP SERVERS ADD dns2=dns_2
```

CONFIG DHCP SERVERS LIST**Level**

base

History

level base appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

next-server appears in 3.9.0

Description

List configured servers for DHCP clients..

Returns

list of servers in the form of server_name=host_object_name pairs

Example

```
CONFIG DHCP SERVERS LIST  
DefaultGateway=gw2  
dns1=dns_1  
dns2=dns_2
```

CONFIG DHCP SERVERS REMOVE**Level**

network,modify

History

level changes from other,modify to network,modify in Netasq 9.0.0

www appears in 2.0.0

next-server appears in 3.9.0

Description

Remove a server.

**Usage**

defaultgateway | dns1 | dns2 | news | ntp | pop | smtp | tftp | wins | www | next-server

Returns

Error code

Example

CONFIG DHCP SERVERS REMOVE dns2

CONFIG DHCP SHOW**Level**

base

Description

Show DHCP configuration.

Returns

[Config]

State={On|Off} # DHCP server state

[Parameters] # show parameters

Parameters list

Example

CONFIG DHCP SHOW

[Config]

State=On

[Parameters]

domain-name=my.domain.com

CONFIG DHCP STATE**Level**

base

Description

Get/set DHCP state.

Usage

[On|Off]

Returns

State={on|off}

Remark

Network and Modify level are required to update the state value

Example

CONFIG DHCP STATE On

CONFIG DHCP STATE Off

CONFIG DHCP6

Service/DHCP

**Level**

base

History

Appears in 1.0.0

Description

Command to manage DHCPv6 server and relay.

CONFIG DHCP6 ACTIVATE**Level**

network,modify

History

Appears in 1.0.0

Description

Activate DHCPv6 configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next reboot.

Returns

Error code

Example

CONFIG DHCP6 ACTIVATE

CONFIG DHCP6 HOST**Level**

base

Description

Configure DHCPv6 hosts

CONFIG DHCP6 HOST ADD**Level**

network,modify

History

Appears in 1.0.0

dns1, dns2, domain appear in 2.0.0

Description

Add a host to DHCPv6 server configuration.

Usage

```
name=<hostname> duid=<duid-ll|duid-llt|duid-en> [dns1=objhost] [dns2=objhost]  
[domain=str]
```

Returns



Error code

Example

```
CONFIG DHCP6 HOST ADD name=host2 duid=0:1:0:1:16:61:e:c0:0:d:b4:2:6d:c3
```

CONFIG DHCP6 HOST LIST**Level**

base

History

Appears in 1.0.0

Description

List DHCP server hosts

Returns

list of hosts in the form:

```
pos=num host=objhost duid=<duid-ll|duid-llt|duid-en> [dns1=objhost] [dns2=objhost]  
[domain=str]
```

Format

section_line

Example

```
CONFIG DHCP6 HOST LIST
```

```
pos=1 host=host6 duid=0:1:0:1:16:61:e:c0:0:d:b4:2:6d:c3
```

CONFIG DHCP6 HOST REMOVE**Level**

network,modify

History

Appears in 1.0.0

Description

Remove a host from DHCPv6 server configuration.

Usage

```
name=<hostname>
```

Returns

Error code

Example

```
CONFIG DHCP6 HOST REMOVE name=host1
```

CONFIG DHCP6 PARAMETERS**Level**

base

Description

Configure DHCPv6 server global parameters.

CONFIG DHCP6 PARAMETERS ADD**Level**



network,modify

History

Appears in 1.0.0

Description

Add a global parameter to DHCPv6 server.

Usage

domain-name=<name> | default-ltime=<seconds> | max-ltime=<seconds> | min-ltime=<seconds> | wpad=Off|On | custom-option1=<name>,<id>,{str|ip|ipv6|iparray|ipv6array},(<string>|<host name>|<host6 name>|<hostgroup name>|<hostgroup6 name>) | custom-option2=<name>,<id>,{str|ip|ipv6|iparray|ipv6array},(<string>|<host name>|<host6 name>|<hostgroup name>|<hostgroup6 name>)

Returns

Error code

Example

CONFIG DHCP6 PARAMETERS ADD domain-name=my.domain.com

CONFIG DHCP6 PARAMETERS LIST**Level**

network

History

Appears in 1.0.0

Description

List DHCPv6 server global parameters and options.

Returns

[Parameters]

domain-name=domain name for clients

default-ltime=default lease time for clients

min-ltime=minimum lease time for clients

max-ltime=maximum lease time for clients

Example

CONFIG DHCP PARAMETERS LIST

[Parameters]

domain-name=my.domain.com

CONFIG DHCP6 PARAMETERS REMOVE**Level**

network,modify

History

Appears in 1.0.0

Description

Remove a global parameter from DHCPv6 server.

Usage

domain-name

default-ltime



min-ltime
max-ltime
wpad

Returns

Error code

Example

CONFIG DHCP6 PARAMETERS REMOVE domain-name

CONFIG DHCP6 RANGE**Level**

base

Description

Configure ranges of IPv6 addresses.

CONFIG DHCP6 RANGE ADD**Level**

network,modify

History

Appears in 1.0.0

dns1, dns2, domain appear in 2.0.0

Description

Add a DHCP IPv6 range.

Usage

name=<rangename> [dns1=objhost] [dns2=objhost] [domain=str]

Returns

Error code

Example

CONFIG DHCP6 RANGE ADD name=dhcp6_range

CONFIG DHCP6 RANGE LIST**Level**

base

History

Appears in 1.0.0

Description

List DHCP IPv6 ranges.

Returns

list of ranges in the form :

pos=num name=<object name> begin=ipv6 end=ipv6 [dns1=objhost] [dns2=objhost]
[domain=str]

Format

section_line

Example

**CONFIG DHCP6 RANGE LIST**

pos=1 name="dhcp_range" begin=2001:deca::10 end=2001:deca::20

CONFIG DHCP6 RANGE REMOVE**Level**

network,modify

History

Appears in 1.0.0

Description

Delete a DHCP6 range.

Usage

name=<object name>

Returns

Error code

Example

CONFIG DHCP6 RANGE REMOVE name=dhcp6_range

CONFIG DHCP6 RELAY**Level**

base

Description

Configure DHCPv6 relay

CONFIG DHCP6 RELAY FWDINTERFACE**Level**

base

Description

Configure DHCPv6 servers side interfaces.

CONFIG DHCP6 RELAY FWDINTERFACE ADD**Level**

network,modify

History

Appears in 1.0.0

Description

Add a server side interface involved in DHCPv6 traffic relaying.

Usage

name=<Interface Name>

Returns

Error code

Example

CONFIG DHCP6 RELAY FWDINTERFACE ADD name=in

**CONFIG DHCP6 RELAY FWDINTERFACE LIST****Level**

base

History

Appears in 1.0.0

Description

List configured server side interfaces involved in DHCPv6 traffic. relaying

Returns

list all the server side interfaces involved in DHCPv6 traffic relaying

Format

list

Example

```
CONFIG DHCP6 RELAY FWDINTERFACE LIST
```

```
In
```

```
Out
```

CONFIG DHCP6 RELAY FWDINTERFACE REMOVE**Level**

network,modify

History

Appears in 1.0.0

Description

Remove a server side interface involved in DHCPv6 traffic relaying.

Usage

name=<Interface Name>

Returns

Error code

Example

```
CONFIG DHCP6 RELAY FWDINTERFACE REMOVE name=in
```

CONFIG DHCP6 RELAY RCVINTERFACE**Level**

base

Description

Configure DHCPv6 clients side interfaces.

CONFIG DHCP6 RELAY RCVINTERFACE ADD**Level**

network,modify

History

Appears in 1.0.0

Description



Add a client side interface involved in DHCPv6 traffic relaying.

Usage

name=<Interface Name>

Returns

Error code

Example

```
CONFIG DHCP6 RELAY RCVINTERFACE ADD name=in
```

CONFIG DHCP6 RELAY RCVINTERFACE LIST**Level**

base

History

Appears in 1.0.0

Description

List configured client side interfaces involved in DHCPv6 traffic relaying.

Returns

list all the client side interfaces involved in DHCPv6 traffic relaying

Format

list

Example

```
CONFIG DHCP6 RELAY RCVINTERFACE LIST
```

In

Out

CONFIG DHCP6 RELAY RCVINTERFACE REMOVE**Level**

network,modify

History

Appears in 1.0.0

Description

Remove a client side interface involved in DHCPv6 traffic relaying.

Usage

name=<Interface Name>

Returns

Error code

Example

```
CONFIG DHCP6 RELAY RCVINTERFACE REMOVE name=in
```

CONFIG DHCP6 RELAY SERVER**Level**

network,modify

History



Appears in 1.0.0

Description

Set the DHCPv6 server(s) to which the dhcp requests will be forwarded.

Usage

name=<host6|range6|hostgroup6|">

Returns

Error code

Example

```
CONFIG DHCP6 RELAY SERVER name=myhost
```

CONFIG DHCP6 RELAY SHOW**Level**

base

History

Appears in 1.0.0

Description

Show DHCPv6 relay configuration.

Returns

[Config]

State={On|Off} # DHCPv6 relay State

Server={host|range|network|hostgroup}

Example

```
CONFIG DHCP6 RELAY SHOW
```

```
[Config]
```

```
State=On
```

```
Server=myhost
```

CONFIG DHCP6 RELAY STATE**Level**

base

History

Appears in 1.0.0

Description

Get/set DHCPv6 relay state.

Usage

[On|Off]

Returns

State={on|off}

Remark

Network and Modify level are required to update the state value.

Example



CONFIG DHCP6 RELAY STATE On
CONFIG DHCP6 RELAY STATE Off

CONFIG DHCP6 SERVERS

Level

base

Description

Configure various servers for DHCPv6 clients

CONFIG DHCP6 SERVERS ADD

Level

network,modify

History

Appears in 1.0.0

Description

Add a server.

Usage

dns1=<hostname> | dns2=<hostname> | tftp=<hostname>

Returns

Error code

Example

CONFIG DHCP6 SERVERS ADD dns2=dns_2

CONFIG DHCP6 SERVERS LIST

Level

base

History

Appears in 1.0.0

Description

List configured servers for DHCPv6 clients.

Returns

list of servers in the form of server_name=host_object_name pairs

Example

CONFIG DHCP6 SERVERS LIST
dns1=dns_1
dns2=dns_2

CONFIG DHCP6 SERVERS REMOVE

Level

network,modify

History

Appears in 1.0.0

Description



Remove a server.

Usage

name=dns1 | dns2 | tftp

Returns

Error code

Example

CONFIG DHCP6 SERVERS REMOVE dns2

CONFIG DHCP6 SHOW**Level**

base

History

Appears in 1.0.0

Description

Show DHCPv6 configuration.

Returns

[Config]

State={On|Off} # DHCPv6 server state

[Parameters] # show parameters

Parameters list

Example

CONFIG DHCP6 SHOW

[Config]

State=On

[Parameters]

domain-name=my.domain.com

CONFIG DHCP6 STATE**Level**

base

History

Appears in 1.0.0

Description

Get/set DHCPv6 state.

Usage

[On|Off]

Returns

State={on|off}

Remark

Network and Modify level are required to update the state value

Example



CONFIG DHCP6 STATE On
CONFIG DHCP6 STATE Off

CONFIG DNS

Level

base

History

LICENCE deprecated in Netasq 6.0.0

Description

Command to manage DNS cache.

CONFIG DNS ACTIVATE

Level

network,modify

History

CANCEL appears in Netasq 6.0.0

NEXTBOOT appears in Netasq 6.0.0

level changes from other,modify to network,modify in Netasq 9.0.0

Description

Activate DNS configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next reboot.

Returns

Error code

Example

CONFIG DNS ACTIVATE

CONFIG DNS ADVANCED

Service/DNS

Level

network,modify

History

LICENCE appears in Netasq 6.0.0

randomServerOrder appears in Netasq 6.1.0

level changes from other,modify to network,modify in Netasq 9.0.0

ipsend appears in Netasq 9.1.0

Description

Set advanced settings: automatic redirect, and cache size.

**Usage**

[redirect=On|Off] [randomServerOrder=On|Off] [cacheSize=size of cache in bytes]
[ipSend=ip|firewall host object]

Returns

Error code

Example

CONFIG DNS ADVANCED redirect=On

CONFIG DNS CLIENT

Service/DNS

Level

base

History

LICENCE appears in Netasq 6.0.0

Description

Configure clients.

CONFIG DNS CLIENT ADD**Level**

network,modify

History

level changes from other,modify to network,modify in Netasq 9.0.0

Description

Add a DNS cache single client or many clients IP addresses.

Usage

<host | range | network | hostgroup>

Returns

Error code

Example

CONFIG DNS CLIENT ADD Network_in

CONFIG DNS CLIENT LIST**Level**

base

History

level changes from other to base in Netasq 9.0.0

Description

List authorized clients.

Returns

list of authorized clients in the form:
position=host_object_name

**Example**

```
CONFIG DNS CLIENT LIST
1="Network_in"
2="Network_dmz"
```

CONFIG DNS CLIENT REMOVE**Level**

network,modify

History

pos deprecated in Netasq 6.0.0
level changes from other,modify to network,modify in Netasq 9.0.0

Description

Delete a DNS cache client.

Usage

<object name>

Returns

Error code

Example

```
CONFIG DNS CLIENT REMOVE Network_in
```

CONFIG DNS SERVER**Level**

base

Description

Configure servers which will receive requests from firewall.

CONFIG DNS SERVER ADD**Level**

network,modify

History

ip deprecated in Netasq 6.0.0
hostname appears in Netasq 6.0.0
level changes from other,modify to network,modify in Netasq 9.0.0

Description

Add a DNS cache server (default position is end of list).

Usage

<hostname> [pos=<position>]

Returns

Error code

Example

```
CONFIG DNS SERVER ADD dns_1
```



CONFIG DNS SERVER LIST

Level

base

History

level changes from other to base in Netasq 9.0.0

Description

List DNS cache servers.

Returns

list of servers in the form :
position=host_object_name

Example

```
CONFIG DNS SERVER LIST
[Server]
1="dns_1"
2="dns_2"
```

CONFIG DNS SERVER REMOVE

Level

network,modify

History

ip deprecated in Netasq 6.0.0
hostname appears in Netasq 6.0.0
level changes from other,modify to network,modify in Netasq 9.0.0

Description

Remove a DNS cache server from list.

Usage

<hostname>

Returns

Error code

Example

```
CONFIG DNS SERVER REMOVE dns_1
```

CONFIG DNS SHOW

Level

base

Description

Show DNS configuration.

Returns

```
[Config]
State=on|off # DNS proxy State
[Advanced]
redirect=on|off # Redirection state
```



cacheSize=size # Cache size in bytes
cacheMaxSize=size # Maximum cache size in bytes

Example

```
CONFIG DNS SHOW
[Config]
State=On
[Advanced]
redirect=Off
cacheSize=999424
cacheMaxSize=5000000
randomServerOrder=On
ipsend=Firewall_in
```

CONFIG DNS STATE

Service/DNS

Level

base

Description

Get/set DNS state.

Usage

[On|Off]

Returns

State={on|off}

Remark

Network and Modify levels are required to update the state value.

Example

```
CONFIG DNS STATE On
CONFIG DNS STATE Off
```

CONFIG DNS USEROOT

Service/DNS

Level

base

History

Appears in 3.5.0

Description

Enable/Disable DNS Root configuration.

Usage

[state={On|Off}]

Returns

UseRoot={on|off}

Remark



Network and Modify levels are required to update the UseRoot value

Example

```
CONFIG DNS USEROOT state=Off
```

CONFIG DOWNLOAD

Level

base

History

userauth.00 appears in 3.5.0
userauth.01 appears in 3.5.0
userauth.02 appears in 3.5.0
userauth.03 appears in 3.5.0
userauth.04 appears in 3.5.0
userauth.05 appears in 3.5.0
userauth.06 appears in 3.5.0
userauth.07 appears in 3.5.0
userauth.08 appears in 3.5.0
userauth.09 appears in 3.5.0
sshd-banner appears in 3.5.0

Description

Download a file from firewall

Usage

custom.css | index-logo.jpg | httpproxy_blockpage0 | httpproxy_blockpage1 | httpproxy_blockpage2 | httpproxy_blockpage3 | algorithm | vpntunnel | ldapmaps | app_user_req | rej_user_req | app_cert_req | rej_cert_req | keytab | wpad.dat | custom_disclaimer.html | disclaimer.pdf | bird.conf | bird6.conf | userauth.00 | userauth.01 | userauth.02 | userauth.03 | userauth.04 | userauth.05 | userauth.06 | userauth.07 | userauth.08 | userauth.09 | sshd-banner | custom_login_disclaimer

Returns

The requested file

Remark

Additional rights may be needed to read files:

wpad.dat: contentfilter

app_user_req, rej_user_req, ldapmaps, keytab: user

app_cert_req, rej_cert_req: pki

custom_disclaimer.html, disclaimer.pdf, custom_login_disclaimer: admin

index-logo.jpg, custom.css: admin

httpproxy_blockpage0, httpproxy_blockpage1, httpproxy_blockpage2, httpproxy_blockpage3

Example

```
CONFIG DOWNLOAD httpproxy_blockpage2
```

CONFIG FILTER

Level

base

**Description**

Manage filtering rules.

CONFIG FILTER ACTIVATE**Level**

filter,globalfilter,modify

History

level globalfilter added in Netasq 9.0.0 CACHE_CATEGORY filter CACHE_CATEGORY_CLONE filter

Description

Activate current filter slot.

CONFIG FILTER CHECK**Level**

filter_read

Format

section_line

History

Appears in Netasq 9.0.0

Usage

type={filter|nat} index=<policy_idx> [output={plain|xml}] [global={0|1}]

Description

Check the current (non-activated) filter rules.

CONFIG FILTER DEFAULT**Level**

filter,globalfilter,modify

History

Appears in Netasq 9.0.0 CACHE_CATEGORY_CLONE filter

Description

Reset a filter/NAT policy to its default settings.

Usage

index=<policy_idx> type={filter|nat} [global={0|1}]

CONFIG FILTER EXPLICIT**Level**

filter_read CACHE_CATEGORY filter CACHE_CATEGORY_CLONE filter

History

'output' appears in Netasq 9.0.0

'type' appears in Netasq 9.0.0



'global' appears in Netasq 9.0.0
Pagination appears in Netasq 9.0.0
level changes from filter to filter_read in Netasq 9.0.0

Description

List explicit rules.

Usage

```
index=<policy_idx> type={filter|nat} [output={plain|xml}] [global={0|1}] [useclone={0|1}]  
[start=<int> [limit=<int>] [dir={ASC|DESC}] [search=<pattern>] [searchfield=<token>]  
[sort=<token>] [refresh={0|1}]]
```

Format

list

CONFIG FILTER EXPORT

Level

filter_read CACHE_CATEGORY filter CACHE_CATEGORY_CLONE filter

History

Appears in 3.2

Description

Export filter and NAT rules.

Usage

```
index=<policy_idx> [delim=<character>] [global={0|1}]
```

Format

raw

Remark

Export filter and NAT rules to a CSV file.
By default, the csv separator is ','.

Example

```
config filter export index=10
```

CONFIG FILTER IMPLICIT

Level

filter_read

History

'output' appears in Netasq 9.0.0
level changes from filter to filter_read in Netasq 9.0.0

Description

List implicit rules.

Usage

```
[output={plain|xml}]
```

Format



list

CONFIG FILTER MANAGE

Level

filter,modify

History

plugin appears in Netasq 6.0.0
implicit appears in Netasq 6.0.0
fwdefault appears in Netasq 6.0.0
option authd_int for services appears in Netasq 6.0.0
option authd_ext for services appears in Netasq 6.0.0
option httpproxy for services appears in Netasq 6.0.0
option smtpproxy for services appears in Netasq 6.0.0
option pop3proxy for services appears in Netasq 6.0.0
option Xvpnd_int for services appears in Netasq 6.0.0
option Xvpnd_ext for services appears in Netasq 6.0.0
option authd for services deprecated in Netasq 6.0.0
option proxy for services deprecated in Netasq 6.0.0
option webserver for services deprecated in Netasq 7.0.0
option sshd for services Appears in Netasq 7.0.0
option httpproxy for services removed in Netasq 9.0.0
option smtpproxy for services removed in Netasq 9.0.0
option pop3proxy for services removed in Netasq 9.0.0
option ftpproxy for services removed in Netasq 9.0.0
option xvpnd_int for services removed in Netasq 9.0.0
option xvpnd_ext for services removed in Netasq 9.0.0
option webadmin for services appears in Netasq 9.0.0
checkroute appears in Netasq 9.1.0
option Bootps for services appears in 1.0.0
option SslVPN for services appears in 1.0.0
option Rtadv for services appears in 1.0.0
option DHCP6 for services appears in 1.0.0
ipstate appears in 1.0.0
plugin and fwdefault become optional in 1.0.0
checkroute deprecated in 2.0.0
option ipfix for services appears in 3.0.0
options authd_int and authd_ext for services merged into AuthPortal in 3.0.0

Description

Buildfilter configuration.

Usage

```
implicit={0|1} [plugin={0|1}] [fwdefault={0|1}] [ipstate={0|1}] [services=[authportal],[dns],  
[dialup],[ha],[ident],[pptp],[serverd],[sshd],[vpn],[webadmin],[bootps],[sslvpn],[rtadv],  
[dhcp6],[ipfix]]
```

Example

```
CONFIG FILTER MANAGE plugin=1 implicit=1 fwdefault=1 ipstate=1  
services=dialup,dns,ha,ident,pptp,serverd,sshd,vpn,authportal,webadmin,bootps,sslvpn
```



CONFIG FILTER RULE

Level

filter,globalfilter

History

Appears in Netasq 9.0.0

Description

Manage filter rules

CONFIG FILTER RULE ADDSEP

Level

filter,globalfilter,modify

History

Appears in Netasq 9.0.0 CACHE_CATEGORY_CLONE filter

Description

Add/update separator.

Usage

index=<policy_idx> type={filter|nat} color=<hex> comment=<string> collapse={0|1}
[position=<digit>] [default: end of list]
[global={0|1}] [default: 0]
[update={0|1}] [default: 0]

CONFIG FILTER RULE COLLAPSE

Level

filter,globalfilter,modify

History

Appears in Netasq 9.0.0 CACHE_CATEGORY_CLONE filter

Description

Collapse/uncollapse all separators

Usage

index=<policy_idx> type={filter|nat} action={all|none}
[global={0|1}] [default: 0]

CONFIG FILTER RULE COPY

Level

filter,globalfilter,modify

History

Appears in Netasq 9.0.0

name appears in 2.5.0 CACHE_CATEGORY_CLONE filter

Description

Copy one or several rules.

Usage



```
index=<policy idx> type={filter|nat} [ position=<line> | name=<string> ]  
[global={0|1}] [default: 0]  
[to=<rule id>] [default: end of list]  
[nb=<number of rules to copy>] [default: 1]
```

CONFIG FILTER RULE INSERT

Level

filter,globalfilter,modify

Format

section_line

History

Appears in Netasq 9.0.0 CACHE_CATEGORY_CLONE filter

Description

Insert a new rule before the rule with the given position.

Usage

```
index=<policy idx> type={filter|nat} state={on|off} action=  
[pass|block|deleg|reset|log|decrypt|nat]  
srctarget={any|<objectname>[,<objectname>[,...]]} dsttarget={any|<objectname>  
[,<objectname>[,...]]]  
[global={0|1}] [default: 0]  
[position=<digit>] [default: insert at the end of the rule list]  
[output={plain|xml}]  
And any rule tokens accepted by CONFIG FILTER RULE UPDATE.
```

CONFIG FILTER RULE MOVE

Level

filter,globalfilter,modify

History

Appears in Netasq 9.0.0
name appears in 2.5.0 CACHE_CATEGORY_CLONE filter

Description

Move one or several rule.

Usage

```
index=<policy idx> type={filter|nat} [ position=<line> | name=<string> ]  
[global={0|1}] [default: 0]  
[to=<rule id>] [default: end of list]  
[nb=<number of rules to move>] [default: 1]
```

CONFIG FILTER RULE REMOVE

Level

filter,globalfilter,modify

History

Appears in Netasq 9.0.0
name appears in 2.5.0 CACHE_CATEGORY_CLONE filter

Description



Remove one or all filter rules.

Usage

```
index=<policy idx> type={filter|nat} [ position={all|<digit> } | name=<string> ]
[global={0|1}] [default: 0]
```

CONFIG FILTER RULE UPDATE

Level

filter,globalfilter,modify

Format

section_line

History

Appears in Netasq 9.0.0

ipstate appears in Netasq 9.0.2

name appears in 2.5.0

srcgeo,dstgeo,srciprep,dstiprep,srchostrep,dsthostrep,srchostrepop,dsthostrepop appear in 3.0.0

enforceipsecfoward,enforceipsecreverse appear in 3.5.0

nohasync appears in 4.0.0

proxycache removed in 4.1.0 CACHE_CATEGORY_CLONE filter

Description

Update a filter rule.

Usage

```
index=<policy idx> type={filter|nat} [ position=<digit> | name=<string> ]
[output={plain|xml}] [default: plain]
[global={0|1}] [default: 0]
[state={on|off}]
[action={pass|block|deleg|reset|log|decrypt|nat}]
[loglevel={none|log|minor|major}]
[noconnlog={""|all|[disk],[syslog],[ipfix]]]
[count={on|off}]
[rate={""|<tcp>,<udp>,<icmp>,<sctp>,<request>}]
[synproxy={on|off}]
[settos={""|<1-254>}]
[qosid={""|<qid name>}]
[ackqosid={""|<qid name>}]
[qosfairness={""|state|user|host}]
[route={""|<objrouter>|<hostname>|<ipaddr>}]
[inspection={firewall|ids|ips}]
[antivirus={on|off}]
[sandboxing={on|off}]
[antispam={on|off}]
[ftpfiltering={on|off}]
[urlfiltering={""|<0-9>}] [URL policy index]
[mailfiltering={""|<0-9>}] [Mail policy index]
[sslfiltering={""|<0-9>}] [SSL policy index]
[fwservice={""|httpproxy|webportal}]
[webportalexcept={""|urlgroup[,urlgroup[,urlgroup[,...]]]}]
[inbound={""|sip_udp}]
[schedule={anytime|<time object>}]
[securityinspection={""|<0-9>}] [ASQ config index]
```



CONFIG FILTER SHOW

History



sshd config appears in Netasq 7.0.0
level changes from filter to filter_read in Netasq 9.0.0

Description

Dump buildfilter configuration.

Usage

[output=xml]

Returns

[Config]

Plugin=0|1

Implicit=0|1

FwDefault=0|1

Ipstate=0|1

[Services]

Pptp=0|1

HA=0|1

Vpn=0|1

Dns=0|1

Dialup=0|1

Ident=0|1

Serverd=0|1

Sshd=0|1

AuthPortal=0|1

WebAdmin=0|1

Bootps=0|1

SsIVPN=0|1

Rtadv=0|1

DHCP6=0|1

Ipfix=0|1

[Plugin]

DNS=0|1

FTP=0|1

HTTP=0|1

IMAP4=0|1

POP3=0|1

SMTP=0|1

SSH=0|1

Telnet=0|1

NNTP=0|1

SSL=0|1

[Global]

StrictUsers=0|1

CONFIG FWADMIN

Level

base

History



Appears in 3.3.0

Description

Commands to configure the centralized administration settings

CONFIG FWADMIN ACTIVATE**Level**

admin,modify

History

Will appear in 3.3.0

Description

Activate/cancel the centralized administration daemon settings

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG FWADMIN ACTIVATE

CONFIG FWADMIN CONTACT**Level**

base

History

Appears in 3.8.0

Description

Commands to configure the centralized administration contact addresses

CONFIG FWADMIN CONTACT ADD**Level**

admin,modify

History

Will appear in 3.8.0 bindaddr appears in 3.9.0

Description

Add a new fwadmin contact address

Usage

address=<address> [port=<port>] [bindaddr=<host>]

Returns

Error code

**Example**

```
CONFIG FWADMIN CONTACT ADD address="192.168.56.1" port=1754 bindaddr="Firewall_foo"  
CONFIG FWADMIN CONTACT ADD address="10.0.0.1"
```

CONFIG FWADMIN CONTACT LIST**Level**

base

History

Will appear in 3.8.0

Description

List all fwadmin contact addresses

Returns

Error code

Example

```
CONFIG FWADMIN CONTACT LIST
```

CONFIG FWADMIN CONTACT REMOVE**Level**

admin,modify

History

Will appear in 3.8.0

Description

Remove a fwadmin contact address given its index or all contacts at once

Usage

pos={<int>|all}

Returns

Error code

Example

```
CONFIG FWADMIN CONTACT REMOVE pos=1  
CONFIG FWADMIN CONTACT REMOVE pos=all
```

CONFIG FWADMIN UPDATE**Level**

admin,modify

History

Will appear in 3.3.0

Description

Configure the fwadmin daemon

Usage

BindAddr=[host|<empty string>]

**Returns**

Error code

Example

```
CONFIG FWADMIN bindaddr="foobar"  
CONFIG FWADMIN bindaddr=""
```

CONFIG GLOBAL**Level**

base

History

Appears in Netasq 6.0.0

Description

Global configuration

CONFIG GLOBAL OBJECT**Level**

base

History

Appears in Netasq 6.0.0

Description

Global object administration

Remark

most of the code is shared with CONFIG.OBJECT

Invalid name for objects are:

Firewall_*

Network_*

broadcast

anonymous

any

object commands update object configuration files and serverd memory structure

CONFIG GLOBAL OBJECT EXPORT**Level**

globalobject

History

Appears in 3.0.0

router type appears in 4.3.0 time type appears in 4.3.0

Format

raw

Description



Export global objects into a CSV file

Usage

type=<all|[,host|[,range|[,network|[,protocol|[,service|[,group|[,servicegroup|[,router|[,time|[,fqdn]>

Remark

Export only global objects to CSV file
this command returns an error code if :
No global object is found.

Example

config global object export type=host

CONFIG GLOBAL OBJECT FQDN**Level**

base

History

Appears in 3.0.0

Description

Fqdn object administration

Remark**CONFIG GLOBAL OBJECT FQDN CHECK****Level**

object

History

Appears in 3.0.0

Description

Check fqdn object

Usage

name=<fqdn>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG GLOBAL OBJECT FQDN CHECK name=fqdn.com
[Configuration]
module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT FQDN DELETE**Level**

object,modify

**History**

Appears in 3.0.0

Description

Remove fqdn object

Usage

name=<fqdn> [force=1]

Remark

this command returns a warning code if specified object does not exist

Example

CONFIG GLOBAL OBJECT FQDN DELETE name=fqdn.com CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT FQDN NEW**Level**

object,modify

History

Appears in 3.0.0

Description

Add fqdn object

Usage

name=<fqdn> [ip=<ipaddress>] [ipv6=<ipv6address>] [localfirst=0|1] [color=xxxxxx]
[comment=<comment>] [update=<0|1|2>]

At least one ip (v4 or v6) must be specified

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

CONFIG GLOBAL OBJECT FQDN NEW name=fqdn.com ipv4=10.0.0.1 comment="IPv4 only fqdn"
CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT FQDN SHOW**Level**

base

History

Appears in 3.0.0

Description

Show one object fqdn

Usage

name=<fqdn> [start=<int>] [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<fqdnname>]
ip="1.2.3.4" ipv6="b1a::b1a"

**Format**

section_line

Example

```
CONFIG GLOBAL OBJECT FQDN SHOW name=fqdn.com
[fqdn.com]
ip="216.58.211.100"
ip="216.58.208.196"
ipv6="b1a::b1a"
ipv6="b1a::b1a:b1a" CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT GEOGROUP**Level**

base

History

Appears in 3.0.0

Description

Global geogroups category administration

Remark**CONFIG GLOBAL OBJECT GEOGROUP ADDTO****Level**

object,modify

History

Appears in 3.0.0

Description

Add geo object to global geo group

Usage

```
group=<geogroup name> node=<node to add name> [update=<0|1|2>]
```

Remark

node must be a geo object

this comment returns an error if:

"group" or "node" don't exist

"node" is an object already included in "group" (no error if update>0)

Example

```
CONFIG GLOBAL OBJECT GEOGROUP ADDTO group=geogroup1 node=geo1 CACHE_CATEGORY
objects
```

CONFIG GLOBAL OBJECT GEOGROUP CHECK**Level**

object

History

Appears in 3.0.0

Description



Check global geo group

Usage

name=<geogroupname>

Returns

[Configuration]

module=<string> [slot=00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG GLOBAL OBJECT GEOGROUP CHECK name=geogroup1

[Configuration]

module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT GEOGROUP DELETE**Level**

object,modify

History

Appears in 3.0.0

Description

Remove a global geo group

Usage

name=<geogroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

CONFIG GLOBAL OBJECT GEOGROUP DELETE name=geogroup1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT GEOGROUP NEW**Level**

object,modify

History

Appears in 3.0.0

Description

Create new global empty geo group category

Usage

name=<geogroupname> [comment=<geogroup comment>] [update=<0|1>]

Remark

returns an error if a geo group with identical name exists

Example

CONFIG GLOBAL OBJECT GEOGROUP NEW name=geogroup1 CACHE_CATEGORY objects

**CONFIG GLOBAL OBJECT GEOGROUP REMOVEFROM****Level**

object,modify

History

Appears in 3.0.0

Description

Remove geo object from global geo group

Usage

group=<geogroup name> node=<node to remove name>

Remark

node must be a geo object
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

CONFIG GLOBAL OBJECT GEOGROUP REMOVEFROM group=geogroup1 node=geo1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT GEOGROUP SHOW**Level**

base

History

Appears in 3.0.0

Description

Show global geo group

Usage

name=<geogroupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<geogroup name>]
name=<nodename>
...

Format

section_line

Example

CONFIG GLOBAL OBJECT GEOGROUP SHOW name=eu6
[eu6]
name=eu:de
name=eu:lu
name=eu:be
name=eu:nl
name=eu:it
name=eu:fr
CACHE_CATEGORY objects



CONFIG GLOBAL OBJECT GET

Level

base

History

Appears in Netasq 9.0.0

fqdn appears in 3.0.0

Description

Return a unique global object from its name

Usage

type=<host|range|fqdn|network|group|protocol|time|service|servicegroup> name=<objname>

Returns

Return one line with the global object properties:

[Object]

type=host modify=<0|1> global=<0|1> comment=<comment> name=<hostname> ip=<ip>

ipv6=<ipv6> resolve=<static|dynamic>

type=range modify=<0|1> global=<0|1> comment=<comment> name=<rangename>

begin=<firstip> end=<lastip> beginv6=<firstipv6> endv6=<lastipv6>

type=network modify=<0|1> global=<0|1> comment=<comment> name=<rangename>

ip=<ip> mask=<netmask> prefixlen=<ipv4 prefix len> ipv6=<ipv6> prefixlenv6=<ipv6 prefix len>

type=protocol modify=<0|1> global=<0|1> comment=<comment> name=<protocolname>

protonumber=<ip protocol number>

type=service modify=<0|1> global=<0|1> comment=<comment> name=<servicename>

port=<port> toport=<""|lastport> proto=<protocolname>

type=time modify=<0|1> global=<0|1> comment=<comment> name=<timename>

time=<time> weekday=<weekdays> yearday=<yearday> date=<date>

type=group modify=<0|1> global=<0|1> comment=<comment> name=<groupname>

type=servicegroup modify=<0|1> global=<0|1> comment=<comment> name=<groupname>

...

Format

section_line

Example

config global object get type=host name=mycomputer

[Object]

type=host modify=1 global=1 comment="" name=mycomputer ip=10.0.0.0 ipv6=fe80::1

resolve=static

CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT GROUP

Level

base

History

Appears in Netasq 6.0.0

Description

Global object groups administration

Remark



most of the code is shared with CONFIG.GLOBAL.OBJECT.SERVICEGROUP

CONFIG GLOBAL OBJECT GROUP ADDTO

Level

globalobject,modify

History

Appears in Netasq 6.0.0

added position arg in Netasq 9.0.0

added update arg in 2.4.0

Description

Add object to global group

Usage

group=<groupname> node=<node to add name> [pos=<position>] [update=<0|1|2>]

Remark

node might be an object or a group

this command returns an error if:

"group" or "node" don't exist

"node" is an object already included in "group" (no error if update>0)

"node" is an object included in a subgroup of "group"

"node" is a group and contains common element(s) with "group"

"node" is a group and contains an other group which contains "group"(it creates a loop)

"node" is a group and contains an other group which has common element(s) with "group" or another node

Example

CONFIG GLOBAL OBJECT GROUP ADDTO group=group1 node=host1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT GROUP CHECK

Level

globalobject

History

Appears in Netasq 6.1.0

level globalobject Appears in Netasq 6.1.3

level object deprecated in Netasq 6.1.3

Format Appears in Netasq 9.0.0

Description

Check global object group

Usage

name=<group name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>

section=<string>]

Format

section_line

Example



CONFIG GLOBAL OBJECT GROUP CHECK name=group1
[Configuration]
module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT GROUP DELETE

Level

globalobject,modify

History

force Appears in Netasq 6.1.0

Description

Delete global object group

Usage

name=<groupname> [force=1]

Remark

returns an error if no group with this name exists

Example

CONFIG GLOBAL OBJECT GROUP DELETE name=group1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT GROUP NEW

Level

globalobject,modify

History

Appears in Netasq 6.0.0

Description

Create new empty object group

Usage

name=<groupname> [comment=<group comment>] [update=<0|1>]

Remark

returns an error if a group with identical name exists

Example

CONFIG GLOBAL OBJECT GROUP NEW name=group1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT GROUP REMOVEFROM

Level

globalobject,modify

History

Appears in Netasq 6.0.0

Description

Remove global object from group

Usage

group=<groupname> node=<node to remove name>

Remark



node might be an object or a group
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

```
CONFIG GLOBAL OBJECT GROUP REMOVEFROM group=group1 node=host1 CACHE_CATEGORY  
objects
```

CONFIG GLOBAL OBJECT GROUP SHOW**Level**

base

History

Appears in Netasq 6.0.0
Format Appears in Netasq 9.0.0
all disappears in Netasq 9.0.0

Description

Show one object group

Usage

```
name=<groupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]  
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]
```

Returns

```
[<groupname>]  
name=<nodename>...
```

Format

section_line

Example

```
CONFIG GLOBAL OBJECT GROUP SHOW name=group1  
[group1]  
name=host1 CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT HOST**Level**

base

History

Appears in Netasq 6.0.0

Description

Global host object administration

CONFIG GLOBAL OBJECT HOST CHECK**Level**

globalobject

History

Appears in Netasq 6.1.0
level globalobject Appears in Netasq 6.1.3



level object deprecated in Netasq 6.1.3
Format Appears in Netasq 9.0.0

Description

Check global host object

Usage

name=<hostname>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG GLOBAL OBJECT HOST CHECK name=host1

[Configuration]

module=DNS section=Servers

module=Filter slot=04 line=1

module=DHCP section=Server

CONFIG GLOBAL OBJECT HOST DELETE**Level**

globalobject,modify

History

force Appears in Netasq 6.1.0

Description

Remove global host object

Usage

name=<hostname> [force=1]

Remark

this command returns an error code if object is in a group

this command returns a warning code if specified object does not exist

Example

CONFIG GLOBAL OBJECT HOST DELETE name=host1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT HOST NEW**Level**

globalobject,modify

History

Appears in Netasq 6.0.0

Description

Add global host object

Usage



```

name=<hostname> [ip=<ipaddress>] [ipv6=<ipv6address>] [type=router|server|host]
[resolve=static|dynamic|manual] [mac=xx:xx:xx:xx:xx:xx] [color=xxxxxx] [localfirst=0|1]
[comment=<comment>] [update=<0|1|2>]
name=<rangename> [begin=<range first ip> end=<range last ip>] [beginv6=<range first ipv6>
endv6=<range last ipv6>] [color=xxxxxx] [localfirst=0|1] [comment=<comment>]
[update=<0|1|2>]

```

For single host at least one ip (v4 or v6) must be specified

For range at least one begin and end (v4 or v6) must be specified

Remark

Without update parameter, command will return an error if an object with the same name exists.

With update=2, modules which use the object are not reloaded.

Example

```

CONFIG GLOBAL OBJECT HOST NEW name=host4 ip=10.0.0.1 resolve=static comment="Global
IPv4 only host" mac=11:22:33:44:55:66
CONFIG GLOBAL OBJECT HOST NEW name=host6 ipv6=fe80::1 resolve=static comment="Global
IPv6 only host"
CONFIG GLOBAL OBJECT HOST NEW name=host46 ip=10.0.0.1 ipv6=fe80::1 resolve=static
comment="Global IPv4v6 host"
CONFIG GLOBAL OBJECT HOST NEW name=range4 begin=10.0.0.1 end=10.0.0.10
comment="Global IPv4 only range"
CONFIG GLOBAL OBJECT HOST NEW name=range6 beginv6=fe80::1 endv6=fe80::10
comment="Global IPv6 only range"
CONFIG GLOBAL OBJECT HOST NEW name=range46 begin=10.0.0.1 end=10.0.0.10
beginv6=fe80::1 endv6=fe80::10 comment="Global IPv4v6 range" CACHE_CATEGORY objects

```

CONFIG GLOBAL OBJECT IMPORT

Level

globalobject, modify

History

Appears in 3.0.0

Description

Global objects import functions

CONFIG GLOBAL OBJECT IMPORT ACTIVATE

Level

globalobject, modify

History

Appears in 3.0.0

Description

Import global objects from CSV uploaded

Remark

Import objects from CSV file

this command returns an error code if :

At least one object can't be imported

There are too many global objects to import.

Example



config global object import activate

CONFIG GLOBAL OBJECT IMPORT CANCEL

Level

globalobject, modify

History

Appears in 3.0.0

Description

Cancel current global import process

Remark

Called by user action or end of session.

Example

config global object import cancel

CONFIG GLOBAL OBJECT IMPORT STATUS

Level

base

History

Appears in 3.0.0

Description

Show the status of the last import

Example

config object import status

CONFIG GLOBAL OBJECT IMPORT UPLOAD

Level

globalobject, modify

History

Appears in 3.0.0

Description

Upload CSV file in order to import global objects

Remark

Has to be followed by config global object import activate.

Example

config global object import upload

CONFIG GLOBAL OBJECT IPREPGROUP

Level

base

History

Appears in 3.0.0

Description



Global iprepgroups category administration

Remark

CONFIG GLOBAL OBJECT IPREPGROUP ADDTO

Level

object,modify

History

Appears in 3.0.0

Description

Add iprep object to global iprep group

Usage

group=<iprepgroup name> node=<node to add name> [update=<0|1|2>]

Remark

node must be a iprep object

this comment returns an error if:

"group" or "node" don't exist

"node" is an object already included in "group" (no error if update>0)

Example

```
CONFIG GLOBAL OBJECT IPREPGROUP ADDTO group=iprepgroup1 node=iprep1 CACHE_CATEGORY
objects
```

CONFIG GLOBAL OBJECT IPREPGROUP CHECK

Level

object

History

Appears in 3.0.0

Description

Check global iprep group

Usage

name=<iprepgroupname>

Returns

[Configuration]

module=<string> (slot=00-10> line=<int>| section=<string>|profile=<00-03>

section=<string>]

Format

section_line

Example

```
CONFIG GLOBAL OBJECT IPREPGROUP CHECK name=iprepgroup1
```

[Configuration]

module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT IPREPGROUP DELETE

Level

object,modify

**History**

Appears in 3.0.0

Description

Remove a global iprep group

Usage

name=<iprepgroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

CONFIG GLOBAL OBJECT IPREPGROUP DELETE name=iprepgroup1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT IPREPGROUP NEW**Level**

object,modify

History

Appears in 3.0.0

Description

Create new global empty iprep group category

Usage

name=<iprepgroupname> [comment=<iprepgroup comment>] [update=<0|1>]

Remark

returns an error if a iprep group with identical name exists

Example

CONFIG GLOBAL OBJECT IPREPGROUP NEW name=iprepgroup1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT IPREPGROUP REMOVEFROM**Level**

object,modify

History

Appears in 3.0.0

Description

Remove iprep object from global iprep group

Usage

group=<iprepgroup name> node=<node to remove name>

Remark

node must be an iprep object
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example



CONFIG GLOBAL OBJECT IPREPGROUP REMOVEFROM group=iprepgroup1 node=iprep1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT IPREPGROUP SHOW

Level

base

History

Appears in 3.0.0

Description

Show global iprep group

Usage

name=<iprepgroupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>] [searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<iprepgroup name>]
name=<nodename>
...

Format

section_line

Example

CONFIG GLOBAL OBJECT IPREPGROUP SHOW name=bad
[bad]
name=malware
name=botnet
name=spam
name=scanner
CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT NETWORK

Level

base

History

Appears in Netasq 6.0.0

Description

Global network object administration

CONFIG GLOBAL OBJECT NETWORK CHECK

Level

globalobject

History

Appears in Netasq 6.1.0
level globalobject Appears in Netasq 6.1.3
level object deprecated in Netasq 6.1.3
Format Appears in Netasq 9.0.0

Description



Check global network object

Usage

name=<network name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG GLOBAL OBJECT NETWORK CHECK name=network1

[Configuration]

module=DNS section=Clients

module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT NETWORK DELETE**Level**

globalobject,modify

History

force Appears in Netasq 6.1.0

Description

Remove global network object

Usage

name=<netname> [force=1]

Remark

this command returns an error code if object is in a group

this command returns a warning code if specified object does not exist

Example

CONFIG GLOBAL OBJECT NET DELETE name=net1 CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT NETWORK NEW**Level**

globalobject,modify

History

Appears in Netasq 6.0.0

Description

Add global network object

Usage

name=<netname> [ip=<network IPV4 address> mask=<netmask>|prefixlen=<prefixlen>]
[ipv6=<network IPv6 address> prefixlenv6=<prefixlen>] [localfirst=0|1] [color=xxxxxx]
[comment=<comment>] [update=<0|1|2>]

Remark

At least one ip (v4 or v6) must be specified

without update parameter, command will return an error if an object with the same name



exists.

0.0.0.0 and 255.255.255.255 IPv4 netmasks are not allowed

/0 and /32 IPv4 prefix len are not allowed

/0 and /128 IPv6 prefix len are not allowed

With update=2, modules which use the object are not reloaded.

Example

```
CONFIG GLOBAL OBJECT NETWORK NEW name=net0 ip=10.0.0.0 prefixlen=16 localfirst=1
```

```
comment="Global IPv4 only network"
```

```
CONFIG GLOBAL OBJECT NETWORK NEW name=net1 ip=10.0.0.0 mask=255.0.0.0 localfirst=1
```

```
comment="Global IPv4 only network"
```

```
CONFIG GLOBAL OBJECT NETWORK NEW name=net2 ipv6=fe80:: prefixlen6=64 localfirst=1
```

```
comment="Global IPv6 only network"
```

```
CONFIG GLOBAL OBJECT NETWORK NEW name=net3 ip=10.0.0.0 mask=255.0.0.0 ipv6=fe80::  
prefixlen6=64 localfirst=1 comment="Global IPv4v6 network" CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT PROTOCOL

Level

base

History

Appears in Netasq 6.0.0

Description

Global protocol object administration

Remark

most of the code is shared with CONFIG.GLOBAL.OBJECT.NETWORK and CONFIG OBJECT.HOST

CONFIG GLOBAL OBJECT PROTOCOL CHECK

Level

globalobject

History

Appears in Netasq 6.1.0

level globalobject Appears in Netasq 6.1.3

level object deprecated in Netasq 6.1.3

Format Appears in Netasq 9.0.0

Description

Check global protocol object

Usage

name=<protocol name>

Returns

[Configuration]

module=<string> (slot=<00-10> line=<int>| section=<string>|profile=<00-03>

section=<string>)

Format

section_line

Example



```
CONFIG GLOBAL OBJECT PROTOCOL CHECK name=proto1  
[Configuration]  
module=Filter slot=04 line=1
```

CONFIG GLOBAL OBJECT PROTOCOL DELETE

Level

globalobject,modify

History

force Appears in Netasq 6.1.0

Description

Delete global protocol object

Usage

name=<protocolname> [force=1]

Remark

this command returns an error code if object is in a group

this command returns a warning code if specified object does not exist

Example

```
CONFIG GLOBAL OBJECT PROTOCOL DELETE name=chaos CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT PROTOCOL NEW

Level

globalobject,modify

History

Appears in Netasq 6.0.0

value replaced by protonumber in Netasq 9.0.0

Description

Add global protocol object

Usage

name=<protocolname> protonumber=<IP protocol number> [color=xxxxxx]
[comment=<comment>] [update=<0|1|2>]

Remark

Without update parameter, command will return an error if an object with the same name exists.

With update=2, modules which use the object are not reloaded.

Example

```
CONFIG GLOBAL OBJECT PROTOCOL NEW name=chaos protonumber=16 color=123456  
comment="CHAOS protocol" CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT RENAME

Level

globalobject,modify

History

Appears in Netasq 9.0.0

Description



Rename global objects

Usage

type=<host|range|network|service|time|group|servicegroup> oldname=<old_objname>
newname=<new_objname>

Remark

rename all the occurrences of old_objname to new_objname in the configuration files
this command returns an error code if :
old_objname is not found.
new_objname already exists.

Example

config global object rename type=host oldname=foo newname=bar CACHE_CATEGORY
objects,filter CACHE_CATEGORY_CLONE objects,filter

CONFIG GLOBAL OBJECT ROUTER**Level**

base

History

Appears in 3.1.0

Description

Global Router object administration

CONFIG GLOBAL OBJECT ROUTER CHECK**Level**

object

History

Appears in 3.1.0

Description

Check where a global router object is used

Usage

name=<router name>

Returns

[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>]

Format

section_line

Example

CONFIG GLOBAL OBJECT ROUTER CHECK name=myrouter
[Configuration]
module=Filter slot=04 line=1
module=Route section=DefaultRoute

CONFIG GLOBAL OBJECT ROUTER DELETE**Level**

object,modify

**History**

Appears in 3.1.0

Description

Remove global router object

Usage

name=<name> [force=1]

Remark

this command returns a warning code if specified object does not exist

Example

CONFIG GLOBAL OBJECT ROUTER delete name=myrouter CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT ROUTER GATEWAY**Level**

base

History

Appears in 3.1.0

Description

Command to manage global router object gateways

CONFIG GLOBAL OBJECT ROUTER GATEWAY ADD**Level**

object,modify

History

Appears in 3.1.0

Description

Add a new gateway (principal or backup) to a global router object

Usage

name=<routername> type=<principalgateway|backupgateway> host=<host>
[check=<host|group>] [pos=<position> (0 or default: end of list)] [weight=<int>]
[monitor=<all|none|icmp>] [comment=<comment>]

Returns

Error Code

Example

CONFIG GLOBAL OBJECT ROUTER GATEWAY ADD name=my_router host=my_gw
Type=principalgateway check=host_behind_my_gw

CONFIG GLOBAL OBJECT ROUTER GATEWAY MOVE**Level**

object,modify

History

Appears in 3.1.0

Description



Move a gateway (principal or backup) in a global router object

Usage

name=<routername> type=(principalgateway|backupgateway) pos=<int> offset=<+/-num>

Returns

Error Code

Example

```
CONFIG GLOBAL OBJECT ROUTER GATEWAY MOVE name=my_router type=principalgateway pos=1  
offset=+1
```

CONFIG GLOBAL OBJECT ROUTER GATEWAY REMOVE**Level**

object,modify

History

Appears in 3.1.0

Description

Remove one or all gateway(s) (principal or backup) from a global router object

Usage

name=<routername> type=(principalgateway|backupgateway) (pos=(<int>|all) | host=
<gateway name|any>))

Returns

Error Code

Example

```
CONFIG GLOBAL OBJECT ROUTER GATEWAY REMOVE name=my_router type=principalgateway  
pos=all  
CONFIG GLOBAL OBJECT ROUTER GATEWAY REMOVE name=my_router type=principalgateway  
host=MyGatewayHost
```

CONFIG GLOBAL OBJECT ROUTER GATEWAY UPDATE**Level**

object,modify

History

Appears in 3.1.0

Description

Update a gateway (principal or backup) from a global router object

Usage

name=<routername> type=<principalgateway|backupgateway> pos=<position> [host=<host>]
[check=<host|group>] [weight=<int>] [monitor=<all|none|icmp>] [httpMethod=<GET|HEAD>]
[comment=<comment>]

Returns

Error Code

Example

```
CONFIG GLOBAL OBJECT ROUTER GATEWAY UPDATE name=my_router type=principalgateway  
pos=3 check=host_behind_my_gw
```

**CONFIG GLOBAL OBJECT ROUTER NEW****Level**

object,modify

History

Appears in 3.1.0

monitor appears in 4.3.0

triesup appears in 4.3.0

slause appears in 4.3.0

slajitter appears in 4.3.0

slalency appears in 4.3.0

slalossrate appears in 4.3.0

slaunreachablerate appears in 4.3.0

Description

Add global router object

Usage**Remark**

name=<router name> [monitor=<icmp|tcp_probe>] [port=<service_name>]
[comment=<comment>] [tries=<int>] [triesup=<int>] [wait=<seconds>]
[frequency=<seconds>] [gatewaythreshold=<int>] [activateallbackup={on|off}]
[loadbalancing=<none|conhash|srchash>] [onfailpolicy={pass|block}] [slause=<0|1>]
[slajitter=<milliseconds>] [slalency=<milliseconds>] [slalossrate=<float>]
[slaunreachablerate=<int>] [update=<0|1|2>] With update=2, modules which use the object
are not reloaded.

When load balancing is enabled, if there are less than GatewayThreshold principals active,
backups will be used

Gatewaythreshold=0 means to use backups when at least one principal is down

Gatewaythreshold=1 means to use backups when all principals are down

Example

CONFIG GLOBAL OBJECT ROUTER NEW name=myrouter comment="My router object"
gatewaythreshold=1 tries=3 triesup=0 wait=2 frequency=15 loadbalancing=none
onfailpolicy=pass CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT ROUTER SHOW**Level**

base

History

Appears in 3.1.0

Description

Show a global router object

Usage

name=<router name>

Format

section_line

Example



```
CONFIG GLOBAL OBJECT ROUTER SHOW name=myrouter
[Config]
name=myrouter
comment="nice comment"
gatewaythreshold=1
activateallbackup=0
frequency=15
tries=3
triesup=0
wait=2
loadbalancing=connhash
onfailpolicy=Pass
slause=0
slatency=
slajitter=
slalossrate=
slaunreachablerate=

[PrincipalGateway]
pos=1 host=host1 check=www.google.com comment="First router"
pos=2 host=host2 check=www.google.com comment="Second router"
pos=2 host=Global_host1 check=www.google.com comment="Global router"

[BackupGateway]
pos=1 host=host3 check=www.google.com comment=""
```

CONFIG GLOBAL OBJECT SERVICE

Level

base

History

Appears in Netasq 6.0.0

Description

Global service object administration

Remark

most of the code is shared with CONFIG.GLOBAL.OBJECT.NETWORK and CONFIG OBJECT.HOST

CONFIG GLOBAL OBJECT SERVICE CHECK

Level

globalobject

History

Appears in Netasq 6.1.0

level globalobject Appears in Netasq 6.1.3

level object deprecated in Netasq 6.1.3

Format Appears in Netasq 9.0.0

Description

Check global service object

Usage

name=<service name>

**Returns**

[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG GLOBAL OBJECT SERVICE CHECK name=service1
[Configuration]
module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT SERVICE DELETE**Level**

globalobject,modify

History

force Appears in Netasq 6.1.0

Description

Delete global service object

Usage

name=<servicename> [force=1]

Remark

this command returns an error code if object is in a group
this command returns a warning code if specified object does not exist

Example

CONFIG GLOBAL OBJECT SERVICE DELETE name=dns CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT SERVICE NEW**Level**

globalobject,modify

History

Appears in Netasq 6.0.0
Removed plugin attribute in Netasq 9.0.0

Description

Add global service object

Usage

name=<servicename> port=<port number> proto=<tcp|udp|any> [toport=<porthigh>]
[color=xxxxxx] [comment=<comment>] [update=<0|1|2>]

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

CONFIG GLOBAL OBJECT SERVICE NEW name=dns port=53 proto=tcp comment="DNS service"
CACHE_CATEGORY objects



CONFIG GLOBAL OBJECT SERVICEGROUP

Level

base

History

Appears in Netasq 6.0.0

Description

Global service groups administration

Remark

most of the code is shared with CONFIG.GLOBAL.OBJECT.OBJECTGROUP

CONFIG GLOBAL OBJECT SERVICEGROUP ADDTO

Level

globalobject,modify

History

Appears in Netasq 6.0.0

arg Update appears in 2.4.0

Description

Add service object to global service group

Usage

group=<servicegroup name> node=<node to add name> [update=<0|1|2>]

Remark

node must be a service

this command returns an error if:

"group" or "node" don't exist

"node" is an object already included in "group" (no error if update>0)

Example

CONFIG OBJECT SERVICEGROUP ADDTO group=group1 node=dns CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT SERVICEGROUP CHECK

Level

globalobject

History

Appears in Netasq 6.1.0

level globalobject Appears in Netasq 6.1.3

level object deprecated in Netasq 6.1.3

Format Appears in Netasq 9.0.0

Description

Check global service group

Usage

name=<service group name>

Returns



```
[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]
```

Format

section_line

Example

```
CONFIG GLOBAL OBJECT SERVICEGROUP CHECK name=servicegroup1
[Configuration]
module=Filter slot=04 line=1
```

CONFIG GLOBAL OBJECT SERVICEGROUP DELETE**Level**

globalobject,modify

History

force Appears in Netasq 6.1.0

Description

Remove service group

Usage

name=<servicegroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

```
CONFIG GLOBAL OBJECT SERVICEGROUP DELETE name=servicegroup1 CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT SERVICEGROUP NEW**Level**

globalobject,modify

History

Appears in Netasq 6.0.0

Description

Create new empty global service group

Usage

name=<servicegroupname> [comment=<servicegroup comment>] [update=<0|1>]

Remark

returns an error if a service group with identical name exists

Example

```
CONFIG GLOBAL OBJECT SERVICEGROUP NEW name=servicegroup1 CACHE_CATEGORY objects
```

CONFIG GLOBAL OBJECT SERVICEGROUP REMOVEFROM**Level**

globalobject,modify

History

Appears in Netasq 6.0.0

**Description**

Remove service object from global service group

Usage

group=<servicegroup name> node=<node to remove name>

Remark

node must be a service

this command returns an error if :

"group" or "node" don't exist

"node" is not in "group"

Example

CONFIG OBJECT GLOBAL SERVICEGROUP REMOVEFROM group=servicegroup1 node=dns CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT SERVICEGROUP SHOW**Level**

base

History

Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0

all disappears in Netasq 9.0.0

Description

Show global service group

Usage

name=<servicegroup name> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<servicegroup name>]

name=<nodename>...

Format

section_line

Example

CONFIG GLOBAL OBJECT SERVICEGROUP SHOW name=web

[web]

name=dns_udp

name=http

name=https

CONFIG GLOBAL OBJECT TIME**Level**

base

History

Appears in Netasq 9.0.0

Description

Global Time object administration

**CONFIG GLOBAL OBJECT TIME CHECK****Level**

globalobject

History

Appears in Netasq 9.0.0

Description

Check global time object

Usage

name=<timeobject name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]**Format**

section_line

Example

config global object host check name=daysoff

[Configuration]

module=Filter slot=04 line=1

CONFIG GLOBAL OBJECT TIME DELETE**Level**

globalobject,modify

History

Appears in Netasq 9.0.0

Description

Remove global time object

Usage

name=<timeobject name> [force=1]

Remark

this command returns a warning code if specified object does not exist

Example

config global object host delete name=daysoff CACHE_CATEGORY objects

CONFIG GLOBAL OBJECT TIME NEW**Level**

globalobject,modify

History

Appears in Netasq 9.0.0

Description

Add a global time object

Usage



```
name=<timeobject name> time=["|hh:mm-hh:mm[;hh:mm-hh:mm]..." weekday=["|dow[-dow]
[-dow[-dow]]..." yearday=["|mm:dd[-mm:dd][;mm:dd[-mm:dd]]..." date=["|yyyy:mm:dd
[:hh:mm][-yyyy:mm:dd[:hh:mm]]] [color=xxxxxx] [comment=<comment>] [update=<0|1|2>]
```

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

```
config global object time new name=work time=08:00-12:00;14:00-19:00 weekday=1;3;5-7
comment="working hours"
config global object time new name=daysoff
yearday=01:01;05:01;05:08;07:14;08:15;11:11;12:25 CACHE_CATEGORY objects
```

CONFIG HA

Level

base

Description

Configure HA functions

CONFIG HA ACTIVATE

Level

maintenance,modify

Description

Activate HA configuration

Returns

Error code

Remark

May start a full config file sync in order to apply changes also on peers at the same time

Example

```
CONFIG HA ACTIVATE
```

CONFIG HA CREATE

Level

maintenance,modify

History

sendarp Appears in Netasq 9.0.0
interfaceslipflop appears in Netasq 9.0.1
tokentimeout appears in 9.0.4
MulticastAddr appears in 2.0.0
LACPWhenPassive appears in 2.6.0
ConnOlderThan appears in 3.2.0
SynchronizationDelay appears in 3.5.0
DelayConnUpd replaces ConnOlderThan in 4.0.0



LACPMembersHaveWeight appears in 3.10.0
FailoverMembersHaveWeight appears in 4.3.0

Description

Initialize an HA cluster

Usage

```
password=<ha password> ifname=<interface user name> [ifname2=<interface user name>]  
[priority=<0-9999>]  
[waitingpeertimeout=<0-9999>] [SynchronizationDelay=<0-9999>] [purgearp=<0|1>]  
[sendarp=<0|1>]  
[sendarpperiod=<1-9999>] [secure=<0|1>] [nbping=<0-300>]  
[interfacesflipflop=<0-20000>] [tokentimeout=<1-99999>] [MulticastAddr=<multicast IPv4>]  
[LACPWhenPassive=<0|1>] [DelayConnUpd=<integer>] [LACPMembersHaveWeight=<0|1>]  
[FailoverMembersHaveWeight=<0|1>]
```

Returns

Error code

Remark

Interfaces are expected to be ethernet or vlan interfaces.

Argument "peer_waiting_timeout" indicates how long each firewall must wait at boot before considering their peer as offline. is given in seconds.
Default value for "peer_waiting_timeout" is 10s.

Argument "purge_arp" indicates if the ARP table must be purged when the firewall becomes active (default is 0).

send_arp and send_arp_period defines if an ARP packet must be send periodically by the active firewall as a reminder for other machines (default: 0, default period: 5s).

If secure is set to 1, connections sync packets will be encrypted. However you may experience reduced performances (default is 0)

nbping indicates how many ICMP requests must be sent once Corosync consider the peer to be dead. This is used to confirm that the Corosync notification wasn't a false-positive due to an overload on the peer. ICMP requests are sent with an interval of 50ms. Set this value to 0 to disable the confirmation mechanism.

interfacesflipflop indicates how long, in milliseconds, non-HA interfaces must go down when the firewall becomes passive. This is intended to reduce issues with the ARP tables of switches during user-requested HA swaps when using a bridged network configuration. Bringing non-HA interfaces down should force the switches to flush their ARP tables. This approach does not work with all switches. (default is 1000, 0 to disable)

tokentimeout indicates how long Corosync must wait when it doesn't get any message from the peer(s). Once this delay is passed, Corosync will notify Stated. Stated will then try to ping the peer. If Stated doesn't get any reply either, the local firewall will become active.

MulticastAddr indicates the multicast address used for Corosync communication between firewalls

LACPWhenPassive indicates if the passive firewall should take part to the lacp negotiation or re-negotiate lacp when swap happens.

DelayConnUpd indicates that connections living less than this value (in seconds) won't be synchronized.

LACPMembersHaveWeight indicates if the LACP members are included in the quality



computation.

FailoverMembersHaveWeight indicates if the Failover members are included in the quality computation.

Example

```
CONFIG HA CREATE password=password ifname=vlan0
```

CONFIG HA JOIN**Level**

maintenance,modify

History

Command appears in Netasq 9.0.0

Description

Make the firewall joins an existing HA cluster

Usage

```
password=<ha password> ip=<ip master> [priority=<0-9999>]
```

Returns

Error code

Example

```
CONFIG HA JOIN password=password ip=192.168.0.1
```

CONFIG HA SHOW**Level**

base

Description

Display firewall HA configuration

Returns

[Global]

State=0|1 : Is HA activated?

Initialized=0|1 : HA initialization

SendARP=0|1 : SendARP state

SendARPPeriod=<sec> : delay {sec} between 2 ARPs

Secure=0|1 : Crypto state on the HA link

InterfacesFlipFlop=<0-20000> : How long, in milliseconds, non-HA interfaces must go down when the firewall becomes passive (0=disabled)

LACPWhenPassive=1 : Maintain LACP negotiations while being passive

DelayConnUpd=10 : Connections living less than this value (in seconds) won't be synchronized

LACPMembersHaveWeight=1 : Include LACP members in quality computation

FailoverMembersHaveWeight=1 : Include Failover members in quality computation

[Communication]

ifname=<interf> : HA interface

ifname2=<interf> : HA backup interface

[ICMP]



NbPing=(0-300) : Number of death confirmation pings
[Corosync]
TokenTimeout=2000 : Timeout for peer loss detection by Corosync (in milliseconds)
MulticastAddr=226.94.1.1 : Multicast address used for Corosync communication between
firewalls

Example

CONFIG HA SHOW

CONFIG HA STATE

Level

base

Description

Get/set firewall HA state

Usage

[on|off]

Returns

Error code

Remark

Changing state need Ha or Maintenance and Modify levels

Example

CONFIG HA STATE on

CONFIG HA UPDATE

Level

maintenance,modify,ha

History

level maintenance Appears in Netasq 6.0.0
level admin deprecated in Netasq 6.0.0
interf2 deprecated in Netasq 6.1.0
interf2 Appears in 6.1.2
option serial0 for interf deprecated in 6.1.2
sendarp Appears in Netasq 9.0.0
sendarpperiod Appears in Netasq 9.0.0
purgearp Appears in Netasq 9.0.0
nbping appears in Netasq 9.0.0
ip and ip2 removed in Netasq 9.0.0
timeout removed in Netasq 9.0.0
period removed in Netasq 9.0.0
foperiod removed in Netasq 9.0.0
limit removed in Netasq 9.0.0
interfacesflipflop appears in Netasq 9.0.1
tokentimeout appears in 9.0.4
secure removed in 2.0.0
LACPWhenPassive appears in 2.6.0
ConnOlderThan appears in 3.2.0



SynchronizationDelay appears in 3.5.0
DelayConnUpd replaces ConnOlderThan in 4.0.0
LACPMembersHaveWeight appears in 3.10.0
FailoverMembersHaveWeight appears in 4.3.0

Description

Update HA configuration

Usage

```
[password=<ha password>]
[ifname=<ethernet|vlan>]
[ifname2={"|"}<ethernet|vlan>]]
[forward=<All|None|Connections|Tcp|Udp|SIP|Assoc>]
[waitingpeertimeout=<0-9999>]
[SynchronizationDelay=<0-9999>]
[purgearp=<0-1>]
[sendarp=<0|1>]
[sendarpperiod=<1-9999>]
[nbping={0-300}]
[interfacesflipflop=<0-20000>] [tokentimeout=<1-99999>] [LACPWhenPassive=<0|1>]
[DelayConnUpd=<integer>] [LACPMembersHaveWeight=<0|1>]
[FailoverMembersHaveWeight=<0|1>]
```

Returns

Error code

Example

CONFIG HA UPDATE password=newpassword

CONFIG HA WEIGHT

Level

base

Description

Change HA weights on each network interface to influence HA quality computation

CONFIG HA WEIGHT ACTIVATE

Level

maintenance,modify

Description

Activate changes on weights

Returns

Error code

Example

CONFIG HA WEIGHT ACTIVATE

CONFIG HA WEIGHT SHOW

Level

base

**Description**

Display current weights on network interfaces

Returns

[Weights]

ethernet<X>=<0-9999>

ethernet<Y>=<0-9999>

[...]

Example

CONFIG HA WEIGHT SHOW

[Weights]

ethernet0=0

ethernet1=0

ethernet2=100

ethernet3=100

CONFIG HA WEIGHT UPDATE**Level**

maintenance,modify

Description

Update a weight on a specific interface

Usage

ifname=<user name> weight=<0-9999>

Returns

Error code

Example

CONFIG HA WEIGHT UPDATE ifname=dmz3 weight=0

CONFIG HOSTREP**Level**

base

Description

Configure host reputation

CONFIG HOSTREP ACTIVATE**Level**

base,modify

History

Appears in 3.0.0

Description

Activate host reputation configuration

Usage



[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

```
CONFIG HOSTREP ACTIVATE CONFIG HOSTREP ACTIVATE cancel
```

CONFIG HOSTREP HOSTLIST

Level

base

History

Appears in 3.0.0

Description

Configure monitored hosts for hostreputation

CONFIG HOSTREP HOSTLIST ADD

Level

base,modify

History

Appears in 3.0.0

Description

Add a machine in one of the hostreputation lists. IPv6 addresses are ignored

Usage

```
Host=<host|network|group> [Type=<included|excluded>]
```

Returns

Error code

Example

```
CONFIG HOSTREP HOSTLIST ADD host=network_internals Type=included  
CONFIG HOSTREP HOSTLIST ADD Type=excluded Host=my_mail_server
```

CONFIG HOSTREP HOSTLIST CLEAR

Level

base,modify

History

Appears in 3.0.0

Description

Clear the included list or the excluded list

Usage

```
Type=<included|excluded>
```

**Returns**

Error code

Example

```
CONFIG HOSTREP HOSTLIST CLEAR Type=included
```

CONFIG HOSTREP HOSTLIST REMOVE**Level**

base,modify

History

Appears in 3.0.0

Description

Remove an object from the included list or the excluded list

Usage

```
Host=<host|network|group> [Type=<included|excluded>]
```

Returns

Error code

Example

```
CONFIG HOSTREP HOSTLIST REMOVE Type=included Host=host_x  
CONFIG HOSTREP HOSTLIST REMOVE Host=range_y
```

CONFIG HOSTREP HOSTLIST SHOW**Level**

base

History

Appears in 3.0.0

Description

Show the list of included and excluded hosts

Returns

host : object name that represent a host, a range, a network or a group

Format

list

Example

```
CONFIG HOSTREP HOSTLIST SHOW  
101 code=00a01000 msg="Début"  
[included]  
host_1  
host_2  
[excluded]  
host_3
```

CONFIG HOSTREP SHOW**Level**



base

History

Appears in 3.0.0

Description

Display current configuration for host reputation

Format

section

Example

```
CONFIG HOSTREP SHOW
[Global]
State=1/0
[Alarm]
Minor=value
Major=value
[Sandboxing]
Suspicious=value
Malicious=value
[Antivirus]
infected=value
unknown=value
failed=value
```

CONFIG HOSTREP UPDATE

Level

base,modify

History

Appears in 3.0.0

Description

Update host reputation configuration

Usage

```
[State={1|0}]
[AlarmMinor=<integer>] [AlarmMajor=<integer>]
[SandboxingSuspicious=<integer>] [SandboxingMalicious=<integer>]
[SandboxingFailed=<integer>]
[AntivirusInfected=<integer>] [AntivirusUnknown=<integer>] [AntivirusFailed=<integer>]
```

Returns

Error code

Example

```
CONFIG HOSTREP UPDATE State=1 AlarmMinor=10 AlarmMajor=50 SandboxingMalicious=250
AntivirusInfected=500
CONFIG HOSTREP UPDATE State=0
```



CONFIG IPSEC

Level

base

History

Appears in Netasq 9.0.0

Description

IPsec management

CONFIG IPSEC ACTIVATE

Level

vpn,modify

History

Appears in Netasq 9.0.0

Description

Activate/cancel modifications of IPsec configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

```
CONFIG IPSEC ACTIVATE CACHE_CATEGORY ipsec_peer,ipsec_pgateway,ipsec_pmobile,ipsec_psk  
CACHE_CATEGORY_CLONE ipsec_peer,ipsec_pgateway,ipsec_pmobile,ipsec_psk
```

CONFIG IPSEC CA

Level

base

History

Appears in Netasq 9.0.0

Description

CA management

CONFIG IPSEC CA ADD

Level

vpn,modify

History

Appears in Netasq 9.0.0

Description



Add trusted certificate authority.

Usage

name=<caname> [global=<0|1>]

Example

CONFIG IPSEC CA ADD name=myca

CONFIG IPSEC CA LIST**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

List trusted certificate authorities

Usage

[global=<0|1>]

Example

CONFIG IPSEC CA LIST

Format

section_line

CONFIG IPSEC CA REMOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Remove trusted certificate authority.

Usage

name=<caname> [global=<0|1>]

Example

CONFIG IPSEC CA REMOVE name=myca

CONFIG IPSEC CA UPDATE**Level**

vpn,modify

History

Appears in 4.1.0

Description

Update trusted certificate authority list.

Usage



name=<old_caname> newname=<new_caname> [global=<0|1>]

Example

CONFIG IPSEC CA UPDATE name=myca newname=mynewca

CONFIG IPSEC CHECK**Level**

vpn_read

History

Appears in 2.0

Usage

index=<policy_idx> [global=<0|1>]

Description

Check the current (non-activated) IPsec rules

Example

CONFIG IPSEC CHECK index=1

Format

section_line

CONFIG IPSEC CRYPTOLB**Level**

base

History

Appears in 4.3.0

Description

Configure the cryptographic load balancing behavior

CONFIG IPSEC CRYPTOLB SHOW**Level**

vpn_read

History

Appears in 4.3.0

Description

Display the cryptographic load balancing configuration

Example

CONFIG IPSEC CRYPTOLB SHOW

CONFIG IPSEC CRYPTOLB UPDATE**Level**

vpn,modify

History



Appears in 4.3.0

Description

Configure the cryptographic load balancing behavior

Usage

ifincoming=<interface> ifoutgoing=<interface> state=<0|1>

state: 0 to disable state, 1 to configure interfaces if any given AND let CryptoLoadBalance token in VPN slot take over

Example

```
CONFIG IPSEC CRYPTOLB UPDATE ifincoming=dmz1 ifoutgoing=out
CONFIG IPSEC CRYPTOLB UPDATE ifincoming= ifoutgoing=
CONFIG IPSEC CRYPTOLB UPDATE state=1
```

CONFIG IPSEC LDAPLOOKUP

Level

base

History

Appears in 3.3.0

Description

Configure the Ldap lookup order.

CONFIG IPSEC LDAPLOOKUP ADD

Level

vpn,modify

History

Appears in 4.1.0

Description

Add a new ldap.

Usage

domain=<ldap>

Example

```
CONFIG AUTH LDAPLOOKUP ADD domain=ldap_entry
```

CONFIG IPSEC LDAPLOOKUP LIST

Level

vpn_read

History

Appears in 3.3.0

Description

Configure the Ldap lookup order.

Example

```
CONFIG AUTH LDAPLOOKUP LIST
[ldap]
```




pos=0 domain=ldap_entry_1
pos=1 domain=ldap_entry_2

Format

section_line

CONFIG IPSEC LDAPLOOKUP METHOD**Level**

vpn,modify

History

Appears in 3.3.0

Description

Configure the Ldap lookup method.

Usage

lookup=<default|multildap_lookup>

Example

CONFIG IPSEC LDAPLOOKUP METHOD lookup=default

CONFIG IPSEC LDAPLOOKUP MOVE**Level**

vpn,modify

History

Appears in 4.1.0

Description

Configure the Ldap lookup order.

Usage

domain=<ldap> offset=<n>|-<n>

Example

CONFIG AUTH LDAPLOOKUP MOVE domain=ldap_entry offset=1 CONFIG AUTH LDAPLOOKUP MOVE
domain=ldap_entry offset=-1

CONFIG IPSEC LDAPLOOKUP REMOVE**Level**

vpn,modify

History

Appears in 4.1.0

Description

Remove an ldap.

Usage

domain=<ldap>

Example

CONFIG AUTH LDAPLOOKUP REMOVE domain=ldap_entry



CONFIG IPSEC LDAPLOOKUP SHOW

Level

vpn_read

History

Appears in 3.3.0

Description

Display the Ldap lookup method.

Usage**Example**

```
CONFIG IPSEC LDAPLOOKUP SHOW
```

CONFIG IPSEC LDAPLOOKUP UPDATE

Level

vpn,modify

History

Appears in 3.3.0

pos appears in 4.2.0

Description

Modify the name of a Ldap domain at a given position.

Usage

pos=<number>

domain=<ldap_name>

Example

```
CONFIG IPSEC LDAPLOOKUP UPDATE pos=0 domain=ldap1
```

CONFIG IPSEC PEER

Level

base

History

Appears in Netasq 9.0.0

Description

IPsec peers

CONFIG IPSEC PEER CHECK

Level

vpn_read

History

Appears in Netasq 9.0.0

FORMAT appears in 4.2.0

useclone appears in 4.2.0

Description



Check if peer is used by policies

Usage

name=<profilename> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PEER CHECK name=mypeer

Format

section_line

CONFIG IPSEC PEER LIST**Level**

vpn_read

History

Appears in Netasq 9.0.0

ikeversion appears in 2.0.0

useclone appears in 4.2.0

Description

List IPsec peers

Usage

[type=<anonymous|gateway|all>] [global=<0|1>] [ikeversion=<1|2>] [start=<int>
[limit=<int>] [dir=<ASC|DESC>] [search=<pattern>] [sort=<0|1>] [refresh=<0|1>]]
[useclone=<0|1>]

Example

CONFIG IPSEC PEER LIST type=anonymous

Format

section_line CACHE_CATEGORY ipsec_peer CACHE_CATEGORY_CLONE ipsec_peer

CONFIG IPSEC PEER NEW**Level**

vpn,modify

History

Appears in Netasq 9.0.0

auto mode appears in Netasq 9.0.1

ikeversion appears in 2.0.0

peeridentifier appears in 3.0.0

reauth appears in 3.5.0

inactivity appears in 3.8.0

ikedscp appears in 3.10.0

useclone appears in 4.2.0

force appears in 4.2.0

sharesa removed in 4.2.0

backupmode removed in 4.2.0

backuppeer removed in 4.2.0

checkmode removed in 4.2.0

dpd_delay removed in 4.2.0

dpd_retry removed in 4.2.0

dpd_maxfail removed in 4.2.0



xauth method removed in 4.2.1
 mobike appears in 4.3.0
 unique appears in 4.5.0
 UDPEncapPreferred appears in 4.7.2

Description

Create a new peer

Usage

```
name=<peername> dst=<host|any> src=<host|any> conf=<phase1profile> [comment=<str>]
[global=<0|1>] [force=<0|1>] [ikeversion=<1|2>] [dpd_mode=<passive|low|high>]
[useclone=<0|1>] [specific mandatory/optionnal tokens for this authentication method]
[specific mandatory/optional tokens for this ike version]
IKEV1 TOKENS
method=<psk|pki|xauth_pki>
```

```
[mode=<main|aggressive>]
[responderonly=<0|1>]
[natt=<auto|force>]
[ike_frag=<0|1>]
IKEV2 TOKENS
method=<psk|pki>
[natt=<auto|force>]
[responderonly=<0|1>]
[ike_frag=<0|1>]
[reauth=<0|1>] : Enable the IKE SA reauthentication when it is about to expire (default is 1)
[inactivity=<num>]
[mobike=<0|1>]
PSK TOKENS
[psk=<key>]
[identifier=<asn1dn|user fqdn|fqdn|ip>]
[peeridentifier=<asn1dn|user fqdn|fqdn|ip>]
psk can be specified in roadwarrior psks instead of here.
```

PKI TOKENS

```
cert=<certname>
[identifier=<asn1dn|user fqdn|fqdn|ip>]
[peeridentifier=<asn1dn|user fqdn|fqdn|ip>]
[peercert=<certname>]
[sendcert=<0|1>]
[sendcr=<0|1>]
in IKEv2, the identifiers have to be confirmed by the certificates
```

XAUTH/XAUTH_PKI TOKENS

```
cert=<certname>
```

MISC TOKENS

```
[unique=<keep|replace|no|never>] : enforce a uniqueness policy, using INITIAL_CONTACT notifies
[ikedscp=[""]<0-63>]]
[UDPEncapPreferred=<on|off>] : force udp encapsulation in DR mode
```

Example

```
CONFIG IPSEC PEER NEW name=mypeer type=pki dst=host1 src=Firewall_Out conf=myph1
cert=mycert CACHE_CATEGORY_CLONE ipsec_peer
```

CONFIG IPSEC PEER REMOVE**Level**



vpn,modify

History

Appears in Netasq 9.0.0
useclone appears in 4.2.0

Description

Remove IPsec peer if not used

Usage

name=<profilename> [global=<0|1>] [useclone=<0|1>]]

Example

CONFIG IPSEC PEER name=mypeer CACHE_CATEGORY_CLONE ipsec_peer

CONFIG IPSEC PEER RENAME**Level**

vpn, modify

History

Appears in 3.0.0
useclone appears in 4.2.0

Description

Rename a peer

Usage

name=<profilename> newname=<newprofilename> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PEER RENAME name=mypeer newname=mynewpeer

CONFIG IPSEC PEER SHOW**Level**

vpn_read

History

Appears in Netasq 9.0.0
useclone appears in 4.2.0

Description

Show information about peer

Usage

name=<peername> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PEER SHOW name=mypeer

CONFIG IPSEC PEER UPDATE**Level**

vpn,modify

History



Appears in Netasq 9.0.0
auto mode appears in Netasq 9.0.1
ikeversion appears in 2.0.0
peeridentifier appears in 3.0.0
reauth appears in 3.5.0
inactivity appears in 3.8.0
ikedscp appears in 3.10.0
useclone appears in 4.2.0
force appears in 4.2.0
sharesda removed in 4.2.0
backupmode removed in 4.2.0
backuppeer removed in 4.2.0
checkmode removed in 4.2.0
dpd_delay removed in 4.2.0
dpd_retry removed in 4.2.0
dpd_maxfail removed in 4.2.0
xauth method removed in 4.2.1
mobike appears in 4.3.0
unique appears in 4.5.0
UDPEncapPreferred appears in 4.7.2

Description

Update a peer

Usage

```
name=<peername> [method=<psk|pki|xauth_pki>] [mode=<main|aggressive>]  
[dst=<host|any>] [src=<host|any>] [responderonly=<0|1>] [natt=<none|auto|force>] [dpd_  
mode=<passive|low|high>] [ike_frag=<0|1>] [identifier=<asn1dn|user_fqdn|fqdn|ip>]  
[peeridentifier=<asn1dn|user_fqdn|fqdn|ip>] [peercert=<certname>] [cert=<certname>]  
[sendcert=<0|1>] [sendcr=<0|1>] [psk=<key>] [conf=<phase1profile>] [comment=<str>]  
[global=<0|1>] [ikeversion=<1|2>] [reauth=<0|1>] [inactivity=<num>] [ikedscp="{<0-63>}"]  
[useclone=<0|1>] [force=<0|1>] [mobike=<0|1>] [unique=<keep|replace|no|never>]  
[UDPEncapPreferred=<on|off>]
```

Example

```
CONFIG IPSEC PEER UPDATE name=mypeer natt=force
```

CONFIG IPSEC POLICY

Level

base

History

Appears in Netasq 9.0.0

Description

IPsec policy

CONFIG IPSEC POLICY GATEWAY

Level

base

History

Appears in Netasq 9.0.0

**Description**

IPsec gateway policy

CONFIG IPSEC POLICY GATEWAY ADD**Level**

vpn,modify

History

Appears in Netasq 9.0.0

GRE protocol appears in 2.0

name appears in 3.4

tfc appears in 4.2.0 rulename appears in 4.2.0

Description

Add gateway-gateway policy. To add bypass policy, peer must be 'none'.

Usage

```
slot=<1-10> state=<on|off> local=<object|all|all_v4|all_v6> remote=<object|all>  
[peer=<peername> conf=<phase2profile> | peer=none] [proto=<any|tcp|udp|icmp|gre>  
[keepalive=<0|30|60|120|300|600>] [comment=<str>] [position=<pos> | name=<string>]  
[rulename=<string>] [global=<0|1>] [tfc=<length>]
```

Example

```
CONFIG IPSEC POLICY GATEWAY ADD slot=01 state=on local=net_remote remote=host_remote  
peer=mypeer conf=myph2 CACHE_CATEGORY_CLONE ipsec_pgateway
```

CONFIG IPSEC POLICY GATEWAY ADDSEP**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Add/update separator

Usage

```
slot=<1-10> color=<hexa color> collapse=<0|1> comment=<str> [update=<0|1>]  
[position=<pos>] [global=<0|1>]
```

Example

```
CONFIG IPSEC POLICY GATEWAY ADDSEP slot=01 position=5 color="#557788" collapse=0  
comment="a comment" CACHE_CATEGORY_CLONE ipsec_pgateway
```

CONFIG IPSEC POLICY GATEWAY COLLAPSE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Collapse/uncollapse all separators

Usage



slot=<1-10> action=<all|none> [global=<0|1>]

Example

```
CONFIG IPSEC POLICY GATEWAY COLLAPSE slot=01 action=all CACHE_CATEGORY_CLONE ipsec_
pgateway
```

CONFIG IPSEC POLICY GATEWAY LIST**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

List gateway-gateway policies and separators

Usage

slot=<1-10> [useclone=<0|1>] [global=<0|1>] [start=<int> [limit=<int>] [dir=<ASC|DESC>]
[search=<pattern>] [searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Example

```
CONFIG IPSEC POLICY GATEWAY LIST slot=01
```

Format

section_line CACHE_CATEGORY ipsec_pgateway CACHE_CATEGORY_CLONE ipsec_pgateway

CONFIG IPSEC POLICY GATEWAY MOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Move gateway-gateway policy or separator

Usage

slot=<1-10> position=<pos> offset=<+/-num> [global=<0|1>]

Example

```
CONFIG IPSEC POLICY GATEWAY MOVE slot=01 position=1 offset=-1 CACHE_CATEGORY_CLONE
ipsec_pgateway
```

CONFIG IPSEC POLICY GATEWAY REMOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0
name appears in 3.4

Description

Remove gateway-gateway policy or separator

Usage

slot=<1-10> [position=<pos> | name=<string>] [global=<0|1>]

**Example**

```
CONFIG IPSEC POLICY GATEWAY REMOVE slot=01 position=1 CONFIG IPSEC POLICY GATEWAY  
REMOVE slot=01 name=rule_a CACHE_CATEGORY_CLONE ipsec_pgateway
```

CONFIG IPSEC POLICY GATEWAY UPDATE**Level**

vpn,modify

History

Appears in Netasq 9.0.0
GRE protocol appears in 2.0
name appears in 3.4
rulename appears in 3.4
tfc appears in 4.2.0

Description

Update gateway-gateway policy

Usage

```
slot=<1-10> [ position=<pos> | name=<string> ] [ state=<on|off> ] [ local=<object|all|all_v4|all_v6> ]  
[ remote=<object|all> ] [ peer=<peername|none> ] [ conf=<phase2profile> ]  
[ proto=<any|tcp|udp|icmp|gre> ] [ keepalive=<0|30|60|120|300|600> ] [ comment=<str> ]  
[ global=<0|1> ] [ rulename=<string> ] [ tfc=<length> ]  
- name: the name of the rule  
- rulename: the new name for the rule
```

Example

```
CONFIG IPSEC POLICY GATEWAY UPDATE slot=01 position=1 proto=tcp CONFIG IPSEC POLICY  
GATEWAY UPDATE slot=01 name=rule_a rulename=rule_b CACHE_CATEGORY_CLONE ipsec_  
pgateway
```

CONFIG IPSEC POLICY MOBILE**Level**

base

History

Appears in Netasq 9.0.0

Description

IPsec mobile policy

CONFIG IPSEC POLICY MOBILE ADD**Level**

vpn,modify

History

Appears in Netasq 9.0.0
GRE protocol appears in 2.0.0
group and domain appear in 3.8.0
tfc appears in 4.2.0 rulename appears in 4.2.0

Description

Add mobile policy. All mobile policies must have the same anonymous peer. Only one mobile policy can use mode config. slot=<1-10> state=<on|off> local=<object|all|any>



```
remote=<object|all|any> peer=<peername> conf=<phase2profile>  
[proto=<any|tcp|udp|icmp|gre>] [keepalive=<0|30|60|120|300|600>] [modeconfig=<0|1>]  
[comment=<str>] [position=<pos> | name=<string>] [rulename=<string>] [domain=<string>  
[group=<string>]] [global=<0|1>] [tfc=<length>]
```

Example

```
CONFIG IPSEC POLICY MOBILE ADD slot=01 state=on local=net_remote remote=any  
peer=myanonymousepeer conf=myph2 CACHE_CATEGORY_CLONE ipsec_pmobile
```

CONFIG IPSEC POLICY MOBILE ADDSEP**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Add/update separator

Usage

```
slot=<1-10> color=<hexa color> collapse=<0|1> comment=<str> [update=<0|1>]  
[position=<pos>] [global=<0|1>]
```

Example

```
CONFIG IPSEC POLICY MOBILE ADDSEP slot=01 position=5 color="#557788" collapse=0  
comment="a comment" CACHE_CATEGORY_CLONE ipsec_pmobile
```

CONFIG IPSEC POLICY MOBILE COLLAPSE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Collapse/uncollapse all separators

Usage

```
slot=<1-10> action=<all|none> [global=<0|1>]
```

Example

```
CONFIG IPSEC POLICY MOBILE COLLAPSE slot=01 action=all CACHE_CATEGORY_CLONE ipsec_  
pmobile
```

CONFIG IPSEC POLICY MOBILE GETPEER**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

Get peer used by all mobile policies

Usage

```
slot=<1-10> [global=<0|1>]
```

**CONFIG IPSEC POLICY MOBILE LIST****Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

List mobile policies and separators

Usage

```
slot=<1-10> [global=<0|1>] [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]
```

Example

```
CONFIG IPSEC POLICY MOBILE LIST slot=01
```

Format

```
section_line CACHE_CATEGORY ipsec_pmobile CACHE_CATEGORY_CLONE ipsec_pmobile
```

CONFIG IPSEC POLICY MOBILE MOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Move mobile policy or separator

Usage

```
slot=<1-10> position=<pos> offset=<+/-num> [global=<0|1>]
```

Example

```
CONFIG IPSEC POLICY MOBILE MOVE slot=01 position=1 offset=-1 CACHE_CATEGORY_CLONE ipsec_
pmobile
```

CONFIG IPSEC POLICY MOBILE REMOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Remove mobile policy or separator

Usage

```
slot=<1-10> ( position=<pos> | name=<string> ) [global=<0|1>]
```

Example

```
CONFIG IPSEC POLICY MOBILE REMOVE slot=01 position=1 CONFIG IPSEC POLICY MOBILE REMOVE
slot=01 name=rule_a CACHE_CATEGORY_CLONE ipsec_pmobile
```

**CONFIG IPSEC POLICY MOBILE SETPEER****Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Update peer used by all mobile policies

Usage

slot=<1-10> peer=<peername> [global=<0|1>]

ExampleCONFIG IPSEC POLICY MOBILE SETPEER slot=01 peer=peerx CACHE_CATEGORY_CLONE ipsec_
pmobile**CONFIG IPSEC POLICY MOBILE UPDATE****Level**

vpn,modify

History

Appears in Netasq 9.0.0

GRE protocol appears in 2.0.0

group and domain appear in 3.6.0

tfc appears in 4.2.0

Description

Update mobile policy

Usageslot=<1-10> [position=<pos> | name=<string>] [state=<on|off>] [local=<object|all|any>]
[remote=<object|all|any>] [peer=<peername>] [conf=<phase2profile>]
[proto=<any|tcp|udp|icmp|gre>] [keepalive=<0|30|60|120|300|600>] [modeconfig=<0|1>]
[group=<string> domain=<string>] [comment=<str>] [rulename=<string>] [global=<0|1>]
[tfc=<length>]**Example**CONFIG IPSEC POLICY MOBILE UPDATE slot=01 position=1 proto=tcp CONFIG IPSEC POLICY
MOBILE UPDATE slot=01 name=rule_a rulename=rule_b CACHE_CATEGORY_CLONE ipsec_pmobile**CONFIG IPSEC PROFILE****Level**

base

History

Appears in Netasq 9.0.0

Description

IPsec profiles

CONFIG IPSEC PROFILE PHASE1**Level**



base

History

Appears in Netasq 9.0.0

Description

IPsec phase 1 profiles

CONFIG IPSEC PROFILE PHASE1 CHECK**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

Check if profile is used by peers

Usage

name=<profilename> [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 CHECK name=myp1

Format

section_line

CONFIG IPSEC PROFILE PHASE1 GETDEFAULT**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

Get default phase1 profile

Usage

[global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 GETDEFAULT

CONFIG IPSEC PROFILE PHASE1 LIST**Level**

vpn_read

History

Appears in Netasq 9.0.0

useclone appears in 4.2.0

Description

List phase 1 profiles

Usage

[global=<0|1>] [useclone=<0|1>]

**Example**

```
CONFIG IPSEC PROFILE PHASE1 LIST
```

Format

section_line

CONFIG IPSEC PROFILE PHASE1 NEW**Level**

vpn,modify

History

Appears in Netasq 9.0.0

defaultprf appears in 4.3.0

prf appears in 4.3.0

Description

Create IPsec phase 1 profile

Usage

```
name=<profilename> defaultdh=<dh> [defaultprf=<defaultprf>] [lifetime=<seconds>]  
enc=<algo[/size]> auth=<algo[/size]> [dh=<dh>] [prf=<prf>] [comment=<str>]  
[global=<0|1>]
```

Example

```
CONFIG IPSEC PROFILE PHASE1 NEW name=myph1 defaultdh=1 enc=aes/128 auth=md5  
prf=SHA256
```

CONFIG IPSEC PROFILE PHASE1 PROPOSALS**Level**

base

History

Appears in 4.1.0

Description

IPsec phase 1 profiles proposals

CONFIG IPSEC PROFILE PHASE1 PROPOSALS ADD**Level**

vpn,modify

History

Appears in Netasq 9.0.0

New prototype in 4.1.0

prf appears in 4.3.0

Description

Add a proposition

Usage

```
name=<profilename> enc=<algo[/size]> auth=<algo[/size]> [dh=<dh>] [prf=<prf>]  
[global=<0|1>]
```

Example



CONFIG IPSEC PROFILE PHASE1 PROPOSALS ADD name=myp1 enc=aes/256 auth=sha1 dh=3
prf=SHA256

CONFIG IPSEC PROFILE PHASE1 PROPOSALS LIST

Level

vpn_read

History

Appears in 4.1.0

Description

Show information about phase 1

Usage

name=<profilename> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 PROPOSALS LIST name=myph1

Format

section_line

CONFIG IPSEC PROFILE PHASE1 PROPOSALS MOVE

Level

vpn,modify

History

Appears in Netasq 9.0.0

New prototype in 4.1.0

Description

Move a proposition

Usage

name=<profilename> position=<pos> offset=<+/-num> [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 PROPOSALS MOVE name=myp1 position=2 offset=+1

CONFIG IPSEC PROFILE PHASE1 PROPOSALS REMOVE

Level

vpn,modify

History

Appears in Netasq 9.0.0

New prototype in 4.1.0

Description

Remove a proposition

Usage

name=<profilename> position=<pos> [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 PROPOSALS REMOVE name=myp1 position=2

**CONFIG IPSEC PROFILE PHASE1 PROPOSALS UPDATE****Level**

vpn,modify

History

Appears in 4.1.0

prf appears in 4.3.0

Description

Update a proposition

Usage

```
name=<profilename> enc=<algo[/size]> auth=<algo[/size]> [dh=<dh>] [prf=<prf>]  
position=<pos> [global=<0|1>]
```

Example

```
CONFIG IPSEC PROFILE PHASE1 PROPOSALS UPDATE name=mysp1 enc=aes/256 auth=sha1 dh=3  
prf=SHA256 position=1
```

CONFIG IPSEC PROFILE PHASE1 REMOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Remove IPsec phase 1 profile if not used

Usage

```
name=<profilename> [global=<0|1>]
```

Example

```
CONFIG IPSEC PROFILE PHASE1 REMOVE name=mysp1
```

CONFIG IPSEC PROFILE PHASE1 SETDEFAULT**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Set default phase1 profile

Usage

```
name=<profilename> [global=<0|1>]
```

Example

```
CONFIG IPSEC PROFILE PHASE1 SETDEFAULT name=mysp1
```

CONFIG IPSEC PROFILE PHASE1 SHOW**Level**

vpn_read

**History**

Appears in Netasq 9.0.0
useclone appears in 4.2.0

Description

Show information about phase 1

Usage

name=<profilename> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 SHOW name=myph1

Format

section

CONFIG IPSEC PROFILE PHASE1 UPDATE**Level**

vpn,modify

History

Appears in Netasq 9.0.0
defaultprf appears in 4.3.0

Description

Update default dh, lifetime or comment

Usage

name=<profilename> [defaultdh=<dh>] [defaultprf=<prf>] [lifetime=<seconds>]
[comment=<str>] [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE1 UPDATE name=myp1 lifetime=21600

CONFIG IPSEC PROFILE PHASE2**Level**

base

History

Appears in Netasq 9.0.0

Description

IPsec phase 2 profiles

CONFIG IPSEC PROFILE PHASE2 CHECK**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

Check if profile is used by peers

Usage



name=<profilename> [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 CHECK name=myph2

Format

section_line

CONFIG IPSEC PROFILE PHASE2 GETDEFAULT**Level**

vpn_read

History

Appears in Netasq 9.0.0

Description

Get default phase2 profile

Usage

[global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 GETDEFAULT

CONFIG IPSEC PROFILE PHASE2 LIST**Level**

vpn_read

History

Appears in Netasq 9.0.0

useclone appears in 4.2.0

Description

List phase 2 profiles

Usage

[global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 LIST

Format

section_line

CONFIG IPSEC PROFILE PHASE2 NEW**Level**

vpn,modify

History

Appears in Netasq 9.0.0

replaywsiz appears in 9.0.5

Description

Create IPsec phase 2 profile

Usage



name=<profilename> enc=<algo[/size],algo[/size],...> auth=<algo[/size],algo[/size],...>
[pfs=<dh>] [lifetime=<seconds>] [replaywsz=<from 0 to 33554400 in steps of 8>]
[comment=<str>] [global=<0|1>]

replaywsz: the size should be a power of 2 less 32 (2^x-32) to optimize memory use. Set to 0 to deactivate anti-replay protection.

Example

```
CONFIG IPSEC PROFILE PHASE2 NEW name=myph2 pfs=1 enc=aes/256,aes/128 auth=md5
```

CONFIG IPSEC PROFILE PHASE2 PROPOSALS**Level**

base

History

Appears in 4.1.0

Description

IPsec phase 2 profiles proposals

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION**Level**

base

History

Appears in 4.1.0

Description

IPsec phase 2 profiles proposals authentication algorithms

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION ADD**Level**

vpn,modify

History

Appears in 4.1.0

Description

Add authentication algo in list

Usage

name=<profilename> [global=<0|1>] algo=<authalgo>

Example

```
CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION ADD name=myph2 algo=md5
```

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION LIST**Level**

vpn_read

History

Appears in 4.1.0

Description

List authentication algos

**Usage**

name=<profilename> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION LIST name=myph2

Format

section_line

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION REMOVE

Level

vpn,modify

History

Appears in 4.1.0

Description

Remove authentication algo in list

Usage

name=<profilename> [global=<0|1>] position=<position>

Example

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION REMOVE position=1

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION UPDATE

Level

vpn,modify

History

Appears in 4.1.0

Description

Update authentication algo at specified position in list

Usage

name=<profilename> [global=<0|1>] position=<position> algo=<auth_algo>

Example

CONFIG IPSEC PROFILE PHASE2 PROPOSALS AUTHENTICATION UPDATE position=1 algo=hmac_
sha256

CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION

Level

base

History

Appears in 4.1.0

Description

IPsec phase 2 profiles proposals encryption algorithms

CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION ADD

Level

vpn,modify

**History**

Appears in 4.1.0

Description

Add encryption algo in list

Usage

name=<profilename> [global=<0|1>] algo=<encalgo>

Example

```
CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION ADD name=myph2 algo=des/64
```

CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION LIST**Level**

vpn_read

History

Appears in 4.1.0

Description

List encryption algos

Usage

name=<profilename> [global=<0|1>] [useclone=<0|1>]

Example

```
CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION LIST name=myph2
```

Format

section_line

CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION REMOVE**Level**

vpn,modify

History

Appears in 4.1.0

Description

Remove encryption algo in list

Usage

name=<profilename> [global=<0|1>] position=<position>

Example

```
CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION REMOVE position=1
```

CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION UPDATE**Level**

vpn,modify

History

Appears in 4.1.0

Description

Update encryption algo at specified position in list

**Usage**

name=<profilename> [global=<0|1>] position=<position> algo=<enc_algo>

Example

CONFIG IPSEC PROFILE PHASE2 PROPOSALS ENCRYPTION UPDATE position=1 algo=des/64

CONFIG IPSEC PROFILE PHASE2 REMOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Remove IPsec phase 2 profile if not used

Usage

name=<profilename> [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 REMOVE name=myph2

CONFIG IPSEC PROFILE PHASE2 SETDEFAULT**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Set default phase2 profile

Usage

name=<profilename> [global=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 SETDEFAULT name=myp1

CONFIG IPSEC PROFILE PHASE2 SHOW**Level**

vpn_read

History

Appears in Netasq 9.0.0
useclone appears in 4.2.0

Description

Show information about phase 2

Usage

name=<profilename> [global=<0|1>] [useclone=<0|1>]

Example

CONFIG IPSEC PROFILE PHASE2 SHOW name=myph2

Format



section

CONFIG IPSEC PROFILE PHASE2 UPDATE

Level

vpn,modify

History

Appears in Netasq 9.0.0

replaywsiz appears in 9.0.5

Description

Update phase 2 profile

Usage

name=<profilename> [enc=<algo[/size],algo[/size],...>] [auth=<algo[/size],algo[/size],...>]

[pfs=<dh>] [lifetime=<seconds>] [replaywsiz=<from 0 to 33554400 in steps of 8>]

[comment=<str>] [global=<0|1>]

replaywsiz: the size should be a power of 2 less 32 (2^x-32) to optimize memory use. Set to 0 to deactivate anti-replay protection.

Example

CONFIG IPSEC PROFILE PHASE2 UPDATE name=myph2 lifetime=21600

CONFIG IPSEC PROPERTY

Level

vpn_read

History

Appears in Netasq 9.0.0

Description

Display global information about IPsec for this firewall.

Example

CONFIG IPSEC PROPERTY

Format

section_line

CONFIG IPSEC PSK

Level

base

History

Appears in Netasq 9.0.0

Description

Preshared keys management

CONFIG IPSEC PSK ADD

Level



vpn,modify

History

Appears in Netasq 9.0.0

id was renamed identifier in 4.1.0

Description

Add a key of update it if exists

Usage

identifier=<identifier> psk=<hex value> [global=<0|1>]

Returns

Error code

Example

```
CONFIG IPSEC PSK ADD identifier=toto psk=0x01010101 global=1 CACHE_CATEGORY_CLONE  
ipsec_psk
```

CONFIG IPSEC PSK LIST**Level**

vpn_read

History

Appears in Netasq 9.0.0

id was renamed identifier in 4.1.0

Description

Lists keys

Usage

[global=<0|1>] [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>] [sort=<0|1>]
[refresh=<0|1>]]

Returns

identifier=<identifier> psk=<hex value> global=<0|1>

Example

```
CONFIG IPSEC PSK LIST  
identifier="10.60.3.101" psk="0x61646D696E61646D696E"  
identifier="admin@global.conf" psk="0x61646D696E61646D696E"
```

Format

section_line CACHE_CATEGORY ipsec_psk CACHE_CATEGORY_CLONE ipsec_psk

CONFIG IPSEC PSK REMOVE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

id was renamed identifier in 4.1.0

Description

Dels a key

**Usage**

identifier=<identifier> [global=<0|1>]

Returns

Error code

Example

```
CONFIG IPSEC PSK REMOVE id=testkey CACHE_CATEGORY_CLONE ipsec_psk
```

CONFIG IPSEC RELOAD

Level

vpn,pki,modify

History

Appears in 3.7.0

Description

Force ipsec configuration reload with 'envpn -u'

CONFIG IPSEC SHOW

Level

vpn_read

History

Appears in Netasq 9.0.0

Description

Display global information about a slot

Usage

slot=<1-10> [global=<0|1>]

Example

```
CONFIG IPSEC SHOW slot=01
```

CONFIG IPSEC UPDATE

Level

vpn,modify

History

Appears in Netasq 9.0.0

CRLrequired appears in Netasq 9.0.1

cfg_domain appears in Netasq 9.0.1

DoSProtection appears in 2.3.0

CookieThreshold appears in 2.3.0

BlockThreshold appears in 2.3.0

RetransmitTries appears in 2.3.0

RetransmitTimeout appears in 2.3.0

RetransmitBase appears in 2.3.0

MakeBeforeBreak appears in 3.0.0

NATKeepalive appears in 3.0.0



FragmentSize appears in 3.2.0
IKEDaemon appears in 3.3.0
CheckDuplicatePh1 appears in 4.0.0
CryptoLoadBalance appears in 2.7.3
CryptoLoadBalance can be auto in 4.2.0
IKEDaemon removed in 4.2.0
retry removed in 4.2.0
interval removed in 4.2.0
ph1delay removed in 4.2.0
ph2delay removed in 4.2.0
bindall removed in 4.2.0
PMTUD appears in 4.3.0
UsedInterface appears in 4.3.0
RemoteFetch appears in 4.7.0
UACForceCert appears in 4.7.0
HalfOpenTimeout appears in 4.3.18
NewSADelay appears in 4.3.20
DRCertSHA2 appears in 4.7.0

Description

Update global information about a slot

Usage

```
slot=<1-10> [cfg dns=<host>] [cfg domain=<domain1,domain2,...>] [useoldsa=<0|1>]  
[certNID=<num>] [LdapField=<str>] [CRLrequired=<0|1>] [UACServCert=<0|1>]  
[DoSPProtection=<0|1>] [CookieThreshold=<num>] [BlockThreshold=<num>]  
[RetransmitTries=<num>] [RetransmitTimeout=<num>] [RetransmitBase=<float>]  
[MakeBeforeBreak=<0|1>] [NATKeepalive=<num>] [FragmentSize=<num>]  
[BypassLocalTraffic=<0|1>] [global=<0|1>] [CheckDuplicatePh1=<0|1>]  
[CryptoLoadBalance=<0|1|auto>] [PMTUD=<0|1|2>] [UsedInterface=<itf1,itf2,...>]  
[HalfOpenTimeout=<num>] [NewSADelay=<delay>]  
- cfg domain: 32 domains max  
- RetransmitBase: min is 1  
- NATKeepalive: period in seconds between keepalive packets when NAT is detected (0 to  
disable)  
- FragmentSize: min is 512  
- BypassLocalTraffic: set to 1 to generate a bypass policy for each local IP addresses that are  
included in the remote IP addresses  
- CRLRequired: certificate is checked with OCSP if available and CRL if needed. If all checks  
failed, no tunnel is negotiated  
- CheckDuplicatePh1: each time a phase1 is up on StrongSwan, we check if an old one should  
be deleted.  
- CryptoLoadBalance: 0 to disable load balancing, 1 to enable, auto to let SNS choose  
- PMTUD: 0 to disable IPsec DF bit, 1 to force DF bit, 2 to set DF bit only if clear packet has DF bit  
set  
- UsedInterface: comma separated list of interfaces on which Strongswan should listen.  
- RemoteFetch: 1 to enable remote CRL / OCSP fetch by IKE daemon, 0 to disable  
- HalfOpenTimeout: timeout in seconds for connecting IKE_SAs  
- NewSaDelay: Delay in seconds before using newly created SA when there are multiple SAs  
- DRCertSHA2: Set to 1 to use SHA2 for CERTREQ payloads
```

Example

```
CONFIG IPSEC UPDATE slot=01 dnscfg=host5
```



CONFIG KEY

Level

base

History

Appears in Netasq 6.0.0
deprecated in Netasq 9.0.0

Description

Keys management

CONFIG KEY ADD

Level

vpn,modify

History

Appears in Netasq 6.0.0
deprecated in Netasq 9.0.0

Description

Add a key

Usage

(type=psk name=<keyname> [fqdn=<fqdn>|user_fqdn=<user_fqdn>|address=<address>]
psk=<Hexadecimal presharedkey>] | (type=static name=<keyname> key=<Hexadecimal
statickey>)

Returns

Error code

Example

CONFIG KEY ADD type=psk name=testkey fqdn=toto.stormshield.eu psk=0x63646364

CONFIG KEY LIST

Level

vpn

History

Appears in Netasq 6.0.0
deprecated in Netasq 9.0.0

Description

Lists keys with type filter (optional)

Usage

[type=psk|static]

Returns

[PSK]

Id=[ADDRESS|FQDN|USER_FQDN],<identifier>,<hex value>

[Static_VPN]

**Example**

```
CONFIG KEY LIST type=psk
[PSK]
fw_peer=ADDRESS,fwpeer obj,0x61616161
fw_other=ADDRESS,192.168.2.2,0x666F6F626172
otherpeer=FQDN,other.example.com,0x6364636463646364
```

CONFIG KEY REMOVE**Level**

vpn,modify

History

Appears in Netasq 6.0.0
deprecated in Netasq 9.0.0

Description

Dels a key

Usage

type=psk|static name=<keyname>

Returns

Error code

Example

```
CONFIG KEY REMOVE type=psk name=testkey
```

CONFIG LCD**Level**

base

History

Appears in 3.8.0

Description

LCD configuration

CONFIG LCD ACTIVATE**Level**

maintenance,modify

History

Appears in 3.8.0

Description

Activates the LCD configuration.

Usage



[CANCEL]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

Example

```
CONFIG LCD ACTIVATE  
CONFIG LCD ACTIVATE CANCEL
```

CONFIG LCD SHOW

Level

base

History

Appears in 3.8.0

Description

Show LCD state.

Returns

LCD={on|off}

Example

```
CONFIG LCD SHOW
```

CONFIG LCD UPDATE

Level

maintenance,modify

History

Appears in 3.8.0

Description

Enable/Disable LCD display.

Usage

state={On|Off}

Returns

Warning/Error messages or ok

Example

```
SYSTEM LCD UPDATE state=Off
```

CONFIG LDAP

Level

base

Description



LDAP management functions

CONFIG LDAP ACTIVATE

Level

admin,modify

History

Appears in Netasq 9.0.0

Remark

You can not do a "ACTIVATE NEXTBOOT" if you initialize a local or remote server

Description

Activate the LDAP server with lastest configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG LDAP ACTIVATE

CONFIG LDAP CHECK

Level

base

History

Add possibility to check any LDAP server in Netasq 9.0.0

Add possibility to check a server being created "in the clone" (before an ACTIVATE command)

Description

Try to connect to the LDAP server, but perform no operation. If there are no argument, this command checks the ldap configuration on firewall, else checks ldap server specified by arguments.

Usage

[domainname=<domain>] [host=<Host IP> basedn=<Base DN> [port=<Port>] [user=<LDAP User> [password=<LDAP password>] [auth=Simple|SSL] [version=2|3]]] [useclone=on|off]

Returns

Error code

Example

CONFIG LDAP CHECK

CONFIG LDAP CHECK host="ldap.intranet.int" basedn="o=stormshield,dc=eu"
user="cn=StormshieldAdmin" password="LDAPadmin"



CONFIG LDAP COUNT

Level

base

History

Appears in 3.0.0

Description

Count the LDAP [internal/external] on the UTM

Returns

The number of LDAP on the UTM, activated or not

Example

```
CONFIG LDAP COUNT
```

CONFIG LDAP DEFAULT

Level

admin,modify

History

Appears in 3.0.0

Description

Set the default LDAP

If domainname parameter isn't supplied, return the current default LDAP.

Usage

```
[domainname=<domain>]
```

Returns

Error code

Example

```
CONFIG LDAP DEFAULT domainname=my_ldap CONFIG LDAP DEFAULT
```

CONFIG LDAP DELMAP

Level

admin,modify

Description

Delete a LDAP attribute map. Delete ALL LDAP attributes maps if none is given.

History

Attribute appears in 3.0.0

Usage

```
[domainname=<domain>]
```

```
[attribute=cn|sn|uid|mail|userPassword|userCertificate;binary|userPKCS12|givenName|userPrincipalName|telephoneNumber|serialNumber]
```

Returns



Error code

Remark

All maps will be deleted if no attribute is given.

Example

```
CONFIG LDAP DELMAP attribute=mail
CONFIG LDAP DELMAP domainname=external.de attribute=userPassword
CONFIG LDAP DELMAP
```

CONFIG LDAP EXTERNAL

Level

admin,modify

History

firewallid Appears in Netasq 6.0.0
cndn Appears in Netasq 6.2.3
protectchars Appears in 6.3.0
readonly Appears in Netasq 9.0.0
serversdn and serversfilter Appears in Netasq 9.0.0
GroupSchema appears in 1.2.0
realbind and FullAdminDN appear in 3.0.0
protectchars removed in 3.4.0

Description

Specify parameters for an external LDAP server

Usage

```
domainname=<domain> basedn=<Base DN> host=<Host IP> [port=<Port>]
[backuphost=<host IP> [backupport=<Port>]]
[user=<LDAP User> [password=<LDAP password>]] [auth=Simple|SSL] [cacert=<certname>]
[usersdn=<users dn>] [serversdn=<servers dn>] [groupsdn=<groups dn>] [confdn=<config
dn>]
[usersfilter=<LDAP filter for users>] [serversfilter=<LDAP filter for servers>]
[groupsfilter=<LDAP filter for groups>]
[cndn=0|1] [readonly=0|1] [groupschema=groupofmember|posixgroup] [realbind=on|off]
[FullAdminDN=0|1]
```

Returns

Error code

Remark

Internal LDAP base will be destroyed if exists.
usersdn, groupsdn and confdn are required for (resp) users, groups and configs creation.
cacert use external CA to check the LDAP server certificate (in SSL mode)
With SSL mode, the server host name MUST exist in DNS and match certificate subject name.
Default value for GroupSchema is GroupOfMember.

Example

```
CONFIG LDAP EXTERNAL domainname=external basedn="o=stormshield,dc=fr"
host="ldap.intranet.int" user="cn=StormshieldAdmin" password="LDAPadmin"
CONFIG LDAP EXTERNAL domainname=external basedn="o=stormshield,dc=fr"
host="ldap.intranet.int" user="cn=StormshieldAdmin" password="LDAPadmin" auth=SSL
```




```
cacert="trust ca"  
CONFIG LDAP EXTERNAL domainname=ororo.munroe basedn="o=stormshield,dc=eu"  
host="ldap.ororo.int" user="cn=StormshieldAdmin" password="adminadmin" realbind=off
```

CONFIG LDAP INITIALIZE

Level

admin,modify

History

firewallid Appears in Netasq 6.0.0

db disappears in Netasq 9.0.0

realbind appears in 3.0.0

Description

Initialize the local LDAP server LICENCE Service/LdapBase

Usage

domainname=<domain> o=<Organization name> dc=<Domain Country>

password=<adminpassword> [realbind=on|off]

Returns

Error code

Remark

Generate a new internal LDAP database in /usr/Firewall/Data/Ldapbase

Create an database administrator with login "cn=StormshieldAdmin" and password value The backend is BDB.

Example

```
CONFIG LDAP INITIALIZE domain=stormshield.eu o=stormshield dc=france  
password="LDAPAdmin"
```

CONFIG LDAP LIST

Level

base

History

Appears in 3.0.0

Description

List the LDAP on the UTM

Returns

The list of LDAP on the UTM, activated or not

Example

```
CONFIG LDAP LIST
```

Format

section_line



CONFIG LDAP PASSWORD

Level

admin,modify

History

firewallid Appears in Netasq 6.0.0 Password appears in 3.0.0

Description

Update the LDAP password

Usage

[domainname=<domain>] Password=<password>

Returns

Error code

Remark

Update password of administrator (StormshieldAdmin)

Example

CONFIG LDAP PASSWORD password="LdapAdmin"

CONFIG LDAP PUBLIC

Level

admin,modify

Description

Modify local server's access.

History

realbind appears in 3.0.0

Usage

[plain=0|1] [serverkey=<keyname>] [realbind=on|off]

Returns

Error code

Remark

Configure LDAP server to public access with SSL or not.

Keyname is a couple key and cert in external certificate list.

Send token "serverkey" empty to disable SSL.

Example

The server key is a certificat with its private key present in the PKI.

The name is like : 'authority name:certificate name'

CONFIG LDAP PUBLIC serverkey='authority:certificate_with_privkey'

CONFIG LDAP REMOVE

Level

admin,modify

**History**

Appears in 3.0.0

Description

Remove a LDAP from the UTM

Usage

domainname=<domain> [force=on|off]

Returns

Error code

Example

```
CONFIG LDAP REMOVE domain=ldap_1
CONFIG LDAP REMOVE domain=used_ldap force=on
```

CONFIG LDAP RENAME

Level

admin,modify

History

Appears in 3.0.0

Description

Rename a LDAP

Usage

domainname=<old_domain_name> newname=<new_domain_name>

Returns

Error code

Example

```
CONFIG LDAP RENAME domainname="my_ldap" newname="their_ldap"
```

CONFIG LDAP SETMAP

Level

base

History

Format Appears in Netasq 9.0.0

Description

Set LDAP attributes maps, or shows mappable attributes list if no map given.

Usage

[domainname=<domain>] <attribute>=<value>

Returns

Error code

Remark

Admin and modify flags needed to set a map.

**Format**

list

Example

CONFIG LDAP SETMAP mail=emailaddress

CONFIG LDAP SHOW**Level**

base

History

cndn Appears in Netasq 6.2.3

readonly Appears in Netasq 9.0.0

Format Appears in Netasq 9.0.0

GroupSchema appears in 1.2.0

Description

Show the LDAP configuration

Usage

[domainname=<domain>]

Format

section_line

Returns

The LDAP configuration for internal server:

[LDAP]

o : Organization.

dc : Domain component.

RealBind : RealBind to LDAP

state : ldap daemon state.

method : Authentication method for new user.

hash : Hash method for new user password.

firewallid : optionnal FirewallID for per firewall attributes.

Plain : Plain acces from network

ServerKey : X509 Certificate for SSL network access

The LDAP configuration for external server:

[EXT_LDAP]

host : Server host name.

port : Server port (default 389 and 636 with SSL).

basedn : Base dn of LDAP hierarchy.

RealBind : RealBind to LDAP

user : Login use by Firewall to manage LDAP external server.

fwca : Distinguished name of the CA certificat use in PKI.

auth : LDAP protocol (LDAP or LDAPS).

state : ldap daemon state.

method : Authentication method for new user.

hash : Hash method for new user password.

firewallid : optionnal FirewallID for per firewall attributes.

cndn : 1 if CN must be used in DNs for config entries.

readonly : 1 if configuration restricts LDAP access to read only mode.

groupschema : groupofmember or posixgroup

**Example**

```
CONFIG LDAP SHOW  
[LDAP]
```

0=

Example

```
Dc=COM  
RealBind=1  
Plain=1  
State=1  
Method=None  
Hash=SSHA
```

CONFIG LDAP STATE**Level**

base

Description

Get/set the status of the LDAP server

History

State token appears in 3.0.0

Usage

```
[domainname=<domain>] State=[On|Off]
```

Returns

The state of the server

Remark

Changing state need admin and modify level

Example

```
CONFIG LDAP STATE state=off
```

CONFIG LDAP UPDATE**Level**

admin,modify

Description

Update the LDAP configuration

History

```
realbind and FullAdminDN appear in 3.0.0  
protectchars removed in 3.4.0
```

Usage

internal LDAP:

```
[domainname=<domain>] [HASH=<hash>] [FWCA=<fwca>] [FirewallID=<firewallid>]  
[nestedgroups=0|1]
```

external LDAP:

```
[domainname=<domain>] [HASH=<hash>] [FWCA=<fwca>] [FirewallID=<firewallid>]
```



```
[basedn=<Base DN>] [host=<Host IP>] [port=<Port>] [backuphost=<host IP>]
[backupport=<Port>]]
[user=<LDAP User> [password=<LDAP password>]] [auth=Simple|SSL] [cacert=<certname>]
[usersdn=<users dn>] [serversdn=<servers dn>] [groupsdn=<groups dn>] [confdn=<config
dn>]
[usersfilter=<LDAP filter for users>] [serversfilter=<LDAP filter for servers>]
[groupsfilter=<LDAP filter for groups>] [cndn=0|1] [ReadOnly=<0|1>]
[groupschema=groupofmember|posixgroup] [realbind=on|off] [realbindaddr=<IP>]
[FullAdminDN=0|1]
[nestedgroups=0|1]
```

Returns

Error code

Remark

method and hash are method used for a new user.

fwca is the path of the CA certificat (Only in an EXTERNAL LDAP database)

FirewallID update does NOT updates LDAP existing objects !

Example

CONFIG LDAP UPDATE hash=SSHA

CONFIG LDAP UPDATE fwca="cn=authority, ou=cas, o=stormshield, dc=eu"

CONFIG LDAP UPDATE FWID=Main_Firewall

CONFIG LDAP UPDATE domainname=ororo.munroe realbind=0

CONFIG LDAP USAGE

Level

base

History

Appears in 3.0.0

Description

Verify that the given LDAP is in use within the conf

Usage

name=<domain>

Returns

Error code

Example

CONFIG LDAP USAGE name="my_ldap"

Format

section_line

CONFIG LOG

Level

base

Description



Configure logs.

CONFIG LOG ACTIVATE

Level

log,modify

History

Syslog removed in 3.0.0 CANCEL appears in Netasq 6.0.0

NEXTBOOT appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Reload logd configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next reboot.

Returns

Error code

Example

CONFIG LOG ACTIVATE

CONFIG LOG ALARM

Level

log,modify

History

BlockOverflow appears in Netasq 6.1.0

BlockOverflow moved to CONFIG ASQ LOG ALARM in Netasq 9.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure alarm log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [Delay=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example



CONFIG LOG ALARM Full=1 MaxSize=13 Delay=3

CONFIG LOG AUTH

Level

log,modify

History

Full appears in Netasq 6.0.0

MaxSize appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure authentication log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG AUTH full=0 maxsize=10

CONFIG LOG AUTH full=0 maxsize=10

CONFIG LOG COMMUNICATION

Level

base

Description

Specify if logs are sent via SMTP and/or SNMP.

CONFIG LOG COMMUNICATION EMAIL

Level

log,modify

History

Appears in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Specify if logs are sent by email, and specify the email recipient

Usage

Event={sysevent|asq} State={0|1} [SendMinor={0|1}] [MailGroup=<Mail_Group_Name>]

**Returns**

Error code

Example

```
CONFIG LOG COMMUNICATION EMAIL Event=asq State=0 SendMinor=1 MailGroup=MyMailGroup
```

CONFIG LOG COMMUNICATION SNMP**Level**

log,modify

History

Appears in Netasq 8.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Specify which logs are sent via SNMP (based on log level and type).

Usage

```
Event={sysevent|asq} State={0|1} [SendMinor={0|1}]
```

Returns

Error code

Example

```
CONFIG LOG COMMUNICATION SNMP Event=asq State=0 SendMinor=1
```

CONFIG LOG CONNECTION**Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure connection log.

Usage

```
[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]
```

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

```
CONFIG LOG CONNECTION FULL=0 MAXSIZE=20
```



CONFIG LOG FILTER

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure filter log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG FILTER Full=1 MaxSize=13

CONFIG LOG FTP

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure FTP proxy log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG FTP Full=1 MaxSize=15



CONFIG LOG MONITOR

Level

log,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure statistical monitoring log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG MONITOR full=0 maxsize=12

CONFIG LOG MONITOR full=2 maxsize=12

CONFIG LOG PCAP

Level

log,modify

History

Appears in 4.3

Description

Configure PCAP log.

Usage

[MaxSize=<Integer>] [State={0|1}]

where:

- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG PCAP state=1 maxsize=12



CONFIG LOG PLUGIN

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure ASQ Plugins log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG PLUGIN Full=1 MaxSize=12

CONFIG LOG POP3

Level

log,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure Pop3 proxy log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example



CONFIG LOG POP3 Full=0 MaxSize=10

CONFIG LOG PVM

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure PVM log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG PVM Full=0 MaxSize=12

CONFIG LOG ROUTERSTAT

Level

log,modify

History

Appears in 4.3

Renamed in 4.3.x

Description

Configure routerstat statistics log.

Usage

[MaxSize=<Integer>] [State={0|1}]

where:

- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG ROUTERSTAT state=1 maxsize=12



CONFIG LOG SANDBOXING

Level

log,modify

History

Appears in 2.3.0

Description

Configure sandboxing proxy log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG SANDBOXING Full=2 MaxSize=14

CONFIG LOG SERVER

Level

log,modify

History

Full appears in Netasq 6.0.0

MaxSize appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure server log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG SERVER full=0 maxsize=2



CONFIG LOG SHOW

Level

base

History

Output changed in Netasq 7.0.0 to take the email groups into account.
nat statistic disappears in Netasq 9.0.0

Description

Dump the log configuration.

Returns

```
[EmailSysEvent]
State=1
SendMinor=1
MailGroup=AdminsSys
[EmailASQ]
State=1
SendMinor=1
MailGroup=AdminSecu
[LogConnection]
Full=1
MaxSize=25
Udp=1
[LogSystem]
Full=0
MaxSize=2
[LogAlarm]
Full=0
MaxSize=40
Delay=0
[LogWeb]
Full=1
MaxSize=10
[LogPlugin]
Full=0
MaxSize=15
[LogSmtP]
Full=0
MaxSize=8
[LogFilter]
Full=2
MaxSize=5
[LogVPN]
Full=1
MaxSize=5
[LogXVPN]
Full=0
MaxSize=5
[LogMonitor]
Full=0
MaxSize=1
[LogPvm]
Full=0
```



MaxSize=10
[Statistic]
Filter=15m
Count=15m
[LogSsl]
Full=0
MaxSize=4

Example

CONFIG LOG SHOW

CONFIG LOG SMTP

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0
state appears in Netasq 9.0.0
Syslog removed in 3.0.0

Description

Configure SMTP proxy log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG SMTP Full=0 MaxSize=12

CONFIG LOG SSL

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0
Appears in Netasq 9.0.0
Syslog removed in 3.0.0

Description

Configure SSL proxy log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:



- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

CONFIG LOG SSL Full=2 MaxSize=14

CONFIG LOG STAT

Level

log,modify

History

monitor Appears in Netasq 6.1.0

nat disappears in Netasq 9.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

monitor disappears in 3.0.0

Description

Configure the filter statistics.

Usage

[filter=<string>] [count=<string>]

Returns

Error code

Example

CONFIG LOG STAT filter=1d count=30m

CONFIG LOG SYSTEM

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure system log.

Usage

[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.



- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

```
CONFIG LOG SYSTEM Full=1 MaxSize=12
```

CONFIG LOG VPN

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure VPN log.

Usage

```
[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]
```

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

```
CONFIG LOG VPN Full=1 MaxSize=5
```

CONFIG LOG WEB

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure Web proxy log.

Usage

```
[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]
```

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;



- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

```
CONFIG LOG WEB Full=2 MaxSize=14
```

CONFIG LOG XVPN

Level

log,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

state appears in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Configure VPN-SSL log.

Usage

```
[Full={0|1|2}] [MaxSize=<Integer>] [State={0|1}]
```

where:

- Full=0 means that log files rotate when they are full;
- Full=1 means that no more log is written when log files are full;
- Full=2 means that the firewall is halted when log files are full.
- MaxSize is the percentage of these logs among all logs (the sum of all MaxSizes must be 100).

Returns

Error code

Example

```
CONFIG LOG XVPN full=0 maxsize=12
```

```
CONFIG LOG XVPN full=2 maxsize=12
```

CONFIG MAILFILTERING

Level

base,contentfilter

History

Appears in Netasq 9.0.0

Description

MAIL rules and profile files management

CONFIG MAILFILTERING ACTIVATE

Level



contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Activate : Copy all clones in real profiles.

Usage

[CANCEL]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

Example

```
CONFIG MAILFILTERING ACTIVATE  
CONFIG MAILFILTERING ACTIVATE cancel
```

CONFIG MAILFILTERING COPY

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Copy profile X to Y

Usage

index=<profile_idx> to=<profile_idx>

Returns

Error code

Example

```
CONFIG MAILFILTERING COPY index=2 to=3
```

CONFIG MAILFILTERING DEFAULT

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Set profile X with the default rules

Usage

index=<profile_idx>

Returns



Error code

Example

CONFIG MAILFILTERING DEFAULT index=9

CONFIG MAILFILTERING LIST**Level**

base

History

Appears in Netasq 9.0.0

Description

List the specified profile of MAIL filtering rules. If profile is not specified, then list all the profiles.

Usage

[index=<profile_idx>]

Returns

Error code

Example

[index]
name=<policy_name>
lastmod=<last modified date>
comment=blabla

CONFIG MAILFILTERING RULE**Level**

base,contentfilter

History

Appears in Netasq 9.0.0

Description

Manage mailfiltering rules of a profile

CONFIG MAILFILTERING RULE INSERT**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Insert new rule at given line or Insert at the end if no ruleid is defined.

Usage

index=<profile_idx> [ruleid=<digit>] state=on|off action=pass|block from=<sender>
to=<recipient> [comment=<string>]
Insert at the end if no ruleid is defined.



state : enable or disable the rule
index : profile number
ruleid : rule line number
action : action to apply
from : address mail of the sender
to : address mail of the recipient
comment : comment for the rule

Returns

Error code

Remark

ruleid : insert a rule before the line index 'ruleid'

Example

```
CONFIG MAILFILTERING RULE INSERT index=0 ruleid=3 action=pass from=*@stormshield.eu  
to=* comment="Pass all mail from STORMSHIELD"
```

```
CONFIG MAILFILTERING RULE INSERT index=0 ruleid=3 action=block from=*@*spam.com to=*
```

CONFIG MAILFILTERING RULE MOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Move rule from a line to another line

Usage

```
index=<profile_idx> ruleid=<digit> to=<digit>
```

index : profile number

ruleid : rule line number to move from

to : rule line number to move to

Example

```
CONFIG MAILFILTERING RULE MOVE index=0 ruleid=2 to=3
```

CONFIG MAILFILTERING RULE REMOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Remove a rule.

Usage

```
config=<profile_idx>
```

index : profile number

ruleid : {all|<digit>}

Example

```
CONFIG MAILFILTERING RULE REMOVE index=0 ruleid=3
```



CONFIG MAILFILTERING RULE SHOW

Level

contentfilter

History

Appears in Netasq 9.0.0

Description

Show all rules of a profile.

Usage

index=<profile_idx>

Returns

index=<profile_idx> [ruleid=<digit>] state=on|off action=pass|block from=<sender>
to=<recipient> [comment=<string>]

Format

section_line

Example

```
CONFIG MAILFILTERING RULE SHOW index=9
101 code=00a01000 msg="Begin" format="section_line"
ruleid=1 state=on action=pass from="*@stormshield.eu" to="*" comment="bla bla bla ..."
ruleid=2 state=on action=block from="*@spam*" to="*" comment=""
100 code=00a01000 msg="Ok"
```

CONFIG MAILFILTERING RULE UPDATE

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Modify a rule in configuration file at given line.

Usage

index=<profile_idx> ruleid=<digit> [state=on|off] [action=pass|block] [from=<sender>]
[to=<recipient>] [comment=<string>]
state : enable or disable the rule
index : profile number
ruleid : rule line number
action : action to apply
from : address mail of the sender
to : address mail of the recipient
comment : comment for the rule

Example

```
CONFIG MAILFILTERING RULE UPDATE index=0 ruleid=3 action=block
CONFIG MAILFILTERING RULE UPDATE index=0 ruleid=3 to="*@stormshield.eu"
```



CONFIG MAILFILTERING UPDATE

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Change name and comment of profile X

Usage

index=<profile_idx> [name=<profile name>] [comment=<profile description>]

Returns

Error code

Example

CONFIG MAILFILTERING UPDATE index=9 name="pass all" comment="Just a pass all"

CONFIG MODEM

Level

base

History

Appears in 2.5.0

Description

Commands to configure the modems

CONFIG MODEM ACTIVATE

Level

maintenance,modify

History

Appears in 2.5.0

Description

Activates the modem configuration

Usage

[CANCEL]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

Example

CONFIG MODEM ACTIVATE
CONFIG MODEM ACTIVATE CANCEL



CONFIG MODEM SHOW

Level

base

History

Appears in 2.5.0

Description

Show the specified modem. If index is not specified, then list all the modems.

Usage

[index=<modem_idx>]

Returns

[index]

State : The modem state

Name : The modem user name

Model : The modem model

VendorId : The modem vendor id (hexa)

ProductIdInit : The modem product initialization id (hexa)

ModeSwitchString: An hexa string to switch the device from a disk storage to a modem device

ProductId : The modem product id (hexa)

CommandPort : The modem command port

MonitoringPort : The modem monitoring port

InitString1 : The modem initialization string 1

InitString2 : The modem initialization string 2

InitString3 : The modem initialization string 3

Example

CONFIG MODEM SHOW index=0

CONFIG MODEM UPDATE

Level

maintenance,modify

History

Appears in 2.5.0

Description

Configure a modem

Usage

Index=<modem_idx> [State={1|0}] [Name=<modem user name>] [Model={<string>|""}]

[VendorId={<hex string>|""}] [ProductIdInit={<hex string>|""}]

[ModeSwitchString=<hex string>|""] [ProductId=<hex string>|""] [CommandPort=<integer>|""]

[MonitoringPort=<integer>|""]

[InitString1={<string>|""}] [InitString2={<string>|""}] [InitString3={<string>|""}]

where:

- Name is the user name of the modem (may be the operator name)

- Model is the string which represents the model of the modem

Returns

Error code

**Example**

```
CONFIG MODEM UPDATE Index=0 State=1 Name="My 4G Operator" Model="My 4G Key Model"  
VendorId=01ab ProductId=08ff  
CONFIG MODEM UPDATE Index=0 State=0
```

CONFIG NETWORK**Level**

base

Description

Command to manage network

CONFIG NETWORK ACTIVATE**Level**

network,modify

Format

section_line

History

Appears in Netasq 6.0.0
Format appears in 4.0.0

Description

Checks network conf changes and activates all network configuration

Usage

[CANCEL|NEXTBOOT|RESET]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot;
- RESET: changes are activated immediately and resets the protected and activated interface.

Returns

Error code

Example

```
CONFIG NETWORK ACTIVATE  
CONFIG NETWORK ACTIVATE Reset  
CONFIG NETWORK ACTIVATE Cancel  
CONFIG NETWORK ACTIVATE Nextboot CACHE_CATEGORY objects
```

CONFIG NETWORK CHECK**Level**

base

Format

section_line

History



Appears in 4.0.0

Description

Checks network configuration

Usage

[useclone=0|1]

Returns

List of errors or warnings about network configuration

Example

```
[Check] type=error code=6 interface=vlan2 msg="This VLAN has no physical interface"
type=error code=7 interface=dialup0 msg="This PPPoE dialup has no physical interface"
type=error code=8 interface=dialup1 msg="This PPTP dialup has no modem IP" type=warning
code=2 interface=bridge0 msg="The Bridge 'bridge0' is composed of 0 interface" value=0
```

CONFIG NETWORK DEFAULTROUTE

Level

base

History

Appears in 2.0.0

Description

Commands to manage default route

CONFIG NETWORK DEFAULTROUTE ACTIVATE

Level

route,modify

History

Appears in 2.0.0

Description

Apply default route configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG NETWORK DEFAULTROUTE ACTIVATE

CONFIG NETWORK DEFAULTROUTE SET

Level

route,modify

**History**

Appears in 2.0.0

name=blackhole appears in 4.3.21

Description

Set the default router for IPv4 or IPv6

Usage

name=<routername|host|blackhole|""> type={ipv4|ipv6}

Returns

Error Code

Example

CONFIG NETWORK DEFAULTROUTE SET type=ipv4 name=my_obj_router

CONFIG NETWORK DEFAULTROUTE SHOW**Level**

base

History

Appears in 2.0.0

Description

Show default routes

Returns

[Defaultroute]

IPv4=my_obj_router

IPv6=ipv6_gateway

CONFIG NETWORK GATEWAY**Level**

base

History

Appears in Netasq 7.0.0

Removed in 2.0.0

Description

Command to manage gateways

CONFIG NETWORK GATEWAY ACTIVATE**Level**

route,modify

History

Appears in Netasq 7.0.0

Removed in 2.0.0

Description

Flush and reload gateways configuration

**Usage**

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG NETWORK GATEWAY ACTIVATE

CONFIG NETWORK GATEWAY ADD**Level**

route,modify

History

Appears in Netasq 7.0.0

Check Appears in 7.0.4

Force appears in Netasq 9.0.2

Force deprecated in Netasq 9.0.5

Removed in 2.0.0

Description

Add a new gateway in the corresponding list (principal or backup)

Usage

Host=<Host> Type=[PrincipalGateway|BackupGateway]

[Check=<Host|Group>] [pos=<position> (default: end of list)] [comment=<comment>]

Returns

Error Code

Example

CONFIG NETWORK GATEWAY ADD Host=HOST_ROUTER_NEXT_2 Type=PrincipalGateway
Check=HOST_BEHIND_ROUTER_NEXT_2

CONFIG NETWORK GATEWAY IPV6**Level**

base

History

Appears in Netasq 9.0.1

Removed in 2.0.0

Description

Command to manage IPv6 gateway

CONFIG NETWORK GATEWAY IPV6 ADD**Level**

route,modify

History



Appears in Netasq 9.0.1
Type, Check, Pos and Comment appear in 1.0.0
Removed in 2.0.0

Description

Add an IPv6 gateway

Usage

Host=<Host> Type={PrincipalGateway|BackupGateway}
[Check=<Host|Group>] [pos=<position> (default: end of list)] [comment=<comment>]

Returns

Error code

CONFIG NETWORK GATEWAY IPV6 REMOVE**Level**

route,modify

History

Appears in Netasq 9.0.1
Host and Type appear in 1.0.0
Removed in 2.0.0

Description

Remove an IPv6 gateway

Usage

Host={<Host>|Any} Type={PrincipalGateway|BackupGateway}

Returns

Error code

CONFIG NETWORK GATEWAY IPV6 SET**Level**

route,modify

History

Appears in 1.0.0
Removed in 2.0.0

Description

Change IPv6 gateway configuration

Usage

[Tries=<int>] [Wait=<seconds>] [Frequency=<seconds>] [GatewayThreshold=<int>]
[ActivateallBackup={on|off}]

Returns

Error Code

Example

CONFIG NETWORK GATEWAY IPV6 SET Tries=1 Wait=5 Frequency=10 GatewayThreshold=3
ActivateallBackup=On

CONFIG NETWORK GATEWAY IPV6 SHOW**Level**



base

History

Appears in Netasq 9.0.1
Format changes in 1.0.0
Removed in 2.0.0

Description

Show IPv6 gateways and their configuration

Format

section_line

Returns

[Config]

State=1

GatewayThreshold=1

Tries=3

Wait=5

Frequency=60

ActivateAllBackup=0

[PrincipalGateway]

Pos=1 Host=Host_Default_IPv6Router Check=Host_Behind_Default_Router Comment="default"

Pos=2 Host=Host_Router_Next Comment=""

[BackupGateway]

Pos=1 Host=Host_Bkp_Router Comment=""

Pos=2 Host=Host_Bkp_Router_Next Comment=""

CONFIG NETWORK GATEWAY IPV6 UPDATE

Level

route,modify

History

Appears in 1.0.0
Removed in 2.0.0

Description

Update a gateway in the list

Usage

pos=<position nb> type=[PrincipalGateway|BackupGateway]
[Host=<Host>] [Check=<Host|Group>] [comment=<comment>]

Returns

Error Code

Example

CONFIG NETWORK GATEWAY IPV6 UPDATE pos=3 type=PrincipalGateway Host=HOST_ROUTER_NEXT_2

CONFIG NETWORK GATEWAY REMOVE

Level

route,modify

**History**

Appears in Netasq 7.0.0

Removed in 2.0.0

Description

Remove a gateway anywhere in the list

Usage

Host=[<Host>|Any] Type={PrincipalGateway|BackupGateway}

Returns

Error Code

Example

CONFIG NETWORK GATEWAY REMOVE Host=HOST_ROUTER_NEXT_2 Type=PrincipalGateway

CONFIG NETWORK GATEWAY SET**Level**

route,modify

History

Appears in Netasq 7.0.0

State deprecated in Netasq 9.1.0

Removed in 2.0.0

Description

Change gateway configuration

Usage

[Tries=<int>] [Wait=<seconds>] [Frequency=<seconds>] [GatewayThreshold=<int>]
[ActivateallBackup={on|off}]

Returns

Error Code

Example

CONFIG NETWORK GATEWAY SET Tries=1 Wait=5 Frequency=10 GatewayThreshold=3
ActivateallBackup=On

CONFIG NETWORK GATEWAY SHOW**Level**

base

History

Appears in Netasq 7.0.0

Check Appears in 7.0.4

Removed in 2.0.0

Description

Show complete gateway configuration

Format

section_line

Returns



```
[Config]
State=1
GatewayThreshold=1
Tries=3
Wait=5
Frequency=60
ActivateAllBackup=0

[PrincipalGateway]
Pos=1 Host=Host_Default_Router Check=Host_Behind_Default_Router Comment="default"
Pos=2 Host=Host_Router_Next Comment=""

[BackupGateway]
Pos=1 Host=Host_Bkp_Router Comment=""
Pos=2 Host=Host_Bkp_Router_Next Comment=""
```

CONFIG NETWORK GATEWAY UPDATE

Level

route,modify

History

Force appears in Netasq 9.0.2
Force deprecated in Netasq 9.0.5
Removed in 2.0.0

Description

Update a gateway in the list

Usage

```
pos=<position nb> type=[PrincipalGateway|BackupGateway]
[Host=<Host>] [Check=<Host|Group>] [comment=<comment>]
```

Returns

Error Code

Example

```
CONFIG NETWORK GATEWAY UPDATE pos=3 type=PrincipalGateway Host=HOST_ROUTER_NEXT_2
```

CONFIG NETWORK INTERFACE

Level

base

History

Appears in Netasq 6.0.0

Description

Commands to manage interfaces

CONFIG NETWORK INTERFACE ACTIVATE

Level

network,modify

Format



section_line

History

Appears in Netasq 6.1.0

Format appears in 4.0.0

Description

Checks network conf changes and activates interfaces configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG NETWORK INTERFACE ACTIVATE

CONFIG NETWORK INTERFACE ACTIVATE Cancel

CONFIG NETWORK INTERFACE ACTIVATE Nextboot CACHE_CATEGORY objects

CONFIG NETWORK INTERFACE ADDRESS

Level

base

History

Appears in Netasq 6.0.0

Description

Commands to manage interfaces addresses

CONFIG NETWORK INTERFACE ADDRESS ADD

Level

network,modify

History

Appears in Netasq 6.0.0

RequestDNS Appears in Netasq 6.1.0

DHCPVendorClassId, DHCPUserClass, DHCPAuthsend appear in 4.1.0

Description

Add an address/mask to an interface

Usage

ifname=<interface name> [address=<address> mask=<mask>

[addresscomment=<comment>]

| address=DHCP [dhcpleasetime=<lease time>] [DHCPHostName=<name>]

[DHCPVendorClassId=<DHCP vendor class identifier>] [DHCPUserClass=<DHCP user class>]

[DHCPAuthsend=<DHCP authsend>] [RequestDNS=<0|1>]]

Returns

Error code

Remark



All existing interface addresses and all existing DHCP options will be deleted if address=DHCP specified

Mask must not be specified if address=DHCP

DHCP options will NOT be parsed if address=DHCP is not specified (even if already in DHCP mode)

Example

```
CONFIG NETWORK INTERFACE ADDRESS ADD ifname=bridge5 address=192.168.1.1
mask=255.255.255.0
CONFIG NETWORK INTERFACE ADDRESS ADD ifname=bridge5 address=192.168.1.1
mask=255.255.255.0 addresscomment="My Address"
CONFIG NETWORK INTERFACE ADDRESS ADD ifname=bridge5 address=DHCP
DHCPLeaseTime=3600 DHCPHostname=stormshield
CONFIG NETWORK INTERFACE ADDRESS ADD ifname=GreTun0 address=192.168.1.1
mask=255.255.255.252
```

CONFIG NETWORK INTERFACE ADDRESS REMOVE**Level**

network,modify

History

Appears in Netasq 6.0.0

Description

Remove an address/mask to an interface

Usage

ifname=<interface name> address=<address>

Returns

Error code

Remark

Addresses with an higher number will be updated (address5=>address4, etc...).

Example

```
CONFIG NETWORK INTERFACE ADDRESS REMOVE ifname=bridge5 address=192.168.1.1
```

CONFIG NETWORK INTERFACE ADDRESS UPDATE**Level**

network,modify

History

Appears in Netasq 6.0.0

Description

Update an address/mask of an interface

Usage

ifname=<interface name> [refaddress=<old address> | addrnb=<index>] address=<new address> mask=<new mask> [addresscomment=<comment>]

Returns

Error code

Remark



Only "real" addresses are allowed. DHCP mode must be set with CONFIG NETWORK INTERFACE ADDRESS ADD command.

Example

```
CONFIG NETWORK INTERFACE ADDRESS UPDATE ifname=bridge5 refaddress=192.168.1.1
address=192.168.1.2 mask=255.255.255.128
CONFIG NETWORK INTERFACE ADDRESS UPDATE ifname=bridge5 refaddress=192.168.1.1
address=192.168.1.2 mask=255.255.255.128 addresscomment="My Address"
CONFIG NETWORK INTERFACE ADDRESS UPDATE ifname=GreTun0 addrnb=0
address=192.168.1.2 mask=255.255.255.252
```

CONFIG NETWORK INTERFACE AGGREGATE**Level**

network,modify

History

Appears in 1.0.0

Laggmode appears in 4.3.0

Description

Create an Agg interface from an Ethernet interface

Usage

```
ifname=<Ethernet or Gretap interface name>
[Laggmode={lacp|failover}]
```

Returns

The new section for the Ethernet or Gretap interface

Example

```
[Ethernet1]
State=1
Name=Ethernet_1
Media=0
Color=408080
Agg=agg1
```

CONFIG NETWORK INTERFACE CAPABILITIES**Level**

base

History

Appears in 9.0.4

Description

Indicates what the interfaces are capable of.

Returns

For each interface, indicates a list of capabilities.

Format

list

Example



[Ethernet1]

[Ethernet2]
EEE

CONFIG NETWORK INTERFACE CHECK

Level

network

History

Appears in Netasq 6.2.0

Format Appears in Netasq 9.0.0

Description

Checks all generated objects for an interface

Usage

ifname=<interface name> [IgnoreGeneratedGroupMembership={0|1}]

Remark

if parameter IgnoreGeneratedGroupMembership is set to 1 (default is 0) the usage of the interface through generated groups (Firewall_all, Network_internals) won't be returned

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>] index=<int>

Format

section_line

Example

CONFIG NETWORK INTERFACE CHECK ifname=bridge0

CONFIG NETWORK INTERFACE CREATE

Level

network,modify

History

Appears in Netasq 6.0.0

DHCPRequestGW and dialdefault deprecated in Netasq 7.0.0

Dialtype GPRS appears in Netasq 9.0.1

LocalARP (for bridges only) appears in 9.1.2

Interface Agg appears in 1.0.0

UseSTP, STPPriority, STPForwardDelay, STPMaxAgeTime and STPHelloTime (for bridges only) appear in 2.0.0

MSTConfigIDFormatSelector, MSTConfigName, MSTConfigRevision (for bridges only) appear in 2.0.0

GRETUN and GRETAP interface type appear in 2.0.0

USBETHERNET interface type appear in 3.2.0

Priority for VLANs appear in 3.3.0

MigrateRarp for bridged interfaces appears in 3.7.0

MigrateArp for bridged interfaces appears in 4.2.0



Laggmode appears in 4.3.0

LaggFailoverMaster appears in 4.3.0

Description

Create a new interface

Usage

```
ifname=<interface name> name=<username>
[comment=<comment>] [color=<color>] [type={0|1|2}]
[DynamicDNS=<existing DynDNS conf>] [if Address=DHCP]
+ specific mandatory/optional tokens=values for interface type
```

* PARAMETERS FOR VLAN, AGG AND GRETAP INTERFACES:

```
Protected={0|1}
[Address=<IPv4 address>|DHCP] [Mask=<IPv4 mask>]]
[IPv6Address=<IPv6 address>|DHCP|SLAAC> [IPv6Mask={1-128} [eui64={0|1}]]]
[gateway=<gateway>] [State={0|1}] [Bridge=<bridge name>]
[FastRoute={0|1} [KeepVLANID={0|1}]] [if interface is in a bridge]
[MigrateRarp={0|1}] [if interface is in a bridge]
[MigrateArp={0|1}] [if interface is in a bridge]
[ForwardIPX={0|1}] [if interface is in a bridge]
[ForwardNetbios={0|1}] [if interface is in a bridge]
[ForwardAppletalk={0|1}] [if interface is in a bridge]
[ForwardPPPoE={0|1}] [if interface is in a bridge]
[ForwardIPv6={0|1}] [if interface is in a bridge]
[ForwardCustomLLC=0-65535[,0-65535]*] [if interface is in a bridge]
[ForwardCustomEther=0-65535[,0-65535]*] [if interface is in a bridge]
[MTU={140-MTUmax}] [if interface is NOT in a bridge; MTUmax displayed by SYSTEM PROPERTY]
```

* PARAMETERS FOR VLAN INTERFACES:

```
Physical=<eth/vlan interface name> Tag={1-4094} [MaxThroughput=<int>]
[KeepVLANPriority={0|1}] [Priority={0-7}]
```

* PARAMETERS FOR AGG INTERFACES:

```
Interfaces=<list of aggregated ethernet interfaces>
[Laggmode={lacp|failover}]
[MACAddress=xx:xx:xx:xx:xx:xx] [if agg is NOT in a bridge]
```

* PARAMETERS FOR ETHERNET INTERFACES:

```
[LaggFailoverMaster={0|1}] [if interface is in a failover Agg]
```

* PARAMETERS FOR GRETAP INTERFACES:

```
LocalTunnel=<Firewall_XXX object>
RemoteTunnel=<Host object>
[MACAddress=xx:xx:xx:xx:xx:xx] [if gretap is NOT in a bridge]
[LaggFailoverMaster={0|1}] [if interface is in a failover Agg]
```

* PARAMETERS FOR BRIDGE INTERFACES:

```
Interfaces=<list of bridged interfaces> [Address=<IPv4 address>|DHCP] [Mask=<IPv4 mask>]]
[IPv6Address=<IPv6 address>|DHCP|SLAAC> [IPv6Mask={1-128}] [eui64={0|1}]]
[MACAddress=xx:xx:xx:xx:xx:xx] [AddressComment=<comment>] [gateway=<gateway>]
[LocalARP={0|1}]
[UseSTP={0|1|2}] [STPPriority={0-61440 step 4096}] [STPForwardDelay={4-30}]
[STPMaxAgeTime={4-30}] [STPHelloTime={1-10}]
[MSTConfigIdFormatSelector={0-255}] [MSTConfigName=<str>] [MSTConfigRevision={0-
```



```
65535]]  
[MaxThroughput=<int>  
[MTU={140-MTUmax}] (MTUmax is displayed by SYSTEM PROPERTY)
```

* PARAMETERS FOR DIALUP INTERFACES:

```
DialAuthName=<login> DialAuthKey=<passwd> DialMode={ddial|auto} DialType=  
(PPP|L2TP|PPTP|PPPoE|GPRS)  
[State={0|1}] [RequestDNS={0|1}] [DynamicDNS=<existing DynDNS conf>] [DialIdle=<int>]  
[MaxThroughput=<int>  
DialType=PPP DialPhone=<dial number> [DialString=<dial string>]  
DialType=L2TP DialL2TPLNS=<server> [DialL2TPSecret=<passwd>]  
[DialL2TPBackupLNS=<server>] [DialL2TPRedialTimeout=<int>] [DialL2TPMaxRedial=<int>]  
[DialL2TPLengthBit={0|1}] [DialL2TPHiddenAVP={0|1}] [DialL2TPChallengeAuth=<int>]  
DialType=PPTP DialModemIP=<ip>  
DialType=PPPoE DialInterface=<eth/vlan interface username> [DialService=<service>]  
DialType=GPRS DialPhone=<dial number> DialAPN=<string> DialDefPeer=<IP>  
[DialAPNum=<int>] [DialSimPin=<PIN code>] [DialSimWait=<int>] [DialModem=<string>]
```

* PARAMETERS FOR LOOPBACK AND IPSEC INTERFACES:

```
[State=<0|1>  
[Protected=<0|1>  
[Address=<IPv4 address> Mask=<IPv4 mask>  
[IPv6Address=IPv6 address IPv6Mask={1-128}]  
[MTU={140-16384}]
```

* PARAMETERS FOR GRETUN INTERFACES:

```
[State=<0|1>  
[Protected=<0|1>  
[Address=<IPv4 address> Mask=<IPv4 mask>  
[IPv6Address=IPv6 address IPv6Mask={1-128}]  
LocalTunnel=<Firewall_XXX object>  
RemoteTunnel=<Host object>  
[MTU={140-16384}]
```

* PARAMETERS FOR WIFI INTERFACES:

```
ifname=<interface name> name=<username>  
SSID=<ssid name> (only printable characters, at least 5 characters and at max 31 characters  
long)  
[WPA=<0|1|2>] (0 = open, 1 = wpa1, 2 = wpa2)  
[Aplsolate=<0|1>  
[PassPhrase=<passphrase>] (when wpa = <1|2>, only printable characters, at least 8  
characters and at max 63 characters long)  
[color=<color>] [type={0|1|2}]  
[State=<0|1>  
[Protected=<0|1>  
[Address=<IPv4 address> Mask=<IPv4 mask>] [IPv6Address=IPv6 address IPv6Mask={1-  
128}] | [Bridge=<bridge name>] (maximum 1 wifi interface per bridge)  
[gateway=<gateway>  
[MTU={140-7951}]
```

* PARAMETERS FOR USBETHERNET INTERFACES:

```
ifname=<interface name> name=<username>  
[State=<0|1>  
[Address={<IPv4 address>|DHCP} [Mask=<IPv4 mask>]]
```



[Protected=<0|1>]

Returns

Error code

Example

```
CONFIG NETWORK INTERFACE CREATE ifname=Vlan0 Name=VLANNetwork Address=DHCP
DHCPLeaseTime=3600 Tag=123 MTU=1496 Physical=Ethernet1 Color=C0C0C0 Protected=1
Type=0 Comment="VLAN Network"
CONFIG NETWORK INTERFACE CREATE ifname=bridge0 Name=Bridge Address=192.168.1.1
Mask=255.255.255.0 Interfaces=Ethernet0,VLANNetwork
CONFIG NETWORK INTERFACE CREATE ifname=dialup0 Name=Test DialAuthName=test
DialAuthKey=test DialMode=auto DialType=L2TP DialL2TPLNS=lns_host DialL2TPSecret=secret
DialL2TPBackupLNS=bckp_lns_host
CONFIG NETWORK INTERFACE CREATE ifname=Loopback1 Name=TunnelAg1
Address=192.168.255.254 Mask=255.255.255.255 IPv6Address=fc00::4 IPv6Mask=128
MTU=1400
CONFIG NETWORK INTERFACE CREATE ifname=GreTun0 Name=TunGreHQ
Address=192.168.255.254 RemoteAddress=172.31.128.254 IPv6Address=fc00::5 MTU=1400
LocalTunnel=Firewall_out RemoteTunnel=Peer
CONFIG NETWORK INTERFACE CREATE ifname=GreTap0 Name=VPNBRIDGE
Address=192.168.255.254 Mask=255.255.255.255 IPv6Address=fc00::4 IPv6Mask=128
MTU=1400 LocalTunnel=Firewall_out RemoteTunnel=Peer
CONFIG NETWORK INTERFACE CREATE ifname=usbethernet0 Name=MyUsbModem
Address=192.168.8.2 Mask=255.255.255.0 Protected=0 Comment="4G USB modem"
```

CONFIG NETWORK INTERFACE IPSEC**Level**

network,modify

History

Appears in Netasq 9.0.0

Description

Set the default ipsec networks as internal or not

Usage

protected=<0|1>

Returns

Error code

Remark

This command replaces old "InternalPeers" token used in VPN configuration file.

CONFIG NETWORK INTERFACE IPV6**Level**

base

Description

Commands to manage IPv6 on interfaces

**CONFIG NETWORK INTERFACE IPV6 ADDRESS****Level**

base

History

Appears in Netasq 9.0.1

Description

Commands to manage IPv6 addresses on interfaces

CONFIG NETWORK INTERFACE IPV6 ADDRESS ADD**Level**

network,modify

History

Appears in Netasq 9.0.1

dhcpleasetime, DHCPHostName and RequestDNS appear in 1.0.0

Description

Add an IPv6 address to an interface

Usage

```
ifname=<interface name> [address=<IPv6 address> mask={1-128} [eui64={0|1}]]  
| address=<DHCP|SLAAC> [dhcpleasetime=<lease time>] [DHCPHostName=<name>]  
[RequestDNS=<0|1>]] [addresscomment=<comment>]
```

Returns

Error code

CONFIG NETWORK INTERFACE IPV6 ADDRESS REMOVE**Level**

network,modify

History

Appears in Netasq 9.0.1

Description

Remove an IPv6 address from an interface

Usage

```
ifname=<interface name> address=<IPv6 address>
```

Returns

Error code

CONFIG NETWORK INTERFACE IPV6 ADDRESS UPDATE**Level**

network,modify

History

Appears in Netasq 9.0.1

dhcpleasetime, DHCPHostName and RequestDNS appear in 1.0.0

Description

Update an IPv6 address of an interface

**Usage**

ifname=<interface name> [refaddress=<old address> | addrnb=<index>] [address=<new IPv6 address> mask={1-128} [eui64={0|1}]]
| address=<DHCP|SLAAC> [dhcpleasetime=<lease time>] [DHCPhostName=<name>]
[RequestDNS=<0|1>]] [addresscomment=<comment>]

Returns

Error code

CONFIG NETWORK INTERFACE IPV6 ROUTERADV**Level**

base

History

Appears in Netasq 9.0.1

Description

Commands to configure Router Advertisement

CONFIG NETWORK INTERFACE IPV6 ROUTERADV CONFIG**Level**

network,modify

History

Appears in Netasq 9.0.1

sendprefix and RouterPreference appear in 1.0.0

Description

Configure general parameters for Router Advertisement

Usage

ifname=<interface name> [state={on|off|auto}] [sendprefix={0|1}][MinInterval=<int>]
[MaxInterval={4-1800}] [CurHopLimit=<int>]
[ManagedFlag={0|1}] [OtherConfigFlag={0|1}] [RouterLifetime=<int>] [ReachableTime=<int>]
[RetransTimer=<int>]
[MTU=<int>] [RDNSSLifetime=<int>] [RDNSS1=<first dns ipv6 object>] [RDNSS2=<second dns
ipv6 object>]
[DNSSLLifetime=<int>] [DNSSL=<domain name>] [RouterPreference=""|low|medium|high|]

Remark

if SendPrefix is 0 or not specified, no prefix will be sent at all (even if some IPv6 prefixes are configured)

if RouterPreference is not specified or empty, the default router preference is medium

Returns

Error code

CONFIG NETWORK INTERFACE IPV6 ROUTERADV PREFIX**Level**

base

Description

Commands to configure IPv6 prefixes to advertise

**CONFIG NETWORK INTERFACE IPV6 ROUTERADV PREFIX ADD****Level**

network,modify

History

Appears in Netasq 9.0.1

Description

Add a prefix on interface

Usage

```
ifname=<interface name> address=<prefix address>  
[AutonomousFlag=0|1] [OnlinkFlag=0|1] [ValidLifetime=<seconds>]  
[PreferredLifetime=<seconds>] [comment=<comment>]
```

Returns

Error code

CONFIG NETWORK INTERFACE IPV6 ROUTERADV PREFIX REMOVE**Level**

network,modify

History

Appears in Netasq 9.0.1

Description

Remove a prefix on interface

Usage

```
ifname=<interface name> address=<prefix address>
```

Returns

Error code

CONFIG NETWORK INTERFACE IPV6 ROUTERADV PREFIX UPDATE**Level**

network,modify

History

Appears in Netasq 9.0.1

Description

Update a prefix on interface

Usage

```
ifname=<interface name> [refaddress=<address> | prefixnb=<index>] [address=<prefix  
address>] [AutonomousFlag=0|1] [OnlinkFlag=0|1]  
[ValidLifetime=<seconds>] [PreferredLifetime=<seconds>] [comment=<comment>]
```

Returns

Error code

CONFIG NETWORK INTERFACE LIMIT**Level**



base

Description

Commands to configure various limits related to network interfaces like number of vlans and ptps

CONFIG NETWORK INTERFACE LIMIT SHOW**Level**

base

History

Appears in Netasq 8.0.0

Description

Show interface network limits

Returns

One section for each kind interface limits

Example

```
CONFIG NETWORK INTERFACE LIMIT SHOW
[Interface]
ModelLimit=32
[Bridge]
ModelLimit=32
```

CONFIG NETWORK INTERFACE MSTI**Level**

base

History

Appears in 2.0.0

Description

Commands for Multiple Spanning Tree configuration

CONFIG NETWORK INTERFACE MSTI ADD**Level**

network,modify

History

Appears in 2.0.0

Description

Add a MSTI to bridge

Usage

```
ifname=<bridge name> mstinb=<MSTID index> MSTID=<comma separated list of VLAN tags>
[MSTIDPriority={0-61440 step 4096}]
```

Returns

Error code

CONFIG NETWORK INTERFACE MSTI REMOVE**Level**



network,modify

History

Appears in 2.0.0

Description

Remove a MSTI from a bridge

Usage

ifname=<bridge name> mstinb=<MSTID index>

Returns

Error code

CONFIG NETWORK INTERFACE MSTI UPDATE**Level**

network,modify

History

Appears in 4.0.0

Description

Update a bridge MSTI

Usage

ifname=<bridge name> mstinb=<MSTID index> [MSTID=<comma separated list of VLAN tags>]
[MSTIDPriority={0-61440 step 4096}]

Returns

Error code

CONFIG NETWORK INTERFACE REMOVE**Level**

network,modify

History

Appears in Netasq 6.0.0

Description

Remove an interface

Usage

ifname=<interface name> [force={0|1}]

Returns

Error code

Remark

Interfaces of the same type with an higher number will be updated (bridge6=>bridge5, etc.).
Parameter 'force' is useful only to remove a VLAN used by a PPPoE dialup.

Example

CONFIG NETWORK INTERFACE REMOVE ifname=bridge5



CONFIG NETWORK INTERFACE RENAME

Level

network,modify

History

Appears in Netasq 9.0.2

Description

Rename an interface

Usage

ifname=<interface name> name=<string>

Returns

Error code

Remark

Change is made immediately: there must be no clone file in use.

Example

```
CONFIG NETWORK INTERFACE RENAME ifname=dialup0 name=modem CACHE_CATEGORY
objects,route,filter
```

CONFIG NETWORK INTERFACE SHOW

Level

base

History

Appears in Netasq 6.0.0
useclone appears in 4.0.0

Description

Show interfaces' configurations

Usage

```
[useclone=<0|1>] [ifname=<interface name>|filter=<comma,separated,types,of,interfaces>]
- The filter accept the type: Bridge, Ethernet, Wifi, Vlan, Dialup, Agg, Ipsec, Loopback, Gretun,
Gretap, UsbEthernet
- by default, the filter is set to Bridge,Ethernet,Wifi,Vlan,Dialup,Agg,Gretap,UsbEthernet
```

Returns

One section for each interface, with its parameters

Example

```
CONFIG NETWORK INTERFACE SHOW filter=Bridge,Ethernet
[ethernet0]
...
[ethernet1]
...
[Bridge0]
...

CONFIG NETWORK INTERFACE SHOW ifname=ethernet0
[ethernet0]
Name="out"
```



```
State="1"  
Protected="0"  
Gateway=""  
Media="0"  
Type="0"  
Color="111111"  
Bridge="bridge0"  
comment="Out interface"
```

CONFIG NETWORK INTERFACE UPDATE

Level

network,modify

History

Appears in Netasq 6.0.0

Dialtype GPRS appears in Netasq 9.0.1

Name deprecated in Netasq 9.0.2: use CONFIG NETWORK INTERFACE RENAME instead

LocalARP (for bridges only) appears in Netasq 9.1.2

Interface Agg appears in 1.0.0

UseSTP, STPPriority, STPForwardDelay, STPMaxAgeTime and STPHelloTime (for bridges only) appear in 2.0.0

MSTConfigIDFormatSelector, MSTConfigName, MSTConfigRevision (for bridges only) appear in 2.0.0

GRETUN and GRETAP interface type appear in 2.0.0

USBETHERNET interface type appear in 3.2.0

Priority for VLANs appear in 3.3.0

MigrateRarp for bridged interfaces appears in 3.7.0

DHCPVendorClassId, DHCPUserClass, DHCPAuthsend appear in 4.1.0

MigrateArp for bridged interfaces appears in 4.2.0

Laggmode appears in 4.3.0

LaggFailoverMaster appears in 4.3.0

Description

Update an interface

Usage

```
ifname=<interface name> [comment=<comment>] [color=<color>]
```

```
[type={0|1|2}] [0=unknown, 1=machine, 2=server]
```

```
[name=<new name>] (works only if interface is not enabled)
```

* PARAMETERS FOR ETHERNET, AGG, VLAN and GRETAP INTERFACES:

```
[gateway=<gateway>] [Protected={0|1}] [State={0|1}] [Bridge=<bridge name>]
```

```
[FastRoute={0|1} [KeepVLANID={0|1}]] (if interface is in a bridge)
```

```
[MigrateRarp={0|1}] (if interface is in a bridge)
```

```
[MigrateArp={0|1}] (if interface is in a bridge)
```

```
[ForwardIPX={0|1}] (if interface is in a bridge)
```

```
[ForwardNetbios={0|1}] (if interface is in a bridge)
```

```
[ForwardAppletalk={0|1}] (if interface is in a bridge)
```

```
[ForwardPPPoE={0|1}] (if interface is in a bridge)
```

```
[ForwardIPv6={0|1}] (if interface is in a bridge)
```

```
[ForwardCustomLLC=0-65535[,0-65535]*] (if interface is in a bridge)
```

```
[ForwardCustomEther=0-65535[,0-65535]*] (if interface is in a bridge)
```

```
[MTU={140-MTUmax}] (MTUmax is displayed by SYSTEM PROPERTY)
```

```
[DynamicDNS=<existing DynDNS conf>] (if interface is NOT in a bridge and has Address=DHCP)
```



```
[DHCPLeaseTime=<new DHCP Lease Time>] [if interface has Address=DHCP]
[DHCPHostName=<new DHCP hostname>] [if interface has Address=DHCP]
[DHCPVendorClassId=<new DHCP vendor class identifier>] [if interface has Address=DHCP]
[DHCPUserClass=<new DHCP user class>] [if interface has Address=DHCP]
[DHCPAuthsend=<new DHCP authsend>] [if interface has Address=DHCP]
[RequestDNS={0|1}]
```

* PARAMETERS FOR ETHERNET INTERFACES:

```
[Media={0-11}]
[MaxThroughput=<int>]
[MACAddress=xx:xx:xx:xx:xx:xx] [if interface is NOT in a bridge and NOT in Agg]
[EEE={0|1}] [FlowControl={0|1}]
[LaggFailoverMaster={0|1}] [if interface is in a failover Agg]
```

* PARAMETERS FOR AGG INTERFACES:

```
[Interfaces=<list of aggregated interfaces>]
[Laggmode={lACP|failover}]
```

* PARAMETERS FOR VLAN INTERFACES:

```
[Physical=<eth/vlan interface name>] [Tag={1-4094}]
[MaxThroughput=<int>] [KeepVLANPriority={0|1}] [Priority={0-7}]
```

* PARAMETERS FOR BRIDGE INTERFACES:

```
[Interfaces=<list of bridged interfaces>] [MACAddress=xx:xx:xx:xx:xx:xx]
[Gateway=<gateway>]
[LocalARP={0|1}]
[UseSTP={0|1|2}] [STPPriority={0-61440 step 4096}] [STPForwardDelay={4-30}]
[STPMaxAgeTime={4-30}] [STPHelloTime={1-10}]
[MSTConfigIdFormatSelector={0-255}] [MSTConfigName=<str>] [MSTConfigRevision={0-65535}]
[MaxThroughput=<int>]
[MTU={140-MTUmax}] [MTUmax is displayed by SYSTEM PROPERTY]
[DynamicDNS=<existing DynDNS conf>] [if Address=DHCP]
[DHCPLeaseTime=<new DHCP Lease Time>] [if bridge has Address=DHCP]
[DHCPHostName=<new DHCP hostname>] [if bridge has Address=DHCP]
[DHCPVendorClassId=<new DHCP vendor class identifier>] [if interface has Address=DHCP]
[DHCPUserClass=<new DHCP user class>] [if interface has Address=DHCP]
[DHCPAuthsend=<new DHCP authsend>] [if interface has Address=DHCP]
[RequestDNS={0|1}]
```

* PARAMETERS FOR DIALUP INTERFACES:

```
[State={0|1}] [RequestDNS={0|1}] [DynamicDNS=<existing DynDNS conf>]
[MaxThroughput=<int>]
[DialAuthName=<login>] [DialAuthKey=<passwd>] [DialMode={ddial|auto}] [DialIdle=<int>]
[DialType=PPP [DialPhone=<dial number>] [DialString=<dial string>]]
[DialType=L2TP [DialL2TPLNS=<server>] [DialL2TPSecret=<passwd>]
[DialL2TPBackupLNS=<server>] [DialL2TPRedialTimeout=<int>] [DialL2TPMaxRedial=<int>]
[DialL2TPLengthBit={0|1}] [DialL2TPHiddenAVP={0|1}] [DialL2TPChallengeAuth=<int>]]
[DialType=PPTP [DialModemIP=<ip>]]
[DialType=PPPoE DialInterface=<eth/vlan interface username> [DialService=<service>]]
[DialType=GPRS DialPhone=<dial number> DialAPN=<string> [DialAPNum=<int>]
[DialDefPeer=<IP>] [DialSimPin=<PIN code>] [DialSimWait=<int>] [DialModem=<string>]]
```

* PARAMETERS FOR WIFI INTERFACES:



[SSID=<ssid name>] [only printable characters, at least 5 characters and at max 31 characters long]

[WPA=<0|1|2>] [0 = open, 1 = wpa1, 2 = wpa2]

[Apsolate=<0|1>]

[PassPhrase=<passphrase>] [when wpa = <1|2>, only printable characters, at least 8 characters and at max 63 characters long]

*** PARAMETERS FOR LOOPBACK AND IPSEC INTERFACES:**

[State=<0|1>]

[MTU={140-16384}]

[Protected=<0|1>]

[gateway=<gateway>]

[Address=<IPv4 address> Mask=<IPv4 mask>] [IPv6Address=IPv6 address IPv6Mask={1-128}]

*** PARAMETERS FOR GRETUN INTERFACES:**

[State=<0|1>]

[LocalTunnel=<Firewall_XXX object>]

[RemoteTunnel=<Host object>]

[MTU={140-16384}]

[Protected=<0|1>]

[Address=<IPv4 address> Mask=<IPv4 mask>] [IPv6Address=IPv6 address IPv6Mask={1-128}]

*** PARAMETERS FOR GRETAP INTERFACES:**

[State=<0|1>]

[MACAddress=xx:xx:xx:xx:xx:xx] [if interface is NOT in a bridge and NOT in Agg]

[MaxThroughput=<int>]

[LocalTunnel=<Firewall_XXX object>]

[RemoteTunnel=<Host object>]

[Protected=<0|1>]

*** PARAMETERS FOR USBETHERNET INTERFACES:**

[State=<0|1>]

[Protected=<0|1>]

Returns

Error code

Remark

Addresses (including DHCP and DHCP options, and SLAAC) must be updated via ADDRESS ADD and ADDRESS DEL

Dialup parameters specific to a dialtype will only be parsed if this dialtype is specified on the command

All addresses will be removed if a bridge is specified

All configuration (except Name, Color, State, Media and MaxThroughput) will be removed if an Agg is specified

Example

```
CONFIG NETWORK INTERFACE UPDATE ifname=bridge3 gateway=net_host2 color=AB12E3  
maxthroughput=1234567
```

```
CONFIG NETWORK INTERFACE UPDATE ifname=Dialup4 DialType="PPP"
```

```
DialPhone="0123456789" DialAuthName="name@provider"
```

```
CONFIG NETWORK INTERFACE UPDATE ifname=Dialup4 DialType="PPTP"
```

```
DialModemIP=10.2.9.223
```

```
CONFIG NETWORK INTERFACE UPDATE ifname=Dialup4 DialType="PPPoE" DialInterface=in
```



```
DialService="mod str"  
CONFIG NETWORK INTERFACE UPDATE ifname=Dialup4 DialType="L2TP" DialL2TPLNS="LNS1"  
DialL2TPChallengeAuth="1"  
CONFIG NETWORK INTERFACE UPDATE ifname=ethernet3 name="my_eth" color=AB12E3  
DynamicDNS="dyndns_network" state=1  
CONFIG NETWORK INTERFACE UPDATE ifname=vlan0 ForwardCustomLLC=5,0,65535  
ForwardPPPoE=1 ForwardIPv6=1  
CONFIG NETWORK INTERFACE UPDATE ifname=vlan3 tag=44 physical=ethernet3 name="my_vlan" gateway=10.2.9.10  
CONFIG NETWORK INTERFACE UPDATE ifname=Loopback1 Name=TunnelAg1 Address=192.168.255.254 Mask=255.255.255.255 IPv6Address=fc00::4  
IPv6Mask=128 MTU=1400  
CONFIG NETWORK INTERFACE UPDATE ifname=GreTun0 Name=TunGreHQ Address=192.168.255.254 RemoteAddress=172.31.128.254 IPv6Address=fc00::5 MTU=1400  
LocalTunnel=Firewall_out RemoteTunnel=Peer  
CONFIG NETWORK INTERFACE UPDATE ifname=GreTap0 Name=TapGreHQ Address=192.168.255.254 Mask=255.255.255.254 IPv6Address=fc00::5 MTU=1400  
LocalTunnel=Firewall_out RemoteTunnel=Peer MACAddress=50:60:70:80:90:a0  
CONFIG NETWORK INTERFACE UPDATE ifname=usbethernet0 Name=MyUsbModem Address=192.168.8.2 Mask=255.255.255.0  
CONFIG NETWORK INTERFACE UPDATE ifname=Vlan0 DHCPLeaseTime=5400 MTU=1514  
DHCPHostName=stormshield RequestDNS=0
```

CONFIG NETWORK IPV6

Level

base

Description

Commands for global IPv6 configuration

CONFIG NETWORK IPV6 STATE

Level

base

History

Appears in Netasq 9.0.1

Description

Change or display IPv6 activation state

Usage

[ON|OFF]

- no argument: display status
- ON: enables IPv6
- OFF: disables IPv6

Remark

Changing state requires levels network and modify

Returns

State=on|off or error code

Example



CONFIG NETWORK IPV6 STATE on
CONFIG NETWORK IPV6 STATE off
CONFIG NETWORK IPV6 STATE

CONFIG NETWORK ROUTE

Level

base

Description

Command to manage routing

CONFIG NETWORK ROUTE ACTIVATE

Level

route,modify

Description

Flush and reload routing configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

```
CONFIG NETWORK ROUTE ACTIVATE
CONFIG NETWORK ROUTE ACTIVATE Cancel
CONFIG NETWORK ROUTE ACTIVATE Nextboot CACHE_CATEGORY route,objects CACHE_CATEGORY_
CLONE route
```

CONFIG NETWORK ROUTE ADD

Level

route,modify

History

Appears in Netasq 6.0.0
option remote=default removed in Netasq 9.0.0
state appears in Netasq 9.1.0
ipsecBypass appears in 3.7.22
gateway=blackhole appears in 4.3.21

Description

Add an IPv4 static route

Usage

remote=<remote object> [interface={<ifname>|blackhole}] [gateway=<gateway>]
[color=<color>] [comment=<comment>] [state={0|1}] [ipsecBypass={0|1}]
ipsecBypass=1 : the destination network of the static route takes part in the IPSEC local bypass
if enabled in VPN slot (default: ipsecBypass=0)

**Returns**

Error code

Example

```
CONFIG NETWORK ROUTE ADD remote=net-remote-1 gateway=router1 interface=in color=acc0ac  
comment="route to remote network 1" CACHE_CATEGORY_CLONE route
```

CONFIG NETWORK ROUTE IPV6**Level**

base

History

Appears in Netasq 9.0.1

Description

Commands to manage IPv6 routing

CONFIG NETWORK ROUTE IPV6 ADD**Level**

route,modify

History

Appears in Netasq 9.0.1

state appears in Netasq 9.1.0

Description

Add a static IPv6 route

Usage

```
remote=<remote object> [interface=<ifname>] [gateway=<host>] [color=<color>]  
[comment=<comment>] [state={0|1}] [ipsecBypass={0|1}]  
ipsecBypass=1 : the destination network of the static route takes part in the IPSEC local  
bypass if enabled in VPN slot (default: ipsecBypass=0)
```

Returns

Error code CACHE_CATEGORY_CLONE route

CONFIG NETWORK ROUTE IPV6 REMOVE**Level**

route,modify

History

Appears in Netasq 9.0.1

Description

Remove a static IPv6 route

Usage

```
remote=<remote object>
```

Returns

Error code CACHE_CATEGORY_CLONE route

CONFIG NETWORK ROUTE IPV6 REVERSE**Level**



base

History

Appears in 2.0.0

Description

Commands to manage IPv6 reverse routes

CONFIG NETWORK ROUTE IPV6 REVERSE ADD**Level**

route,modify

History

Appears in 2.0.0

Description

Add a IPv6 reverse route

Usage

interface=<ifname> gateway=<host> [comment=<comment>] [state={0|1}]

Returns

Error code

CONFIG NETWORK ROUTE IPV6 REVERSE REMOVE**Level**

route,modify

History

Appears in 2.0.0

Description

Remove a IPv6 reverse route

Usage

interface=<ifname> gateway=<host>

Returns

Error code

CONFIG NETWORK ROUTE IPV6 REVERSE SHOW**Level**

base

History

Appears in 2.0.0

Description

Show reverse IPv6 routers

Returns

[ReverseRoutes]

Interface=name Gateway=host State=0|1 Comment="comment"

Format

section_line

**CONFIG NETWORK ROUTE IPV6 REVERSE UPDATE****Level**

route,modify

History

Appears in 2.0.0

Argument name newinterface and newgateway appears in 3.8.0

Description

Update a IPv6 reverse route

Usage

interface=<ifname> gateway=<gateway> [newinterface=<ifname>] [newgateway=<gateway>]
[comment=<comment>] [state={0|1}]

Returns

Error code

CONFIG NETWORK ROUTE IPV6 SHOW**Level**

base

History

Appears in Netasq 9.0.1

Description

Show static IPv6 routes

Returns

[StaticRoutes]

Remote=<remote_object> Interface=<ifname> [Gateway=<host>] [Color=<color>]

Protected=0|1 State=0|1 [ipsecBypass=1] Comment="<comment>"

Format

section_line CACHE_CATEGORY route CACHE_CATEGORY_CLONE route

CONFIG NETWORK ROUTE IPV6 UPDATE**Level**

route,modify

History

Appears in Netasq 9.0.1

state appears in Netasq 9.1.0

Description

Update a static IPv6 route

Usage

remote=<remote object> [newRemote=<remote object>] [interface=<ifname>]
[gateway=<host>] [color=<color>] [comment=<comment>] [state={0|1}] [ipsecBypass=
{0|1}]

ipsecBypass=1 : the destination network of the static route takes part in the IPSEC local
bypass if enabled in VPN slot (default: ipsecBypass=0)

Returns



Error code CACHE_CATEGORY_CLONE route

CONFIG NETWORK ROUTE REMOVE

Level

route,modify

History

Appears in Netasq 6.0.0

option remote=default removed in Netasq 9.0.0

Description

Remove a route

Usage

remote=<remote object>

Returns

Error code

Example

CONFIG NETWORK ROUTE REMOVE remote=net-remote-1

CONFIG NETWORK ROUTE REMOVE remote=192.168.200.0/255.255.255.0 CACHE_CATEGORY_CLONE route

CONFIG NETWORK ROUTE REVERSE

Level

base

History

Appears in 2.0.0

Description

Commands to manage reverse routers

CONFIG NETWORK ROUTE REVERSE ADD

Level

route,modify

History

Appears in 2.0.0

Description

Add an IPv4 reverse route

Usage

interface=<ifname> gateway=<gateway> [comment=<comment>] [state={0|1}]

Returns

Error code

Example

CONFIG NETWORK ROUTE REVERSE ADD interface=in gateway=router1 comment="reverse router for interface in"

**CONFIG NETWORK ROUTE REVERSE REMOVE****Level**

route,modify

History

Appears in 2.0.0

Description

Remove a reverse route

Usage

interface=<ifname> gateway=<gateway>

Returns

Error code

Example

CONFIG NETWORK ROUTE REVERSE REMOVE interface=out gateway=MyRouter

CONFIG NETWORK ROUTE REVERSE SHOW**Level**

base

History

Appears in 2.0.0

Description

Show IPv4 reverse routes

Usage

[useclone=<0|1>]

Returns

[ReverseRoutes]

Interface=name Gateway=host State=0|1 Comment="comment"

Format

section_line

Example

CONFIG NETWORK ROUTE REVERSE SHOW

101 code=00a01000 msg="Début"

[ReverseRoutes]

Interface=out Gateway=MyRouter State=1 Comment="test route"

100 code=00a00100 msg="Ok"

CONFIG NETWORK ROUTE REVERSE UPDATE**Level**

route,modify

History

Appears in 2.0.0

Argument name newinterface and newgateway appears in 3.8.0

Description



Update a reverse route

Usage

```
interface=<ifname> gateway=<gateway> [newinterface=<ifname>] [newgateway=<gateway>]  
[comment=<comment>] [state={0|1}]
```

Returns

Error code

Example

```
CONFIG NETWORK ROUTE REVERSE UPDATE interface=in gateway=router1 newinterface=out  
newgateway=router2 comment="route updated"
```

CONFIG NETWORK ROUTE SHOW

Level

base

History

Appears in Netasq 6.0.0

[Router] removed in Netasq 9.0.0

FORMAT appears in Netasq 9.0.0

pagination appears in Netasq 9.0.0

Description

Show IPv4 static routes

Usage

```
[useclone=<0|1>] [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]  
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]
```

Returns

[StaticRoutes]

Remote=host Address=ip [Interface=name] [Gateway=gw] [Color=color] GatewayHasLB=0|1
Protected=0|1 State=0|1 [ipsecBypass=1] Comment="comment"

Remote=range Begin=start End=end [Interface=name] [Gateway=gw] [Color=color]
GatewayHasLB=0|1 Protected=0|1 State=0|1 [ipsecBypass=1] Comment="comment"

Remote=network Address=ip/prefix [Interface=name] [Gateway=gw] [Color=color]
GatewayHasLB=0|1 Protected=0|1 State=0|1 [ipsecBypass=1] Comment="comment"

Remote=ip/mask [Interface=name] [Gateway=gw] [Color=color] GatewayHasLB=0|1
Protected=0|1 State=0|1 [ipsecBypass=1] Comment="comment"

Format

section_line

Example

```
CONFIG NETWORK ROUTE SHOW
```

```
101 code=00a01000 msg="Début"
```

```
[StaticRoutes]
```

```
Remote=mynet Address=172.168.100.0/24 Interface=out Gateway=10.2.0.1 Color=000c0a  
GatewayHasLB=0 Protected=0 State=0 Comment=""
```

```
Remote=192.168.100.0/255.255.255.0 Interface=in Gateway=10.2.2.1 Color=0a0c0a  
GatewayHasLB=0 Protected=1 State=1 Comment="test route"
```

```
Remote=mynet Address=10.3.0.0/16 Interface=in Gateway=myrouter Color=0a0c0a  
GatewayHasLB=1 Protected=1 State=1 Comment=""
```

```
100 code=00a00100 msg="Ok" CACHE_CATEGORY route CACHE_CATEGORY_CLONE route
```



CONFIG NETWORK ROUTE UPDATE

Level

route,modify

History

ipsecBypass appears in 3.7.22

Description

Update a route

Usage

remote=<remote object> [newRemote=<remote object>] [interface={<ifname>|blackhole}]
[gateway=<gateway>] [color=<color>] [comment=<comment>] [state={0|1}] [ipsecBypass=
0|1]]
ipsecBypass=1 : the destination network of the static route takes part in the IPSEC local
bypass if enabled in VPN slot (default: ipsecBypass=0)

Returns

Error code

Example

CONFIG NETWORK ROUTE UPDATE remote=net-remote-1 newRemote=net-remote-2
gateway=router1 interface=in color=acc0ac comment="route updated" CACHE_CATEGORY_CLONE
route

CONFIG NETWORK SWITCH

Level

base

History

Appears in Netasq 7.0.3.1 Removed in Netasq 9.0.2

Description

Commands to manage switch configuration

CONFIG NETWORK SWITCH ACTIVATE

Level

network,modify

History

Appears in Netasq 7.0.3.1 Removed in Netasq 9.0.2

Description

Flush and reload switch configuration

Usage

[CANCEL]
- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

**Example**

```
CONFIG NETWORK SWITCH ACTIVATE  
CONFIG NETWORK SWITCH ACTIVATE Cancel
```

CONFIG NETWORK SWITCH ADD**Level**

network, modify

History

Appears in Netasq 7.0.3.1 Removed in Netasq 9.0.2

Description

Configure ports used by given interface

Usage

ifname=<interface name> ports=<number or range of numbers (min-max) separated by commas>

Returns

Error code

Example

```
CONFIG NETWORK SWITCH ADD ifname="Ethernet0" ports="1,3-5"
```

CONFIG NETWORK SWITCH MODIFY**Level**

network, modify

History

Appears in Netasq 7.0.3.1 Removed in Netasq 9.0.2

Description

Modify ports used by given interface

Usage

ifname=<interface name> ports=<number or range of numbers (min-max) separated by commas>

Returns

Error code

Example

```
CONFIG NETWORK SWITCH MODIFY ifname="Ethernet0" ports="1-6"
```

CONFIG NETWORK SWITCH SHOW**Level**

base

History

Appears in Netasq 7.0.3.1 Removed in Netasq 9.0.2

Description

Display current switch configuration



CONFIG NTP

History

LICENCE deprecated in Netasq 9.0.0

Level

base

Description

Command to manage NTP client

CONFIG NTP ACTIVATE

Level

maintenance,modify

History

CANCEL/NEXTBOOT Appears in Netasq 9.0.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Description

Activate NTP configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG NTP ACTIVATE CONFIG NTP ACTIVATE cancel

CONFIG NTP ADVANCED

Level

base

Description

Get/set NTP advanced settings : allow unauthenticated servers

Usage

[allowUnauth=on|off]

Returns

allowUnauth={on|off}
nb_nokey_server=number

Remark

Maintenance and Modify levels are required to update the value

Example



CONFIG NTP ADVANCED
CONFIG NTP ADVANCED allowUnauth=on

CONFIG NTP KEY

Level

base

Description

Configure NTP keys

CONFIG NTP KEY ADD

Level

maintenance,modify

History

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Description

Add a NTP key in md5 ascii format.

Usage

md5-ascii=<key data> keynum=<unique key number>

Returns

Error code

Example

CONFIG NTP KEY ADD md5-ascii=AA keynum=1

CONFIG NTP KEY LIST

Level

maintenance

History

Format Appears in Netasq 9.0.0

level changes from other to maintenance in Netasq 9.0.0

Description

List NTP keys.

Returns

keynum=<key id> keytype=<key type> data=<key data>

Format

section_line

Example

CONFIG NTP KEY LIST
keynum=1 keytype=md5-ascii data="AA"

CONFIG NTP KEY REMOVE

Level



maintenance,modify

History

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Description

Remove a NTP key from list.

Usage

<key number>

Returns

Error code

Example

CONFIG NTP KEY REMOVE 1

CONFIG NTP SERVER

Level

base

Description

Configure NTP servers

CONFIG NTP SERVER ADD

Level

maintenance,modify

History

option groupname for name Appears in Netasq 6.0.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

bindaddr appears in 3.11.0

Description

Add a NTP server.

Usage

name=<hostname| groupname> [keynum=<authentication key number>] [bindaddr=<Firewall_obj>]

Returns

Error code

Example

CONFIG NTP SERVER ADD name=ntp_1 keynum=1

CONFIG NTP SERVER ADD name=ntp_2 bindaddr=Firewall_dmz3

CONFIG NTP SERVER LIST

Level

maintenance

History

type Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0



level changes from other to maintenance in Netasq 9.0.0
bindaddr appears in 3.11.0

Description

List NTP servers.

Returns

list of servers in the form :

name=<name of server> keynum=[1-16]|none type=<host|range|group> bindaddr=<host>

Format

section_line

Example

CONFIG NTP SERVER LIST

name=ntp_1 keynum=1 type=host bindaddr=

name=ntp_2 keynum=none type=host bindaddr=Firewall_dmz3

CONFIG NTP SERVER REMOVE**Level**

maintenance,modify

History

option groupname for name Appears in Netasq 6.0.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Description

Remove a NTP server from list.

Usage

<hostname|groupname>

Returns

Error code

Example

CONFIG NTP SERVER REMOVE name=ntp_1

CONFIG NTP SHOW**Level**

base

Description

Show NTP configuration.

Returns

[Config]

State={on|off}

allowUnauth={on|off}

Example

CONFIG NTP SHOW

[Config]



State=on
allowUnauth=off

CONFIG NTP STATE

Level

base

Description

Get/set NTP daemon state.

Usage

[On|Off]

Returns

State={on|off}

Remark

Maintenance and Modify levels are required to update the state value

Example

CONFIG NTP STATE On
CONFIG NTP STATE Off

CONFIG OBJECT

Level

base

History

Appears in Netasq 6.0.0

Description

Object administration

Remark

Invalid name for objects are (case unsensitive):

Firewall*

Network*

Global*

ephemeral*

broadcast

anonymous

any

object commands update object configuration files and serverd memory structure

CONFIG OBJECT ACTIVATE

Level

object,globalobject,modify

History



Appears in Netasq 6.0.0

Description

Update object resolution file

CONFIG OBJECT CNCATEGORYGROUP**Level**

base

History

Appears in Netasq 9.1.0

Description

Cn group category administration

Remark

most of the code is shared with CONFIG.OBJECT.OBJECTGROUP

CONFIG OBJECT CNCATEGORYGROUP ADDTO**Level**

object,modify

History

Appears in Netasq 9.1.0

arg Update appears in 2.4.0

Description

Add service object to cn group category

Usage

group=<cncategorygroup name> node=<node to add name> [update=<0|1|2>]

Remark

node must be a cn group

this command returns an error if:

"group" or "node" don't exist

"node" is an object already included in "group" (no error if update>0)

Example

```
CONFIG OBJECT CNCATEGORYGROUP ADDTO group=group1 node=cngroup1 CACHE_CATEGORY  
objects
```

CONFIG OBJECT CNCATEGORYGROUP CHECK**Level**

object

History

Appears in Netasq 9.1.0

Description

Check cn group category

Usage



name=<cncategorygroupname>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG OBJECT CNCATEGORYGROUP CHECK name=cncategorygroup1

[Configuration]

module=Filter slot=04 line=1

CONFIG OBJECT CNCATEGORYGROUP DELETE**Level**

object,modify

History

Appears in Netasq 9.1.0

Description

Remove an cn category group

Usage

name=<cn group category name> [force=1]

Remark

returns an error if no group with this name exist

Example

CONFIG OBJECT CNCATEGORYGROUP DELETE name=cncategorygroup1 CACHE_CATEGORY objects

CONFIG OBJECT CNCATEGORYGROUP NEW**Level**

object,modify

History

Appears in Netasq 9.1.0

Description

Create new empty cn group category

Usage

name=<cncategorygroupname> [comment=<cncategorygroup comment>] [update=<0|1>]

Remark

returns an error if an cn category group with identical name exists

Example

CONFIG OBJECT SERVICEGROUP NEW name=cncategorygroup1 CACHE_CATEGORY objects

CONFIG OBJECT CNCATEGORYGROUP REMOVEFROM**Level**



object,modify

History

Appears in Netasq 9.1.0

Description

Remove service object from cn group category

Usage

group=<cncategorygroupname> node=<node to remove name>

Remark

node must be a cn group or a cn group category
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

```
CONFIG OBJECT CNCATEGORYGROUP REMOVEFROM group=cncategorygroup1 node=cngroup1  
CACHE_CATEGORY objects
```

CONFIG OBJECT CNCATEGORYGROUP SHOW**Level**

base

History

Appears in Netasq 9.1.0

Description

Show cn group category

Usage

name=<cncategorygroupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>]
[search=<pattern>] [searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<cncategorygroup name>]
name=<nodename>
...

Format

section_line

Example

```
CONFIG OBJECT CNCATEGORYGROUP SHOW name=web  
[web]  
name=cngroup1  
name=cngroup2  
name=cncategorygroup3  
CACHE_CATEGORY objects
```

CONFIG OBJECT EXPORT**Level**

object

**History**

Appears in 3.0.0

router type appears in 4.3.0 time type appears in 4.3.0

Description

Export objects into a CSV file

Usage

```
type=<all|[host][,range][,network][,protocol][,service][,group][,servicegroup][,router][,time]  
[,fqdn]>
```

Format

raw

Remark

Export objects to CSV file

this command returns an error code if :

No object is found.

Example

config object export type=host

CONFIG OBJECT FQDN**Level**

base

History

Appears in 3.0.0

Description

Fqdn object administration

Remark**CONFIG OBJECT FQDN CHECK****Level**

object

History

Appears in 3.0.0

Format**Description**

Check fqdn object

Usage

```
name=<fqdn>
```

Returns

[Configuration]

```
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
```

```
section=<string>]
```

**Format**

section_line

Example

```
CONFIG OBJECT FQDN CHECK name=fqdn.com  
[Configuration]  
module=Filter slot=04 line=1
```

CONFIG OBJECT FQDN DELETE**Level**

object,modify

History

Appears in 3.0.0

Description

Remove fqdn object

Usage

name=<fqdn> [force=1]

Remark

this command returns a warning code if specified object does not exist

Example

```
CONFIG OBJECT FQDN DELETE name=fqdn.com CACHE_CATEGORY objects
```

CONFIG OBJECT FQDN NEW**Level**

object,modify

History

Appears in 3.0.0

Description

Add fqdn object

Usage

```
name=<fqdn> [ip=<ipaddress>] [ipv6=<ipv6address>] [color=xxxxxx]  
[comment=<comment>] [update=<0|1|2>]
```

At least one ip (v4 or v6) must be specified

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

```
CONFIG OBJECT FQDN NEW name=fqdn.com ipv4=10.0.0.1 comment="IPv4 only fqdn" CACHE_  
CATEGORY objects
```

CONFIG OBJECT FQDN SHOW**Level**



base

History

Appears in 3.0.0

Format

Description

Show one object fqdn

Usage

```
name=<fqdn> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]
```

Returns

```
[<fqdnname>]
```

```
ip=<ipv4>
```

```
ipv6=<ipv6>
```

```
...
```

Format

```
section_line
```

Example

```
CONFIG OBJECT FQDN SHOW name=fqdn.com
[fqdn.com]
ip="216.58.211.100"
ip="216.58.208.196"
ipv6="b1a::b1a"
ipv6="b1a::b1a:b1a" CACHE_CATEGORY objects
```

CONFIG OBJECT GEOGROUP

Level

base

History

Appears in 3.0.0

Description

Geogroups category administration

Remark

CONFIG OBJECT GEOGROUP ADDTO

Level

object,modify

History

Appears in 3.0.0

Description

Add geo object to geo group

Usage



group=<geogroup name> node=<node to add name> [update=<0|1|2>]

Remark

node must be a geo object
this comment returns an error if:
"group" or "node" don't exist
"node" is an object already included in "group" (no error if update>0)

Example

CONFIG OBJECT GEOGROUP ADDTO group=geogroup1 node=geo1 CACHE_CATEGORY objects

CONFIG OBJECT GEOGROUP CHECK**Level**

object

History

Appears in 3.0.0

Description

Check geo group

Usage

name=<geogroupname>

Returns

[Configuration]
module=<string> (slot=00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG OBJECT GEOGROUP CHECK name=geogroup1
[Configuration]
module=Filter slot=04 line=1

CONFIG OBJECT GEOGROUP DELETE**Level**

object,modify

History

Appears in 3.0.0

Description

Remove a geo group

Usage

name=<geogroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

CONFIG OBJECT GEOGROUP DELETE name=geogroup1 CACHE_CATEGORY objects



CONFIG OBJECT GEOGROUP NEW

Level

object,modify

History

Appears in 3.0.0

Description

Create new empty geo group

Usage

name=<geogroupname> [comment=<geogroup comment>] [update=<0|1>]

Remark

returns an error if a geo group with identical name exists

Example

CONFIG OBJECT GEOGROUP NEW name=geogroup1 CACHE_CATEGORY objects

CONFIG OBJECT GEOGROUP REMOVEFROM

Level

object,modify

History

Appears in 3.0.0

Description

Remove geo object from geo group

Usage

group=<geogroup name> node=<node to remove name>

Remark

node must be a geo object
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

CONFIG OBJECT GEOGROUP REMOVEFROM group=geogroup1 node=geo1 CACHE_CATEGORY objects

CONFIG OBJECT GEOGROUP SHOW

Level

base

History

Appears in 3.0.0

Description

Show geo group

Usage



name=<geogroupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<geogroup name>]
name=<nodename>
...

Format

section_line

Example

```
CONFIG OBJECT GEOGROUP SHOW name=eu6
[eu6]
name=eu:de
name=eu:lu
name=eu:be
name=eu:nl
name=eu:it
name=eu:fr
CACHE_CATEGORY objects
```

CONFIG OBJECT GET**Level**

base

History

appears in Netasq 9.0.0
router type appears in 2.0.0
fqdn appears in 3.0.0
monitor appears in 4.3.0

Description

Return a unique object from its name

Usage

type=<host,range,fqdn,network,router,group,protocol,service,time,servicegroup,urlgroup,cngrou
p,oemgroup> name=<objname>

Remark

Types have to be in the same namespace

Returns

Return one line with the object properties:

```
[Object]
type=host global=<0|1> modify=<0|1> comment=<comment> name=<hostname> ip=<ip>
ipv6=<ipv6> resolve=<static|dynamic>
type=range global=<0|1> modify=<0|1> comment=<comment> name=<rangename>
begin=<firstip> end=<lastip> beginv6=<firstipv6> endv6=<lastipv6>
type=network global=<0|1> modify=<0|1> comment=<comment> name=<rangename>
ip=<ip> mask=<netmask> prefixlen=<ipv4 prefix len> ipv6=<ipv6> prefixlenv6=<ipv6 prefix
len>
type=router global=0 modify=<0|1> name=<routername> comment=<comment>
```



```

gatewaythreshold=<int> activateallbackup=<0|1> frequency=<int> wait=<int> tries=<int>
triesup=<int> loadbalancing=<none|connhash|srchash> onfailpolicy=<pass|block>
type=protocol global=<0|1> modify=<0|1> comment=<comment> name=<protocolname>
protonumber=<ip protocol number>
type=service global=<0|1> modify=<0|1> comment=<comment> name=<servicename>
port=<port> toport=<""|lastport> proto=<protocolname>
type=time global=<0|1> modify=<0|1> comment=<comment> name=<timename>
time=<time> weekday=<weekdays> yearday=<yearday> date=<date>
type=group global=<0|1> modify=<0|1> comment=<comment> name=<groupname>
type=servicegroup global=<0|1> modify=<0|1> comment=<comment> name=<groupname>
type=urlgroup global=0 modify=1 comment=<comment> name=<groupname>
type=cngroup global=0 modify=1 comment=<comment> name=<groupname>
type=oemgroup global=0 modify=0 comment=<comment> name=<groupname>
...

```

Format

section_line

Example

```

config object get type=host,network,group name=myobject
[Object]
type=host modify=1 global=0 comment="" name=myobject ip=10.0.0.0 ipv6=fe80::1
resolve=static
CACHE_CATEGORY objects

```

CONFIG OBJECT GROUP**Level**

base

History

Appears in Netasq 6.0.0

Description

Object groups administration

Remark

most of the code is shared with CONFIG.OBJECT.SERVICEGROUP

CONFIG OBJECT GROUP ADDTO**Level**

object,modify

History

Appears in Netasq 6.0.0

added position arg in Netasq 9.0.0

added update arg in 2.4.0

Description

Add object to group

Usage

```
group=<groupname> node=<node to add name> [pos=<position>] [update=<0|1|2>]
```

Remark



node might be an object or a group
this command returns an error if:
"group" or "node" don't exist
"node" is an object already included in "group" (no error if update>0)
"node" is an object included in a subgroup of "group"
"node" is a group and contains common element(s) with "group"
"node" is a group and contains an other group which contains "group" (it creates a loop)
"node" is a group and contains an other group which has common element(s) with "group" or another node

Example

```
CONFIG OBJECT GROUP ADDTO group=group1 node=host1 CACHE_CATEGORY objects
```

CONFIG OBJECT GROUP CHECK**Level**

object

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check object group

Usage

name=<group name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

```
CONFIG OBJECT GROUP CHECK name=group1
```

[Configuration]

```
module=Filter slot=04 line=1
```

CONFIG OBJECT GROUP DELETE**Level**

object,modify

History

Appears in Netasq 6.0.0

force Appears in Netasq 6.1.0

Description

Delete object group

Usage

name=<groupname> [force=1]

Remark



returns an error if no group with this name exist

Example

```
CONFIG OBJECT GROUP DELETE name=group1 CACHE_CATEGORY objects
```

CONFIG OBJECT GROUP NEW**Level**

object,modify

History

Appears in Netasq 6.0.0

Description

Create new empty object group

Usage

```
name=<groupname> [comment=<group comment>] [update=<0|1>]
```

Remark

returns an error if a group with identical name exists

Example

```
CONFIG OBJECT GROUP NEW name=group1 CACHE_CATEGORY objects
```

CONFIG OBJECT GROUP REMOVEFROM**Level**

object,modify

History

Appears in Netasq 6.0.0

Description

Remove object from group

Usage

```
group=<groupname> node=<node to remove name>
```

Remark

node might be an object or a group
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

```
CONFIG OBJECT GROUP REMOVEFROM group=group1 node=host1 CACHE_CATEGORY objects
```

CONFIG OBJECT GROUP SHOW**Level**

base

History

Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0

all disappears in Netasq 9.0.0

**Description**

Show one object group

Usage

name=<groupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<groupname>]
name=<nodename>
...

Format

section_line

Example

CONFIG OBJECT GROUP SHOW name=group1
[group1]
name=host1 CACHE_CATEGORY objects

CONFIG OBJECT HOST**Level**

base

History

Appears in Netasq 6.0.0

Description

Host object administration

Remark

most of the code is shared with CONFIG.OBJECT.NETWORK and CONFIG OBJECT.SERVICE

CONFIG OBJECT HOST CHECK**Level**

object

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check host object

Usage

name=<hostname>

Returns

[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format



section_line

Example

```
config object host check name=host1
[Configuration]
module=DNS section=Servers
module=Filter slot=04 line=1
module=DHCP section=Server
```

CONFIG OBJECT HOST DELETE**Level**

object,modify

History

force Appears in Netasq 6.1.0

Description

Remove host object

Usage

name=<hostname> [force=1]

Remark

this command returns an error code if object is in a group
this command returns a warning code if specified object does not exist

Example

```
config object host delete name=host1 CACHE_CATEGORY objects
```

CONFIG OBJECT HOST NEW**Level**

object,modify

History

Appears in Netasq 6.0.0 mac range appears in 4.1.0

Description

Add host object

Usage

```
name=<hostname> [ip=<ipaddress>] [ipv6=<ipv6address>] [type=router|server|host]
[resolve=static|dynamic|manual] [mac=xx:xx:xx:xx:xx:xx] [color=xxxxxx]
[comment=<comment>] [update=<0|1|2>]
name=<rangename> [begin=<range first ip> end=<range last ip>] [beginv6=<range first ipv6>
endv6=<range last ipv6>] [beginmac=<range first mac> endmac=<range last mac>]
[color=xxxxxx] [comment=<comment>] [update=<0|1|2>]
```

For single host at least one address (ipv4 or ipv6 or mac) must be specified
For range at least one begin and end (v4 or v6 or mac) must be specified

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example



```
CONFIG OBJECT HOST NEW name=host4 ip=10.0.0.1 resolve=static comment="IPv4 only host"
mac=11:22:33:44:55:66
CONFIG OBJECT HOST NEW name=host6 ipv6=fe80::1 resolve=static comment="IPv6 only host"
CONFIG OBJECT HOST NEW name=host46 ip=10.0.0.1 ipv6=fe80::1 resolve=static
comment="IPv4v6 host"
CONFIG OBJECT HOST NEW name=range4 begin=10.0.0.1 end=10.0.0.10 comment="IPv4 only
range"
CONFIG OBJECT HOST NEW name=range6 beginv6=fe80::1 endv6=fe80::10 comment="IPv6
only range"
CONFIG OBJECT HOST NEW name=range46 begin=10.0.0.1 end=10.0.0.10 beginv6=fe80::1
endv6=fe80::10 comment="IPv4v6 range"
CONFIG OBJECT HOST NEW name=rangemac beginmac=11:22:33:44:55:60
endmac=11:22:33:44:55:70 comment="mac range"
CONFIG OBJECT HOST NEW name=hostmac mac=11:22:33:44:55:66 comment="mac only host"
CACHE_CATEGORY objects
```

CONFIG OBJECT IMPORT

Level

object, modify

History

Appears in 3.0.0

Description

Objects import functions

CONFIG OBJECT IMPORT ACTIVATE

Level

object, modify

History

Appears in 3.0.0

Description

Import objects from CSV uploaded

Remark

Import objects from CSV file
this command returns an error code if :
At least one object can't be imported
There are too many objects to import.

Example

config object import activate

CONFIG OBJECT IMPORT CANCEL

Level

object, modify

History

Appears in 3.0.0

Description



Cancel current import process

Remark

Called by user action or end of session.

Example

config object import cancel

CONFIG OBJECT IMPORT STATUS**Level**

base

History

Appears in 3.0.0

Description

Show the status of the last import

Example

config object import status

CONFIG OBJECT IMPORT UPLOAD**Level**

object, modify

History

Appears in 3.0.0

Description

Upload CSV file in order to import objects

Remark

Has to be followed by config object import activate.

Example

config global object import upload

CONFIG OBJECT INTERNET**Level**

base

History

Appears in Netasq 9.0.0

Description

handling of the object 'Internet'

CONFIG OBJECT INTERNET SHOW**Level**

base

History



Appears in Netasq 9.0.0

Description

Show to which object the object 'internet' points to

Returns

```
[Internet]  
operator={ne|eq}  
object={host|range|net|group}
```

Example

```
CONFIG OBJECT INTERNET SHOW [Internet]  
operator=ne  
object=Network_internals
```

CONFIG OBJECT INTERNET UPDATE**Level**

object,modify

History

Appears in Netasq 9.0.0

Description

Update the object 'internet'

Usage

```
[operator={ne|eq}] [object={host|range|net|group}]
```

Example

```
CONFIG OBJECT INTERNET UPDATE operator=ne object=Network_internals CACHE_CATEGORY filter
```

CONFIG OBJECT IPREPGROUP**Level**

base

History

Appears in 3.0.0

Description

IPreps category administration

Remark**CONFIG OBJECT IPREPGROUP ADDTO****Level**

object,modify

History

Appears in 3.0.0

Description

Add iprep object to an iprep group

Usage



group=<iprepgroup name> node=<node to add name> [update=<0|1|2>]

Remark

node must be a iprep object
this comment returns an error if:
"group" or "node" don't exist
"node" is an object already included in "group" (no error if update>0)

Example

CONFIG OBJECT IPREPGROUP ADDTO group=iprepgroup1 node=iprep1 CACHE_CATEGORY objects

CONFIG OBJECT IPREPGROUP CHECK**Level**

object

History

Appears in 3.0.0

Description

Check iprep group

Usage

name=<iprepgroupname>

Returns

[Configuration]
module=<string> (slot=00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

CONFIG OBJECT IPREPGROUP CHECK name=iprepgroup1
[Configuration]
module=Filter slot=04 line=1

CONFIG OBJECT IPREPGROUP DELETE**Level**

object,modify

History

Appears in 3.0.0

Description

Remove an iprep group

Usage

name=<iprepgroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

CONFIG OBJECT IPREPGROUP DELETE name=iprepgroup1 CACHE_CATEGORY objects



CONFIG OBJECT IPREPGROUP NEW

Level

object,modify

History

Appears in 3.0.0

Description

Create new empty iprep group

Usage

name=<iprepgroupname> [comment=<iprepgroup comment>] [update=<0|1>]

Remark

returns an error if an iprep group with identical name exists

Example

CONFIG OBJECT IPREPGROUP NEW name=iprepgroup1 CACHE_CATEGORY objects

CONFIG OBJECT IPREPGROUP REMOVEFROM

Level

object,modify

History

Appears in 3.0.0

Description

Remove iprep object from iprep group

Usage

group=<iprepgroup name> node=<node to remove name>

Remark

node must be a iprep object
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

CONFIG OBJECT IPREPGROUP REMOVEFROM group=iprepgroup1 node=iprep1 CACHE_CATEGORY objects

CONFIG OBJECT IPREPGROUP SHOW

Level

base

History

Appears in 3.0.0

Description

Show iprep group

Usage



name=<iprepgroupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<iprepgroup name>
name=<nodename>
...

Format

section_line

Example

```
CONFIG OBJECT IPREPGROUP SHOW name=bad
[bad]
name=malware
name=botnet
name=spam
name=scanner
CACHE_CATEGORY objects
```

CONFIG OBJECT LIST**Level**

base

History

appears in Netasq 9.0.0
havingipversion appears in 1.0.0
router type appears in 2.0.0
usage appears in 3.0.0
geo and geogroup appear in 3.0.0 iprep and iprepgroup appear in 3.0.0 fqdn appears in 3.0.0

Description

List and search objects

Usage

type=<all|[host][,range][,fqdn][,network][,router][,group][,protocol][,service][,time]
[,servicegroup][,urlgroup][,cngroup][,oemgroup][,urlcategorygroup][,cncategorygroup][,geo]
[,geogroup][,iprep][,iprepgroup]> [havingipversion=<4|6|any|none>]
[usage=<off|used|unused|any>] [start=<int> [limit=<int>] [dir=<ASC|DESC>]
[search=<pattern>] [searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[Object]

type=host global=<0|1> modify=<0|1> comment=<comment> name=<hostname> ip=<ip>
ipv6=<ipv6> resolve=<static|dynamic> used=<0|1>
type=range global=<0|1> modify=<0|1> comment=<comment> name=<rangename>
begin=<firstip> end=<lastip> beginv6=<firstipv6> endv6=<lastipv6> used=<0|1>
type=network global=<0|1> modify=<0|1> comment=<comment> name=<rangename>
ip=<ip> mask=<netmask> prefixlen=<ipv4 prefix len> ipv6=<ipv6> prefixlenv6=<ipv6 prefix
len>used=<0|1>
type=router global=0 modify=<0|1> name=<routername> comment=<comment>
gatewaythreshold=<int> activateallbackup=<0|1> frequency=<int> wait=<int> tries=<int>
triesup=<int> loadbalancing=<none|conhash|srchash> onfailpolicy=<pass|block>



```

used=<0|1>
type=protocol global=<0|1> modify=<0|1> comment=<comment> name=<protocolname>
protonumber=<ip protocol number> used=<0|1>
type=service global=<0|1> modify=<0|1> comment=<comment> name=<servicename>
port=<port> toport=<""|lastport> proto=<protocolname> used=<0|1>
type=time global=<0|1> modify=<0|1> comment=<comment> name=<timename>
time=<time> weekday=<weekdays> yearday=<yearday> date=<date> used=<0|1>
type=group global=<0|1> modify=<0|1> comment=<comment> name=<groupname>
used=<0|1>
type=servicegroup global=<0|1> modify=<0|1> comment=<comment> name=<groupname>
used=<0|1>
type=urlgroup global=0 modify=1 comment=<comment> name=<groupname> used=<0|1>
type=cngroup global=0 modify=1 comment=<comment> name=<groupname> used=<0|1>
type=oemgroup global=0 modify=0 comment=<comment> name=<groupname> used=<0|1>
...

```

Format

section_line

Example

```

CONFIG OBJECT LIST type=host,range usage=used start=1 search=*com* searchfield=name
[Object]
type=host modify=1 global=0 comment="" name=mycomputer ip=10.0.0.1 resolve=static
used=1 CACHE_CATEGORY objects

```

CONFIG OBJECT NETWORK**Level**

base

History

Appears in Netasq 6.0.0

Description

Network object administration

Remark

most of the code is shared with CONFIG.OBJECT.HOST and CONFIG OBJECT.SERVICE

CONFIG OBJECT NETWORK CHECK**Level**

object

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check network object

Usage

name=<network name>

Returns



```
[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]
```

Format

section_line

Example

```
config object network check name=network1
[Configuration]
module=DNS section=Clients
module=Filter slot=04 line=1
```

CONFIG OBJECT NETWORK DELETE**Level**

object,modify

History

force Appears in Netasq 6.1.0

Description

Remove network object

Usage

```
name=<netname> [force=1]
```

Remark

this command returns an error code if object is in a group
this command returns a warning code if specified object does not exist

Example

```
config object net delete name=net1 CACHE_CATEGORY objects
```

CONFIG OBJECT NETWORK NEW**Level**

object,modify

History

Appears in Netasq 6.0.0

Description

Add network object

Usage

```
name=<netname> [ip=<network IPV4 address> mask=<netmask>|prefixlen=<prefixlen>]
[ipv6=<network IPV6 address> prefixlenv6=<prefixlen>] [color=xxxxxx]
[comment=<comment>] [update=<0|1|2>]
```

Remark

at least one ip (v4 or v6) must be specified
Without update parameter, command will return an error if an object with the same name exists.
0.0.0.0 and 255.255.255.255 IPv4 netmasks are not allowed
/0 and /32 IPv4 prefix len are not allowed



/0 and /128 IPv6 prefix len are not allowed

With update=2, modules which use the object are not reloaded.

Example

```
CONFIG OBJECT NETWORK NEW name=net0 ip=10.0.0.0 prefixlen=16 comment="IPv4 only
network"
CONFIG OBJECT NETWORK NEW name=net1 ip=10.0.0.0 mask=255.0.0.0 comment="IPv4 only
network"
CONFIG OBJECT NETWORK NEW name=net2 ipv6=fe80:: prefixlen6=64 comment="IPv6 only
network"
CONFIG OBJECT NETWORK NEW name=net3 ip=10.0.0.0 mask=255.0.0.0 ipv6=fe80::
prefixlen6=64 comment="IPv4v6 network" CACHE_CATEGORY objects
```

CONFIG OBJECT PROTOCOL**Level**

base

History

Appears in Netasq 6.0.0

Description

Protocol object administration

Remark

most of the code is shared with CONFIG.OBJECT.NETWORK and CONFIG OBJECT.HOST

CONFIG OBJECT PROTOCOL CHECK**Level**

object

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check protocol object

Usage

name=<protocol name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

```
CONFIG OBJECT PROTOCOL CHECK name=proto1
[Configuration]
module=Filter slot=04 line=1
```



CONFIG OBJECT PROTOCOL DELETE

Level

object,modify

History

force Appears in Netasq 6.1.0

Description

Remove protocol object

Usage

name=<protocolname> [force=1]

Remark

this command returns an error code if object is in a group
this command returns a warning code if specified object does not exist

Example

CONFIG OBJECT PROTOCOL DELETE name=chaos CACHE_CATEGORY objects

CONFIG OBJECT PROTOCOL NEW

Level

object,modify

History

Appears in Netasq 6.0.0
value replaced by protonumber in Netasq 9.0.0

Description

Add protocol object

Usage

name=<protocolname> protonumber=<IP protocol number> [color=xxxxxx]
[comment=<comment>] [update=<0|1|2>]

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

CONFIG GLOBAL OBJECT PROTOCOL NEW name=chaos protonumber=16 color=123456
comment="CHAOS protocol" CACHE_CATEGORY objects

CONFIG OBJECT QOS

Level

base

History

Appears in Netasq 6.1.0

Description

QoS configuration



CONFIG OBJECT QOS ACTIVATE

Level

filter,modify

History

Appears in Netasq 6.2.0

level changes from object,globalobject,modify to filter,modify in Netasq 9.0.0

Description

Update active rules

Returns

Error code

CONFIG OBJECT QOS DROP

Level

base

History

Appears in Netasq 6.1.0

Description

List drop policies

Returns

<inc.number>=<policy name>

Example

```
101 code=00a01000 msg="Begin"
```

```
[Drop]
```

```
0=TailDrop
```

```
1=BLUE
```

```
100 code=00a00100 msg="Ok"
```

CONFIG OBJECT QOS INTERFACE

Level

base

History

Appears in 4.3.0

Description

QoS interface management

CONFIG OBJECT QOS INTERFACE REMOVE

Level

base

History

Appears in 4.3.0

Description

Delete QoS for interface

**Usage**

[name=<name>]

Returns

Error code

CONFIG OBJECT QOS INTERFACE SET**Level**

filter,modify

History

Appears in 4.3.0

Description

Set QoS parameters for interface

Usage

[name=<name> tbr=<tbr_name> defaultqueue=<qid|bypass> defaultackqueue=<qid|bypass>]

Returns

Error code

CONFIG OBJECT QOS INTERFACE SHOW**Level**

base

History

Appears in 4.3.0

Description

Show the interfaces supporting QoS

Usage

[useclone={0|1}]

Returns

Error code

CONFIG OBJECT QOS QID**Level**

base

History

Appears in Netasq 6.1.0

Description

QoS qid management

CONFIG OBJECT QOS QID ADD**Level**

filter,modify

History

Appears in Netasq 6.1.0
level filter Appears in 6.1.4



level network deprecated in 6.1.4

level other deprecated in 6.1.4

'prioritize_ack' and 'prioritize_lowdelay' become 'prioritizeack' and 'prioritizelowdelay' in Sicilia

lengthrev Appears in 4.3.0

Description

Add a qid

Usage

```
qid=<qid> [comment=<comment>] [type=CBQ min=<min> min_rev=<minrev> max=<max>  
max_rev=<maxrev>] | [type=<PRIQ> pri=<pri>] [color=<color>] [length=<queue_length>  
[lengthrev=<rev_queue_length>] [prioritizeack=<on|off>] [prioritizelowdelay=<on|off>]  
[update=<on|off>]
```

Remark

In order to use a percentage as bandwidth for CBQ, a reference bandwidth must be set using CONFIG OBJECT QOS SET

Example

```
CONFIG OBJECT QOS QID ADD qid=HTTP comment="web" type=CBQ min="65536" min_  
rev="16384" max="0" max_rev="0"  
CONFIG OBJECT QOS QID ADD qid=SSH comment="ssh" type=PRIQ pri=1  
CONFIG OBJECT QOS QID ADD qid=SMTP comment="mail" type=CBQ min="131072"  
max="262144" min_rev="0" max_rev="0"
```

CONFIG OBJECT QOS QID CHECK

Level

base

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check a qid

Usage

```
name=<qid>
```

Format

section_line

CONFIG OBJECT QOS QID LIST

Level

base

History

Appears in Netasq 6.1.0

useclone appears in 4.3.0

Description

List qids

Usage

```
[useclone={0|1}]
```

**CONFIG OBJECT QOS QID REMOVE****Level**

filter,modify

History

Appears in Netasq 6.1.0

level filter Appears in 6.1.4

level network deprecated in 6.1.4

level other deprecated in 6.1.4

Description

Remove a qid

Usage

qid=<qid> [force=1]

Returns

Error code

CONFIG OBJECT QOS QID RENAME**Level**

filter,modify

History

Appears in Netasq 9.0.0

Description

Rename a qid

Usage

oldname=<old_qidname> newname=<new_qidname>

Remark

rename all the occurrences of old_qidname to new_qidname in the configuration files

this command returns an error code if :

old qidname is not found.

new qidname already exists.

Returns

Error code

CONFIG OBJECT QOS SET**Level**

filter,modify

History

Appears in Netasq 6.1.0

level filter Appears in 6.1.4

level network deprecated in 6.1.4

level other deprecated in 6.1.4

Description

Set global QoS parameters

Usage



[drop=<0|1>]

Returns

Error code

CONFIG OBJECT QOS SHOW**Level**

base

History

Appears in Netasq 6.1.0

Description

Show global QoS parameters

Example

```
CONFIG QOS SHOW 101 code=00a01000 msg="Begin"
[QoS]
Drop=0
Max_Qids=98
Default_QLen=200
Max_QLen=500
100 code=00a00100 msg="Ok"
```

CONFIG OBJECT QOS TBR**Level**

base

History

Appears in 4.3.0

Description

QoS Token Bucket Regulator management

CONFIG OBJECT QOS TBR REMOVE**Level**

base

History

Appears in 4.3.0

Description

Delete Token Bucket Regulator

Usage

[name=<name>] [force=<0|1>]

Returns

Error code

CONFIG OBJECT QOS TBR SET**Level**

filter,modify

History



Appears in 4.3.0

Description

Set QoS parameters for Token Bucket Regulator

Usage

[name=<name> bandwidth=<bw>]

Returns

Error code

CONFIG OBJECT QOS TBR SHOW**Level**

base

History

Appears in 4.3.0

Description

Show the Token Bucket Regulators, with their configured bandwidth

Usage

[useclone={0|1}]

Returns

Error code

CONFIG OBJECT RENAME**Level**

object,modify

History

Appears in Netasq 9.0.0

Description

Rename objects

Usage

type=<host|range|network|router|service|time|group|servicegroup|urlgroup|cngroup|urlcategorygroup|cncategorygroup|geogroup|iprepgroup> oldname=<old_objname> newname=<new_objname>

Remark

rename all the occurrences of old_objname to new_objname in the configuration files
this command returns an error code if :
old objname is not found.
new objname already exists.

Example

config object rename type=host oldname=foo newname=bar CACHE_CATEGORY objects,filter
CACHE_CATEGORY_CLONE objects,filter



CONFIG OBJECT ROUTER

Level

base

History

Appears in 2.0.0

Description

Router object administration

CONFIG OBJECT ROUTER CHECK

Level

object

History

Appears in 2.0.0

Description

Check where a router object is used

Usage

name=<router name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>]

Format

section_line

Example

CONFIG OBJECT ROUTER CHECK name=myrouter

[Configuration]

module=Filter slot=04 line=1

module=Route section=DefaultRoute

CONFIG OBJECT ROUTER DELETE

Level

object,modify

History

Appears in 2.0.0

Description

Remove router object

Usage

name=<name> [force=1]

Remark

this command returns a warning code if specified object does not exist

Example

CONFIG OBJECT ROUTER delete name=myrouter CACHE_CATEGORY objects



CONFIG OBJECT ROUTER GATEWAY

Level

base

History

Appears in 2.0.0

Description

Command to manage router object gateways

CONFIG OBJECT ROUTER GATEWAY ADD

Level

object,modify

History

Appears in 2.0.0

Added value ALL to monitor in 4.3.0

Description

Add a new gateway (principal or backup) to a router object

Usage

name=<routername> type=<principalgateway|backupgateway> host=<host>
[check=<host|group>] [pos=<position> (0 or default: end of list)] [weight=<int>]
[monitor=<all|icmp|none>] [comment=<comment>]
- monitor=all means this gateway use monitoring;
- monitor=none means this gateway is not monitored;

Remark

The value ICMP for monitor is kept for backward compatibility and is equivalent to the value ALL

Returns

Error Code

Example

CONFIG OBJECT ROUTER GATEWAY ADD name=my_router host=my_gw Type=principalgateway
check=host_behind_my_gw

CONFIG OBJECT ROUTER GATEWAY MOVE

Level

object,modify

History

Appears in 2.0.0

Description

Move a gateway (principal or backup) in a router object

Usage

name=<routername> type=[principalgateway|backupgateway] pos=<int> offset=<+/-num>

Returns

Error Code

Example



```
CONFIG OBJECT ROUTER GATEWAY MOVE name=my_router type=principalgateway pos=1  
offset=+1
```

CONFIG OBJECT ROUTER GATEWAY REMOVE

Level

object,modify

History

Appears in 2.0.0

Description

Remove one or all gateway(s) (principal or backup) from a router object

Usage

```
name=<routername> type={principalgateway|backupgateway} (pos={<int>|all} | host=  
{<gateway name|any>})
```

Returns

Error Code

Example

```
CONFIG OBJECT ROUTER GATEWAY REMOVE name=my_router type=principalgateway pos=all  
CONFIG OBJECT ROUTER GATEWAY REMOVE name=my_router type=principalgateway  
host=MyGatewayHost
```

CONFIG OBJECT ROUTER GATEWAY UPDATE

Level

object,modify

History

Appears in 2.0.0

Added value ALL to monitor in 4.3.0

Description

Update a gateway (principal or backup) from a router object

Usage

```
name=<routername> type=<principalgateway|backupgateway> pos=<position> [host=<host>]  
[check=<host|group>] [weight=<int>] [monitor=<all|icmp|none>] [comment=<comment>]  
- monitor=all means this gateway use monitoring;  
- monitor=none means this gateway is not monitored;
```

Remark

The value ICMP for monitor is kept for backward compatibility and is equivalent to the value ALL

Returns

Error Code

Example

```
CONFIG OBJECT ROUTER GATEWAY UPDATE name=my_router type=principalgateway pos=3  
check=host_behind_my_gw
```

CONFIG OBJECT ROUTER NEW

Level

object,modify

**History**

Appears in 2.0.0
monitor appears in 4.3.0
triesup appears in 4.3.0
slause appears in 4.3.0
slajitter appears in 4.3.0
slalatency appears in 4.3.0
slalossrate appears in 4.3.0
slaunreachablerate appears in 4.3.0

Description

Add router object

Usage

```
name=<router name> [monitor=<icmp|tcp_probe>] [port=<service_name>]  
[comment=<comment>] [tries=<int>] [triesup=<int>] [wait=<seconds>]  
[frequency=<seconds>] [gatewaythreshold=<int>] [activateallbackup={on|off}]  
[loadbalancing=<none|conhash|srchash>] [onfailpolicy={pass|block}] [slause=<0|1>]  
[slajitter=<milliseconds>] [slalatency=<milliseconds>] [slalossrate=<float>]  
[slaunreachablerate=<int>] [update=<0|1|2>]
```

Remark

With update=2, modules which use the object are not reloaded.
When load balancing is enabled, if there are less than GatewayThreshold principals active, backups will be used
Gatewaythreshold=0 means to use backups when at least one principal is down
Gatewaythreshold=1 means to use backups when all principals are down The port parameter is for TCP_PROBE monitoring only and must be the name or the port number of a tcp service object

Example

```
CONFIG OBJECT ROUTER NEW name=myrouter monitor=TCP_PROBE port=tcp_service  
comment="My router object" gatewaythreshold=1 tries=3 triesup=0 wait=2 frequency=15  
loadbalancing=none onfailpolicy=pass CACHE_CATEGORY objects
```

CONFIG OBJECT ROUTER SHOW**Level**

base

History

Appears in 2.0.0 monitor appears in 4.3.0

Description

Show a router object

Usage

```
name=<router name>
```

Format

```
section_line
```

Example

```
CONFIG OBJECT ROUTER SHOW name=myrouter  
[Config]  
name=myrouter  
monitor=TCP_PROBE
```



```
port=tcp_service
comment="nice comment"
gatewaythreshold=1
activateallbackup=0
frequency=15
tries=3
triesup=0
wait=2
loadbalancing=connhash
onfailpolicy=Pass
slause=0
slalateny=
slajitter=
slalossrate=
slaunreachablerate=

[PrincipalGateway]
pos=1 host=host1 check=www.google.com comment="First router"
pos=2 host=host2 check=www.google.com comment="Second router"

[BackupGateway]
pos=1 host=host3 check=www.google.com comment=""
```

CONFIG OBJECT SERVICE

Level

base

History

Appears in Netasq 6.0.0

Description

Service object administration

Remark

most of the code is shared with CONFIG.OBJECT.NETWORK and CONFIG OBJECT.HOST

CONFIG OBJECT SERVICE CHECK

Level

object

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check service object

Usage

name=<service name>

Returns



[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

config object service check name=service1
[Configuration]
module=Filter slot=04 line=1

CONFIG OBJECT SERVICE DELETE**Level**

object,modify

History

force Appears in Netasq 6.1.0

Description

Remove service object

Usage

name=<servicename> [force=1]

Remark

this command returns an error code if object is in a group
this command returns a warning code if specified object does not exist

Example

config object service delete name=dns CACHE_CATEGORY objects

CONFIG OBJECT SERVICE NEW**Level**

object,modify

History

Appears in Netasq 6.0.0
Removed plugin attribute in Netasq 9.0.0

Description

Add service object

Usage

name=<servicename> port=<port number> proto=<tcp|udp|any> [toport=<porthigh>]
[color=xxxxxx] [comment=<comment>] [update=<0|1|2>]

Remark

without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

CONFIG OBJECT SERVICE NEW name=dns port=53 proto=tcp comment="DNS service" CACHE_CATEGORY objects



CONFIG OBJECT SERVICEGROUP

Level

base

History

Appears in Netasq 6.0.0

Description

Service groups administration

Remark

most of the code is shared with CONFIG.OBJECT.OBJECTGROUP

CONFIG OBJECT SERVICEGROUP ADDTO

Level

object,modify

History

Appears in Netasq 6.0.0

arg Update appears in 2.4.0

Description

Add service object to service group

Usage

group=<servicegroup name> node=<node to add name> [update=<0|1|2>]

Remark

node must be a service

this command returns an error if:

"group" or "node" don't exist

"node" is an object already included in "group" (no error if update>0)

Example

CONFIG OBJECT SERVICEGROUP ADDTO group=group1 node=dns CACHE_CATEGORY objects

CONFIG OBJECT SERVICEGROUP CHECK

Level

object

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

Description

Check service group

Usage

name=<service group name>

Returns



```
[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]
```

Format

section_line

Example

```
CONFIG OBJECT SERVICEGROUP CHECK name=servicegroup1
[Configuration]
module=Filter slot=04 line=1
```

CONFIG OBJECT SERVICEGROUP DELETE**Level**

object,modify

History

force Appears in Netasq 6.1.0

Description

Remove service group

Usage

name=<servicegroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

```
CONFIG OBJECT SERVICEGROUP DELETE name=servicegroup1 CACHE_CATEGORY objects
```

CONFIG OBJECT SERVICEGROUP NEW**Level**

object,modify

History

Appears in Netasq 6.0.0

Description

Create new empty service group

Usage

name=<servicegroupname> [comment=<servicegroup comment>] [update=<0|1>]

Remark

returns an error if a service group with identical name exists

Example

```
CONFIG OBJECT SERVICEGROUP NEW name=servicegroup1 CACHE_CATEGORY objects
```

CONFIG OBJECT SERVICEGROUP REMOVEFROM**Level**

object,modify

History



Appears in Netasq 6.0.0

Description

Remove service object from service group

Usage

group=<servicegroup name> node=<node to remove name>

Remark

node must be a service
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

CONFIG OBJECT SERVICEGROUP REMOVEFROM group=servcegroup1 node=dns CACHE_CATEGORY
objects

CONFIG OBJECT SERVICEGROUP SHOW**Level**

base

History

Appears in Netasq 6.0.0
Format Appears in Netasq 9.0.0
all disappears in Netasq 9.0.0

Description

Show service group

Usage

name=<servicegroup name> [start=<int> [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>]
[searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<servicegroup name>]
name=<nodename>
...

Format

section_line

Example

CONFIG OBJECT SERVICEGROUP SHOW name=web
[web]
name=dns_udp
name=http
name=https
CACHE_CATEGORY objects

CONFIG OBJECT SYNC**Level**

object

**History**

Appears in 4.3.0

Description

Objectsync configuration functions

CONFIG OBJECT SYNC ACTIVATE**Level**

object, modify

History

Appears in 4.3.0

Description

Update the objectsync configuration file

Example

CONFIG OBJECT SYNC ACTIVATE

CONFIG OBJECT SYNC SHOW**Level**

object

History

Appears in 4.3.0

Description

Show the objectsync configuration

Example

CONFIG OBJECT SYNC SHOW

CONFIG OBJECT SYNC UPDATE**Level**

object, modify

History

Appears in 4.3.0

Description

Update the objectsync configuration

Usage

[state=<0|1>]

[period=<period>]

[bindaddr=<host>]

Remark

Period must be between 1 minute and 1 day.

Example

CONFIG OBJECT SYNC UPDATE state=1 period=6h5m4s bindaddr=Firewall_in



CONFIG OBJECT TIME

Level

base

History

Appears in Netasq 9.0.0

Description

Time object administration

CONFIG OBJECT TIME CHECK

Level

object

History

Appears in Netasq 9.0.0

Description

Check time object

Usage

name=<timeobject name>

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

config object host check name=daysoff

[Configuration]

module=Filter slot=04 line=1

CONFIG OBJECT TIME DELETE

Level

object,modify

History

force Appears in Netasq 9.0.0

Description

Remove time object

Usage

name=<timeobject name> [force=1]

Remark

this command returns a warning code if specified object does not exist

Example

config object host delete name=daysoff CACHE_CATEGORY objects



CONFIG OBJECT TIME NEW

Level

object,modify

History

Appears in Netasq 9.0.0

Description

Add a time object

Usage

```
name=<timeobject name> time=["|hh:mm-hh:mm[;hh:mm-hh:mm]... weekday=["|dow[-dow]
[;dow[-dow]]... yearday=["|mm:dd[-mm:dd][;mm:dd[-mm:dd]]... date=["|yyyy:mm:dd
[:hh:mm][-yyyy:mm:dd[:hh:mm]] [color=xxxxxx] [comment=<comment>] [update=<0|1|2>]
```

Remark

Without update parameter, command will return an error if an object with the same name exists.
With update=2, modules which use the object are not reloaded.

Example

```
config object time new name=work time=08:00-12:00;14:00-19:00 weekday="1;3;5-7"
yearday="" date="" comment="working hours"
config object time new name=daysoff time="" weekday=""
yearday="01:01;05:01;05:08;07:14;08:15;11:11;12:25" date="" CACHE_CATEGORY objects
```

CONFIG OBJECT URLCATEGORYGROUP

Level

base

History

Appears in Netasq 9.1.0

Description

Url category groups administration

Remark

most of the code is shared with CONFIG.OBJECT.OBJECTGROUP

CONFIG OBJECT URLCATEGORYGROUP ADDTO

Level

object,modify

History

Appears in Netasq 9.1.0
arg Update appears in 2.4.0

Description

Add url group object to url group category

Usage

```
group=<urlcategorygroup name> node=<node to add name> [update=<0|1|2>]
```

Remark



node must be an url group
this command returns an error if:
"group" or "node" don't exist
"node" is an object already included in "group" (no error if update>0)

Example

```
CONFIG OBJECT URLCATEGORYGROUP ADDTO group=group1 node=dns CACHE_CATEGORY objects
```

CONFIG OBJECT URLCATEGORYGROUP CHECK**Level**

object

History

Appears in Netasq 9.1.0

Description

Check url group category

Usage

name=<urlcategorygroupname>

Returns

[Configuration]
module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

```
CONFIG OBJECT URLCATEGORYGROUP CHECK name=urlcategorygroup1  
[Configuration]  
module=Filter slot=04 line=1
```

CONFIG OBJECT URLCATEGORYGROUP DELETE**Level**

object,modify

History

Appears in Netasq 9.1.0

Description

Remove an url group category

Usage

name=<servicegroup name> [force=1]

Remark

returns an error if no group with this name exist

Example

```
CONFIG OBJECT URLCATEGORYGROUP DELETE name=urlcategorygroup1 CACHE_CATEGORY objects
```



CONFIG OBJECT URLCATEGORYGROUP NEW

Level

object,modify

History

Appears in Netasq 9.1.0

Description

Create new empty url group category

Usage

name=<urlcategorygroupname> [comment=<urlcategorygroup comment>] [update=<0|1>]

Remark

returns an error if an url category group with identical name exists

Example

CONFIG OBJECT SERVICEGROUP NEW name=urlcategorygroup1 CACHE_CATEGORY objects

CONFIG OBJECT URLCATEGORYGROUP REMOVEFROM

Level

object,modify

History

Appears in Netasq 9.1.0

Description

Remove service object from url group category

Usage

group=<urlcategorygroupname> node=<node to remove name>

Remark

node must be a service
this command returns an error if :
"group" or "node" don't exist
"node" is not in "group"

Example

CONFIG OBJECT URLCATEGORYGROUP REMOVEFROM group=urlcategorygroup1 node=dns CACHE_CATEGORY objects

CONFIG OBJECT URLCATEGORYGROUP SHOW

Level

base

History

Appears in Netasq 9.1.0

Description

Show url group category

Usage



name=<urlcategorygroupname> [start=<int> [limit=<int>] [dir=<ASC|DESC>]
[search=<pattern>] [searchfield=<token>] [sort=<token>] [refresh=<0|1>]]

Returns

[<urlcategorygroup name>]
name=<nodename>
...

Format

section_line

Example

```
CONFIG OBJECT URLCATEGORYGROUP SHOW name=web  
[web]  
name=dns_udp  
name=http  
name=https  
CACHE_CATEGORY objects
```

CONFIG OBJECT URLGROUP**Level**

base

History

appears on Netasq 9.0.0

Description

URL and CN groups administration

CONFIG OBJECT URLGROUP ADDTO**Level**

contentfilter,modify

History

appears on Netasq 9.0.0

comment and update appear in 2.0.0

Description

Add an url to an URL/CN group

Usage

group=<groupname> type=(urlgroup|cngroup) url=<url> [comment=<comment>]
[update=<0|1>]
group : group name to use for filter
type : type of urlgroup (urlgroup or cngroup)
url : url to add to urlgroup
comment : comment for the url
update : indicate if the comment should be updated

Returns

Error code

Example



```
CONFIG OBJECT URLGROUP ADDTO group=antivirus_bypass type=urlgroup url=*.stormshield.eu/*  
CONFIG OBJECT URLGROUP ADDTO group=antivirus_bypass type=urlgroup  
url=*.stormshield.eu/* comment="stormshield" update=1  
CONFIG OBJECT URLGROUP ADDTO group=bank_bypass type=cngroup url=www.bank.com  
CACHE_CATEGORY objects
```

CONFIG OBJECT URLGROUP CHECK

Level

base

History

appears in Netasq 9.0.0

Description

Check an URL/CN/OEM group object

Usage

name=<groupname> type=(urlgroup|cngroup|oemgroup)

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

Example

```
CONFIG OBJECT URLGROUP CHECK name=antivirus_bypass type=urlgroup  
CONFIG OBJECT URLGROUP CHECK name=bank_bypass type=cngroup  
CONFIG OBJECT URLGROUP CHECK name=ads type=oemgroup
```

CONFIG OBJECT URLGROUP CLASSIFY

Level

base

History

appears in 9.1

Description

Show which groups the specified URL belongs to

Usage

url=<url_to_check>

Format

section

Returns

[groups]

<oemgroup|urlgroup>=group1

<oemgroup|urlgroup>=group2

...

<oemgroup|urlgroup>=groupN

**Example**

```
CONFIG OBJECT URLGROUP CLASSIFY url=www.stormshield.eu
```

CONFIG OBJECT URLGROUP DELETE**Level**

contentfilter,modify

History

appears on Netasq 9.0.0

Description

Delete an URL/CN group

Usage

```
name=<groupname> type={urlgroup|cngroup} [force=1]
```

Returns

Error code

Example

```
CONFIG OBJECT URLGROUP DELETE name=antivirus_bypass type=urlgroup
```

```
CONFIG OBJECT URLGROUP DELETE name=bank_bypass type=cngroup CACHE_CATEGORY objects
```

CONFIG OBJECT URLGROUP NEW**Level**

contentfilter,modify

History

appears on Netasq 9.0.0

Description

Create a new empty URL/CN group

Usage

```
name=<groupname> type={urlgroup|cngroup} [comment=<comment>] [update=<0|1>]
```

Returns

Error code

Example

```
CONFIG OBJECT URLGROUP NEW name=antivirus_bypass type=urlgroup
```

```
CONFIG OBJECT URLGROUP NEW name=bank_bypass type=cngroup CACHE_CATEGORY objects
```

CONFIG OBJECT URLGROUP REMOVEFROM**Level**

contentfilter,modify

History

appears on Netasq 9.0.0

Description

Delete an url from an URL/CN group

**Usage**

group=<groupname> type={urlgroup|cngroup} url=<url>

Returns

Error code

Example

```
CONFIG OBJECT URLGROUP REMOVEFROM group=antivirus_bypass type=urlgroup
url=*.stormshield.eu/*
CONFIG OBJECT URLGROUP REMOVEFROM group=antivirus_bypass type=cngroup
url=www.bank.com CACHE_CATEGORY objects
```

CONFIG OBJECT URLGROUP SETBASE**Level**

base

History

FORMAT appears in Netasq 9.0.0
modify name on Netasq 9.0.0
was CONFIG.OBJECT.URL.SETBASE
appears in Netasq 6.2.0

Description

Switch the OEM group database used by URL/SSL Filtering, or display the actual used one.

Usage

[base=<NONE|NETASQ|CLOUDURL>]

Returns

Without args:

[Config]

URLFiltering=<base name>

When setting a base: Error code.

Remark

contentfilter and modify levels needed to set a base

Format

section

Example

```
CONFIG OBJECT URLGROUP SETBASE base=NETASQ CACHE_CATEGORY objects
```

CONFIG OBJECT URLGROUP SHOW**Level**

base

History

modify on Netasq 9.0.0
FORMAT appears on Netasq 9.0.0
appears in Netasq 6.0.0

Description

Show one or all custom URL/CN groups

**Usage**

name=<groupname> type=(urlgroup|cngroup) [start=<int> [limit=<int>] [dir=<ASC|DESC>]
[refresh=<0|1>]]

Returns

A list of URLs/CNs of matching custom group
[<groupname>
<url>
<url>

Format

section_line

Example

```
CONFIG OBJECT URLGROUP SHOW name=antivirus_bypass type=urlgroup  
[antivirus_bypass]  
*.windowsupdate.com/*  
*.windowsupdate.microsoft.com/* CACHE_CATEGORY objects
```

CONFIG OPENVPN

Level

base

History

Appears in 1.0.0

Description

Openvpn related functions

CONFIG OPENVPN ACTIVATE

Level

vpn,modify,network

History

Appears in 1.0.0

Description

Apply openvpn configuration and reload openvpn service with this new configuration

Usage

[CANCEL] : changes are discarded

Returns

Error code

CONFIG OPENVPN DEFAULT

Level

vpn,modify,network

History



Appears in 1.0.0

Description

Set the default configuration (in clone file) for openvpn server

Returns

Error code

CONFIG OPENVPN DOWNLOAD**Level**

vpn,maintenance,network

History

Appears in 2.0.0

usb disappears in 4.0.0

Description

Download openvpn config file

Format

raw

Returns

Error code

Example

CONFIG OPENVPN DOWNLOAD

CONFIG OPENVPN LIST**Level**

base

History

Appears in 3.5.0

Description

List the available TLS/Ciphers/Digests/Curves

Usage

type=[tls|ciphers|digests|curves]

type=tls: Show all TLS ciphers (TLS used only as a control channel).

type=ciphers: Show cipher algorithms.

type=digests: Show message digest algorithms.

type=curves: Show Diffie–Hellman's elliptic curve (For ECDHE-XXXXXXX tls).

Usage

type=[tls|ciphers|digests|curves]

Returns

Error code



CONFIG OPENVPN SHOW

Level

base

History

Appears in 1.0.0

Description

Display openvpn information

Usage

`[[useclone=0|1]][crypto=authAlgo|cipher|tlsCipher]]`

useclone : specify if displayed configuration comes from clone file or not

crypto=authAlgo : display available Auth algorithms

crypto=cipher : display available Cipher algorithms

crypto=tlsCipher : display available TLS algorithms

Returns

[Config]

state= : openvpn activation state

pool= : IP addresses pool

Port= : public listening port for the service

route= : pushed routes on openvpn client

serverPublicAddr= : public address to contact openvpn server

timeout= : renegotiation time of channel

serverCertificate= : server certificate

clientCertificate= : client certificate

cipher= : used encrypt algorithm

tlsCipher= : used encrypt algorithm for tls

authAlgo= : message digest algorithm

persist= : client IP persistency

primaryDns= : pushed primary dns on openvpn client

secondaryDns= : pushed secondary dns on openvpn client

domainName= : pushed domain name on openvpn client

verbose= : verbose activation level

verboseFile= : used verbose file

udpBindAddr= : Firewall local IP used to bind the OpenVPN UDP server

Compress= : enable/disable LZ4 compression

StrictCert= : enable/disable strict server certificate check (type server and name)

HandWindow= : configure Handshake Window -- the TLS-based key exchange must finalize within n seconds of handshake initiation by any peer

Example

CONFIG OPENVPN SHOW

CONFIG OPENVPN SHOW useclone=1

CONFIG OPENVPN SHOW crypto=authAlgo

CONFIG OPENVPN UPDATE

Level

vpn,modify,network

History



Appears in 1.0.0
RegisterDNS and BlockOutDNS appear in 3.0.0
udppool appears in 3.2.0
udpBindAddr appears in 3.4.0
Compress and StrictCert appear in 3.8.0
BindAddr appears in 4.3.25

Description

Update OpenVPN configuration (in clone file) for openvpn server

Usage

[state=0|1] : openvpn server state
[pool=<network_object>] : IP tcp pool allocated to openvpn clients
[udppool=<network_object>] : IP udp pool allocated to openvpn clients
[udpport=<port>] : public listening udp port for the service
[route=<any|host|network|group_object>] : Networks pushed on openvpn clients
[timeout=<seconds>] : period of data channel renegotiation
[serverCertificate=<cert_name>] : certificate of server
[clientCertificate=<cert_name>] : certificate of client
[cipher=<algo>] : specify algorithm to encrypt packets
[tlsCipher=<algo>] : specify algorithm to encrypt packets for tls
[authAlgo=<algo>] : specify algorithm for message digest
[persistIp=0|1] : client IP address persistency
[serverPublicAddr=<ip> or <hostname>] : public address to contact openvpn server
[port=<port>] : public listening port for the service
[primaryDns=<host_object>] : pushed primary dns on openvpn client
[secondaryDns=<host_object>] : pushed secondary dns on openvpn client
[domainName=<domain name>] : pushed domain name on openvpn client
[ping=<ping timer>] : Interval in seconds between 2 ping requests
[pingrestart=<no response timer>] : Timeout in seconds after which the connection will be restarted if no ping response was received
[RegisterDNS=<on|off>] : On connection initiation, run Windows commands that will force to recognize pushed DNS servers.
[BlockOutDNS=<on|off>] : Block DNS servers on other network adapters to prevent DNS leaks.
[udpBindAddr={<firewall_ip_object>|""}] : Firewall local IP used to bind the OpenVPN UDP server
[Compress=0|1] : enable/disable LZ4 compression
[StrictCert=0|1] : enable/disable strict server certificate check (type server and name)
[HandWindow=[n]] : configure Handshake Window -- the TLS-based key exchange must finalize within n seconds of handshake initiation by any peer
[BindAddr={<firewall_ip_object>|""}] : Firewall local IP used to bind the OpenVPN server (only works if OpenVPN is not sharing his port)

Returns

Error code

CONFIG PASSWDPOLICY

Level

base

History

Appears in 2.0.0

Description



Commands related to passwords criteria

CONFIG PASSWDPOLICY ACTIVATE

Level

maintenance,modify

History

Appears in 2.0.0

Description

Apply passwords criteria configuration

Usage

[CANCEL] : changes are discarded

Returns

Error code

CONFIG PASSWDPOLICY SET

Level

maintenance,modify

History

Appears in 2.0.0

MinEntropy appears in 4.1

Description

Update passwords criteria

Usage

MinLength=<int> MinSetOfChars={None|AlphaNum|AlphaSpecial} [MinEntropy=<int>]

Returns

Error code

CONFIG PASSWDPOLICY SHOW

Level

base

History

Appears in 2.0.0

MinEntropy appears in 4.1

Description

Display passwords criteria

Returns

[PasswordPolicy]

MinLength=<int>

MinSetOfChars=None|AlphaNum|AlphaSpecial

MinEntropy=<int>

**Example**

```
[PasswordPolicy]  
MinLength=4  
MinSetOfChars=None MinEntropy=20
```

CONFIG PPTP**Level**

base

Description

PPTP server configuration

CONFIG PPTP ACTIVATE**Level**

vpn,modify

History

CANCEL/NEXTBOOT Appears in Netasq 9.0.0
level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Reload PPTP server with latest configuration or cancel modifications

Usage

```
[CANCEL|NEXTBOOT]  
- no argument: changes are activated immediately;  
- CANCEL: changes are discarded;  
- NEXTBOOT: changes will be activated on next boot.
```

Returns

Error code

Remark

check licence PPTP flag before activate

Example

```
CONFIG PPTP ACTIVATE  
CONFIG PPTP ACTIVATE cancel
```

CONFIG PPTP ADVANCED**Level**

vpn,modify

History

level changes from other,modify to vpn,modify in Netasq 9.0.0
ReloadFilteringPolicy appears in Netasq 9.1.0

Description

Advanced parameters configuration

**Usage**

[DNS=<ip address>] [NBDNS=<ip address>] [ReloadFilteringPolicy=0|1]

Returns

Error code

Remark

DNS and NBDNS should be empty

Example

CONFIG PPTP ADVANCED dns=dns_1

CONFIG PPTP ADVANCED dns= ReloadFilteringPolicy=1

CONFIG PPTP METHOD

Level

vpn,modify

History

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Specify authorized encryption methods

Usage

allowed=none|[mppe40],[mppe56],[mppe128],[mppsels]

Returns

Error code

Remark

check licence VPN flag for MPPE 128 bits encryption

Example

CONFIG PPTP METHOD allowed=mppe40,mppe128

CONFIG PPTP POOL

Level

vpn,modify

History

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Specify Ip address pool used in client IP allocation

Usage

<hostgroupname>

Returns

Error code

Remark

You must set an IP address pool to activate PPTP server

**Example**

```
CONFIG PPTP POOL pptp_add
```

CONFIG PPTP SHOW**Level**

vpn_read

History

level changes from base to vpn_read in Netasq 9.0.0

Description

Show PPTP server config

Returns

[Global]

State=0|1 : PPTP server state

Pool=<hostgroup> : Host group name

CryptoRequired=0|1 : Accept only request with encryption

MPPE40=0|1 : Accept MPPE 40 bits proposition

MPPE56=0|1 : Accept MPPE 56 bits proposition

MPPE128=0|1 : Accept MPPE 128 bits proposition

MPPESL=0|1 : Accept MPPE stateless proposition

DNS=<ip address> : DNS IP address sent to the client

NBDNS=<ip address> : WINS IP address sent to the client

ReloadFilteringPolicy=0|1: reload policy when a client connects or disconnects

Example

```
CONFIG PPTP SHOW
```

```
[Global]
```

```
Pool=pptp_add
```

```
State=1
```

```
CryptoRequired=1
```

```
MPPE40=0
```

```
MPPE56=0
```

```
MPPE128=1
```

```
MPPESL=1
```

```
DNS=
```

```
NBDNS=
```

```
ReloadFilteringPolicy=0
```

CONFIG PPTP STATE**Level**

vpn_read

History

level changes from base to vpn_read in Netasq 9.0.0

Description

Get/set the status of the PPTP server

Usage

[On|Off]

**Returns**

The state of the server

Remark

check licence PPTP flag before activate
Vpn level needed to update state value

Example

CONFIG PPTP STATE on
CONFIG PPTP STATE off

CONFIG PPTP USER**Level**

base

Description

PPTP user configuration

History

Appears in Netasq 9.0.0

CONFIG PPTP USER ACTIVATE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Reload PPTP users with lastest configuration or cancel modifications

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Remark

check licence PPTP flag before activate

Example

CONFIG PPTP USERS ACTIVATE CONFIG PPTP USERS ACTIVATE cancel

CONFIG PPTP USER ADD**Level**

vpn,modify

Description

Allow a user to connect pptp

**History**

Appears in Netasq 9.0.0

Usage

user=<username> password=<password>

CONFIG PPTP USER LIST**Level**

vpn_read

Description

List PPTP users how have access to PPTP

History

Appears in Netasq 9.0.0

CONFIG PPTP USER REMOVE**Level**

vpn,modify

Description

Denied a user to connect PPTP

History

Appears in Netasq 9.0.0

Usage

<username>

CONFIG PROTOCOL**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure protocol profiles

CONFIG PROTOCOL ACTIVATE**Level**

asq,modify

History

Appears in Netasq 9.0.0

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;



- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Description

Activate the protocol's configuration

Returns

Error code

Example

CONFIG PROTOCOL <protocol name> ACTIVATE CACHE_CATEGORY alarms

CONFIG PROTOCOL BACNETIP**Level**

base,asq

Description

Commands for the BACNETIP protocol

CONFIG PROTOCOL BACNETIP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the BACNETIP protocol's configuration

Returns

Error code

CONFIG PROTOCOL BACNETIP COMMON**Level**

base,asq

Description

BACNETIP protocol's common settings

CONFIG PROTOCOL BACNETIP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set BACNETIP protocol's common settings

Returns

Error code

**CONFIG PROTOCOL BACNETIP COMMON DEFAULT****Level**

asq,modify

Usage**Description**

Reset BACNETIP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL BACNETIP COMMON SHOW**Level**

base,asq

Usage**Description**

Show BACNETIP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL BACNETIP PROFILE**Level**

base,asq

Description

BACNETIP protocol's profile settings

CONFIG PROTOCOL BACNETIP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the BACNETIP protocol

CONFIG PROTOCOL BACNETIP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the BACNETIP protocol

Returns

Error code

**CONFIG PROTOCOL BACNETIP PROFILE ALARM SHOW****Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the BACNETIP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL BACNETIP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the BACNETIP protocol

Returns

Error code

CONFIG PROTOCOL BACNETIP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the BACNETIP protocol

Returns

Config=00 ...

CONFIG PROTOCOL BACNETIP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description



Copy a BACNETIP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL BACNETIP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset BACNETIP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL BACNETIP PROFILE IPS**Level**

base,asq

Description

BACNETIP protocol's IPS settings

CONFIG PROTOCOL BACNETIP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowConfirmedService=<string>] [AllowUnconfirmedService=<string>]
[DenyConfirmedService=<string>] [DenyUnconfirmedService=<string>] [Log=On|Off]
[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the BACNETIP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL BACNETIP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the BACNETIP protocol

Returns

[00]
name="default"



```
lastmod="2011-02-23 10:47:45"
```

```
...
```

CONFIG PROTOCOL BACNETIP PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show BACNETIP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL BACNETIP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the BACNETIP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL COMMON

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Protocol's common settings

CONFIG PROTOCOL COMMON CONFIG

Level

asq,modify

Description

Set protocol's common settings

**Usage**

[DefaultPort=<service_group_list>|<service_list>] [SSLDefaultPort=<service_list>]

History

Appears in Netasq 9.0.0

Returns

Error code

CONFIG PROTOCOL COMMON DEFAULT**Level**

asq,modify

Description

Reset protocol's common settings to default

History

Appears in Netasq 9.0.0

Returns

Error code

CONFIG PROTOCOL COMMON IPS**Level**

base,asq

Description

Protocol's common IPS settings

CONFIG PROTOCOL COMMON IPS CONFIG**Level**

asq,modify

Description

Set protocol's common IPS settings

Returns

Error code

CONFIG PROTOCOL COMMON SHOW**Level**

base,asq

Description

Show protocol's common settings

History

Appears in Netasq 9.0.0

Returns

Error code



CONFIG PROTOCOL COTP

Level

base,asq

Description

Commands for the COTP protocol

CONFIG PROTOCOL COTP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the COTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL COTP COMMON

Level

base,asq

Description

COTP protocol's common settings

CONFIG PROTOCOL COTP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set COTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL COTP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset COTP protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL COTP COMMON SHOW****Level**

base,asq

Usage**Description**

Show COTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL COTP PROFILE**Level**

base,asq

Description

COTP protocol's profile settings

CONFIG PROTOCOL COTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the COTP protocol

CONFIG PROTOCOL COTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the COTP protocol

Returns

Error code

CONFIG PROTOCOL COTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the COTP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL COTP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the COTP protocol

Returns

Error code

CONFIG PROTOCOL COTP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the COTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL COTP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a COTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL COTP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset COTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL COTP PROFILE IPS**Level**

base,asq

Description

COTP protocol's IPS settings

CONFIG PROTOCOL COTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the COTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL COTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the COTP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL COTP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show COTP protocol profile's settings

Returns

[Common]

[IPS]



State=1
Log=1
Probe=1
...

CONFIG PROTOCOL COTP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the COTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP

Level

base,asq

Description

Commands for the DCERPC_TCP protocol

CONFIG PROTOCOL DCERPC_TCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the DCERPC_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP COMMON

Level

base,asq

Description

DCERPC_TCP protocol's common settings

CONFIG PROTOCOL DCERPC TCP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description



Set DCERPC_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset DCERPC_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP COMMON SHOW**Level**

base,asq

Usage**Description**

Show DCERPC_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL DCERPC_TCP PROFILE**Level**

base,asq

Description

DCERPC_TCP protocol's profile settings

CONFIG PROTOCOL DCERPC_TCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the DCERPC_TCP protocol

CONFIG PROTOCOL DCERPC_TCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description



Reset to a default template alarms for the DCERPC_TCP protocol

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context=(protocol|<ASQ context name>)] [extended=0|1]

Description

Dump the alarm configuration for the DCERPC_TCP protocol

Returns

context=(protocol|<ASQ context name>) id=<alarmid> action=(block|pass) level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_template|new) [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL DCERPC_TCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)] [level=(minor|major|ignore)] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the DCERPC_TCP protocol

Returns

Error code

CONFIG PROTOCOL DCERPC TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the DCERPC_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL DCERPC TCP PROFILE COPY**Level**

asq,modify

Usage



index=<profile_idx> to=<0..9>

Description

Copy a DCERPC_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset DCERPC_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS**Level**

base,asq

Description

DCERPC_TCP protocol's IPS settings

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [EnforceUser=On|Off] [Log=On|Off] [MsbkrpBackupKey=Pass|Block]
[MsdcomlActivation=Pass|Block] [MsdcomlActivationPropertiesIn=Pass|Block]
[MsdcomlActivationPropertiesOut=Pass|Block] [MsdcomlConnectionPoint=Pass|Block]
[MsdcomlConnectionPointContainer=Pass|Block] [MsdcomlContext=Pass|Block]
[MsdcomlEnumGUID=Pass|Block] [MsdcomlEnumString=Pass|Block]
[MsdcomlEnumUnknown=Pass|Block] [MsdcomlObjectExporter=Pass|Block]
[MsdcomlRemUnknown=Pass|Block] [MsdcomlRemUnknown2=Pass|Block]
[MsdcomlRemoteSCMAActivator=Pass|Block] [MsdcomlUnknown=Pass|Block]
[Mseven6EventLog=Pass|Block] [MspanIRPCAsyncNotify=Pass|Block]
[MspanIRPCRemoteObject=Pass|Block] [MsrpcAsyncEmsmdb=Pass|Block]
[MsrpcAtsvc=Pass|Block] [MsrpcAudiosrv=Pass|Block] [MsrpcBrowser=Pass|Block]
[MsrpcDavclntprc=Pass|Block] [MsrpcDnsserver=Pass|Block] [MsrpcEmsmdb=Pass|Block]
[MsrpcEpmf=Pass|Block] [MsrpcEventlog=Pass|Block] [MsrpcGetusertoken=Pass|Block]
[MsrpcHydrals=Pass|Block] [MsrpcIRemoteWinspool=Pass|Block]
[MsrpcIcertpassage=Pass|Block] [MsrpcIcertprotect=Pass|Block] [MsrpcIkeysvc=Pass|Block]
[MsrpcIinitshutdown=Pass|Block] [MsrpcIstoreprov=Pass|Block] [MsrpcIseclogon=Pass|Block]
[MsrpcLlsrpc=Pass|Block] [MsrpcLsarp=Pass|Block] [MsrpcMsDfr=Pass|Block]
[MsrpcMsDtc=Pass|Block] [MsrpcMsExchDatabase=Pass|Block]
[MsrpcMsExchDirectory=Pass|Block] [MsrpcMsExchInfostore=Pass|Block]
[MsrpcMsExchSysatd=Pass|Block] [MsrpcMsFr=Pass|Block] [MsrpcMsIIISCom=Pass|Block]
[MsrpcMsIIISimap4=Pass|Block] [MsrpcMsIIISinetinfo=Pass|Block]



```
[MsrpcMsIISSntp=Pass|Block] [MsrpcMsIISSPop3=Pass|Block] [MsrpcMsIISSmtp=Pass|Block]
[MsrpcMsIsmServ=Pass|Block] [MsrpcMsMessenger=Pass|Block] [MsrpcMsMqqm=Pass|Block]
[MsrpcMsNetlogon=Pass|Block] [MsrpcMsScheduler=Pass|Block] [MsrpcMsadBr=Pass|Block]
[MsrpcMsadDrSuapi=Pass|Block] [MsrpcMsadDsrole=Pass|Block]
[MsrpcMsadDssetup=Pass|Block] [MsrpcNddeapi=Pass|Block] [MsrpcNetdfs=Pass|Block]
[MsrpcNsis=Pass|Block] [MsrpcPmapapi=Pass|Block] [MsrpcPnp=Pass|Block]
[MsrpcPolicyagent=Pass|Block] [MsrpcRpcManagement=Pass|Block] [MsrpcRras=Pass|Block]
[MsrpcSamr=Pass|Block] [MsrpcScesvc=Pass|Block] [MsrpcSfcapi=Pass|Block]
[MsrpcSpoolss=Pass|Block] [MsrpcSrvc=Pass|Block] [MsrpcSsdpsrv=Pass|Block]
[MsrpcSvcctl=Pass|Block] [MsrpcTapsrv=Pass|Block] [MsrpcTrkws=Pass|Block]
[MsrpcW32time=Pass|Block] [MsrpcWinreg=Pass|Block] [MsrpcWinsif=Pass|Block]
[MsrpcWinstationrpc=Pass|Block] [MsrpcWkssvc=Pass|Block]
[MswmilwbemFetchSmartEnum=Pass|Block] [MswmilwbemLoginClientID=Pass|Block]
[MswmilwbemWCOSmartEnum=Pass|Block] [NbSkeletonPerIp=<1..10>]
[OpcaelopcEventAreaBrowser=Pass|Block] [OpcaelopcEventServer=Pass|Block]
[OpcaelopcEventServer2=Pass|Block] [OpcaelopcEventSink=Pass|Block]
[OpcaelopcEventSubscriptionMgt=Pass|Block] [OpcaelopcEventSubscriptionMgt2=Pass|Block]
[OpcaeOpcEventServerCategoryId=Pass|Block] [OpcaeTypeLib10=Pass|Block]
[OpcdalopcEnumOpclItemAttributes=Pass|Block] [OpcdalopcAsyncIo=Pass|Block]
[OpcdalopcAsyncIo2=Pass|Block] [OpcdalopcAsyncIo3=Pass|Block]
[OpcdalopcBrowse=Pass|Block] [OpcdalopcBrowseAddressSpace=Pass|Block]
[OpcdalopcCommon=Pass|Block] [OpcdalopcDataCallback=Pass|Block]
[OpcdalopcEnumGuid=Pass|Block] [OpcdalopcGroupStateMgt=Pass|Block]
[OpcdalopcGroupStateMgt2=Pass|Block] [OpcdalopcItemDeadBandMgt=Pass|Block]
[OpcdalopcItemIo=Pass|Block] [OpcdalopcItemMgt=Pass|Block]
[OpcdalopcItemProperties=Pass|Block] [OpcdalopcItemSamplingMgt=Pass|Block]
[OpcdalopcPublicGroupStateMgt=Pass|Block] [OpcdalopcServer=Pass|Block]
[OpcdalopcServerList=Pass|Block] [OpcdalopcServerList2=Pass|Block]
[OpcdalopcServerPublicGroups=Pass|Block] [OpcdalopcShutdown=Pass|Block]
[OpcdalopcSyncIo=Pass|Block] [OpcdalopcSyncIo2=Pass|Block]
[OpcdaOpcComntTypeLib=Pass|Block] [OpcdaServer10=Pass|Block]
[OpcdaServer20=Pass|Block] [OpcdaServer30=Pass|Block] [OpcdaTypeLib20=Pass|Block]
[OpcdaTypeLib30=Pass|Block] [OpcdaXmldaServer10=Pass|Block]
[OpchdaCatidServer10=Pass|Block] [OpchdalopcAsyncAnnotations=Pass|Block]
[OpchdalopcAsyncRead=Pass|Block] [OpchdalopcAsyncUpdate=Pass|Block]
[OpchdalopcBrowser=Pass|Block] [OpchdalopcDataCallback=Pass|Block]
[OpchdalopcPlayback=Pass|Block] [OpchdalopcServer=Pass|Block]
[OpchdalopcSyncAnnotations=Pass|Block] [OpchdalopcSyncRead=Pass|Block]
[OpchdalopcSyncUpdate=Pass|Block] [OpchdaTypeLib10=Pass|Block] [Probe=On|Off]
[Skeleton=On|Off] [SkeletonTimeout=<0..600>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the DCERPC_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS NBEPMAP

Level

base,asq

History

Appears in 4.0.0

**Description**

Commands to manipulate IPSNbEpmmap section

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS NBEPMAP CONFIG

Level

asq,modify

History

Appears in 4.0.0

Description

Commands to configure token of IPSNbEpmmap section

Usage

index=<profile index> [SkeletonOnlyLocalAddr=<on|off>]
[SkeletonOnlyMsExchangeUUID=<on|off>]

Returns

Error code

Example

CONFIG PROTOCOL DCERPC_TCP PROFILE NBEPMAP CONFIG index=1 SkeletonOnlyLocalAddr=on
SkeletonOnlyMsExchangeUUID=off

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID

History

Appears in 3.2.0

Level

base,asq

Description

Commands to manipulate uuid rules in IPSUUID section

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID INSERT

Level

asq,modify

History

Appears in 3.2.0

Description

add a new uuid rule to IPSUUID section

Usage

index=<profile index> uuid=<string> action=pass|block [group=<string>]

Returns

Error code

Example

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID INSERT index=0 uuid="00000000-0000-0000-0000-000000000000" action=pass group="group1"

**CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID REMOVE****Level**

asq,modify

History

Appears in 3.2.0

Description

remove an uuid rule[s] from IPSUUID section

Usage

index=<profile index> ruleid={<nb>|all}

Returns

Error code

Example

```
CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID add index=0 rule=1
```

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID SHOW**Level**

base,asq

History

Appears in 3.2.0

Format

section_line

Description

dump the uuid rules list from IPSUUID section

Usage

index=<profile index>

Returns

the list in the format : ruleid=nb uuid=<string> action=pass|block group=<string>

Example

```
CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID SHOW index=0
```

CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID UPDATE**Level**

asq,modify

History

Appears in 3.2.0

Description

update an uuid rule in the IPSUUID section

Usage

index=<profile index> ruleid=<nb> [uuid=<string>] [action=pass|block] [group=<string>]

Returns

Error code

**Example**

```
CONFIG PROTOCOL DCERPC_TCP PROFILE IPS UUID UPDATE index=0 rule=1 uuid="00000000-0000-0000-0000-000000000000" action=block group="group2"
```

CONFIG PROTOCOL DCERPC_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the DCERPC_TCP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL DCERPC_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show DCERPC_TCP protocol profile's settings

Returns

```
[Common]

[IPS]
State=1
Log=1
Probe=1
...
```

CONFIG PROTOCOL DCERPC_TCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the DCERPC_TCP protocol profile's informations

Returns

Error code



CONFIG PROTOCOL DNS_TCP

Level

base,asq

Description

Commands for the DNS_TCP protocol

CONFIG PROTOCOL DNS_TCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the DNS_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL DNS_TCP COMMON

Level

base,asq

Description

DNS_TCP protocol's common settings

CONFIG PROTOCOL DNS_TCP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set DNS_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL DNS_TCP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset DNS_TCP protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL DNS_TCP COMMON SHOW****Level**

base,asq

Usage**Description**

Show DNS_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL DNS_TCP PROFILE**Level**

base,asq

Description

DNS_TCP protocol's profile settings

CONFIG PROTOCOL DNS_TCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the DNS_TCP protocol

CONFIG PROTOCOL DNS_TCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the DNS_TCP protocol

Returns

Error code

CONFIG PROTOCOL DNS_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the DNS_TCP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL DNS_TCP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the DNS_TCP protocol

Returns

Error code

CONFIG PROTOCOL DNS TCP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the DNS_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL DNS TCP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a DNS_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL DNS TCP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset DNS_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL DNS_TCP PROFILE IPS**Level**

base,asq

Description

DNS_TCP protocol's IPS settings

CONFIG PROTOCOL DNS_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

```
[DenyNsType=<string>] [DetectLargeMsg=On|Off] [DetectTunneling=On|Off]
[InternalDomain=<string>] [LargeMsgSize=<0..65535>] [NameBuffer=<10..2048>]
[RegisterName=On|Off] [RequestTimeout=<1..60>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the DNS_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL DNS_TCP PROFILE LIST**Level**

base,asq

Usage

```
[index=<profile_idx>]
```

Description

List all available profiles or a specific profile for the DNS_TCP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL DNS_TCP PROFILE SHOW**Level**

base,asq

Usage

```
index=<profile_idx>
```

Description

Show DNS_TCP protocol profile's settings

Returns



[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL DNS TCP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the DNS_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL DNS_UDP

Level

base,asq

Description

Commands for the DNS_UDP protocol

CONFIG PROTOCOL DNS_UDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the DNS_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL DNS_UDP COMMON

Level

base,asq

Description

DNS_UDP protocol's common settings

CONFIG PROTOCOL DNS_UDP COMMON CONFIG

Level

asq,modify

**Usage**

[DefaultPort=<list of obj services>]

Description

Set DNS_UDP protocol's common settings

Returns

Error code

CONFIG PROTOCOL DNS_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset DNS_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL DNS_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show DNS_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL DNS_UDP PROFILE**Level**

base,asq

Description

DNS_UDP protocol's profile settings

CONFIG PROTOCOL DNS_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the DNS_UDP protocol

CONFIG PROTOCOL DNS_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

**Usage**

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the DNS_UDP protocol

Returns

Error code

CONFIG PROTOCOL DNS_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the DNS_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL DNS_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the DNS_UDP protocol

Returns

Error code

CONFIG PROTOCOL DNS_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the DNS_UDP protocol

Returns

Config=00 ...

**CONFIG PROTOCOL DNS_UDP PROFILE COPY****Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a DNS_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL DNS_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset DNS_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL DNS_UDP PROFILE IPS**Level**

base,asq

Description

DNS_UDP protocol's IPS settings

CONFIG PROTOCOL DNS_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

```
[DenyNsType=<string>] [DetectLargeMsg=On|Off] [DetectTunneling=On|Off]  
[InternalDomain=<string>] [LargeMsgSize=<0..65535>] [NameBuffer=<10..2048>]  
[RegisterName=On|Off] [RequestTimeout=<1..60>] [State=On|Off]  
[TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the DNS_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL DNS_UDP PROFILE LIST**Level**

base,asq

Usage



[index=<profile_idx>]

Description

List all available profiles or a specific profile for the DNS_UDP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL DNS_UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show DNS_UDP protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

CONFIG PROTOCOL DNS_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the DNS_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL EDONKEY**Level**

base,asq

Description

Commands for the EDONKEY protocol

CONFIG PROTOCOL EDONKEY ACTIVATE**Level**

asq,modify

**Usage**

[CANCEL|NEXTBOOT]

Description

Activate the EDONKEY protocol's configuration

Returns

Error code

CONFIG PROTOCOL EDONKEY COMMON**Level**

base,asq

Description

EDONKEY protocol's common settings

CONFIG PROTOCOL EDONKEY COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set EDONKEY protocol's common settings

Returns

Error code

CONFIG PROTOCOL EDONKEY COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset EDONKEY protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL EDONKEY COMMON SHOW**Level**

base,asq

Usage**Description**

Show EDONKEY protocol's common settings

Returns

[Common]

...

[IPS]

...



CONFIG PROTOCOL EDONKEY PROFILE

Level

base,asq

Description

EDONKEY protocol's profile settings

CONFIG PROTOCOL EDONKEY PROFILE ALARM

Level

base,asq

Description

Alarm commands for the EDONKEY protocol

CONFIG PROTOCOL EDONKEY PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the EDONKEY protocol

Returns

Error code

CONFIG PROTOCOL EDONKEY PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the EDONKEY protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL EDONKEY PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the EDONKEY protocol

Returns

Error code

CONFIG PROTOCOL EDONKEY PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the EDONKEY protocol

Returns

Config=00 ...

CONFIG PROTOCOL EDONKEY PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a EDONKEY protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL EDONKEY PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset EDONKEY protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL EDONKEY PROFILE IPS**Level**

base,asq

Description

EDONKEY protocol's IPS settings

CONFIG PROTOCOL EDONKEY PROFILE IPS CONFIG**Level**

asq,modify

Usage



[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the EDONKEY protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL EDONKEY PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the EDONKEY protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL EDONKEY PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show EDONKEY protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

CONFIG PROTOCOL EDONKEY PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the EDONKEY protocol profile's informations

Returns



Error code

CONFIG PROTOCOL ENIP_TCP

Level

base,asq

Description

Commands for the ENIP_TCP protocol

CONFIG PROTOCOL ENIP_TCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the ENIP_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL ENIP_TCP COMMON

Level

base,asq

Description

ENIP_TCP protocol's common settings

CONFIG PROTOCOL ENIP_TCP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set ENIP_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL ENIP_TCP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset ENIP_TCP protocol's common settings to default

Returns



Error code

CONFIG PROTOCOL ENIP_TCP COMMON SHOW

Level

base,asq

Usage

Description

Show ENIP_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL ENIP_TCP PROFILE

Level

base,asq

Description

ENIP_TCP protocol's profile settings

CONFIG PROTOCOL ENIP_TCP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the ENIP_TCP protocol

CONFIG PROTOCOL ENIP_TCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the ENIP_TCP protocol

Returns

Error code

CONFIG PROTOCOL ENIP_TCP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the ENIP_TCP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL ENIP_TCP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the ENIP_TCP protocol

Returns

Error code

CONFIG PROTOCOL ENIP_TCP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the ENIP_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL ENIP_TCP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a ENIP_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL ENIP_TCP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset ENIP_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL ENIP_TCP PROFILE IPS**Level**

base,asq

Description

ENIP_TCP protocol's IPS settings

CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE**History**

Appears in 3.5.0

Level

base,asq

Description

Commands to manipulate CIP service rules in CIPSERVICE section

CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE INSERT**Level**

asq,modify

History

Appears in 3.5.0

Description

add a new CIP service rule to CIPSERVICE section

Usage

index=<profile index> [ruleid=nb] class=<string> DenyService=<string> AllowService=<string>
[Comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE INSERT index=0 class="5-20,250"  
DenyService="15,20,50-255" AllowService="" Comment="No custom services allowed"
```

CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE REMOVE**Level**

asq,modify

History

Appears in 3.5.0

Description

remove an CIP service rule(s) from CIPSERVICE section

Usage

index=<profile index> ruleid=(<nb>|all)

**Returns**

Error code

Example

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE remove index=0 rule=1
```

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE SHOW
```

Level

base,asq

History

Appears in 3.5.0

Format

section_line

Description

dump the CIP service rules list from CIPSERVICE section

Usage

index=<profile index>

Returns

the list in the format : ruleid=nb class=<string> DenyService=<string> AllowService=<string>
Comment=<string>

Example

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE SHOW index=0
```

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE UPDATE
```

Level

asq,modify

History

Appears in 3.5.0

Description

update an CIP service rule in the CIPSERVICE section

Usage

index=<profile index> ruleid=<nb> [class=<string>] [DenyService=<string>]
[AllowService=<string>] [Comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CIPSERVICE UPDATE index=0 rule=1 class="30"  
DenyService="" AllowService="5-40,60" Comment="custom allowed services"
```

```
CONFIG PROTOCOL ENIP_TCP PROFILE IPS CONFIG
```

Level

asq,modify

Usage



```
[AllowCommand=<string>] [AllowTCPUrg=On|Off] [CipMaxMultipleService=<1..65535>]  
[DenyCommand=<string>] [Log=On|Off] [MaxPendingRequest=<1..512>]  
[MsgBuffer=<24..65535>] [Probe=On|Off] [RequestTimeout=<1..3600>] [State=On|Off]  
[TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the ENIP_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL ENIP_TCP PROFILE LIST**Level**

base,asq

Usage

```
[index=<profile_idx>]
```

Description

List all available profiles or a specific profile for the ENIP_TCP protocol

Returns

```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL ENIP_TCP PROFILE SHOW**Level**

base,asq

Usage

```
index=<profile_idx>
```

Description

Show ENIP_TCP protocol profile's settings

Returns

```
[Common]  
  
[IPS]  
State=1  
Log=1  
Probe=1  
...
```

CONFIG PROTOCOL ENIP_TCP PROFILE UPDATE**Level**

asq,modify

Usage

```
index=<profile_idx> [name=<string>] [comment=<string>]
```

Description

Update the ENIP_TCP protocol profile's informations

**Returns**

Error code

CONFIG PROTOCOL ENIP_UDP**Level**

base,asq

Description

Commands for the ENIP_UDP protocol

CONFIG PROTOCOL ENIP_UDP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the ENIP_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL ENIP_UDP COMMON**Level**

base,asq

Description

ENIP_UDP protocol's common settings

CONFIG PROTOCOL ENIP_UDP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set ENIP_UDP protocol's common settings

Returns

Error code

CONFIG PROTOCOL ENIP_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset ENIP_UDP protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL ENIP_UDP COMMON SHOW****Level**

base,asq

Usage**Description**

Show ENIP_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL ENIP_UDP PROFILE**Level**

base,asq

Description

ENIP_UDP protocol's profile settings

CONFIG PROTOCOL ENIP_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the ENIP_UDP protocol

CONFIG PROTOCOL ENIP_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the ENIP_UDP protocol

Returns

Error code

CONFIG PROTOCOL ENIP_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the ENIP_UDP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL ENIP_UDP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the ENIP_UDP protocol

Returns

Error code

CONFIG PROTOCOL ENIP_UDP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the ENIP_UDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL ENIP_UDP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a ENIP_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL ENIP_UDP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset ENIP_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL ENIP_UDP PROFILE IPS**Level**

base,asq

Description

ENIP_UDP protocol's IPS settings

CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE**History**

Appears in 3.5.0

Level

base,asq

Description

Commands to manipulate CIP service rules in CIPSERVICE section

CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE INSERT**Level**

asq,modify

History

Appears in 3.5.0

Description

add a new CIP service rule to CIPSERVICE section

Usage

index=<profile index> [ruleid=nb] class=<string> DenyService=<string> AllowService=<string>
[Comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE INSERT index=0 class="5-20,250"  
DenyService="15,20,50-255" AllowService="" Comment="No custom services allowed"
```

CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE REMOVE**Level**

asq,modify

History

Appears in 3.5.0

Description

remove an CIP service rule(s) from CIPSERVICE section

Usage

index=<profile index> ruleid=(<nb>|all)

**Returns**

Error code

Example

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE remove index=0 rule=1
```

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE SHOW
```

Level

base,asq

History

Appears in 3.5.0

Format

section_line

Description

dump the CIP service rules list from CIPSERVICE section

Usage

index=<profile index>

Returns

the list in the format : ruleid=nb class=<string> DenyService=<string> AllowService=<string>
Comment=<string>

Example

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE SHOW index=0
```

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE UPDATE
```

Level

asq,modify

History

Appears in 3.5.0

Description

update an CIP service rule in the CIPSERVICE section

Usage

index=<profile index> ruleid=<nb> [class=<string>] [DenyService=<string>]
[AllowService=<string>] [Comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CIPSERVICE UPDATE index=0 rule=1 class="30"  
DenyService="" AllowService="5-40,60" Comment="custom allowed services"
```

```
CONFIG PROTOCOL ENIP_UDP PROFILE IPS CONFIG
```

Level

asq,modify

Usage



```
[AllowCommand=<string>] [CipMaxMultipleService=<1..65535>] [DenyCommand=<string>]  
[Log=On|Off] [MaxPendingRequest=<1..512>] [MsgBuffer=<24..65535>] [Probe=On|Off]  
[RequestTimeout=<1..3600>] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the ENIP_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL ENIP_UDP PROFILE LIST**Level**

base,asq

Usage

```
[index=<profile_idx>]
```

Description

List all available profiles or a specific profile for the ENIP_UDP protocol

Returns

```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL ENIP_UDP PROFILE SHOW**Level**

base,asq

Usage

```
index=<profile_idx>
```

Description

Show ENIP_UDP protocol profile's settings

Returns

```
[Common]
```

```
[IPS]  
State=1  
Log=1  
Probe=1  
...
```

CONFIG PROTOCOL ENIP_UDP PROFILE UPDATE**Level**

asq,modify

Usage

```
index=<profile_idx> [name=<string>] [comment=<string>]
```

Description

Update the ENIP_UDP protocol profile's informations

Returns



Error code

CONFIG PROTOCOL FTP

Level

base,asq

Description

Commands for the FTP protocol

CONFIG PROTOCOL FTP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the FTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL FTP COMMON

Level

base,asq

Description

FTP protocol's common settings

CONFIG PROTOCOL FTP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set FTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL FTP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset FTP protocol's common settings to default

Returns



Error code

CONFIG PROTOCOL FTP COMMON PROXY

Level

base,asq

History

Appears in 9.0.4

Description

FTP common proxy configuration

CONFIG PROTOCOL FTP COMMON PROXY CONFIG

Level

asq,modify

History

Appears in 9.0.4

Description

Common parameters configuration

Usage

ApplyNat=<0|1>

ApplyNat : Allow outbound connections from proxies to match any NAT rule instead of just dst-only

Returns

Error code

Example

CONFIG PROTOCOL FTP COMMON PROXY CONFIG ApplyNat=0

CONFIG PROTOCOL FTP COMMON SHOW

Level

base,asq

Usage

Description

Show FTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL FTP PROFILE

Level

base,asq

Description

FTP protocol's profile settings

**CONFIG PROTOCOL FTP PROFILE ALARM****Level**

base,asq

Description

Alarm commands for the FTP protocol

CONFIG PROTOCOL FTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the FTP protocol

Returns

Error code

CONFIG PROTOCOL FTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the FTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL FTP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the FTP protocol

Returns

Error code

CONFIG PROTOCOL FTP PROFILE CHECK**Level**



base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the FTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL FTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a FTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL FTP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset FTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL FTP PROFILE IPS**Level**

base,asq

Description

FTP protocol's IPS settings

CONFIG PROTOCOL FTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowOp=<string>] [AllowTCPUrg=On|Off] [AllowUser=<string>] [AuthSSL=On|Off]
[DenyOp=<string>] [DenyUser=<string>] [LineBuffer=<10..2048>] [Log=On|Off]
[NoAuth=On|Off] [PassBuffer=<10..2048>] [PathBuffer=<10..2048>] [Probe=On|Off]
[RFC775=On|Off] [SiteBuffer=<10..2048>] [SkeletonTimeout=<0..600>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>] [UserBuffer=<10..2048>]

Description



Set the FTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL FTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the FTP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL FTP PROFILE PROXY**Level**

base

History

Appears in Netasq 9.0.0

Description

Commands to configure ftp profile settings

CONFIG PROTOCOL FTP PROFILE PROXY ANTIVIRUS**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the antivirus part of the ftp profile

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]
[ftpAvMode=<upload|download|both>]

Returns

Error code

Example

CONFIG PROTOCOL FTP PROFILE PROXY ANTIVIRUS index=1 OnInfectedPolicy=pass
OnFailedPolicy=pass ftpAvMode=both

CONFIG PROTOCOL FTP PROFILE PROXY CMD**Level**

asq,modify

**History**

Appears in Netasq 9.0.0

Description

Configure the authorized cmd of the ftp profile

Usage

index=<profile index>

<ABOR|ACCT|ADAT|ALLO|APPE|AUTH|CCC|CDUP|CONF|CWD|DELE|ENC|EPRT|EPSV|FEAT|HELP|LIST|MDTM|MIC|MKD|MLSD|MLST|MODE|NLST|NOOP|OPTS|PASS|PASV|PBSZ|PORT|PROT|PWD|QUIT|REIN|REST|RETR|RMD|RNFR|RNT0|SITE|SIZE|SMNT|STAT|STOR|STOU|STRU|SYST|TYPE|USER|XCUP|XCWD|XMKD|XPWD|XRMD>=<block|pass|filter>

Returns

Error code

Example

CONFIG PROTOCOL FTP PROFILE PROXY CMD index=1 ABOR=filter ACCT=block ADAT=pass

CONFIG PROTOCOL FTP PROFILE PROXY CONFIG**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the ftp profile

Usage

index=<profile index> [BindAddr=<binding ip addr>] [WelcomeMsgFiltering=on|off]
[ClientMode=any|active|passive] [ServerMode=any|active|passive] [BounceCheck=on|off]
[FullTransparent=on|off]

Returns

Error code

Example

CONFIG PROTOCOL FTP PROFILE PROXY CONFIG index=1 BindAddr=MyObject

WelcomeMsgFiltering=off

ClientMode=any ServerMode=any BounceCheck=on=on

CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure extracmd profile settings

CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD ADD**Level**

asq,modify

**History**

Appears in Netasq 9.0.0

Description

Add additional authorized cmd of the ftp profile

Usage

index=<profile index> <commandname>

Returns

Error code

Example

```
CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD ADD index=1 NEWCOMMAND
```

```
CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD LIST
```

Level

base,asq

History

Appears in Netasq 9.0.0

Format

list

Description

List additional authorized cmd of the ftp profile

Usage

index=<profile index>

Returns

List of all authorized cmds

Example

```
CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD LIST index=1
```

```
CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD REMOVE
```

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove additional authorized cmd of the ftp profile

Usage

index=<profile index> <commandname>

Returns

Error code

Example

```
CONFIG PROTOCOL FTP PROFILE PROXY EXTRACMD REMOVE index=1 NEWCOMMAND
```

**CONFIG PROTOCOL FTP PROFILE PROXY POSTPROC****Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure post processing of the ftp profile

Usage

index=<profile index> [policy=<block|pass>] [size=<MaxDataSize in KB>] [keepalive=<nb of seconds>]

Returns

Error code

Example

CONFIG PROTOCOL FTP PROFILE PROXY POSTPROC index=1 policy=pass size=4000 keepalive=20

CONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING**History**

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing part of the ftp profile

CONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING POLICY**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure policy for sandboxing in ftp profile

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]

Returns

Error code

Example

CONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING POLICY index=1 OnInfectedPolicy=pass
OnFailedPolicy=pass

CONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING TYPE**History**

Appears in 2.3.0

**Level**

base,asq

Description

Commands to configure the sandboxing types of the ftp profile

CONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING TYPE SHOW**Level**

base,asq

History

Appears in 2.3.0

Format

section_line

Description

Show sandboxing type configuration of ftp profile

Usage

index=<profile index>

Returns

[SandboxingType]

state=<on|off> type="archive" maxsize=<MaxDataSize in KB>

state=<on|off> type="document" maxsize=<MaxDataSize in KB>

state=<on|off> type="executable" maxsize=<MaxDataSize in KB>

state=<on|off> type="pdf" maxsize=<MaxDataSize in KB>

CONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING TYPE UPDATE**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure files specifications for sandboxing in ftp profile

Usage

index=<profile index>

type=<Archive|Document|Executable|Pdf>

[state={0|1}]

[maxsize=<MaxDataSize in KB>]

Returns

Error code

ExampleCONFIG PROTOCOL FTP PROFILE PROXY SANDBOXING TYPE UPDATE index=1 type=Archive state=1
maxsize=1000**CONFIG PROTOCOL FTP PROFILE SHOW****Level**

base,asq

**Usage**

index=<profile_idx>

Description

Show FTP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL FTP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the FTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL H245**Level**

base,asq

Description

Commands for the H245 protocol

CONFIG PROTOCOL H245 ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the H245 protocol's configuration

Returns

Error code

CONFIG PROTOCOL H245 COMMON**Level**

base,asq

**Description**

H245 protocol's common settings

CONFIG PROTOCOL H245 COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset H245 protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL H245 COMMON SHOW**Level**

base,asq

Usage**Description**

Show H245 protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL H245 PROFILE**Level**

base,asq

Description

H245 protocol's profile settings

CONFIG PROTOCOL H245 PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the H245 protocol

CONFIG PROTOCOL H245 PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the H245 protocol

**Returns**

Error code

CONFIG PROTOCOL H245 PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the H245 protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL H245 PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the H245 protocol

Returns

Error code

CONFIG PROTOCOL H245 PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the H245 protocol

Returns

Config=00 ...

CONFIG PROTOCOL H245 PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

**Description**

Copy a H245 protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL H245 PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset H245 protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL H245 PROFILE IPS**Level**

base,asq

Description

H245 protocol's IPS settings

CONFIG PROTOCOL H245 PROFILE IPS CONFIG**Level**

asq,modify

Usage

[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the H245 protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL H245 PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the H245 protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

**CONFIG PROTOCOL H245 PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show H245 protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL H245 PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the H245 protocol profile's informations

Returns

Error code

CONFIG PROTOCOL H323**Level**

base,asq

Description

Commands for the H323 protocol

CONFIG PROTOCOL H323 ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the H323 protocol's configuration

Returns

Error code



CONFIG PROTOCOL H323 COMMON

Level

base,asq

Description

H323 protocol's common settings

CONFIG PROTOCOL H323 COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set H323 protocol's common settings

Returns

Error code

CONFIG PROTOCOL H323 COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset H323 protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL H323 COMMON SHOW

Level

base,asq

Usage**Description**

Show H323 protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL H323 PROFILE

Level

base,asq

Description

H323 protocol's profile settings

**CONFIG PROTOCOL H323 PROFILE ALARM****Level**

base,asq

Description

Alarm commands for the H323 protocol

CONFIG PROTOCOL H323 PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the H323 protocol

Returns

Error code

CONFIG PROTOCOL H323 PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the H323 protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL H323 PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the H323 protocol

Returns

Error code

CONFIG PROTOCOL H323 PROFILE CHECK**Level**



base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the H323 protocol

Returns

Config=00 ...

CONFIG PROTOCOL H323 PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a H323 protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL H323 PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset H323 protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL H323 PROFILE IPS**Level**

base,asq

Description

H323 protocol's IPS settings

CONFIG PROTOCOL H323 PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=0n|Off] [Probe=0n|Off] [SkeletonTimeout=<0..600>] [State=0n|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the H323 protocol profile's IPS settings

Returns



Error code

CONFIG PROTOCOL H323 PROFILE LIST

Level

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the H323 protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL H323 PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show H323 protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL H323 PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the H323 protocol profile's informations

Returns

Error code

CONFIG PROTOCOL HASYNC

Level

base,asq

**Description**

Commands for the HASYNC protocol

CONFIG PROTOCOL HASYNC ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the HASYNC protocol's configuration

Returns

Error code

CONFIG PROTOCOL HASYNC COMMON**Level**

base,asq

Description

HASYNC protocol's common settings

CONFIG PROTOCOL HASYNC COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set HASYNC protocol's common settings

Returns

Error code

CONFIG PROTOCOL HASYNC COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset HASYNC protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL HASYNC COMMON IPS**Level**

base,asq

Description



HASYNC protocol's IPS settings

CONFIG PROTOCOL HASYNC COMMON IPS CONFIG

Level

asq,modify

Usage

[BulkLimitAssoc=<1..1000>] [BulkLimitConn=<1..1000>] [BulkLimitHost=<1..100>]
[BulkLimitIPState=<1..100>] [BulkLimitRouter=<1..100>] [BulkLimitSIP=<1..100>]
[BulkLimitUser=<1..100>] [BulkPauseDuration=<1..1000>]
[DelayConnUpd=<0..4294967294>] [DynamicLimit=<0..65535>]

Description

Set the HASYNC protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL HASYNC COMMON SHOW

Level

base,asq

Usage

Description

Show HASYNC protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL HASYNC PROFILE

Level

base,asq

Description

HASYNC protocol's profile settings

CONFIG PROTOCOL HASYNC PROFILE ALARM

Level

base,asq

Description

Alarm commands for the HASYNC protocol

CONFIG PROTOCOL HASYNC PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description



Reset to a default template alarms for the HASYNC protocol

Returns

Error code

CONFIG PROTOCOL HASYNC PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the HASYNC protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL HASYNC PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the HASYNC protocol

Returns

Error code

CONFIG PROTOCOL HASYNC PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the HASYNC protocol

Returns

Config=00 ...

CONFIG PROTOCOL HASYNC PROFILE COPY**Level**

asq,modify

Usage



index=<profile_idx> to=<0..9>

Description

Copy a HASYNC protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL HASYNC PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset HASYNC protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL HASYNC PROFILE IPS**Level**

base,asq

Description

HASYNC protocol's IPS settings

CONFIG PROTOCOL HASYNC PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the HASYNC protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL HASYNC PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the HASYNC protocol

Returns

[00]
name="default"



```
lastmod="2011-02-23 10:47:45"
```

```
...
```

CONFIG PROTOCOL HASYNC PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show HASYNC protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL HASYNC PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the HASYNC protocol profile's informations

Returns

Error code

CONFIG PROTOCOL HTTP

Level

base,asq

Description

Commands for the HTTP protocol

CONFIG PROTOCOL HTTP-WEBSOCKET

Level

base,asq

Description

Commands for the HTTP-WEBSOCKET protocol

CONFIG PROTOCOL HTTP-WEBSOCKET ACTIVATE

Level

asq,modify

**Usage**

[CANCEL|NEXTBOOT]

Description

Activate the HTTP-WEB_SOCKET protocol's configuration

Returns

Error code

CONFIG PROTOCOL HTTP-WEB_SOCKET COMMON**Level**

base,asq

Description

HTTP-WEB_SOCKET protocol's common settings

CONFIG PROTOCOL HTTP-WEB_SOCKET COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset HTTP-WEB_SOCKET protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL HTTP-WEB_SOCKET COMMON SHOW**Level**

base,asq

Usage**Description**

Show HTTP-WEB_SOCKET protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL HTTP-WEB_SOCKET PROFILE**Level**

base,asq

Description

HTTP-WEB_SOCKET protocol's profile settings

CONFIG PROTOCOL HTTP-WEB_SOCKET PROFILE ALARM**Level**

base,asq

Description



Alarm commands for the HTTP-WEBSOCKET protocol

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the HTTP-WEBSOCKET protocol

Returns

Error code

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the HTTP-WEBSOCKET protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the HTTP-WEBSOCKET protocol

Returns

Error code

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description



List all the config referring to the profile specified by index for the HTTP-WEBSOCKET protocol

Returns

Config=00 ...

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a HTTP-WEBSOCKET protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset HTTP-WEBSOCKET protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE IPS**Level**

base,asq

Description

HTTP-WEBSOCKET protocol's IPS settings

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the HTTP-WEBSOCKET protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE LIST**Level**

base,asq

**Usage**

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the HTTP-WEBSOCKET protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show HTTP-WEBSOCKET protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
State=1
Log=1
Probe=1
...
```

CONFIG PROTOCOL HTTP-WEBSOCKET PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the HTTP-WEBSOCKET protocol profile's informations

Returns

Error code

CONFIG PROTOCOL HTTP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the HTTP protocol's configuration

Returns



Error code

CONFIG PROTOCOL HTTP COMMON

Level

base,asq

Description

HTTP protocol's common settings

CONFIG PROTOCOL HTTP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set HTTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL HTTP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset HTTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL HTTP COMMON PROXY

Level

base,asq

History

Appears in 9.0.4

Description

HTTP common proxy configuration

CONFIG PROTOCOL HTTP COMMON PROXY CONFIG

Level

asq,modify

History

Appears in 9.0.4

HTTPCodeOnFail appears in 3.1.0

Description

Common parameters configuration

**Usage**

[ApplyNat=<0|1>] [HTTPOnFail=<200-599>]

ApplyNat : Allow outbound connections from proxies to match any NAT rule instead of just dst-only

HTTPOnFail : HTTP Header code on fail: 202|403|451|...

CONFIG PROTOCOL HTTP COMMON SHOW**Level**

base,asq

Usage**Description**

Show HTTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL HTTP PROFILE**Level**

base,asq

Description

HTTP protocol's profile settings

CONFIG PROTOCOL HTTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the HTTP protocol

CONFIG PROTOCOL HTTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the HTTP protocol

Returns

Error code

CONFIG PROTOCOL HTTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

**Description**

Dump the alarm configuration for the HTTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL HTTP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the HTTP protocol

Returns

Error code

CONFIG PROTOCOL HTTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the HTTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL HTTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a HTTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL HTTP PROFILE DEFAULT**Level**

asq,modify

**Usage**

index=<profile_idx>

Description

Reset HTTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL HTTP PROFILE IPS**Level**

base,asq

Description

HTTP protocol's IPS settings

CONFIG PROTOCOL HTTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Allow8Bit=<string>] [AllowOp=<string>] [AllowOverflow=<string>] [AllowTCPUrg=On|Off]
[ArgumentBuffer=<128..4096>] [ArgumentCount=<128..512>]
[AuthorizationBearerBuffer=<128..4096>] [AuthorizationBuffer=<128..4096>]
[AuthorizationNegotiateBuffer=<128..4096>] [AuthorizationNtlmBuffer=<128..4096>]
[BodyBuffer=<128..4096>] [ContentSecurityPolicyBuffer=<128..65535>]
[ContentTypeBuffer=<128..4096>] [CookieBuffer=<128..65535>] [DenyOp=<string>]
[EnforceUser=On|Off] [HTMLAttrValueBuffer=<128..65536>] [HTMLCleaning=On|Off]
[HTMLContext=On|Off] [HTMLDebug=On|Off] [HTMLMaxBufferSize=<128..1048576>]
[HostBuffer=<128..4096>] [Inflate=On|Off] [InflateRatioLimit=<10..1024>]
[JavascriptAliases=<string>] [JavascriptContext=On|Off] [Log=On|Off]
[MaxClientHeader=<16..512>] [MaxRanges=<0..1024>] [MaxServerHeader=<16..512>]
[Probe=On|Off] [QueryBuffer=<128..4096>] [RequestTimeout=<1..600>] [SafeSearch=On|Off]
[Shoutcast=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
[UAForce10=<string>] [UrlBuffer=<128..4096>] [WebDAV=On|Off]
[XGoogAppsAllowedDomains=<string>] [YoutubeRestrict=<string>]

Description

Set the HTTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL HTTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the HTTP protocol

Returns



```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL HTTP PROFILE PROXY

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure proxy settings for HTTP protocol

CONFIG PROTOCOL HTTP PROFILE PROXY ANTIVIRUS

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the antivirus part of the http profile

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY ANTIVIRUS index=1 OnInfectedPolicy=pass  
OnFailedPolicy=pass
```

CONFIG PROTOCOL HTTP PROFILE PROXY CONFIG

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the http profile

Usage

```
index=<profile index>  
[BindAddr=<binding ip addr>]  
[CheckEncoding=<on|off>]  
[Connect=<on|off>]  
[ConnectPort=<service>]  
[KeepAlive=<on|off>]  
[MaxDataSize=<maximum download data size (0=unlimited)>]  
[PartialDownload=<block|filter|pass>]  
[ProxyAuth=<on|off>]  
[WebDAV=<on|off>]
```



```
[EncodingFilter=<on|off>]  
[TimeoutConnectSrv=<int>]  
[FullTransparent=on|off]  
[Proxy407=on|off]  
[BypassAuthOnConnect=on|off]  
[BypassCors=on|off]
```

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY CONFIG index=1 BindAddr=addr CheckEncoding=on  
Connect=off  
ConnectPort=port KeepAlive=off MaxDataSize=0 PartialDownload=off  
ProxyAuth=on WebDAV=off EncodingFilter=on TimeoutConnectSrv=20  
Proxy407=off BypassAuthOnConnect=off
```

CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE**History**

Appears in Netasq 9.0.0

Level

base,asq

Description

Commands for protocol HTTP ICAPEXCLUDE

CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE ADD**Level**

asq,modify

Description

Add a host/range/network in the exclude list

Usage

```
index=<profile index> host=<host|range|network>
```

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE ADD index=0 host=hostname
```

CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE LIST**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

dump the icap exclude list

Usage

```
index=<profile index>
```

**Returns**

The list

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE LIST index=0
```

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE REMOVE
```

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove a host/range/network from the exclude list

Usage

index=<profile index> host=<host|range|network>

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPEXCLUDE REMOVE index=0 host=hostname
```

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPREQMOD
```

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure icap reqmod service

Usage

index=<profile index> state=<on|off> host=<hostname|hostgroup> port=<reqmod port
service> [loadbalancing=<roundrobin|random|srchash>] service=<string> LdapAuth=<on|off>
IPAuth=<on|off> [HttpPost=<on|off>]

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPREQMOD index=0 state=on host=hostname  
port=icap
```

```
loadbalancing=roundrobin service=string LdapAuth=off IPAuth=off HttpPost=on
```

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPRESPMOD
```

Level

asq,modify

History

Appears in Netasq 9.0.0

Description



Configure icap respmod service

Usage

index=<profile index> state=<on|off> host=<hostname|hostgroup> port=<respmod port service> [loadbalancing=<roundrobin|random|srchash>] service=<string> LdapAuth=<on|off> IPAuth=<on|off>

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY ICAPRESPMOD index=0 state=on host=hostname  
port=icap  
loadbalancing=roundrobin service=string LdapAuth=off IPAuth=off
```

CONFIG PROTOCOL HTTP PROFILE PROXY MIME**History**

Appears in Netasq 9.0.0

Level

base,asq

Description

Commands for protocol HTTP MIME

CONFIG PROTOCOL HTTP PROFILE PROXY MIME INSERT**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

add a mime in the mime list

Usage

index=<profile index> [ruleid=<nb>] [state=on|off] [action=pass|block|checkvirus]
[mime=<string>] [comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY MIME INSERT index=0 ruleid=1 state=on  
action=checkvirus mime="text/plain"
```

CONFIG PROTOCOL HTTP PROFILE PROXY MIME MOVE**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

move a mime in the mime list

**Usage**

index=<profile index> ruleid=<nb> to=<nb>

Returns

Error code

Example

CONFIG PROTOCOL HTTP PROFILE PROXY MIME MOVE index=0 rule=1 to=5

CONFIG PROTOCOL HTTP PROFILE PROXY MIME REMOVE

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

remove mime rules in the mime list

Usage

index=<profile index> ruleid={<nb>|all}

Returns

Error code

Example

CONFIG PROTOCOL HTTP PROFILE PROXY MIME REMOVE index=0 rule=1

CONFIG PROTOCOL HTTP PROFILE PROXY MIME SHOW

Level

base,asq

History

Appears in Netasq 9.0.0

Format

section_line

Description

dump the mime list

Usage

index=<profile index>

Returns

the list in the format : rule=nb state=on|off action=pass|block|checkvirus mime=<string>

Example

CONFIG PROTOCOL HTTP PROFILE PROXY MIME SHOW index=0

CONFIG PROTOCOL HTTP PROFILE PROXY MIME UPDATE

Level

asq,modify

History

Appears in Netasq 9.0.0

**Description**

update a mime in the mime list

Usage

index=<profile index> ruleid=<nb> [state=on|off] [action=pass|block|checkvirus]
[mime=<string>] [comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY MIME UPDATE index=0 rule=1 state=on  
action=checkvirus mime="text/plain"
```

CONFIG PROTOCOL HTTP PROFILE PROXY POSTPROC

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure post processing limit, policy and bypass

Usage

index=<profile index> [policy=<block|pass>] [size=<MaxDataSize in KB>] [keepalive=<nb of
seconds>] [bypass=<urlgroup name>]

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY POSTPROC index=1 policy=pass size=4000  
keepalive=20 bypass=antivirus_bypass
```

CONFIG PROTOCOL HTTP PROFILE PROXY PROTECTAUTHPORTAL

Level

asq,modify

History

Appears in 3.10.0

Description

Configure the Bruteforce part of the HTTP proxy in order to protect auth. portal redirection.

Usage

index=<profile index> [State=<0|1>] [NbEntries=<value>] [NbAttempt=<value>]
[TriesTime=<value>] [TimeoutBanned=<value>]

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE PROXY PROTECTAUTHPORTAL index=0 State=1 NbEntries=50  
NbAttempt=3 TriesTime=60 TimeoutBanned=300
```

**CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING****History**

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing part of the http profile

CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING TYPE**History**

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing types of the http profile

CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING TYPE SHOW**Level**

base,asq

History

Appears in 2.3.0

Format

section_line

Description

Show sandboxing type configuration of http profile

Usage

index=<profile index>

Returns

[SandboxingType]

state=<on|off> type="archive" maxsize=<MaxDataSize in KB>

state=<on|off> type="document" maxsize=<MaxDataSize in KB>

state=<on|off> type="executable" maxsize=<MaxDataSize in KB>

state=<on|off> type="pdf" maxsize=<MaxDataSize in KB>

CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING TYPE UPDATE**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure files specifications for sandboxing in http profile

Usage



index=<profile index>
type=<Archive|Document|Executable|Pdf>
[state={0|1}]
[maxsize=<MaxDataSize in KB>]

Returns

Error code

Example

CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING TYPE UPDATE index=1 type=Archive
state=1 maxsize=1000

CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING POLICY**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure policy for sandboxing in http profile

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]

Returns

Error code

Example

CONFIG PROTOCOL HTTP PROFILE PROXY SANDBOXING POLICY index=1 OnInfectedPolicy=pass
OnFailedPolicy=pass

CONFIG PROTOCOL HTTP PROFILE PROXY URLFILTERING**Level**

asq,modify

History

Appears in Netasq 9.1.0
AllowIP appears in 1.0.0

Description

Configure the URLFiltering part of the HTTP proxy

Usage

index=<profile index> [OnFailedPolicy=<pass|block>] [CheckHostHeader=<0|1>]
[AllowIP=<0|1>]

Returns

Error code

Example

CONFIG PROTOCOL HTTP PROFILE PROXY URLFILTERING index=1 OnFailedPolicy=block
CheckHostHeader=1 AllowIP=0

CONFIG PROTOCOL HTTP PROFILE SHOW**Level**



base,asq

Usage

index=<profile_idx>

Description

Show HTTP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL HTTP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the HTTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL ICMP**Level**

base,asq

Description

Commands for the ICMP protocol

CONFIG PROTOCOL ICMP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the ICMP protocol's configuration

Returns

Error code

CONFIG PROTOCOL ICMP COMMON**Level**



base,asq

Description

ICMP protocol's common settings

CONFIG PROTOCOL ICMP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset ICMP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL ICMP COMMON IPS**Level**

base,asq

Description

ICMP protocol's IPS settings

CONFIG PROTOCOL ICMP COMMON IPS CONFIG**Level**

asq,modify

Usage

[AutoICMPErrorRate=<0..100000000>]

Description

Set the ICMP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL ICMP COMMON SHOW**Level**

base,asq

Usage**Description**

Show ICMP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL ICMP PROFILE**Level**



base,asq

Description

ICMP protocol's profile settings

CONFIG PROTOCOL ICMP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the ICMP protocol

CONFIG PROTOCOL ICMP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the ICMP protocol

Returns

Error code

CONFIG PROTOCOL ICMP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the ICMP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL ICMP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the ICMP protocol

Returns



Error code

CONFIG PROTOCOL ICMP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the ICMP protocol

Returns

Config=00 ...

CONFIG PROTOCOL ICMP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a ICMP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL ICMP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description

Reset ICMP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL ICMP PROFILE IPS

Level

base,asq

Description

ICMP protocol's IPS settings

CONFIG PROTOCOL ICMP PROFILE IPS CONFIG

Level

asq,modify

Usage

[AutoICMP=On|Off] [PostResponseTimeout=<1..5>] [StateTimeout=<2..60>]
[TemplateAlarm=<low|medium|high|internet>]

**Description**

Set the ICMP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL ICMP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the ICMP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL ICMP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show ICMP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL ICMP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the ICMP protocol profile's informations

Returns

Error code



CONFIG PROTOCOL IEC104

Level

base,asq

Description

Commands for the IEC104 protocol

CONFIG PROTOCOL IEC104 ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IEC104 protocol's configuration

Returns

Error code

CONFIG PROTOCOL IEC104 COMMON

Level

base,asq

Description

IEC104 protocol's common settings

CONFIG PROTOCOL IEC104 COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set IEC104 protocol's common settings

Returns

Error code

CONFIG PROTOCOL IEC104 COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset IEC104 protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL IEC104 COMMON SHOW****Level**

base,asq

Usage**Description**

Show IEC104 protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IEC104 PROFILE**Level**

base,asq

Description

IEC104 protocol's profile settings

CONFIG PROTOCOL IEC104 PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the IEC104 protocol

CONFIG PROTOCOL IEC104 PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the IEC104 protocol

Returns

Error code

CONFIG PROTOCOL IEC104 PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IEC104 protocol

Returns



context=(protocol|<ASQ context name>) id=<alarmid> action=(block|pass) level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_template|new) [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IEC104 PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)] [level=(minor|major|ignore)] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IEC104 protocol

Returns

Error code

CONFIG PROTOCOL IEC104 PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IEC104 protocol

Returns

Config=00 ...

CONFIG PROTOCOL IEC104 PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a IEC104 protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL IEC104 PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset IEC104 protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IEC104 PROFILE IPS**Level**

base,asq

Description

IEC104 protocol's IPS settings

CONFIG PROTOCOL IEC104 PROFILE IPS CAUSE**Level**

base,asq

History

Appears in 3.1.0

Description

IPS commands for IEC104 protocol related to cause identification

CONFIG PROTOCOL IEC104 PROFILE IPS CAUSE CONFIG**History**

Appears in 3.1.0

Level

asq,modify

Description

Set/Erase a list of accepted Causes for a type identification

Usage

index=<profile index> Typeld=<Typeld> [Cause=CauseId]

Returns

Error code

Example

Add cause 34 and 56 for Type Id 12:

```
CONFIG PROTOCOL IEC104 PROFILE IPS CAUSE CONFIG index=00 Typeld=12 Cause=34,56
```

Reset causes for type id 12:

```
CONFIG PROTOCOL IEC104 PROFILE IPS CAUSE CONFIG index=00 Typeid=12
```

CONFIG PROTOCOL IEC104 PROFILE IPS CAUSE LIST**History**

Appears in 3.1.0

Usage

index=<profile_idx>

Level

base,asq

Description



Dump the list of accepted Causes by Type identification

Returns

Type_identification1 = Cause1,Cause2,...

Type_identification2 = Cause3,Cause4,...

Example

```
CONFIG PROTOCOL IEC104 PROFILE IPS CAUSE LIST index=00
```

```
101 code=00a01000 msg="Début" format="section"
```

```
3=6
```

```
124=12
```

```
100 code=00a00100 msg="Ok"
```

CONFIG PROTOCOL IEC104 PROFILE IPS CONFIG**Level**

asq,modify

Usage

```
[AllowTCPUrg=On|Off] [AllowTypeId=<string>] [DenyTypeId=<string>] [Log=On|Off]  
[MaxPendingRequest=<1..32768>] [MaxRedundancyGroup=<1..256>]  
[MaxRedundantConn=<1..256>] [MsgBuffer=<12..255>] [Probe=On|Off]  
[RequestTimeout=<1..255>] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the IEC104 protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IEC104 PROFILE LIST**Level**

base,asq

Usage

```
[index=<profile_idx>]
```

Description

List all available profiles or a specific profile for the IEC104 protocol

Returns

```
[00]
```

```
name="default"
```

```
lastmod="2011-02-23 10:47:45"
```

```
...
```

CONFIG PROTOCOL IEC104 PROFILE SHOW**Level**

base,asq

Usage

```
index=<profile_idx>
```

Description

Show IEC104 protocol profile's settings

Returns



[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL IEC104 PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IEC104 protocol profile's informations

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE

Level

base,asq

Description

Commands for the IEC61850-GOOSE protocol

CONFIG PROTOCOL IEC61850-GOOSE ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IEC61850-GOOSE protocol's configuration

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE COMMON

Level

base,asq

Description

IEC61850-GOOSE protocol's common settings

CONFIG PROTOCOL IEC61850-GOOSE COMMON DEFAULT

Level

asq,modify

**Usage****Description**

Reset IEC61850-GOOSE protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE COMMON SHOW**Level**

base,asq

Usage**Description**

Show IEC61850-GOOSE protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IEC61850-GOOSE PROFILE**Level**

base,asq

Description

IEC61850-GOOSE protocol's profile settings

CONFIG PROTOCOL IEC61850-GOOSE PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the IEC61850-GOOSE protocol

CONFIG PROTOCOL IEC61850-GOOSE PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template=[high|medium|low|internet|"] [reset=0|1]

Description

Reset to a default template alarms for the IEC61850-GOOSE protocol

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE PROFILE ALARM SHOW**Level**

base,asq

**Usage**

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IEC61850-GOOSE protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IEC61850-GOOSE PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IEC61850-GOOSE protocol

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IEC61850-GOOSE protocol

Returns

Config=00 ...

CONFIG PROTOCOL IEC61850-GOOSE PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a IEC61850-GOOSE protocol's profile to another profile

Returns

Error code

**CONFIG PROTOCOL IEC61850-GOOSE PROFILE DEFAULT****Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset IEC61850-GOOSE protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE PROFILE IPS**Level**

base,asq

Description

IEC61850-GOOSE protocol's IPS settings

CONFIG PROTOCOL IEC61850-GOOSE PROFILE IPS CONFIG**Level**

asq,modify

Usage[EtherTimeout=<2..604800>] [Log=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]**Description**

Set the IEC61850-GOOSE protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IEC61850-GOOSE PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the IEC61850-GOOSE protocol

Returns[00]
name="default"
lastmod="2011-02-23 10:47:45"
...**CONFIG PROTOCOL IEC61850-GOOSE PROFILE SHOW****Level**

base,asq

Usage



index=<profile_idx>

Description

Show IEC61850-GOOSE protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL IEC61850-GOOSE PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IEC61850-GOOSE protocol profile's informations

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS**Level**

base,asq

Description

Commands for the IEC61850-MMS protocol

CONFIG PROTOCOL IEC61850-MMS ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IEC61850-MMS protocol's configuration

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS COMMON**Level**

base,asq

Description



IEC61850-MMS protocol's common settings

CONFIG PROTOCOL IEC61850-MMS COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset IEC61850-MMS protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS COMMON SHOW

Level

base,asq

Usage**Description**

Show IEC61850-MMS protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IEC61850-MMS PROFILE

Level

base,asq

Description

IEC61850-MMS protocol's profile settings

CONFIG PROTOCOL IEC61850-MMS PROFILE ALARM

Level

base,asq

Description

Alarm commands for the IEC61850-MMS protocol

CONFIG PROTOCOL IEC61850-MMS PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the IEC61850-MMS protocol

Returns



Error code

CONFIG PROTOCOL IEC61850-MMS PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IEC61850-MMS protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IEC61850-MMS PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IEC61850-MMS protocol

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IEC61850-MMS protocol

Returns

Config=00 ...

CONFIG PROTOCOL IEC61850-MMS PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description



Copy a IEC61850-MMS protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset IEC61850-MMS protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS PROFILE IPS**Level**

base,asq

Description

IEC61850-MMS protocol's IPS settings

CONFIG PROTOCOL IEC61850-MMS PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [DenyAdditionalServiceType=<string>] [DenyServiceType=<string>]
[Log=On|Off] [Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the IEC61850-MMS protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IEC61850-MMS PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the IEC61850-MMS protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

**CONFIG PROTOCOL IEC61850-MMS PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show IEC61850-MMS protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL IEC61850-MMS PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IEC61850-MMS protocol profile's informations

Returns

Error code

CONFIG PROTOCOL IEC61850-SV**Level**

base,asq

Description

Commands for the IEC61850-SV protocol

CONFIG PROTOCOL IEC61850-SV ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IEC61850-SV protocol's configuration

Returns

Error code



CONFIG PROTOCOL IEC61850-SV COMMON

Level

base,asq

Description

IEC61850-SV protocol's common settings

CONFIG PROTOCOL IEC61850-SV COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset IEC61850-SV protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL IEC61850-SV COMMON SHOW

Level

base,asq

Usage

Description

Show IEC61850-SV protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IEC61850-SV PROFILE

Level

base,asq

Description

IEC61850-SV protocol's profile settings

CONFIG PROTOCOL IEC61850-SV PROFILE ALARM

Level

base,asq

Description

Alarm commands for the IEC61850-SV protocol

CONFIG PROTOCOL IEC61850-SV PROFILE ALARM DEFAULT

Level

asq,modify

Usage



index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the IEC61850-SV protocol

Returns

Error code

CONFIG PROTOCOL IEC61850-SV PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IEC61850-SV protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IEC61850-SV PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IEC61850-SV protocol

Returns

Error code

CONFIG PROTOCOL IEC61850-SV PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IEC61850-SV protocol

Returns

Config=00 ...

CONFIG PROTOCOL IEC61850-SV PROFILE COPY**Level**



asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a IEC61850-SV protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL IEC61850-SV PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset IEC61850-SV protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IEC61850-SV PROFILE IPS**Level**

base,asq

Description

IEC61850-SV protocol's IPS settings

CONFIG PROTOCOL IEC61850-SV PROFILE IPS CONFIG**Level**

asq,modify

Usage

[EtherTimeout=<2..604800>] [Log=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the IEC61850-SV protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IEC61850-SV PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the IEC61850-SV protocol

Returns



```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL IEC61850-SV PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show IEC61850-SV protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL IEC61850-SV PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IEC61850-SV protocol profile's informations

Returns

Error code

CONFIG PROTOCOL IGMP

Level

base,asq

Description

Commands for the IGMP protocol

CONFIG PROTOCOL IGMP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IGMP protocol's configuration

**Returns**

Error code

CONFIG PROTOCOL IGMP COMMON**Level**

base,asq

Description

IGMP protocol's common settings

CONFIG PROTOCOL IGMP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set IGMP protocol's common settings

Returns

Error code

CONFIG PROTOCOL IGMP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset IGMP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL IGMP COMMON SHOW**Level**

base,asq

Usage**Description**

Show IGMP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IGMP PROFILE**Level**

base,asq

**Description**

IGMP protocol's profile settings

CONFIG PROTOCOL IGMP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the IGMP protocol

CONFIG PROTOCOL IGMP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the IGMP protocol

Returns

Error code

CONFIG PROTOCOL IGMP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IGMP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IGMP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IGMP protocol

Returns



Error code

CONFIG PROTOCOL IGMP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IGMP protocol

Returns

Config=00 ...

CONFIG PROTOCOL IGMP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a IGMP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL IGMP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description

Reset IGMP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IGMP PROFILE IPS

Level

base,asq

Description

IGMP protocol's IPS settings

CONFIG PROTOCOL IGMP PROFILE IPS CONFIG

Level

asq,modify

Usage



[Log=On|Off] [Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the IGMP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IGMP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the IGMP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL IGMP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show IGMP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL IGMP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IGMP protocol profile's informations

Returns



Error code

CONFIG PROTOCOL IMAP4

Level

base,asq

Description

Commands for the IMAP4 protocol

CONFIG PROTOCOL IMAP4 ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IMAP4 protocol's configuration

Returns

Error code

CONFIG PROTOCOL IMAP4 COMMON

Level

base,asq

Description

IMAP4 protocol's common settings

CONFIG PROTOCOL IMAP4 COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set IMAP4 protocol's common settings

Returns

Error code

CONFIG PROTOCOL IMAP4 COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset IMAP4 protocol's common settings to default

Returns



Error code

CONFIG PROTOCOL IMAP4 COMMON SHOW

Level

base,asq

Usage

Description

Show IMAP4 protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IMAP4 PROFILE

Level

base,asq

Description

IMAP4 protocol's profile settings

CONFIG PROTOCOL IMAP4 PROFILE ALARM

Level

base,asq

Description

Alarm commands for the IMAP4 protocol

CONFIG PROTOCOL IMAP4 PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the IMAP4 protocol

Returns

Error code

CONFIG PROTOCOL IMAP4 PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IMAP4 protocol

Returns



context=(protocol|<ASQ context name>) id=<alarmid> action=(block|pass) level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_template|new) [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IMAP4 PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)] [level=(minor|major|ignore)] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IMAP4 protocol

Returns

Error code

CONFIG PROTOCOL IMAP4 PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IMAP4 protocol

Returns

Config=00 ...

CONFIG PROTOCOL IMAP4 PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a IMAP4 protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL IMAP4 PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset IMAP4 protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IMAP4 PROFILE IPS**Level**

base,asq

Description

IMAP4 protocol's IPS settings

CONFIG PROTOCOL IMAP4 PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the IMAP4 protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IMAP4 PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the IMAP4 protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL IMAP4 PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show IMAP4 protocol profile's settings

Returns

[Common]

[IPS]



State=1
Log=1
Probe=1
...

CONFIG PROTOCOL IMAP4 PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IMAP4 protocol profile's informations

Returns

Error code

CONFIG PROTOCOL IP

Level

base,asq

Description

Commands for the IP protocol

CONFIG PROTOCOL IP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the IP protocol's configuration

Returns

Error code

CONFIG PROTOCOL IP COMMON

Level

base,asq

Description

IP protocol's common settings

CONFIG PROTOCOL IP COMMON DEFAULT

Level

asq,modify

Usage**Description**



Reset IP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL IP COMMON INPUTLOADBALANCE**Level**

asq,modify

History

Appears in 2.7.0 and 3.1.0, deprecate ESPLoadBalance option

Description

Configure the IP input load balance mode.

Usage

[Type=<none|esp-rr|esp-spi|dscp>] [DSCPMAP=<[dscp:isr[,dscp:isr[...]]]]

Type can take 4 values:

- none: off
- esp-rr : CPU round-robin for ESP flows
- esp-spi: CPU dispatch based on SPI
- dscp: CPU dispatch based on DSCPMAP

Returns

Error code

Example

CONFIG PROTOCOL IP COMMON INPUTLOADBALANCE Type=dscp DSCPMAP="40:0,41:1,42:2,48:3"

CONFIG PROTOCOL IP COMMON IPS**Level**

base,asq

Description

IP protocol's IPS settings

CONFIG PROTOCOL IP COMMON IPS CONFIG**Level**

asq,modify

Usage

[ActiveHostTimeout=<5..36000>] [IpstateUseDscp=On|Off] [LearningHostTimeout=<5..2400>]
[MTULimit=<0|140..65535>] [MiniHostTimeout=<5..24000>]
[MulticastHostTimeout=<5..9600>] [OptimizeLargeTable=<0..2>]
[OptimizeRuleMatch=<string>] [PBRPersistConnGw=On|Off] [PurgeHostTimeout=<5..2400>]
[RandomID=On|Off] [RuleMatchCacheTableMinSize=<1..1000000>]
[RuleMatchISLThreshold=<1..1024>] [Stealth=On|Off] [UnanalyzedIpProto=<string>]

Description

Set the IP protocol profile's IPS settings

Returns

Error code

**CONFIG PROTOCOL IP COMMON IPS FRAGMENT****Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure common fragmentation settings for ip

Usage

[FragLimit=<28..65535>] [KeepFrag=<On|Off>] [StateTimeout=<0|2..30>]

Returns

Error code

Example

CONFIG PROTOCOL IP COMMON IPS FRAGMENT PortScanRate=10 UserRemoveState=On

CONFIG PROTOCOL IP COMMON SHOW**Level**

base,asq

Usage**Description**

Show IP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL IP PROFILE**Level**

base,asq

Description

IP protocol's profile settings

CONFIG PROTOCOL IP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the IP protocol

CONFIG PROTOCOL IP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

**Description**

Reset to a default template alarms for the IP protocol

Returns

Error code

CONFIG PROTOCOL IP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the IP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL IP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the IP protocol

Returns

Error code

CONFIG PROTOCOL IP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the IP protocol

Returns

Config=00 ...

CONFIG PROTOCOL IP PROFILE COPY**Level**

asq,modify

**Usage**

index=<profile_idx> to=<0..9>

Description

Copy a IP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL IP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset IP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL IP PROFILE IPS**Level**

base,asq

Description

IP protocol's IPS settings

CONFIG PROTOCOL IP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Log=On|Off] [Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the IP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL IP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the IP protocol

Returns

[00]
name="default"



```
lastmod="2011-02-23 10:47:45"
```

```
...
```

CONFIG PROTOCOL IP PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show IP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

```
...
```

CONFIG PROTOCOL IP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the IP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN

Level

base,asq

Description

Commands for the KASPERSKY-KSN protocol

CONFIG PROTOCOL KASPERSKY-KSN ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the KASPERSKY-KSN protocol's configuration

Returns



Error code

CONFIG PROTOCOL KASPERSKY-KSN COMMON

Level

base,asq

Description

KASPERSKY-KSN protocol's common settings

CONFIG PROTOCOL KASPERSKY-KSN COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset KASPERSKY-KSN protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN COMMON SHOW

Level

base,asq

Usage

Description

Show KASPERSKY-KSN protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL KASPERSKY-KSN PROFILE

Level

base,asq

Description

KASPERSKY-KSN protocol's profile settings

CONFIG PROTOCOL KASPERSKY-KSN PROFILE ALARM

Level

base,asq

Description

Alarm commands for the KASPERSKY-KSN protocol

CONFIG PROTOCOL KASPERSKY-KSN PROFILE ALARM DEFAULT

Level

asq,modify

**Usage**

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the KASPERSKY-KSN protocol

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the KASPERSKY-KSN protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL KASPERSKY-KSN PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the KASPERSKY-KSN protocol

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the KASPERSKY-KSN protocol

Returns

Config=00 ...

**CONFIG PROTOCOL KASPERSKY-KSN PROFILE COPY****Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a KASPERSKY-KSN protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset KASPERSKY-KSN protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN PROFILE IPS**Level**

base,asq

Description

KASPERSKY-KSN protocol's IPS settings

CONFIG PROTOCOL KASPERSKY-KSN PROFILE IPS CONFIG**Level**

asq,modify

Usage[AllowTCPUrg=On|Off] [Log=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]**Description**

Set the KASPERSKY-KSN protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL KASPERSKY-KSN PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description



List all available profiles or a specific profile for the KASPERSKY-KSN protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL KASPERSKY-KSN PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show KASPERSKY-KSN protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL KASPERSKY-KSN PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the KASPERSKY-KSN protocol profile's informations

Returns

Error code

CONFIG PROTOCOL LDAP_TCP**Level**

base,asq

Description

Commands for the LDAP_TCP protocol

CONFIG PROTOCOL LDAP_TCP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

**Description**

Activate the LDAP_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL LDAP_TCP COMMON**Level**

base,asq

Description

LDAP_TCP protocol's common settings

CONFIG PROTOCOL LDAP_TCP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set LDAP_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL LDAP_TCP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset LDAP_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL LDAP_TCP COMMON SHOW**Level**

base,asq

Usage**Description**

Show LDAP_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

**CONFIG PROTOCOL LDAP_TCP PROFILE****Level**

base,asq

Description

LDAP_TCP protocol's profile settings

CONFIG PROTOCOL LDAP_TCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the LDAP_TCP protocol

CONFIG PROTOCOL LDAP_TCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the LDAP_TCP protocol

Returns

Error code

CONFIG PROTOCOL LDAP_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the LDAP_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL LDAP_TCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the LDAP_TCP protocol

Returns

Error code

CONFIG PROTOCOL LDAP_TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the LDAP_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL LDAP_TCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a LDAP_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL LDAP_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset LDAP_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL LDAP_TCP PROFILE IPS**Level**

base,asq

Description

LDAP_TCP protocol's IPS settings

CONFIG PROTOCOL LDAP_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage



[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the LDAP_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL LDAP_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the LDAP_TCP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL LDAP_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show LDAP_TCP protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

CONFIG PROTOCOL LDAP_TCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the LDAP_TCP protocol profile's informations

Returns



Error code

CONFIG PROTOCOL LIST

Level

base,asq

History

Appears in Netasq 9.0.0

Description

List all the supported protocols

CONFIG PROTOCOL MGCP

Level

base,asq

Description

Commands for the MGCP protocol

CONFIG PROTOCOL MGCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the MGCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL MGCP COMMON

Level

base,asq

Description

MGCP protocol's common settings

CONFIG PROTOCOL MGCP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set MGCP protocol's common settings

Returns

Error code

**CONFIG PROTOCOL MGCP COMMON DEFAULT****Level**

asq,modify

Usage**Description**

Reset MGCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL MGCP COMMON SHOW**Level**

base,asq

Usage**Description**

Show MGCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL MGCP PROFILE**Level**

base,asq

Description

MGCP protocol's profile settings

CONFIG PROTOCOL MGCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the MGCP protocol

CONFIG PROTOCOL MGCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the MGCP protocol

Returns

Error code

**CONFIG PROTOCOL MGCP PROFILE ALARM SHOW****Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the MGCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL MGCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the MGCP protocol

Returns

Error code

CONFIG PROTOCOL MGCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the MGCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL MGCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a MGCP protocol's profile to another profile

**Returns**

Error code

CONFIG PROTOCOL MGCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset MGCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL MGCP PROFILE IPS**Level**

base,asq

Description

MGCP protocol's IPS settings

CONFIG PROTOCOL MGCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[ChildTimeout=<60..604800>] [CommandBuffer=<32..1024>] [ParameterBuffer=<32..1024>]
[Probe=On|Off] [SDPBuffer=<32..1024>] [SkeletonTimeout=<0..600>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the MGCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL MGCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the MGCP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

**CONFIG PROTOCOL MGCP PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show MGCP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL MGCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the MGCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL MODBUS**Level**

base,asq

Description

Commands for the MODBUS protocol

CONFIG PROTOCOL MODBUS ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the MODBUS protocol's configuration

Returns

Error code



CONFIG PROTOCOL MODBUS COMMON

Level

base,asq

Description

MODBUS protocol's common settings

CONFIG PROTOCOL MODBUS COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set MODBUS protocol's common settings

Returns

Error code

CONFIG PROTOCOL MODBUS COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset MODBUS protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL MODBUS COMMON SHOW

Level

base,asq

Usage**Description**

Show MODBUS protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL MODBUS PROFILE

Level

base,asq

Description

MODBUS protocol's profile settings

**CONFIG PROTOCOL MODBUS PROFILE ALARM****Level**

base,asq

Description

Alarm commands for the MODBUS protocol

CONFIG PROTOCOL MODBUS PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the MODBUS protocol

Returns

Error code

CONFIG PROTOCOL MODBUS PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the MODBUS protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL MODBUS PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the MODBUS protocol

Returns

Error code

CONFIG PROTOCOL MODBUS PROFILE CHECK**Level**



base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the MODBUS protocol

Returns

Config=00 ...

CONFIG PROTOCOL MODBUS PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a MODBUS protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL MODBUS PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset MODBUS protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL MODBUS PROFILE IPS**Level**

base,asq

Description

MODBUS protocol's IPS settings

CONFIG PROTOCOL MODBUS PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowCode=<string>] [AllowCodeUmas=<string>] [AllowSofbusLacbus=On|Off]
[AllowTCPUrg=On|Off] [AllowUmas=On|Off] [AllowedUnitId=<string>] [DenyCode=<string>]
[DenyCodeUmas=<string>] [Log=On|Off] [MaxFileNumber=<1..65535>]
[MaxPendingRequest=<1..512>] [MaxReservLifeTimeUmas=<0..4294967295>]
[MsgBuffer=<8..4096>] [MsgBufferUmas=<10..4096>] [Probe=On|Off]



[RequestTimeout=<1..3600>] [SerialGateway=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the MODBUS protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS

History

Appears in 4.3.0

Level

base,asq

Description

Commands to manipulate Sofbus/Lacbus custom UI/Blocks in CUSTOMCODESOFBUSLACBUS section

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS INSERT

Level

asq,modify

History

Appears in 4.3.0

Description

add a new Sofbus/Lacbus custom UI/Blocks to CUSTOMCODESOFBUSLACBUS section

Usage

index=<profile index> [ruleid=nb] proto=<sofbus|lacbus> ui=<A-Z> [block=<a-zA-Z>]
[comment=<string>]

Returns

Error code

Example

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS INSERT index=0

proto=lacbus ui=C block=a comment="Lacbus ui C block a is allowed"

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS INSERT index=0

proto=sofbus ui=A comment="Sofbus ui A is allowed"

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS INSERT index=0 ruleid=2

proto=lacbus ui=C comment="Lacbus ui C is allowed"

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS REMOVE

Level

asq,modify

History

Appears in 4.3.0

Description

remove a Sofbus/Lacbus custom UI/Blocks from CUSTOMCODESOFBUSLACBUS section

Usage



index=<profile index> ruleid={<nb>|all}

Returns

Error code

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS remove index=0 ruleid=2
CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS remove index=2
ruleid=all
```

CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS SHOW

Level

base,asq

History

Appears in 4.3.0

Format

section_line

Description

dump the Sofbus/Lacbus custom UI/Blocks list from CUSTOMCODESOFBUSLACBUS section

Usage

index=<profile index>

Returns

the Sofbus/Lacbus custom UI/Blocks list in the format : proto=<sofbus|lacbus> ui=<A-Z>
[block=<a-zA-Z>] [comment=<string>]

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS SHOW index=0
CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS UPDATE
```

Level

asq,modify

History

Appears in 4.3.0

Description

update a Sofbus/Lacbus custom UI/Blocks in the CUSTOMCODESOFBUSLACBUS section

Usage

index=<profile index> ruleid=<nb> proto=<sofbus|lacbus> ui=<A-Z> [block=<a-zA-Z>]
[comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS CUSTOMCODESOFBUSLACBUS UPDATE index=0 ruleid=1
proto=lacbus ui=C comment="Update rule"
```

CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS

History



Appears in 4.3.0

Level

base,asq

Description

Commands to manipulate Sofbus/Lacbus deny UI/Blocks in DENYCODESOFBUSLACBUS section

CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS INSERT**Level**

asq,modify

History

Appears in 4.3.0

Description

add a new Sofbus/Lacbus deny UI/Blocks to DENYCODESOFBUSLACBUS section

Usage

index=<profile index> [ruleid=nb] proto=<sofbus|lacbus> ui=<A-Z> [block=<a-zA-Z>]
[comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS INSERT index=0  
proto=sofbus ui=C block=a comment="Sofbus ui C block a not allowed"  
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS INSERT index=0  
proto=lacbus ui=F comment="Lacbus ui F all blocks not allowed"  
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS INSERT index=0 ruleid=2  
proto=lacbus ui=F comment="Lacbus ui F all blocks not allowed"
```

CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS REMOVE**Level**

asq,modify

History

Appears in 4.3.0

Description

remove a Sofbus/Lacbus deny UI/Blocks from DENYCODESOFBUSLACBUS section

Usage

index=<profile index> ruleid={<nb>|all}

Returns

Error code

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS remove index=0 ruleid=2  
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS remove index=2 ruleid=all
```

CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS SHOW**Level**

base,asq

**History**

Appears in 4.3.0

Format

section_line

Description

dump the Sofbus/Lacbus deny UI/Blocks list from DENYCODESOFBUSLACBUS section

Usage

index=<profile index>

Returns

the Sofbus/Lacbus deny UI/Blocks list in the format : proto=<sofbus|lacbus> ui=<A-Z>
[block=<a-zA-Z>] [comment=<string>]

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS SHOW index=0
```

```
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS UPDATE
```

Level

asq,modify

History

Appears in 4.3.0

Description

update a Sofbus/Lacbus deny UI/Blocks in the DENYCODESOFBUSLACBUS section

Usage

index=<profile index> ruleid=<nb> proto=<sofbus|lacbus> ui=<A-Z> [block=<a-zA-Z>]
[comment=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL MODBUS PROFILE IPS DENYCODESOFBUSLACBUS UPDATE index=0 ruleid=1  
proto=lacbus ui=F comment="Update rule"
```

```
CONFIG PROTOCOL MODBUS PROFILE IPS MEMORYACCESS
```

Level

base,asq

History

Appears in 3.1.0

Description

IPS commands for MODBUS protocol related to memory access management

```
CONFIG PROTOCOL MODBUS PROFILE IPS MEMORYACCESS CONFIG
```

Level

asq,modify

History



Appears in 3.1.0

Description

Configure memory access by function code for MODBUS protocol

Usage

index=<profile index> [01=<value,range_min-range_max,...>] [02=<value,range_min-range_max,...>] [03=<value,range_min-range_max,...>] [04=<value,range_min-range_max,...>] [05=<value,range_min-range_max,...>] [06=<value,range_min-range_max,...>] [15=<value,range_min-range_max,...>] [16=<value,range_min-range_max,...>] [22=<value,range_min-range_max,...>] [23=<value,range_min-range_max,...>] [24=<value,range_min-range_max,...>] where value, range_min and range_max in [0..65535] and multiple address ranges and values can be defined

Returns

Error code

Example

CONFIG PROTOCOL MODBUS PROFILE IPS MEMORYACCESS 01=0-2000 index=1

CONFIG PROTOCOL MODBUS PROFILE LIST

Level

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the MODBUS protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL MODBUS PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show MODBUS protocol profile's settings

Returns

[Common]

```
[IPS]
State=1
Log=1
Probe=1
...
```

**CONFIG PROTOCOL MODBUS PROFILE UPDATE****Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the MODBUS protocol profile's informations

Returns

Error code

CONFIG PROTOCOL MSN**Level**

base,asq

Description

Commands for the MSN protocol

CONFIG PROTOCOL MSN ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the MSN protocol's configuration

Returns

Error code

CONFIG PROTOCOL MSN COMMON**Level**

base,asq

Description

MSN protocol's common settings

CONFIG PROTOCOL MSN COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set MSN protocol's common settings

Returns

Error code

**CONFIG PROTOCOL MSN COMMON DEFAULT****Level**

asq,modify

Usage**Description**

Reset MSN protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL MSN COMMON SHOW**Level**

base,asq

Usage**Description**

Show MSN protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL MSN PROFILE**Level**

base,asq

Description

MSN protocol's profile settings

CONFIG PROTOCOL MSN PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the MSN protocol

CONFIG PROTOCOL MSN PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the MSN protocol

Returns

Error code

**CONFIG PROTOCOL MSN PROFILE ALARM SHOW****Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the MSN protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL MSN PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the MSN protocol

Returns

Error code

CONFIG PROTOCOL MSN PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the MSN protocol

Returns

Config=00 ...

CONFIG PROTOCOL MSN PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a MSN protocol's profile to another profile

**Returns**

Error code

CONFIG PROTOCOL MSN PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset MSN protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL MSN PROFILE IPS**Level**

base,asq

Description

MSN protocol's IPS settings

CONFIG PROTOCOL MSN PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [SkeletonTimeout=<0..600>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the MSN protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL MSN PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the MSN protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL MSN PROFILE SHOW**Level**



base,asq

Usage

index=<profile_idx>

Description

Show MSN protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL MSN PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the MSN protocol profile's informations

Returns

Error code

CONFIG PROTOCOL MYSQL**Level**

base,asq

Description

Commands for the MYSQL protocol

CONFIG PROTOCOL MYSQL ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the MYSQL protocol's configuration

Returns

Error code

CONFIG PROTOCOL MYSQL COMMON**Level**



base,asq

Description

MYSQL protocol's common settings

CONFIG PROTOCOL MYSQL COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set MYSQL protocol's common settings

Returns

Error code

CONFIG PROTOCOL MYSQL COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset MYSQL protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL MYSQL COMMON SHOW**Level**

base,asq

Usage**Description**

Show MYSQL protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL MYSQL PROFILE**Level**

base,asq

Description

MYSQL protocol's profile settings

CONFIG PROTOCOL MYSQL PROFILE ALARM**Level**



base,asq

Description

Alarm commands for the MYSQL protocol

CONFIG PROTOCOL MYSQL PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the MYSQL protocol

Returns

Error code

CONFIG PROTOCOL MYSQL PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the MYSQL protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL MYSQL PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the MYSQL protocol

Returns

Error code

CONFIG PROTOCOL MYSQL PROFILE CHECK

Level

base,asq

Usage



index=<profile_idx>

Description

List all the config referring to the profile specified by index for the MYSQL protocol

Returns

Config=00 ...

CONFIG PROTOCOL MYSQL PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a MYSQL protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL MYSQL PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset MYSQL protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL MYSQL PROFILE IPS**Level**

base,asq

Description

MYSQL protocol's IPS settings

CONFIG PROTOCOL MYSQL PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the MYSQL protocol profile's IPS settings

Returns

Error code

**CONFIG PROTOCOL MYSQL PROFILE LIST****Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the MYSQL protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL MYSQL PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show MYSQL protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL MYSQL PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the MYSQL protocol profile's informations

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP**Level**

base,asq

Description



Commands for the NB-CIFS_TCP protocol

CONFIG PROTOCOL NB-CIFS_TCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the NB-CIFS_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP COMMON

Level

base,asq

Description

NB-CIFS_TCP protocol's common settings

CONFIG PROTOCOL NB-CIFS_TCP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set NB-CIFS_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset NB-CIFS_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP COMMON SHOW

Level

base,asq

Usage**Description**



Show NB-CIFS_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL NB-CIFS_TCP PROFILE**Level**

base,asq

Description

NB-CIFS_TCP protocol's profile settings

CONFIG PROTOCOL NB-CIFS_TCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the NB-CIFS_TCP protocol

CONFIG PROTOCOL NB-CIFS_TCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the NB-CIFS_TCP protocol

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the NB-CIFS_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL NB-CIFS_TCP PROFILE ALARM UPDATE**Level**



asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}]
[level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds>
emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the NB-CIFS_TCP protocol

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the NB-CIFS_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL NB-CIFS_TCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a NB-CIFS_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset NB-CIFS_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS**Level**



base,asq

Description

NB-CIFS_TCP protocol's IPS settings

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [EnforceUser=On|Off] [InspectDcerpc=On|Off] [Probe=On|Off]
[SMB2ReferralFileNameBuffer=<0..65536>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the NB-CIFS_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID**History**

Appears in 3.2.0

Deprecated in 4.0.0

Level

base,asq

Description

Commands to manipulate uuid rules in IPSUUID section

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID INSERT**Level**

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

add a new uuid rule to IPSUUID section

Usage

index=<profile index> uuid=<string> action=pass|block [group=<string>]

Returns

Error code

Example

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID INSERT index=0 uuid="00000000-0000-0000-0000-000000000000" action=pass group="group1"

CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID REMOVE**Level**

asq,modify

**History**

Appears in 3.2.0

Deprecated in 4.0.0

Description

remove an uuid rule[s] from IPSUUID section

Usage

index=<profile index> ruleid=(<nb>|all)

Returns

Error code

Example

```
CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID add index=0 rule=1
```

```
CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID SHOW
```

Level

base,asq

History

Appears in 3.2.0

Deprecated in 4.0.0

Format

section_line

Description

dump the uuid rules list from IPSUUID section

Usage

index=<profile index>

Returns

the list in the format : ruleid=nb uuid=<string> action=pass|block group=<string>

Example

```
CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID SHOW index=0
```

```
CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID UPDATE
```

Level

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

update an uuid rule in the IPSUUID section

Usage

index=<profile index> ruleid=<nb> [uuid=<string>] [action=pass|block] [group=<string>]

Returns

Error code

**Example**

```
CONFIG PROTOCOL NB-CIFS_TCP PROFILE IPS UUID UPDATE index=0 rule=1 uuid="00000000-0000-0000-0000-000000000000" action=block group="group2"
```

CONFIG PROTOCOL NB-CIFS_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the NB-CIFS_TCP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL NB-CIFS_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show NB-CIFS_TCP protocol profile's settings

Returns

```
[Common]

[IPS]
State=1
Log=1
Probe=1
...
```

CONFIG PROTOCOL NB-CIFS_TCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the NB-CIFS_TCP protocol profile's informations

Returns

Error code



CONFIG PROTOCOL NB-CIFS_UDP

Level

base,asq

Description

Commands for the NB-CIFS_UDP protocol

CONFIG PROTOCOL NB-CIFS_UDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the NB-CIFS_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP COMMON

Level

base,asq

Description

NB-CIFS_UDP protocol's common settings

CONFIG PROTOCOL NB-CIFS_UDP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set NB-CIFS_UDP protocol's common settings

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset NB-CIFS_UDP protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL NB-CIFS_UDP COMMON SHOW****Level**

base,asq

Usage**Description**

Show NB-CIFS_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL NB-CIFS_UDP PROFILE**Level**

base,asq

Description

NB-CIFS_UDP protocol's profile settings

CONFIG PROTOCOL NB-CIFS_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the NB-CIFS_UDP protocol

CONFIG PROTOCOL NB-CIFS_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the NB-CIFS_UDP protocol

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the NB-CIFS_UDP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL NB-CIFS_UDP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the NB-CIFS_UDP protocol

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the NB-CIFS_UDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL NB-CIFS_UDP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a NB-CIFS_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset NB-CIFS_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP PROFILE IPS**Level**

base,asq

Description

NB-CIFS_UDP protocol's IPS settings

CONFIG PROTOCOL NB-CIFS_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [SMB2ReferralFileNameBuffer=<0..65536>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the NB-CIFS_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL NB-CIFS_UDP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the NB-CIFS_UDP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL NB-CIFS_UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show NB-CIFS_UDP protocol profile's settings

Returns

[Common]

[IPS]



State=1
Log=1
Probe=1
...

CONFIG PROTOCOL NB-CIFS UDP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the NB-CIFS_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL NB-DGM

Level

base,asq

Description

Commands for the NB-DGM protocol

CONFIG PROTOCOL NB-DGM ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the NB-DGM protocol's configuration

Returns

Error code

CONFIG PROTOCOL NB-DGM COMMON

Level

base,asq

Description

NB-DGM protocol's common settings

CONFIG PROTOCOL NB-DGM COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description



Set NB-DGM protocol's common settings

Returns

Error code

CONFIG PROTOCOL NB-DGM COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset NB-DGM protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL NB-DGM COMMON SHOW**Level**

base,asq

Usage**Description**

Show NB-DGM protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL NB-DGM PROFILE**Level**

base,asq

Description

NB-DGM protocol's profile settings

CONFIG PROTOCOL NB-DGM PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the NB-DGM protocol

CONFIG PROTOCOL NB-DGM PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description



Reset to a default template alarms for the NB-DGM protocol

Returns

Error code

CONFIG PROTOCOL NB-DGM PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the NB-DGM protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL NB-DGM PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the NB-DGM protocol

Returns

Error code

CONFIG PROTOCOL NB-DGM PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the NB-DGM protocol

Returns

Config=00 ...

CONFIG PROTOCOL NB-DGM PROFILE COPY**Level**

asq,modify

Usage



index=<profile_idx> to=<0..9>

Description

Copy a NB-DGM protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL NB-DGM PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset NB-DGM protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL NB-DGM PROFILE IPS**Level**

base,asq

Description

NB-DGM protocol's IPS settings

CONFIG PROTOCOL NB-DGM PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the NB-DGM protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL NB-DGM PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the NB-DGM protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

**CONFIG PROTOCOL NB-DGM PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show NB-DGM protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL NB-DGM PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the NB-DGM protocol profile's informations

Returns

Error code

CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID**History**

Appears in 3.2.0

Deprecated in 4.0.0

Level

base,asq

Description

Commands to manipulate uuid rules in IPSUUID section

CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID INSERT**Level**

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description



add a new uuid rule to IPSUUID section

Usage

index=<profile index> uuid=<string> action=pass|block [group=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID INSERT index=0 uuid="00000000-0000-0000-0000-000000000000" action=pass group="group1"
```

CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID REMOVE**Level**

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

remove an uuid rule(s) from IPSUUID section

Usage

index=<profile index> ruleid={<nb>|all}

Returns

Error code

Example

```
CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID add index=0 rule=1
```

CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID SHOW**Level**

base,asq

History

Appears in 3.2.0

Deprecated in 4.0.0

Format

section_line

Description

dump the uuid rules list from IPSUUID section

Usage

index=<profile index>

Returns

the list in the format : ruleid=nb uuid=<string> action=pass|block group=<string>

Example

```
CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID SHOW index=0
```



CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID UPDATE

Level

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

update an uuid rule in the IPSUUID section

Usage

index=<profile index> ruleid=<nb> [uuid=<string>] [action=pass|block] [group=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL NB-EPMAP_TCP PROFILE IPS UUID UPDATE index=0 rule=1 uuid="00000000-0000-0000-0000-000000000000" action=block group="group2"
```

CONFIG PROTOCOL NB-SSN

Level

base,asq

Description

Commands for the NB-SSN protocol

CONFIG PROTOCOL NB-SSN ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the NB-SSN protocol's configuration

Returns

Error code

CONFIG PROTOCOL NB-SSN COMMON

Level

base,asq

Description

NB-SSN protocol's common settings

CONFIG PROTOCOL NB-SSN COMMON CONFIG

Level

asq,modify

**Usage**

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set NB-SSN protocol's common settings

Returns

Error code

CONFIG PROTOCOL NB-SSN COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset NB-SSN protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL NB-SSN COMMON SHOW**Level**

base,asq

Usage**Description**

Show NB-SSN protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL NB-SSN PROFILE**Level**

base,asq

Description

NB-SSN protocol's profile settings

CONFIG PROTOCOL NB-SSN PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the NB-SSN protocol

CONFIG PROTOCOL NB-SSN PROFILE ALARM DEFAULT**Level**

asq,modify

**Usage**

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the NB-SSN protocol

Returns

Error code

CONFIG PROTOCOL NB-SSN PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the NB-SSN protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile|template|config|template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL NB-SSN PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the NB-SSN protocol

Returns

Error code

CONFIG PROTOCOL NB-SSN PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the NB-SSN protocol

Returns

Config=00 ...

**CONFIG PROTOCOL NB-SSN PROFILE COPY****Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a NB-SSN protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL NB-SSN PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset NB-SSN protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL NB-SSN PROFILE IPS**Level**

base,asq

Description

NB-SSN protocol's IPS settings

CONFIG PROTOCOL NB-SSN PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [InspectDcerpc=On|Off] [Probe=On|Off]
[SMB2ReferralFileNameBuffer=<0..65536>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the NB-SSN protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL NB-SSN PROFILE IPS UUID**History**

Appears in 3.2.0

Deprecated in 4.0.0

Level



base,asq

Description

Commands to manipulate uuid rules in IPSUUID section

CONFIG PROTOCOL NB-SSN PROFILE IPS UUID INSERT**Level**

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

add a new uuid rule to IPSUUID section

Usage

index=<profile index> uuid=<string> action=pass|block [group=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL NB-SSN PROFILE IPS UUID INSERT index=0 uuid="00000000-0000-0000-0000-000000000000" action=pass group="group1"
```

CONFIG PROTOCOL NB-SSN PROFILE IPS UUID REMOVE**Level**

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

remove an uuid rule(s) from IPSUUID section

Usage

index=<profile index> ruleid=(<nb>|all)

Returns

Error code

Example

```
CONFIG PROTOCOL NB-SSN PROFILE IPS UUID add index=0 rule=1
```

CONFIG PROTOCOL NB-SSN PROFILE IPS UUID SHOW**Level**

base,asq

History

Appears in 3.2.0

Deprecated in 4.0.0

Format

section_line

**Description**

dump the uuid rules list from IPSUUID section

Usage

index=<profile index>

Returns

the list in the format : ruleid=nb uuid=<string> action=pass|block group=<string>

Example

```
CONFIG PROTOCOL NB-SSN PROFILE IPS UUID SHOW index=0
```

```
CONFIG PROTOCOL NB-SSN PROFILE IPS UUID UPDATE
```

Level

asq,modify

History

Appears in 3.2.0

Deprecated in 4.0.0

Description

update an uuid rule in the IPSUUID section

Usage

index=<profile index> ruleid=<nb> [uuid=<string>] [action=pass|block] [group=<string>]

Returns

Error code

Example

```
CONFIG PROTOCOL NB-SSN PROFILE IPS UUID UPDATE index=0 rule=1 uuid="00000000-0000-0000-0000-000000000000" action=block group="group2"
```

CONFIG PROTOCOL NB-SSN PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the NB-SSN protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL NB-SSN PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

**Description**

Show NB-SSN protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL NB-SSN PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the NB-SSN protocol profile's informations

Returns

Error code

CONFIG PROTOCOL NNTP**Level**

base,asq

Description

Commands for the NNTP protocol

CONFIG PROTOCOL NNTP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the NNTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL NNTP COMMON**Level**

base,asq

Description

NNTP protocol's common settings

**CONFIG PROTOCOL NNTP COMMON CONFIG****Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set NNTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL NNTP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset NNTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL NNTP COMMON SHOW**Level**

base,asq

Usage**Description**

Show NNTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL NNTP PROFILE**Level**

base,asq

Description

NNTP protocol's profile settings

CONFIG PROTOCOL NNTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the NNTP protocol

**CONFIG PROTOCOL NNTP PROFILE ALARM DEFAULT****Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the NNTP protocol

Returns

Error code

CONFIG PROTOCOL NNTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the NNTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL NNTP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the NNTP protocol

Returns

Error code

CONFIG PROTOCOL NNTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the NNTP protocol

**Returns**

Config=00 ...

CONFIG PROTOCOL NNTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a NNTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL NNTP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset NNTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL NNTP PROFILE IPS**Level**

base,asq

Description

NNTP protocol's IPS settings

CONFIG PROTOCOL NNTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the NNTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL NNTP PROFILE LIST**Level**

base,asq

Usage



[index=<profile_idx>]

Description

List all available profiles or a specific profile for the NNTP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL NNTP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show NNTP protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

CONFIG PROTOCOL NNTP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the NNTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL NTP**Level**

base,asq

Description

Commands for the NTP protocol

CONFIG PROTOCOL NTP ACTIVATE**Level**

asq,modify

**Usage**

[CANCEL|NEXTBOOT]

Description

Activate the NTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL NTP COMMON**Level**

base,asq

Description

NTP protocol's common settings

CONFIG PROTOCOL NTP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set NTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL NTP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset NTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL NTP COMMON SHOW**Level**

base,asq

Usage**Description**

Show NTP protocol's common settings

Returns

[Common]

...

[IPS]

...



CONFIG PROTOCOL NTP PROFILE

Level

base,asq

Description

NTP protocol's profile settings

CONFIG PROTOCOL NTP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the NTP protocol

CONFIG PROTOCOL NTP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the NTP protocol

Returns

Error code

CONFIG PROTOCOL NTP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the NTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL NTP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the NTP protocol

Returns

Error code

CONFIG PROTOCOL NTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the NTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL NTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a NTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL NTP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset NTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL NTP PROFILE IPS**Level**

base,asq

Description

NTP protocol's IPS settings

CONFIG PROTOCOL NTP PROFILE IPS CONFIG**Level**

asq,modify

Usage



```
[AllowNTPv1Mode=<0..30>] [AllowNTPv2Mode=<0..255>] [AllowNTPv3Mode=<0..255>]  
[AllowNTPv4Mode=<0..255>] [BlacklistKoDNTPv4=<string>] [BlacklistRefidNTPv1=<string>]  
[BlacklistRefidNTPv2=<string>] [BlacklistRefidNTPv3=<string>] [BlacklistRefidNTPv4=<string>]  
[DenyNTPv1=0n|0ff] [DenyNTPv2=0n|0ff] [DenyNTPv3=0n|0ff] [DenyNTPv4=0n|0ff]  
[DriftThreshold=<0..1440>] [Log=0n|0ff] [MaxPendingRequest=<1..512>]  
[NTPv1Limit=<48..4096>] [NTPv2Limit=<48..4096>] [NTPv3Limit=<48..4096>]  
[NTPv4Limit=<48..4096>] [RequestTimeout=<1..3600>] [State=0n|0ff]  
[TemplateAlarm=<low|medium|high|internet>] [WhitelistKoDNTPv4=<string>]  
[WhitelistRefidNTPv4=<string>]
```

Description

Set the NTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL NTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the NTP protocol

Returns

```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL NTP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show NTP protocol profile's settings

Returns

[Common]

```
[IPS]  
State=1  
Log=1  
Probe=1  
...
```

CONFIG PROTOCOL NTP PROFILE UPDATE**Level**

asq,modify

Usage



index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the NTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL OPCUA**Level**

base,asq

Description

Commands for the OPCUA protocol

CONFIG PROTOCOL OPCUA ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the OPCUA protocol's configuration

Returns

Error code

CONFIG PROTOCOL OPCUA COMMON**Level**

base,asq

Description

OPCUA protocol's common settings

CONFIG PROTOCOL OPCUA COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set OPCUA protocol's common settings

Returns

Error code

CONFIG PROTOCOL OPCUA COMMON DEFAULT**Level**

asq,modify

Usage

**Description**

Reset OPCUA protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL OPCUA COMMON SHOW**Level**

base,asq

Usage**Description**

Show OPCUA protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL OPCUA PROFILE**Level**

base,asq

Description

OPCUA protocol's profile settings

CONFIG PROTOCOL OPCUA PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the OPCUA protocol

CONFIG PROTOCOL OPCUA PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the OPCUA protocol

Returns

Error code

CONFIG PROTOCOL OPCUA PROFILE ALARM SHOW**Level**

base,asq

Usage



index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the OPCUA protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL OPCUA PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the OPCUA protocol

Returns

Error code

CONFIG PROTOCOL OPCUA PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the OPCUA protocol

Returns

Config=00 ...

CONFIG PROTOCOL OPCUA PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a OPCUA protocol's profile to another profile

Returns

Error code



CONFIG PROTOCOL OPCUA PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description

Reset OPCUA protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL OPCUA PROFILE IPS

Level

base,asq

Description

OPCUA protocol's IPS settings

CONFIG PROTOCOL OPCUA PROFILE IPS CONFIG

Level

asq,modify

Usage

[AllowService=<string>] [AllowTCPUrg=On|Off] [ClientMsgBuffer=<8192..2147483647>]
[DenyService=<string>] [Log=On|Off] [Probe=On|Off] [SecurityMandatory=On|Off]
[ServerMsgBuffer=<8192..2147483647>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the OPCUA protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL OPCUA PROFILE LIST

Level

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the OPCUA protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...



CONFIG PROTOCOL OPCUA PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show OPCUA protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL OPCUA PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the OPCUA protocol profile's informations

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP

Level

base,asq

Description

Commands for the OPENVPN_TCP protocol

CONFIG PROTOCOL OPENVPN_TCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the OPENVPN_TCP protocol's configuration

Returns

Error code



CONFIG PROTOCOL OPENVPN_TCP COMMON

Level

base,asq

Description

OPENVPN_TCP protocol's common settings

CONFIG PROTOCOL OPENVPN_TCP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset OPENVPN_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP COMMON SHOW

Level

base,asq

Usage

Description

Show OPENVPN_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL OPENVPN_TCP PROFILE

Level

base,asq

Description

OPENVPN_TCP protocol's profile settings

CONFIG PROTOCOL OPENVPN_TCP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the OPENVPN_TCP protocol

CONFIG PROTOCOL OPENVPN_TCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage



index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the OPENVPN_TCP protocol

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the OPENVPN_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL OPENVPN_TCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the OPENVPN_TCP protocol

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the OPENVPN_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL OPENVPN_TCP PROFILE COPY**Level**



asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a OPENVPN_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset OPENVPN_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP PROFILE IPS**Level**

base,asq

Description

OPENVPN_TCP protocol's IPS settings

CONFIG PROTOCOL OPENVPN_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the OPENVPN_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL OPENVPN_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the OPENVPN_TCP protocol

Returns



```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL OPENVPN_TCP PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show OPENVPN_TCP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL OPENVPN_TCP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the OPENVPN_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP

Level

base,asq

Description

Commands for the OPENVPN_UDP protocol

CONFIG PROTOCOL OPENVPN_UDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the OPENVPN_UDP protocol's configuration

**Returns**

Error code

CONFIG PROTOCOL OPENVPN_UDP COMMON**Level**

base,asq

Description

OPENVPN_UDP protocol's common settings

CONFIG PROTOCOL OPENVPN_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset OPENVPN_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show OPENVPN_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL OPENVPN_UDP PROFILE**Level**

base,asq

Description

OPENVPN_UDP protocol's profile settings

CONFIG PROTOCOL OPENVPN_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the OPENVPN_UDP protocol

CONFIG PROTOCOL OPENVPN_UDP PROFILE ALARM DEFAULT**Level**



asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the OPENVPN_UDP protocol

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the OPENVPN_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile|template|config|template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL OPENVPN_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the OPENVPN_UDP protocol

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the OPENVPN_UDP protocol

Returns

Config=00 ...

**CONFIG PROTOCOL OPENVPN_UDP PROFILE COPY****Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a OPENVPN_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset OPENVPN_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP PROFILE IPS**Level**

base,asq

Description

OPENVPN_UDP protocol's IPS settings

CONFIG PROTOCOL OPENVPN_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the OPENVPN_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL OPENVPN_UDP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the OPENVPN_UDP protocol

**Returns**

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL OPENVPN UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show OPENVPN_UDP protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL OPENVPN_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the OPENVPN_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS**Level**

base,asq

Description

Commands for the ORACLE-TNS protocol

CONFIG PROTOCOL ORACLE-TNS ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description



Activate the ORACLE-TNS protocol's configuration

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS COMMON**Level**

base,asq

Description

ORACLE-TNS protocol's common settings

CONFIG PROTOCOL ORACLE-TNS COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set ORACLE-TNS protocol's common settings

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset ORACLE-TNS protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS COMMON SHOW**Level**

base,asq

Usage**Description**

Show ORACLE-TNS protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL ORACLE-TNS PROFILE**Level**



base,asq

Description

ORACLE-TNS protocol's profile settings

CONFIG PROTOCOL ORACLE-TNS PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the ORACLE-TNS protocol

CONFIG PROTOCOL ORACLE-TNS PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the ORACLE-TNS protocol

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the ORACLE-TNS protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL ORACLE-TNS PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the ORACLE-TNS protocol

Returns



Error code

CONFIG PROTOCOL ORACLE-TNS PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the ORACLE-TNS protocol

Returns

Config=00 ...

CONFIG PROTOCOL ORACLE-TNS PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a ORACLE-TNS protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description

Reset ORACLE-TNS protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS PROFILE IPS

Level

base,asq

Description

ORACLE-TNS protocol's IPS settings

CONFIG PROTOCOL ORACLE-TNS PROFILE IPS CONFIG

Level

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

**Description**

Set the ORACLE-TNS protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS**Level**

base,asq

History

Appears in 3.4.0

Description

IPS commands for ORACLE-TNS protocol in order to handle redirections

CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS INSERT**Level**

asq,modify

History

Appears in 3.4.0

Description

Register a new host for ORACLE-TNS protocol

Usage

index=<profile index> host=<objhost>

Returns

Error code

Example

```
CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS CONFIG INSERT index=1 host=some_host_
object
```

CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS REMOVE**Level**

asq,modify

History

Appears in 3.4.0

Description

Remove an existing host for ORACLE-TNS protocol

Usage

index=<profile index> host=<objhost>

Returns

Error code

Example

```
CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS CONFIG REMOVE index=1 host=some_host_
object
```

**CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS SHOW****Level**

base,asq

History

Appears in 3.4.0

Description

List registered hosts for ORACLE-TNS protocol

Usage

index=<profile index>

Returns

objhost1
objhost2

Example

CONFIG PROTOCOL ORACLE-TNS PROFILE IPS HOSTS CONFIG SHOW index=1

CONFIG PROTOCOL ORACLE-TNS PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the ORACLE-TNS protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL ORACLE-TNS PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show ORACLE-TNS protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

**CONFIG PROTOCOL ORACLE-TNS PROFILE UPDATE****Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the ORACLE-TNS protocol profile's informations

Returns

Error code

CONFIG PROTOCOL OSCAR**Level**

base,asq

Description

Commands for the OSCAR protocol

CONFIG PROTOCOL OSCAR ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the OSCAR protocol's configuration

Returns

Error code

CONFIG PROTOCOL OSCAR COMMON**Level**

base,asq

Description

OSCAR protocol's common settings

CONFIG PROTOCOL OSCAR COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set OSCAR protocol's common settings

Returns

Error code

**CONFIG PROTOCOL OSCAR COMMON DEFAULT****Level**

asq,modify

Usage**Description**

Reset OSCAR protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL OSCAR COMMON SHOW**Level**

base,asq

Usage**Description**

Show OSCAR protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL OSCAR PROFILE**Level**

base,asq

Description

OSCAR protocol's profile settings

CONFIG PROTOCOL OSCAR PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the OSCAR protocol

CONFIG PROTOCOL OSCAR PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the OSCAR protocol

Returns

Error code

**CONFIG PROTOCOL OSCAR PROFILE ALARM SHOW****Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the OSCAR protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL OSCAR PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the OSCAR protocol

Returns

Error code

CONFIG PROTOCOL OSCAR PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the OSCAR protocol

Returns

Config=00 ...

CONFIG PROTOCOL OSCAR PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a OSCAR protocol's profile to another profile

**Returns**

Error code

CONFIG PROTOCOL OSCAR PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset OSCAR protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL OSCAR PROFILE IPS**Level**

base,asq

Description

OSCAR protocol's IPS settings

CONFIG PROTOCOL OSCAR PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [SkeletonTimeout=<0..600>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the OSCAR protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL OSCAR PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the OSCAR protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL OSCAR PROFILE SHOW**Level**



base,asq

Usage

index=<profile_idx>

Description

Show OSCAR protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL OSCAR PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the OSCAR protocol profile's informations

Returns

Error code

CONFIG PROTOCOL PGSQL**Level**

base,asq

Description

Commands for the PGSQL protocol

CONFIG PROTOCOL PGSQL ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PGSQL protocol's configuration

Returns

Error code

CONFIG PROTOCOL PGSQL COMMON**Level**



base,asq

Description

PGSQL protocol's common settings

CONFIG PROTOCOL PGSQL COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set PGSQL protocol's common settings

Returns

Error code

CONFIG PROTOCOL PGSQL COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset PGSQL protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PGSQL COMMON SHOW**Level**

base,asq

Usage**Description**

Show PGSQL protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL PGSQL PROFILE**Level**

base,asq

Description

PGSQL protocol's profile settings

CONFIG PROTOCOL PGSQL PROFILE ALARM**Level**



base,asq

Description

Alarm commands for the PGSQL protocol

CONFIG PROTOCOL PGSQL PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PGSQL protocol

Returns

Error code

CONFIG PROTOCOL PGSQL PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PGSQL protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PGSQL PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the PGSQL protocol

Returns

Error code

CONFIG PROTOCOL PGSQL PROFILE CHECK

Level

base,asq

Usage



index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PGSQL protocol

Returns

Config=00 ...

CONFIG PROTOCOL PGSQL PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PGSQL protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PGSQL PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset PGSQL protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PGSQL PROFILE IPS**Level**

base,asq

Description

PGSQL protocol's IPS settings

CONFIG PROTOCOL PGSQL PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the PGSQL protocol profile's IPS settings

Returns

Error code

**CONFIG PROTOCOL PGSQL PROFILE LIST****Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PGSQL protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL PGSQL PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show PGSQL protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL PGSQL PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PGSQL protocol profile's informations

Returns

Error code

CONFIG PROTOCOL PNIO-CM**Level**

base,asq

Description



Commands for the PNIO-CM protocol

CONFIG PROTOCOL PNIO-CM ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PNIO-CM protocol's configuration

Returns

Error code

CONFIG PROTOCOL PNIO-CM COMMON

Level

base,asq

Description

PNIO-CM protocol's common settings

CONFIG PROTOCOL PNIO-CM COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set PNIO-CM protocol's common settings

Returns

Error code

CONFIG PROTOCOL PNIO-CM COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset PNIO-CM protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PNIO-CM COMMON SHOW

Level

base,asq

Usage**Description**



Show PNIO-CM protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL PNIO-CM PROFILE**Level**

base,asq

Description

PNIO-CM protocol's profile settings

CONFIG PROTOCOL PNIO-CM PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the PNIO-CM protocol

CONFIG PROTOCOL PNIO-CM PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PNIO-CM protocol

Returns

Error code

CONFIG PROTOCOL PNIO-CM PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PNIO-CM protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PNIO-CM PROFILE ALARM UPDATE**Level**



asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}]
[level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds>
emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the PNIO-CM protocol

Returns

Error code

CONFIG PROTOCOL PNIO-CM PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PNIO-CM protocol

Returns

Config=00 ...

CONFIG PROTOCOL PNIO-CM PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PNIO-CM protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PNIO-CM PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset PNIO-CM protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PNIO-CM PROFILE IPS**Level**



base,asq

Description

PNIO-CM protocol's IPS settings

CONFIG PROTOCOL PNIO-CM PROFILE IPS CONFIG**Level**

asq,modify

Usage

[DenyCode=<string>] [Log=On|Off] [Probe=On|Off] [Skeleton=On|Off] [SkeletonEmap=On|Off]
[SkeletonTimeout=<0..600>] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
[UUID_IO_ControllerInterface=Pass|Block] [UUID_IO_DeviceInterface=Pass|Block] [UUID_IO_
EmapInterface=Pass|Block] [UUID_IO_ParameterServerInterface=Pass|Block] [UUID_IO_
SupervisorInterface=Pass|Block]

Description

Set the PNIO-CM protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL PNIO-CM PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PNIO-CM protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL PNIO-CM PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show PNIO-CM protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

**CONFIG PROTOCOL PNIO-CM PROFILE UPDATE****Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PNIO-CM protocol profile's informations

Returns

Error code

CONFIG PROTOCOL POP3**Level**

base,asq

Description

Commands for the POP3 protocol

CONFIG PROTOCOL POP3 ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the POP3 protocol's configuration

Returns

Error code

CONFIG PROTOCOL POP3 COMMON**Level**

base,asq

Description

POP3 protocol's common settings

CONFIG PROTOCOL POP3 COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set POP3 protocol's common settings

Returns

Error code

**CONFIG PROTOCOL POP3 COMMON DEFAULT****Level**

asq,modify

Usage**Description**

Reset POP3 protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL POP3 COMMON PROXY**Level**

base,asq

History

Appears in 9.0.4

Description

POP3 common proxy configuration

CONFIG PROTOCOL POP3 COMMON PROXY CONFIG**Level**

asq,modify

History

Appears in 9.0.4

Description

Common parameters configuration

Usage

ApplyNat=<0|1>

ApplyNat : Allow outbound connections from proxies to match any NAT rule instead of just dst-only

Returns

Error code

Example

CONFIG PROTOCOL POP3 COMMON PROXY CONFIG ApplyNat=0

CONFIG PROTOCOL POP3 COMMON SHOW**Level**

base,asq

Usage**Description**

Show POP3 protocol's common settings

Returns

[Common]

...



[IPS]

...

CONFIG PROTOCOL POP3 PROFILE

Level

base,asq

Description

POP3 protocol's profile settings

CONFIG PROTOCOL POP3 PROFILE ALARM

Level

base,asq

Description

Alarm commands for the POP3 protocol

CONFIG PROTOCOL POP3 PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the POP3 protocol

Returns

Error code

CONFIG PROTOCOL POP3 PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the POP3 protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL POP3 PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds>



emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the POP3 protocol

Returns

Error code

CONFIG PROTOCOL POP3 PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the POP3 protocol

Returns

Config=00 ...

CONFIG PROTOCOL POP3 PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a POP3 protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL POP3 PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset POP3 protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL POP3 PROFILE IPS**Level**

base,asq

Description

POP3 protocol's IPS settings

**CONFIG PROTOCOL POP3 PROFILE IPS CONFIG****Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the POP3 protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL POP3 PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the POP3 protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL POP3 PROFILE PROXY**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure pop3 profile settings

CONFIG PROTOCOL POP3 PROFILE PROXY ANTIVIRUS**Level**

asq,modify

Description

Configure the antivirus part of the pop3 profile

History

Appears in Netasq 9.0.0

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]
[OnFragmentedEmailPolicy=<pass|block>]

Returns



Error code

Example

```
CONFIG PROTOCOL POP3 PROFILE PROXY ANTIVIRUS index=1 OnInfectedPolicy=pass  
OnFailedPolicy=pass OnFragmentedEmailPolicy=block
```

CONFIG PROTOCOL POP3 PROFILE PROXY CMD

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the authorized cmd of the pop3 profile

Usage

```
index=<profile index>  
<QUIT|CAPA|USER|PASS|APOP|AUTH|STLS|STAT|LIST|RETR|DELE|NOOP|RSET|TOP|UIDL|LAST>=<blo  
ck|pass|filter>
```

Returns

Error code

Example

```
CONFIG PROTOCOL POP3 PROFILE PROXY CMD index=1 QUIT=filter CAPA=filter USER=filter  
PASS=filter APOP=filter AUTH=filter STLS=block STAT=filter LIST=filter RETR=filter  
DELE=filter NOOP=filter RSET=filter TOP=filter UIDL=filter LAST=block
```

CONFIG PROTOCOL POP3 PROFILE PROXY CONFIG

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the pop3 profile

Usage

```
index=<profile index> [BindAddr=<binding ip addr>] [FullTransparent=on|off]  
[WelcomeMsgFiltering=<on|off>]
```

Returns

Error code

Example

```
CONFIG PROTOCOL POP3 PROFILE PROXY CONFIG index=1 BindAddr=MyObject  
MaxDataSize=4096 MaxRecipient=1000 WelcomeMsgFiltering=on
```

CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD

Level

base,asq

History

Appears in Netasq 9.0.0

**Description**

Commands to configure extracmd profile settings

CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD ADD**Level**

asq,modify

Description

Add additional authorized cmd of the pop3 profile

Usage

index=<profile index> <commandname>

Returns

Error code

Example

CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD ADD index=1 NEWCOMMAND

CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD LIST**Level**

base,asq

History

Appears in Netasq 9.0.0

Format

list

Description

List additional authorized cmd of the pop3 profile

Usage

index=<profile index>

Returns

List of all authorized cmds

Example

CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD LIST index=1

CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD REMOVE**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove additional authorized cmd of the pop3 profile

Usage

index=<profile index> <commandname>

Returns

Error code

**Example**

```
CONFIG PROTOCOL POP3 PROFILE PROXY EXTRACMD REMOVE index=1 NEWCOMMAND
```

```
CONFIG PROTOCOL POP3 PROFILE PROXY POSTPROC
```

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure post processing of the pop3 profile

Usage

```
index=<profile index> [policy=<block|pass>] [size=<MaxDataSize in KB>] [keepalive=<nb of seconds>]
```

Returns

Error code

Example

```
CONFIG PROTOCOL POP3 PROFILE PROXY POSTPROC index=1 policy=pass size=4000  
keepalive=20
```

```
CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING
```

History

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing part of the pop3 profile

```
CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING MAXSIZE
```

History

Appears in 2.4.0

Level

base,asq

Description

Commands to configure the sandboxing mail maxsize of the pop3 profile

```
CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING MAXSIZE SET
```

Level

asq,modify

History

Appears in 2.4.0

Description

Set sandboxing mail maxsize of pop3 profile

Usage



index=<profile index> maxsize=<MaxDataSize in KB>

Returns

Error code

CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING MAXSIZE SHOW

Level

base,asq

History

Appears in 2.4.0

Description

Show sandboxing mail maxsize of pop3 profile

Usage

index=<profile index>

Returns

[Mail]

maxsize=<MaxDataSize in KB>

CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING POLICY

Level

asq,modify

History

Appears in 2.3.0

Description

Configure policy for sandboxing in pop3 profile

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]

Returns

Error code

Example

CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING POLICY index=1 OnInfectedPolicy=pass
OnFailedPolicy=pass

CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING TYPE

History

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing types of the pop3 profile

CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING TYPE SHOW

Level

base,asq

**History**

Appears in 2.3.0

Format

section_line

Description

Show sandboxing type configuration of pop3 profile

Usage

index=<profile index>

Returns

```
[SandboxingType]
state=<on|off> type="archive" maxsize=<MaxDataSize in KB>
state=<on|off> type="document" maxsize=<MaxDataSize in KB>
state=<on|off> type="executable" maxsize=<MaxDataSize in KB>
state=<on|off> type="pdf" maxsize=<MaxDataSize in KB>
```

CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING TYPE UPDATE**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure files specifications for sandboxing in pop3 profile

Usage

```
index=<profile index>
type=<Archive|Document|Executable|Pdf>
[state={0|1}]
[maxsize=<MaxDataSize in KB>]
```

Returns

Error code

Example

```
CONFIG PROTOCOL POP3 PROFILE PROXY SANDBOXING TYPE UPDATE index=1 type=Archive
state=1 maxsize=1000
```

CONFIG PROTOCOL POP3 PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show POP3 protocol profile's settings

Returns

[Common]

[IPS]



State=1
Log=1
Probe=1
...

CONFIG PROTOCOL POP3 PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the POP3 protocol profile's informations

Returns

Error code

CONFIG PROTOCOL PROFILE

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Protocol's profile settings

CONFIG PROTOCOL PROFILE ALARM

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Alarm commands for protocols

CONFIG PROTOCOL PROFILE ALARM DEFAULT

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Reset to a default template alarms for this protocol

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Returns

Error code

**Remark**

if reset=0 or not specified, the command will not reset alarms already user defined

CONFIG PROTOCOL PROFILE ALARM SHOW**Level**

base,asq

History

Appears in Netasq 9.0.0

Added extended parameter and added tokens longmsg and signatures in response in Netasq 9.1.0

reaction split to blacklist and email in Netasq 9.1.0

comment appears in Netasq 9.1.0

qid appears in 2.0.0

Description

Dump the alarm configuration for this protocol

Remark

if extended=0 or not specified, the command will not show the longmsg and signatures tokens

Usage

index=<profile index> [context={protocol|<ASQ context name>}] [extended=0|1]

Returns

context=<asq_context name> id=<alarmid> action={block|pass} level={major|minor|ignore}
dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [qid=<queue
name>] [email=on emailduration=<seconds> emailcount=<int>] [blacklist=on
blduration=<minutes>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1}
category=<category> comment="<comment>" [longmsg=<detailed message>]
[signatures=<number of variants>]

Format

section_line

Example

config protocol http profile alarm show index=1

[Alarm]

context=http:url:decoded id=48 action=block level=major dump=0 new=1 origin=profile_
template msg="Windows : cmd.exe use or access attempt" modify=1 sensible=0 legacy=1
category="" comment=""

context=protocol id=53 action=block level=major dump=0 new=0 origin=profile_template
msg="Invalid HTTP protocol" modify=1 sensible=1 legacy=1 category="" comment=""

context=http:client id=49 action=block level=major dump=0 new=1 origin=profile_template
msg="Malware : PonyDOS botnet detected" modify=1 sensible=0 legacy=1 category=""
comment=""

CONFIG PROTOCOL PROFILE ALARM UPDATE**Level**

asq, modify

History

Appears in Netasq 9.0.0

Reaction split to blacklist and email in Netasq 9.1.0



Comment appears in Netasq 9.1.0
qid appears in 2.0.0

Description

Configure ASQ alarm (IPS alarm)

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)]
[level=(minor|major|ignore)] [dump={0|1}] [email=off | email=on emailduration=<seconds>
emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>] [ackqid=<Queue name>]

Returns

Error code

Example

```
CONFIG PROTOCOL xxx PROFILE ALARM UPDATE index=3 id=0 context=protocol action=block  
level=minor  
CONFIG PROTOCOL xxx PROFILE ALARM UPDATE index=3 id=1 context=protocol dump=1  
CONFIG PROTOCOL xxx PROFILE ALARM UPDATE index=3 id=2 context=protocol email=on  
emailduration=20 emailcount=10  
CONFIG PROTOCOL xxx PROFILE ALARM UPDATE index=3 id=3 context=protocol level=minor  
blacklist=on blduration=20 email=off  
CONFIG PROTOCOL xxx PROFILE ALARM UPDATE index=3 id=4 context=protocol action=pass  
comment="raised by our software"
```

Format

section_line

CONFIG PROTOCOL PROFILE CHECK**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

List all the config referring to the profile specified by index for the given protocol

Usage

index=<profile_idx>

Returns

Error code

Example

```
CONFIG PROTOCOL HTTP PROFILE CHECK index=2
```

CONFIG PROTOCOL PROFILE COPY**Level**

asq,modify

Description

Copy profile

**Usage**

index=<profile_idx> to=<0..9>

History

Appears in Netasq 9.0.0

Returns

Error code

CONFIG PROTOCOL PROFILE DEFAULT**Level**

asq,modify

Description

Reset protocol profile's settings to default

Usage

index=<profile_idx>

History

Appears in Netasq 9.0.0

Returns

Error code

CONFIG PROTOCOL PROFILE IPS**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Protocol's IPS

CONFIG PROTOCOL PROFILE IPS CONFIG**Level**

asq,modify

History

Appears in Netasq 9.0.0

Usage

[index=<profile_idx>] [State=<On|Off>] [Probe=<On|Off>] [AllowTCPUrg=<On|Off>]
[KeepTCPUrg=On|Off] [TemplateAlarm=<high|medium|low|internet>]

Remark

AllowTCPUrg argument is only available for protocol over TCP.

Description

Set the protocol profile's IPS settings

Returns

Error code



CONFIG PROTOCOL PROFILE LIST

Level

base,asq

Description

List all available profiles or a specific profile

Usage

[index=<profile_idx>]

History

Appears in Netasq 9.0.0

Returns

Error code

CONFIG PROTOCOL PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show protocol profile's settings

History

Appears in Netasq 9.0.0

Returns

Error code

CONFIG PROTOCOL PROFILE UPDATE

Level

asq,modify

History

Appears in Netasq 9.0.0

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the protocol profile's informations

Returns

Error code

CONFIG PROTOCOL PROFINET-DCP

Level

base,asq

Description



Commands for the PROFINET-DCP protocol

CONFIG PROTOCOL PROFINET-DCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PROFINET-DCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL PROFINET-DCP COMMON

Level

base,asq

Description

PROFINET-DCP protocol's common settings

CONFIG PROTOCOL PROFINET-DCP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset PROFINET-DCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-DCP COMMON SHOW

Level

base,asq

Usage

Description

Show PROFINET-DCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL PROFINET-DCP PROFILE

Level

base,asq

Description



PROFINET-DCP protocol's profile settings

CONFIG PROTOCOL PROFINET-DCP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the PROFINET-DCP protocol

CONFIG PROTOCOL PROFINET-DCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PROFINET-DCP protocol

Returns

Error code

CONFIG PROTOCOL PROFINET-DCP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PROFINET-DCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PROFINET-DCP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the PROFINET-DCP protocol

Returns

Error code

**CONFIG PROTOCOL PROFINET-DCP PROFILE CHECK****Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PROFINET-DCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL PROFINET-DCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PROFINET-DCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PROFINET-DCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset PROFINET-DCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-DCP PROFILE IPS**Level**

base,asq

Description

PROFINET-DCP protocol's IPS settings

CONFIG PROTOCOL PROFINET-DCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Log=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the PROFINET-DCP protocol profile's IPS settings

**Returns**

Error code

CONFIG PROTOCOL PROFINET-DCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PROFINET-DCP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL PROFINET-DCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show PROFINET-DCP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL PROFINET-DCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PROFINET-DCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL PROFINET-IO**Level**



base,asq

Description

Commands for the PROFINET-IO protocol

CONFIG PROTOCOL PROFINET-IO ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PROFINET-IO protocol's configuration

Returns

Error code

CONFIG PROTOCOL PROFINET-IO COMMON**Level**

base,asq

Description

PROFINET-IO protocol's common settings

CONFIG PROTOCOL PROFINET-IO COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset PROFINET-IO protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-IO COMMON SHOW**Level**

base,asq

Usage**Description**

Show PROFINET-IO protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL PROFINET-IO PROFILE**Level**



base,asq

Description

PROFINET-IO protocol's profile settings

CONFIG PROTOCOL PROFINET-IO PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the PROFINET-IO protocol

CONFIG PROTOCOL PROFINET-IO PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PROFINET-IO protocol

Returns

Error code

CONFIG PROTOCOL PROFINET-IO PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PROFINET-IO protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PROFINET-IO PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the PROFINET-IO protocol

Returns



Error code

CONFIG PROTOCOL PROFINET-IO PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PROFINET-IO protocol

Returns

Config=00 ...

CONFIG PROTOCOL PROFINET-IO PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PROFINET-IO protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PROFINET-IO PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description

Reset PROFINET-IO protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-IO PROFILE IPS

Level

base,asq

Description

PROFINET-IO protocol's IPS settings

CONFIG PROTOCOL PROFINET-IO PROFILE IPS CONFIG

Level

asq,modify

Usage

[Log=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description



Set the PROFINET-IO protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL PROFINET-IO PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PROFINET-IO protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL PROFINET-IO PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show PROFINET-IO protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL PROFINET-IO PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PROFINET-IO protocol profile's informations

Returns

Error code



CONFIG PROTOCOL PROFINET-PTCP

Level

base,asq

Description

Commands for the PROFINET-PTCP protocol

CONFIG PROTOCOL PROFINET-PTCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PROFINET-PTCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP COMMON

Level

base,asq

Description

PROFINET-PTCP protocol's common settings

CONFIG PROTOCOL PROFINET-PTCP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset PROFINET-PTCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP COMMON SHOW

Level

base,asq

Usage**Description**

Show PROFINET-PTCP protocol's common settings

Returns

[Common]

...

[IPS]

...

**CONFIG PROTOCOL PROFINET-PTCP PROFILE****Level**

base,asq

Description

PROFINET-PTCP protocol's profile settings

CONFIG PROTOCOL PROFINET-PTCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the PROFINET-PTCP protocol

CONFIG PROTOCOL PROFINET-PTCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PROFINET-PTCP protocol

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PROFINET-PTCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PROFINET-PTCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the PROFINET-PTCP protocol

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PROFINET-PTCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL PROFINET-PTCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PROFINET-PTCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset PROFINET-PTCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP PROFILE IPS**Level**

base,asq

Description

PROFINET-PTCP protocol's IPS settings

CONFIG PROTOCOL PROFINET-PTCP PROFILE IPS CONFIG**Level**

asq,modify

Usage



[Log=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the PROFINET-PTCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL PROFINET-PTCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PROFINET-PTCP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL PROFINET-PTCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show PROFINET-PTCP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL PROFINET-PTCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PROFINET-PTCP protocol profile's informations

Returns

Error code



CONFIG PROTOCOL PROFINET-RT

Level

base,asq

Description

Commands for the PROFINET-RT protocol

CONFIG PROTOCOL PROFINET-RT ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PROFINET-RT protocol's configuration

Returns

Error code

CONFIG PROTOCOL PROFINET-RT COMMON

Level

base,asq

Description

PROFINET-RT protocol's common settings

CONFIG PROTOCOL PROFINET-RT COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset PROFINET-RT protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-RT COMMON SHOW

Level

base,asq

Usage**Description**

Show PROFINET-RT protocol's common settings

Returns

[Common]

...

[IPS]

...

**CONFIG PROTOCOL PROFINET-RT PROFILE****Level**

base,asq

Description

PROFINET-RT protocol's profile settings

CONFIG PROTOCOL PROFINET-RT PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the PROFINET-RT protocol

CONFIG PROTOCOL PROFINET-RT PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PROFINET-RT protocol

Returns

Error code

CONFIG PROTOCOL PROFINET-RT PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PROFINET-RT protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PROFINET-RT PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the PROFINET-RT protocol

Returns

Error code

CONFIG PROTOCOL PROFINET-RT PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PROFINET-RT protocol

Returns

Config=00 ...

CONFIG PROTOCOL PROFINET-RT PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PROFINET-RT protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PROFINET-RT PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset PROFINET-RT protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PROFINET-RT PROFILE IPS**Level**

base,asq

Description

PROFINET-RT protocol's IPS settings

CONFIG PROTOCOL PROFINET-RT PROFILE IPS CONFIG**Level**

asq,modify

Usage



```
[EtherTimeout=<2..604800>] [Log=On|Off] [State=On|Off]  
[TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the PROFINET-RT protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL PROFINET-RT PROFILE LIST**Level**

base,asq

Usage

```
[index=<profile_idx>]
```

Description

List all available profiles or a specific profile for the PROFINET-RT protocol

Returns

```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL PROFINET-RT PROFILE SHOW**Level**

base,asq

Usage

```
index=<profile_idx>
```

Description

Show PROFINET-RT protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL PROFINET-RT PROFILE UPDATE**Level**

asq,modify

Usage

```
index=<profile_idx> [name=<string>] [comment=<string>]
```

Description

Update the PROFINET-RT protocol profile's informations

Returns



Error code

CONFIG PROTOCOL PROXY_TCP

Level

base,asq

Description

Commands for the PROXY_TCP protocol

CONFIG PROTOCOL PROXY_TCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PROXY_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL PROXY_TCP COMMON

Level

base,asq

Description

PROXY_TCP protocol's common settings

CONFIG PROTOCOL PROXY_TCP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set PROXY_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL PROXY_TCP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset PROXY_TCP protocol's common settings to default

Returns



Error code

CONFIG PROTOCOL PROXY_TCP COMMON SHOW

Level

base,asq

Usage**Description**

Show PROXY_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL PROXY_TCP PROFILE

Level

base,asq

Description

PROXY_TCP protocol's profile settings

CONFIG PROTOCOL PROXY_TCP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the PROXY_TCP protocol

CONFIG PROTOCOL PROXY_TCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the PROXY_TCP protocol

Returns

Error code

CONFIG PROTOCOL PROXY_TCP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PROXY_TCP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PROXY_TCP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the PROXY_TCP protocol

Returns

Error code

CONFIG PROTOCOL PROXY_TCP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PROXY_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL PROXY_TCP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a PROXY_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PROXY_TCP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset PROXY_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PROXY_TCP PROFILE IPS**Level**

base,asq

Description

PROXY_TCP protocol's IPS settings

CONFIG PROTOCOL PROXY_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the PROXY_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL PROXY_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PROXY_TCP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL PROXY_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show PROXY_TCP protocol profile's settings

Returns

[Common]

[IPS]

State=1



Log=1
Probe=1
...

CONFIG PROTOCOL PROXY TCP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PROXY_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL PROXY_UDP

Level

base,asq

Description

Commands for the PROXY_UDP protocol

CONFIG PROTOCOL PROXY_UDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the PROXY_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL PROXY_UDP COMMON

Level

base,asq

Description

PROXY_UDP protocol's common settings

CONFIG PROTOCOL PROXY_UDP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description



Set PROXY_UDP protocol's common settings

Returns

Error code

CONFIG PROTOCOL PROXY_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset PROXY_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL PROXY_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show PROXY_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL PROXY_UDP PROFILE**Level**

base,asq

Description

PROXY_UDP protocol's profile settings

CONFIG PROTOCOL PROXY_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the PROXY_UDP protocol

CONFIG PROTOCOL PROXY_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description



Reset to a default template alarms for the PROXY_UDP protocol

Returns

Error code

CONFIG PROTOCOL PROXY_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the PROXY_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL PROXY_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the PROXY_UDP protocol

Returns

Error code

CONFIG PROTOCOL PROXY_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the PROXY_UDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL PROXY_UDP PROFILE COPY**Level**

asq,modify

Usage



index=<profile_idx> to=<0..9>

Description

Copy a PROXY_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL PROXY_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset PROXY_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL PROXY_UDP PROFILE IPS**Level**

base,asq

Description

PROXY_UDP protocol's IPS settings

CONFIG PROTOCOL PROXY_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the PROXY_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL PROXY_UDP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the PROXY_UDP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

**CONFIG PROTOCOL PROXY_UDP PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show PROXY_UDP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL PROXY_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the PROXY_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL QQIM_TCP**Level**

base,asq

Description

Commands for the QQIM_TCP protocol

CONFIG PROTOCOL QQIM_TCP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the QQIM_TCP protocol's configuration

Returns

Error code



CONFIG PROTOCOL QQIM_TCP COMMON

Level

base,asq

Description

QQIM_TCP protocol's common settings

CONFIG PROTOCOL QQIM_TCP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset QQIM_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL QQIM_TCP COMMON SHOW

Level

base,asq

Usage

Description

Show QQIM_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL QQIM_TCP PROFILE

Level

base,asq

Description

QQIM_TCP protocol's profile settings

CONFIG PROTOCOL QQIM_TCP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the QQIM_TCP protocol

CONFIG PROTOCOL QQIM_TCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage



index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the QQIM_TCP protocol

Returns

Error code

CONFIG PROTOCOL QQIM_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the QQIM_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL QQIM_TCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the QQIM_TCP protocol

Returns

Error code

CONFIG PROTOCOL QQIM TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the QQIM_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL QQIM TCP PROFILE COPY**Level**



asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a QQIM_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL QQIM_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset QQIM_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL QQIM_TCP PROFILE IPS**Level**

base,asq

Description

QQIM_TCP protocol's IPS settings

CONFIG PROTOCOL QQIM_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the QQIM_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL QQIM_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the QQIM_TCP protocol

Returns



```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL QQIM TCP PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show QQIM_TCP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL QQIM_TCP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the QQIM_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL QQIM_UDP

Level

base,asq

Description

Commands for the QQIM_UDP protocol

CONFIG PROTOCOL QQIM_UDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the QQIM_UDP protocol's configuration

**Returns**

Error code

CONFIG PROTOCOL QQIM_UDP COMMON**Level**

base,asq

Description

QQIM_UDP protocol's common settings

CONFIG PROTOCOL QQIM_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset QQIM_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL QQIM_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show QQIM_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL QQIM_UDP PROFILE**Level**

base,asq

Description

QQIM_UDP protocol's profile settings

CONFIG PROTOCOL QQIM_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the QQIM_UDP protocol

CONFIG PROTOCOL QQIM_UDP PROFILE ALARM DEFAULT**Level**



asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the QQIM_UDP protocol

Returns

Error code

CONFIG PROTOCOL QQIM_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the QQIM_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL QQIM_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the QQIM_UDP protocol

Returns

Error code

CONFIG PROTOCOL QQIM_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the QQIM_UDP protocol

Returns

Config=00 ...

**CONFIG PROTOCOL QQIM_UDP PROFILE COPY****Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a QQIM_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL QQIM_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset QQIM_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL QQIM_UDP PROFILE IPS**Level**

base,asq

Description

QQIM_UDP protocol's IPS settings

CONFIG PROTOCOL QQIM_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the QQIM_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL QQIM_UDP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the QQIM_UDP protocol

**Returns**

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL QQIM_UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show QQIM_UDP protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL QQIM_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the QQIM_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL RDP_TCP**Level**

base,asq

Description

Commands for the RDP_TCP protocol

CONFIG PROTOCOL RDP_TCP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description



Activate the RDP_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL RDP_TCP COMMON**Level**

base,asq

Description

RDP_TCP protocol's common settings

CONFIG PROTOCOL RDP_TCP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset RDP_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL RDP_TCP COMMON SHOW**Level**

base,asq

Usage**Description**

Show RDP_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL RDP_TCP PROFILE**Level**

base,asq

Description

RDP_TCP protocol's profile settings

CONFIG PROTOCOL RDP_TCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the RDP_TCP protocol

**CONFIG PROTOCOL RDP_TCP PROFILE ALARM DEFAULT****Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RDP_TCP protocol

Returns

Error code

CONFIG PROTOCOL RDP_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the RDP_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RDP_TCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the RDP_TCP protocol

Returns

Error code

CONFIG PROTOCOL RDP_TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RDP_TCP protocol

**Returns**

Config=00 ...

CONFIG PROTOCOL RDP_TCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a RDP_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL RDP_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset RDP_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RDP_TCP PROFILE IPS**Level**

base,asq

Description

RDP_TCP protocol's IPS settings

CONFIG PROTOCOL RDP_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the RDP_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RDP_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

**Description**

List all available profiles or a specific profile for the RDP_TCP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL RDP_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show RDP_TCP protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL RDP_TCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RDP_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL RDP_UDP**Level**

base,asq

Description

Commands for the RDP_UDP protocol

CONFIG PROTOCOL RDP_UDP ACTIVATE**Level**

asq,modify

Usage



[CANCEL|NEXTBOOT]

Description

Activate the RDP_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL RDP_UDP COMMON**Level**

base,asq

Description

RDP_UDP protocol's common settings

CONFIG PROTOCOL RDP_UDP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set RDP_UDP protocol's common settings

Returns

Error code

CONFIG PROTOCOL RDP_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset RDP_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL RDP_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show RDP_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

**CONFIG PROTOCOL RDP_UDP PROFILE****Level**

base,asq

Description

RDP_UDP protocol's profile settings

CONFIG PROTOCOL RDP_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the RDP_UDP protocol

CONFIG PROTOCOL RDP_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RDP_UDP protocol

Returns

Error code

CONFIG PROTOCOL RDP_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the RDP_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RDP_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the RDP_UDP protocol

Returns

Error code

CONFIG PROTOCOL RDP_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RDP_UDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL RDP_UDP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a RDP_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL RDP_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset RDP_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RDP_UDP PROFILE IPS**Level**

base,asq

Description

RDP_UDP protocol's IPS settings

CONFIG PROTOCOL RDP_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage



[Log=On|Off] [Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the RDP_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RDP_UDP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the RDP_UDP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL RDP_UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show RDP_UDP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL RDP_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RDP_UDP protocol profile's informations

Returns

Error code



CONFIG PROTOCOL RIP

Level

base,asq

Description

Commands for the RIP protocol

CONFIG PROTOCOL RIP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the RIP protocol's configuration

Returns

Error code

CONFIG PROTOCOL RIP COMMON

Level

base,asq

Description

RIP protocol's common settings

CONFIG PROTOCOL RIP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set RIP protocol's common settings

Returns

Error code

CONFIG PROTOCOL RIP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset RIP protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL RIP COMMON SHOW****Level**

base,asq

Usage**Description**

Show RIP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL RIP PROFILE**Level**

base,asq

Description

RIP protocol's profile settings

CONFIG PROTOCOL RIP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the RIP protocol

CONFIG PROTOCOL RIP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RIP protocol

Returns

Error code

CONFIG PROTOCOL RIP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the RIP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RIP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the RIP protocol

Returns

Error code

CONFIG PROTOCOL RIP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RIP protocol

Returns

Config=00 ...

CONFIG PROTOCOL RIP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a RIP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL RIP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset RIP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RIP PROFILE IPS**Level**

base,asq

Description

RIP protocol's IPS settings

CONFIG PROTOCOL RIP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the RIP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RIP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the RIP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL RIP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show RIP protocol profile's settings

Returns

[Common]

[IPS]

State=1



Log=1
Probe=1
...

CONFIG PROTOCOL RIP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RIP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL RTCP

Level

base,asq

Description

Commands for the RTCP protocol

CONFIG PROTOCOL RTCP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the RTCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL RTCP COMMON

Level

base,asq

Description

RTCP protocol's common settings

CONFIG PROTOCOL RTCP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset RTCP protocol's common settings to default

**Returns**

Error code

CONFIG PROTOCOL RTCP COMMON SHOW**Level**

base,asq

Usage**Description**

Show RTCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL RTCP PROFILE**Level**

base,asq

Description

RTCP protocol's profile settings

CONFIG PROTOCOL RTCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the RTCP protocol

CONFIG PROTOCOL RTCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RTCP protocol

Returns

Error code

CONFIG PROTOCOL RTCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the RTCP protocol

**Returns**

context=(protocol|<ASQ context name>) id=<alarmid> action=(block|pass) level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_template|new) [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RTCP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)] [level=(minor|major|ignore)] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the RTCP protocol

Returns

Error code

CONFIG PROTOCOL RTCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RTCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL RTCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a RTCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL RTCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

**Description**

Reset RTCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RTCP PROFILE IPS**Level**

base,asq

Description

RTCP protocol's IPS settings

CONFIG PROTOCOL RTCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowOp=<string>] [DenyOp=<string>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the RTCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RTCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the RTCP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL RTCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show RTCP protocol profile's settings

Returns



[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL RTCP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RTCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL RTP

Level

base,asq

Description

Commands for the RTP protocol

CONFIG PROTOCOL RTP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the RTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL RTP COMMON

Level

base,asq

Description

RTP protocol's common settings

CONFIG PROTOCOL RTP COMMON DEFAULT

Level

asq,modify

**Usage****Description**

Reset RTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL RTP COMMON SHOW**Level**

base,asq

Usage**Description**

Show RTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL RTP PROFILE**Level**

base,asq

Description

RTP protocol's profile settings

CONFIG PROTOCOL RTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the RTP protocol

CONFIG PROTOCOL RTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RTP protocol

Returns

Error code

CONFIG PROTOCOL RTP PROFILE ALARM SHOW**Level**

base,asq

**Usage**

index=<profile_idx> [context=(protocol|<ASQ context name>)] [extended=0|1]

Description

Dump the alarm configuration for the RTP protocol

Returns

context=(protocol|<ASQ context name>) id=<alarmid> action=(block|pass) level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_template|new) [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RTP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the RTP protocol

Returns

Error code

CONFIG PROTOCOL RTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL RTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a RTP protocol's profile to another profile

Returns

Error code

**CONFIG PROTOCOL RTP PROFILE DEFAULT****Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset RTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RTP PROFILE IPS**Level**

base,asq

Description

RTP protocol's IPS settings

CONFIG PROTOCOL RTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowCodec=<string>] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the RTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the RTP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL RTP PROFILE SHOW**Level**

base,asq

Usage



index=<profile_idx>

Description

Show RTP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL RTP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL RTP_RTCP**Level**

base,asq

Description

Commands for the RTP_RTCP protocol

CONFIG PROTOCOL RTP_RTCP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the RTP_RTCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL RTP_RTCP COMMON**Level**

base,asq

Description



RTP_RTCP protocol's common settings

CONFIG PROTOCOL RTP_RTCP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset RTP_RTCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL RTP_RTCP COMMON SHOW

Level

base,asq

Usage**Description**

Show RTP_RTCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL RTP_RTCP PROFILE

Level

base,asq

Description

RTP_RTCP protocol's profile settings

CONFIG PROTOCOL RTP_RTCP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the RTP_RTCP protocol

CONFIG PROTOCOL RTP_RTCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RTP_RTCP protocol

Returns



Error code

CONFIG PROTOCOL RTP_RTCP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the RTP_RTCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RTP_RTCP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the RTP_RTCP protocol

Returns

Error code

CONFIG PROTOCOL RTP RTCP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RTP_RTCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL RTP RTCP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description



Copy a RTP_RTCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL RTP_RTCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset RTP_RTCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RTP_RTCP PROFILE IPS**Level**

base,asq

Description

RTP_RTCP protocol's IPS settings

CONFIG PROTOCOL RTP_RTCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the RTP_RTCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RTP_RTCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the RTP_RTCP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

**CONFIG PROTOCOL RTP RTCP PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show RTP_RTCP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL RTP RTCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RTP_RTCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL RTSP**Level**

base,asq

Description

Commands for the RTSP protocol

CONFIG PROTOCOL RTSP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the RTSP protocol's configuration

Returns

Error code



CONFIG PROTOCOL RTSP COMMON

Level

base,asq

Description

RTSP protocol's common settings

CONFIG PROTOCOL RTSP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set RTSP protocol's common settings

Returns

Error code

CONFIG PROTOCOL RTSP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset RTSP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL RTSP COMMON SHOW

Level

base,asq

Usage

Description

Show RTSP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL RTSP PROFILE

Level

base,asq

Description

RTSP protocol's profile settings

**CONFIG PROTOCOL RTSP PROFILE ALARM****Level**

base,asq

Description

Alarm commands for the RTSP protocol

CONFIG PROTOCOL RTSP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the RTSP protocol

Returns

Error code

CONFIG PROTOCOL RTSP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the RTSP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL RTSP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the RTSP protocol

Returns

Error code

CONFIG PROTOCOL RTSP PROFILE CHECK**Level**



base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the RTSP protocol

Returns

Config=00 ...

CONFIG PROTOCOL RTSP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a RTSP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL RTSP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset RTSP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL RTSP PROFILE IPS**Level**

base,asq

Description

RTSP protocol's IPS settings

CONFIG PROTOCOL RTSP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowContentInErrors=On|Off] [AllowInterleaving=On|Off] [AllowMediaRenegotiation=On|Off]
[AllowOp=<string>] [AllowTCPUrg=On|Off] [ContentTypeBuffer=<64..4096>] [DenyOp=<string>]
[HeaderBuffer=<64..4096>] [Log=On|Off] [MaxPendingRequest=<1..512>] [Probe=On|Off]
[RequestBuffer=<64..4096>] [RequestTimeout=<10..3600>] [SDPBuffer=<64..4096>]
[SessionTimeout=<60..604800>] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

**Description**

Set the RTSP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL RTSP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the RTSP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL RTSP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show RTSP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL RTSP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the RTSP protocol profile's informations

Returns

Error code



CONFIG PROTOCOL S7

Level

base,asq

Description

Commands for the S7 protocol

CONFIG PROTOCOL S7 ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the S7 protocol's configuration

Returns

Error code

CONFIG PROTOCOL S7 COMMON

Level

base,asq

Description

S7 protocol's common settings

CONFIG PROTOCOL S7 COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset S7 protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL S7 COMMON SHOW

Level

base,asq

Usage**Description**

Show S7 protocol's common settings

Returns

[Common]

...

[IPS]

...



CONFIG PROTOCOL S7 PROFILE

Level

base,asq

Description

S7 protocol's profile settings

CONFIG PROTOCOL S7 PROFILE ALARM

Level

base,asq

Description

Alarm commands for the S7 protocol

CONFIG PROTOCOL S7 PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the S7 protocol

Returns

Error code

CONFIG PROTOCOL S7 PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the S7 protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL S7 PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the S7 protocol

Returns

Error code

CONFIG PROTOCOL S7 PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the S7 protocol

Returns

Config=00 ...

CONFIG PROTOCOL S7 PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a S7 protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL S7 PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset S7 protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL S7 PROFILE IPS**Level**

base,asq

Description

S7 protocol's IPS settings

CONFIG PROTOCOL S7 PROFILE IPS CONFIG**Level**

asq,modify

Usage



```
[AllowTCPUrg=On|Off] [DenyCode=<string>] [DenyGroup=<string>] [Log=On|Off]  
[MaxPendingRequest=<1..512>] [MsgBuffer=<11..3837>] [RequestTimeout=<1..3600>]  
[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the S7 protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL S7 PROFILE LIST**Level**

base,asq

Usage

```
[index=<profile_idx>]
```

Description

List all available profiles or a specific profile for the S7 protocol

Returns

```
[00]  
name="default"  
lastmod="2011-02-23 10:47:45"  
...
```

CONFIG PROTOCOL S7 PROFILE SHOW**Level**

base,asq

Usage

```
index=<profile_idx>
```

Description

Show S7 protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL S7 PROFILE UPDATE**Level**

asq,modify

Usage

```
index=<profile_idx> [name=<string>] [comment=<string>]
```

Description

Update the S7 protocol profile's informations

Returns



Error code

CONFIG PROTOCOL SCTP

Level

base,asq

Description

Commands for the SCTP protocol

CONFIG PROTOCOL SCTP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SCTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SCTP COMMON

Level

base,asq

Description

SCTP protocol's common settings

CONFIG PROTOCOL SCTP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset SCTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SCTP COMMON SHOW

Level

base,asq

Usage

Description

Show SCTP protocol's common settings

Returns

[Common]

...



[IPS]

...

CONFIG PROTOCOL SCTP PROFILE

Level

base,asq

Description

SCTP protocol's profile settings

CONFIG PROTOCOL SCTP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SCTP protocol

Returns

Error code

CONFIG PROTOCOL SCTP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SCTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SCTP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SCTP protocol

Returns

Error code

**CONFIG PROTOCOL SCTP PROFILE ALARM****Level**

base,asq

Description

Alarm commands for the SCTP protocol

CONFIG PROTOCOL SCTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SCTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SCTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SCTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SCTP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SCTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SCTP PROFILE IPS**Level**

base,asq

Description

SCTP protocol's IPS settings

CONFIG PROTOCOL SCTP PROFILE IPS ASSOCIATION**Level**



base,asq

History

Appears in 3.9.0

Description

IPS commands for SCTP protocol related to associations management

CONFIG PROTOCOL SCTP PROFILE IPS ASSOCIATION CONFIG**Level**

asq,modify

History

Appears in 3.9.0

Description

Configure profile settings for sctp IPS association

Usage

[HandshakeTimeout=<2..60>] [DataTimeout=<30..604800>] [CloseTimeout=<2..60>]
[NbIpMultihomed=<1..8>]

Returns

Error code

Example

CONFIG PROTOCOL SCTP PROFILE IPS ASSOCIATION DataTimeout=42

CONFIG PROTOCOL SCTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Log=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the SCTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SCTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SCTP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

**CONFIG PROTOCOL SCTP PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show SCTP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL SCTP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SCTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SHOW**Level**

base,asq

History

Appears in Netasq 9.0.0

Usage

[index=<profile_idx>]

Description

Show detailed information about protocols (index=1 if omitted)

Example

CONFIG PROTOCOL SHOW index=0

CONFIG PROTOCOL SIP_TCP**Level**

base,asq

**Description**

Commands for the SIP_TCP protocol

CONFIG PROTOCOL SIP_TCP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SIP_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SIP_TCP COMMON**Level**

base,asq

Description

SIP_TCP protocol's common settings

CONFIG PROTOCOL SIP_TCP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set SIP_TCP protocol's common settings

Returns

Error code

CONFIG PROTOCOL SIP_TCP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset SIP_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SIP_TCP COMMON SHOW**Level**

base,asq

Usage

**Description**

Show SIP_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SIP_TCP PROFILE**Level**

base,asq

Description

SIP_TCP protocol's profile settings

CONFIG PROTOCOL SIP_TCP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the SIP_TCP protocol

CONFIG PROTOCOL SIP_TCP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SIP_TCP protocol

Returns

Error code

CONFIG PROTOCOL SIP_TCP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SIP_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config|template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

**CONFIG PROTOCOL SIP_TCP PROFILE ALARM UPDATE****Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}]
[level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds>
emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SIP_TCP protocol

Returns

Error code

CONFIG PROTOCOL SIP_TCP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SIP_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SIP_TCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SIP_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SIP_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SIP_TCP protocol's profile settings to default

Returns

Error code

**CONFIG PROTOCOL SIP_TCP PROFILE IPS****Level**

base,asq

Description

SIP_TCP protocol's IPS settings

CONFIG PROTOCOL SIP_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

```
[AllowOp=<string>] [AllowTCPUrg=On|Off] [DenyOp=<string>] [HeaderBuffer=<64..4096>]
[KeepAliveCommand=<string>] [Log=On|Off] [MaxPendingRequest=<1..512>]
[Messenger=On|Off] [PINT=On|Off] [PassOnFail=On|Off] [Probe=On|Off] [RFC2976=On|Off]
[RFC3262=On|Off] [RFC3265=On|Off] [RFC3311=On|Off] [RFC3428=On|Off] [RFC3515=On|Off]
[RFC3903=On|Off] [RequestBuffer=<64..4096>] [RequestTimeout=<10..3600>]
[SDPBuffer=<64..4096>] [SessionTimeout=<60..604800>] [SkeletonTimeout=<0..600>]
[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the SIP_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SIP_TCP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SIP_TCP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL SIP_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show SIP_TCP protocol profile's settings

Returns

[Common]



[IPS]
State=1
Log=1
Probe=1
...

CONFIG PROTOCOL SIP TCP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SIP_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SIP_UDP

Level

base,asq

Description

Commands for the SIP_UDP protocol

CONFIG PROTOCOL SIP_UDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SIP_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SIP_UDP COMMON

Level

base,asq

Description

SIP_UDP protocol's common settings

CONFIG PROTOCOL SIP_UDP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

**Description**

Set SIP_UDP protocol's common settings

Returns

Error code

CONFIG PROTOCOL SIP_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset SIP_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SIP_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show SIP_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SIP_UDP PROFILE**Level**

base,asq

Description

SIP_UDP protocol's profile settings

CONFIG PROTOCOL SIP_UDP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the SIP_UDP protocol

CONFIG PROTOCOL SIP_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

**Description**

Reset to a default template alarms for the SIP_UDP protocol

Returns

Error code

CONFIG PROTOCOL SIP_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SIP_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SIP_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SIP_UDP protocol

Returns

Error code

CONFIG PROTOCOL SIP_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SIP_UDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SIP_UDP PROFILE COPY**Level**

asq,modify

**Usage**

index=<profile_idx> to=<0..9>

Description

Copy a SIP_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SIP_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SIP_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SIP_UDP PROFILE IPS**Level**

base,asq

Description

SIP_UDP protocol's IPS settings

CONFIG PROTOCOL SIP_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowOp=<string>] [DenyOp=<string>] [HeaderBuffer=<64..4096>]
[KeepAliveCommand=<string>] [Log=On|Off] [MaxPendingRequest=<1..512>]
[Messenger=On|Off] [PINT=On|Off] [PassOnFail=On|Off] [Probe=On|Off] [RFC2976=On|Off]
[RFC3262=On|Off] [RFC3265=On|Off] [RFC3311=On|Off] [RFC3428=On|Off] [RFC3515=On|Off]
[RFC3903=On|Off] [RequestBuffer=<64..4096>] [RequestTimeout=<10..3600>]
[SDPBuffer=<64..4096>] [SessionTimeout=<60..604800>] [SkeletonTimeout=<0..600>]
[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the SIP_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SIP_UDP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

**Description**

List all available profiles or a specific profile for the SIP_UDP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL SIP_UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show SIP_UDP protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
```

```
State=1
```

```
Log=1
```

```
Probe=1
```

```
...
```

CONFIG PROTOCOL SIP_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SIP_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP**Level**

base,asq

Description

Commands for the SKYPE_TCP protocol

CONFIG PROTOCOL SKYPE_TCP ACTIVATE**Level**

asq,modify

Usage



[CANCEL|NEXTBOOT]

Description

Activate the SKYPE_TCP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP COMMON**Level**

base,asq

Description

SKYPE_TCP protocol's common settings

CONFIG PROTOCOL SKYPE_TCP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset SKYPE_TCP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP COMMON SHOW**Level**

base,asq

Usage**Description**

Show SKYPE_TCP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SKYPE_TCP PROFILE**Level**

base,asq

Description

SKYPE_TCP protocol's profile settings

CONFIG PROTOCOL SKYPE_TCP PROFILE ALARM**Level**

base,asq

Description



Alarm commands for the SKYPE_TCP protocol

CONFIG PROTOCOL SKYPE_TCP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SKYPE_TCP protocol

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SKYPE_TCP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SKYPE_TCP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SKYPE_TCP protocol

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description



List all the config referring to the profile specified by index for the SKYPE_TCP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SKYPE_TCP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SKYPE_TCP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SKYPE_TCP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP PROFILE IPS**Level**

base,asq

Description

SKYPE_TCP protocol's IPS settings

CONFIG PROTOCOL SKYPE_TCP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the SKYPE_TCP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SKYPE_TCP PROFILE LIST**Level**

base,asq

Usage



[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SKYPE_TCP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL SKYPE_TCP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show SKYPE_TCP protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

CONFIG PROTOCOL SKYPE_TCP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SKYPE_TCP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP**Level**

base,asq

Description

Commands for the SKYPE_UDP protocol

CONFIG PROTOCOL SKYPE_UDP ACTIVATE**Level**

asq,modify

**Usage**

[CANCEL|NEXTBOOT]

Description

Activate the SKYPE_UDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP COMMON**Level**

base,asq

Description

SKYPE_UDP protocol's common settings

CONFIG PROTOCOL SKYPE_UDP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset SKYPE_UDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP COMMON SHOW**Level**

base,asq

Usage**Description**

Show SKYPE_UDP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SKYPE_UDP PROFILE**Level**

base,asq

Description

SKYPE_UDP protocol's profile settings

CONFIG PROTOCOL SKYPE_UDP PROFILE ALARM**Level**

base,asq

**Description**

Alarm commands for the SKYPE_UDP protocol

CONFIG PROTOCOL SKYPE_UDP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SKYPE_UDP protocol

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SKYPE_UDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SKYPE_UDP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SKYPE_UDP protocol

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

**Description**

List all the config referring to the profile specified by index for the SKYPE_UDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SKYPE_UDP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SKYPE_UDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SKYPE_UDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP PROFILE IPS**Level**

base,asq

Description

SKYPE_UDP protocol's IPS settings

CONFIG PROTOCOL SKYPE_UDP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the SKYPE_UDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SKYPE_UDP PROFILE LIST**Level**

base,asq

**Usage**

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SKYPE_UDP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL SKYPE_UDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show SKYPE_UDP protocol profile's settings

Returns

```
[Common]
```

```
[IPS]
State=1
Log=1
Probe=1
...
```

CONFIG PROTOCOL SKYPE_UDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SKYPE_UDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SMTP**Level**

base,asq

Description

Commands for the SMTP protocol

CONFIG PROTOCOL SMTP ACTIVATE**Level**



asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SMTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SMTP COMMON**Level**

base,asq

Description

SMTP protocol's common settings

CONFIG PROTOCOL SMTP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set SMTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL SMTP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset SMTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SMTP COMMON PROXY**Level**

base,asq

History

Appears in 9.0.4

Description

SMTP common proxy configuration

CONFIG PROTOCOL SMTP COMMON PROXY CONFIG**Level**



asq,modify

History

Appears in 9.0.4

Description

Common parameters configuration

Usage

ApplyNat=<0|1>

ApplyNat : Allow outbound connections from proxies to match any NAT rule instead of just dst-only

Returns

Error code

Example

CONFIG PROTOCOL SMTP COMMON PROXY CONFIG ApplyNat=0

CONFIG PROTOCOL SMTP COMMON SHOW**Level**

base,asq

Usage**Description**

Show SMTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SMTP PROFILE**Level**

base,asq

Description

SMTP protocol's profile settings

CONFIG PROTOCOL SMTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the SMTP protocol

CONFIG PROTOCOL SMTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

**Description**

Reset to a default template alarms for the SMTP protocol

Returns

Error code

CONFIG PROTOCOL SMTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SMTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SMTP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SMTP protocol

Returns

Error code

CONFIG PROTOCOL SMTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SMTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SMTP PROFILE COPY**Level**

asq,modify

**Usage**

index=<profile_idx> to=<0..9>

Description

Copy a SMTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SMTP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SMTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SMTP PROFILE IPS**Level**

base,asq

Description

SMTP protocol's IPS settings

CONFIG PROTOCOL SMTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowOp=<string>] [AllowTCPUrg=On|Off] [BdatSize=<102400..10485760>]
[CommandLineLimit=<64..4096>] [DenyOp=<string>] [FilterChunkedExtension=On|Off]
[FilterExchangeExtensions=On|Off] [FilterPipeliningExtension=On|Off]
[FilterTurningExtensions=On|Off] [HeaderLineLimit=<64..4096>] [Log=On|Off]
[OutstandingPipelinedRequestLimit=<0..1024>] [Probe=On|Off] [ServerLineLimit=<64..4096>]
[State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
[Xexch50Size=<102400..1073741824>]

Description

Set the SMTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SMTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

**Description**

List all available profiles or a specific profile for the SMTP protocol

Returns

```
[00]
name="default"
lastmod="2011-02-23 10:47:45"
...
```

CONFIG PROTOCOL SMTP PROFILE PROXY**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure smtp profile settings

CONFIG PROTOCOL SMTP PROFILE PROXY ANTIVIRUS**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the antivirus part of the smtp profile

Usage

```
index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]
[OnFragmentedEmailPolicy=<pass|block>]
```

Returns

Error code

Example

```
CONFIG PROTOCOL SMTP PROFILE PROXY ANTIVIRUS index=1 OnInfectedPolicy=pass
OnFailedPolicy=pass OnFragmentedEmailPolicy=block
```

CONFIG PROTOCOL SMTP PROFILE PROXY CMD**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the authorized cmd of the smtp profile

Usage

```
index=<profile index>
<HELO|MAIL|RCPT|DATA|RSET|SEND|SOML|SAML|VRFY|EXPN|HELP|NOOP|QUIT|TURN|EHLO|ETRN|A
UTH|ATRN|BDAT|STARTTLS>=<block|pass|filter>
```

Returns



Error code

Example

```
CONFIG PROTOCOL SMTP PROFILE PROXY CMD index=1 HELO=filter MAIL=filter RCPT=filter  
DATA=filter  
RSET=filter SEND=block SOML=block SAML=block VRFY=block EXPN=block HELP=filter  
NOOP=filter  
QUIT=filter TURN=block EHLO=filter ETRN=filter AUTH=filter ATRN=block BDAT=block  
STARTTLS=block
```

CONFIG PROTOCOL SMTP PROFILE PROXY CONFIG

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure the smtp profile

Usage

```
index=<profile index> [BindAddr=<binding ip addr>] [MaxDataSize=<mail data size limit  
(0=unlimited)>] [MaxRecipient=<max recipients(0=unlimited)>]  
[WelcomeMsgFiltering=<on|off>] [DomainEhloFiltering=<on|off>] [ForceHeloIP=<on|off>]  
[MaxLineLength=<1000..2048>] [FullTransparent=on|off]
```

Returns

Error code

Example

```
CONFIG PROTOCOL SMTP PROFILE PROXY CONFIG index=1 BindAddr=MyObject  
MaxDataSize=4096 MaxRecipient=1000 WelcomeMsgFiltering=on DomainEhloFiltering=on  
ForceHeloIP=off MaxLineLength=1000
```

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure extracmd profile settings

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD ADD

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Add additional authorized cmd of the smtp profile

Usage



index=<profile index> <commandname>

Returns

Error code

Example

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD ADD index=1 NEWCOMMAND

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD LIST

Level

base,asq

History

Appears in Netasq 9.0.0

Format

list

Description

List additional authorized cmd of the smtp profile

Usage

index=<profile index>

Returns

List of all authorized cmds

Example

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD LIST index=1

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD REMOVE

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove additional authorized cmd of the smtp profile

Usage

index=<profile index> <commandname>

Returns

Error code

Example

CONFIG PROTOCOL SMTP PROFILE PROXY EXTRACMD REMOVE index=1 NEWCOMMAND

CONFIG PROTOCOL SMTP PROFILE PROXY POSTPROC

Level

asq,modify

History

Appears in Netasq 9.0.0

Description



Configure post processing of the smtp profile

Usage

index=<profile index> [policy=<block|pass>] [size=<MaxDataSize in KB>]
[ServerKeepAlive=<nb of seconds>] [ClientKeepAlive=<nb of seconds>]
[ClientKeepAliveCode=<smtp code>]

Returns

Error code

Example

```
CONFIG PROTOCOL SMTP PROFILE PROXY POSTPROC index=1 policy=pass size=4000  
ServerKeepAlive=20  
CONFIG PROTOCOL SMTP PROFILE PROXY POSTPROC index=1 ClientKeepAlive=20  
ClientKeepAliveCode=250
```

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING**History**

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing part of the smtp profile

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING MAXSIZE**History**

Appears in 2.4.0

Level

base,asq

Description

Commands to configure the sandboxing mail maxsize of the smtp profile

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING MAXSIZE SET**Level**

asq,modify

History

Appears in 2.4.0

Description

Set sandboxing mail maxsize of smtp profile

Usage

index=<profile index> maxsize=<MaxDataSize in KB>

Returns

Error code

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING MAXSIZE SHOW**Level**

base,asq

**History**

Appears in 2.4.0

Description

Show sandboxing mail maxsize of smtp profile

Usage

index=<profile index>

Returns

[Mail]

maxsize=<MaxDataSize in KB>

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING POLICY**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure policy for sandboxing in smtp profile

Usage

index=<profile index> [OnInfectedPolicy=<pass|block>] [OnFailedPolicy=<pass|block>]

Returns

Error code

Example

```
CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING POLICY index=1 OnInfectedPolicy=pass  
OnFailedPolicy=pass
```

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING TYPE**History**

Appears in 2.3.0

Level

base,asq

Description

Commands to configure the sandboxing types of the smtp profile

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING TYPE SHOW**Level**

base,asq

History

Appears in 2.3.0

Format

section_line

Description

Show sandboxing type configuration of smtp profile

**Usage**

index=<profile index>

Returns

[SandboxingType]

state=<on|off> type="archive" maxsize=<MaxDataSize in KB>

state=<on|off> type="document" maxsize=<MaxDataSize in KB>

state=<on|off> type="executable" maxsize=<MaxDataSize in KB>

state=<on|off> type="pdf" maxsize=<MaxDataSize in KB>

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING TYPE UPDATE**Level**

asq,modify

History

Appears in 2.3.0

Description

Configure files specifications for sandboxing in smtp profile

Usage

index=<profile index>

type=<Archive|Document|Executable|Pdf>

[state={0|1}]

[maxsize=<MaxDataSize in KB>]

Returns

Error code

Example

CONFIG PROTOCOL SMTP PROFILE PROXY SANDBOXING TYPE UPDATE index=1 type=Archive
state=1 maxsize=1000

CONFIG PROTOCOL SMTP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show SMTP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL SMTP PROFILE UPDATE**Level**

asq,modify

**Usage**

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SMTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SNMP**Level**

base,asq

Description

Commands for the SNMP protocol

CONFIG PROTOCOL SNMP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SNMP protocol's configuration

Returns

Error code

CONFIG PROTOCOL SNMP COMMON**Level**

base,asq

Description

SNMP protocol's common settings

CONFIG PROTOCOL SNMP COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set SNMP protocol's common settings

Returns

Error code

CONFIG PROTOCOL SNMP COMMON DEFAULT**Level**

asq,modify

**Usage****Description**

Reset SNMP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SNMP COMMON SHOW**Level**

base,asq

Usage**Description**

Show SNMP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SNMP PROFILE**Level**

base,asq

Description

SNMP protocol's profile settings

CONFIG PROTOCOL SNMP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the SNMP protocol

CONFIG PROTOCOL SNMP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SNMP protocol

Returns

Error code

CONFIG PROTOCOL SNMP PROFILE ALARM SHOW**Level**

base,asq

**Usage**

index=<profile_idx> [context=(protocol|<ASQ context name>)] [extended=0|1]

Description

Dump the alarm configuration for the SNMP protocol

Returns

context=(protocol|<ASQ context name>) id=<alarmid> action=(block|pass) level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_template|new) [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SNMP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context=(protocol|<ASQ context name>) [action=(pass|block)] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SNMP protocol

Returns

Error code

CONFIG PROTOCOL SNMP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SNMP protocol

Returns

Config=00 ...

CONFIG PROTOCOL SNMP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SNMP protocol's profile to another profile

Returns

Error code

**CONFIG PROTOCOL SNMP PROFILE DEFAULT****Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SNMP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SNMP PROFILE IPS**Level**

base,asq

Description

SNMP protocol's IPS settings

CONFIG PROTOCOL SNMP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[BlacklistCommunityName=<string>] [BlacklistOID=<string>] [BlacklistUserName=<string>]
[DenyEmptyField=<string>] [DenyOp=<string>] [DenyVersion=<string>] [Log=On|Off]
[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]
[WhitelistCommunityName=<string>] [WhitelistOID=<string>] [WhitelistUserName=<string>]

Description

Set the SNMP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SNMP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SNMP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL SNMP PROFILE SHOW**Level**



base,asq

Usage

index=<profile_idx>

Description

Show SNMP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL SNMP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SNMP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SSH**Level**

base,asq

Description

Commands for the SSH protocol

CONFIG PROTOCOL SSH ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SSH protocol's configuration

Returns

Error code

CONFIG PROTOCOL SSH COMMON**Level**



base,asq

Description

SSH protocol's common settings

CONFIG PROTOCOL SSH COMMON CONFIG**Level**

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set SSH protocol's common settings

Returns

Error code

CONFIG PROTOCOL SSH COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset SSH protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SSH COMMON SHOW**Level**

base,asq

Usage**Description**

Show SSH protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SSH PROFILE**Level**

base,asq

Description

SSH protocol's profile settings

CONFIG PROTOCOL SSH PROFILE ALARM**Level**



base,asq

Description

Alarm commands for the SSH protocol

CONFIG PROTOCOL SSH PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SSH protocol

Returns

Error code

CONFIG PROTOCOL SSH PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SSH protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SSH PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SSH protocol

Returns

Error code

CONFIG PROTOCOL SSH PROFILE CHECK

Level

base,asq

Usage



index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SSH protocol

Returns

Config=00 ...

CONFIG PROTOCOL SSH PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SSH protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SSH PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SSH protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SSH PROFILE IPS**Level**

base,asq

Description

SSH protocol's IPS settings

CONFIG PROTOCOL SSH PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the SSH protocol profile's IPS settings

Returns

Error code



CONFIG PROTOCOL SSH PROFILE LIST

Level

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SSH protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL SSH PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show SSH protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL SSH PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SSH protocol profile's informations

Returns

Error code

CONFIG PROTOCOL SSL

Level

base,asq

Description



Commands for the SSL protocol

CONFIG PROTOCOL SSL ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the SSL protocol's configuration

Returns

Error code

CONFIG PROTOCOL SSL COMMON

Level

base,asq

Description

SSL protocol's common settings

CONFIG PROTOCOL SSL COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=?]

Description

Set SSL protocol's common settings

Returns

Error code

CONFIG PROTOCOL SSL COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset SSL protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL SSL COMMON IPS

Level

base,asq

Description

SSL protocol's IPS settings

**CONFIG PROTOCOL SSL COMMON IPS CONFIG****Level**

asq,modify

Usage

[TLSCertCacheTTL=<60..1209600>]

Description

Set the SSL protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL SSL COMMON PROXY**Level**

base,asq

Description

SSL common proxy configuration

CONFIG PROTOCOL SSL COMMON PROXY CA**History**

Appears in Netasq 9.0.0

Level

base,asq

Description

Certificates Authority Management

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM**Description**

Custom Certificates Authority Management

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM ADD**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Add the specified custom certificate authority

Usage

<custom certificate object to add>

Returns

Error code

Example

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM ADD CAStormshield.pem

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM LIST**Level**



base,asq

History

Appears in Netasq 9.0.0

Format

list

Description

Show the Custom Certificates Authority list

Usage**Returns**

Error Code

Remark

show the list of all used Custom Certificates Authority

Example

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM LIST

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM REMOVE

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove specified custom certificates authority

Usage

<custom certificate object to remove>

Returns

Error Code

Example

CONFIG PROTOCOL SSL COMMON PROXY CA CUSTOM REMOVE CAstormshield

CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED

History

Appears in Netasq 9.0.0

Level

base,asq

Description

Trusted Certificates Authority Management

CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED DISABLE

Level

asq,modify

History



Appears in Netasq 9.0.0

Description

Disable all the trusted certificates authority, or just the specified certificate object

Usage

all|<trusted certificate file name to disable>

all : disable all trusted certificates authority for proxy ssl

<trusted certificate file name> : disable the specified certificate file name

Returns

Error Code

Example

```
CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED DISABLE all
```

```
CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED DISABLE ddc328ff.0
```

```
CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED ENABLE
```

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Enable all trusted certificates authority, or just the specified file

Usage

all|<trusted certificate file name to enable>

all : enable all trusted certificates authority for proxy ssl

<trusted certificate file name> : enable the specified certificate file name

Returns

Error Code

Example

```
CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED ENABLE all
```

```
CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED ENABLE ddc328ff.0
```

```
CONFIG PROTOCOL SSL COMMON PROXY CA TRUSTED LIST
```

Level

base,asq

Format

section_line

History

Appears in Netasq 9.0.0

Description

Show the Trusted Certificates Authority list

Usage

all|enabled|disabled

The trusted list is already embedded on the IPS

all : show the list of all available trusted Certificates Authority with a status before : Enabled or



Disabled

enabled : show the list of trusted Certificates Authority used by the proxy SSL

disabled : show the list of trusted Certificates Authority not used by the proxy SSL

Returns

Error Code

CONFIG PROTOCOL SSL COMMON PROXY CERT

History

Appears in 1.0.0

Level

base,asq

Description

SSL Proxy Certificates Management

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED

History

Appears in 1.0.0

Level

base,asq

Description

SSL Proxy Trusted Certificates Management

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED ADD

History

Appears in 1.0.0

Level

asq,modify

Description

Add a certificate in the trusted store

Usage

cert=<trusted certificate file name>

Returns

Error Code

Example

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED ADD cert="An authority:Its certificate"

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED LIST

History

Appears in 1.0.0

Level

base,asq

Description

List the trusted certificates. Act as a whitelist for bypass SSL checks

**Format**

list

Example

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED LIST

[Result]

An authority:Its certificate

A second authority:The second certificate

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED REMOVE

History

Appears in 1.0.0

Level

asq,modify

Description

Remove a certificate from the trusted store

Usage

cert=<trusted certificate file name>

Returns

Error Code

Example

CONFIG PROTOCOL SSL COMMON PROXY CERT TRUSTED REMOVE id=2

CONFIG PROTOCOL SSL COMMON PROXY CONFIG

Level

asq,modify

History

Appears in Netasq 9.0.0

HTTPCodeOnFail appears in 3.1.0

NbMaxFakeCertif replaced by PercentFakeCertif in 3.3.0

CachelpSize removed in 4.0.0

PercentFakeCertif removed in 4.0.0

Description

Common parameters configuration

Usage

[CipherLevelAlgorithm=low|medium|high] [FakeCertifValidityDate=<integer>]

[CaCustom=<0|1>] [CATrusted=<All|None|exception>] [CA=<authorityName>]

CAPassphrase=<pass>] [ApplyNat=<0|1>] [HTTPCodeOnFail=<200-599>]

CipherLevelAlgorithm : Cipherlevel is a combination of authorized cipher algorithm composed with : low, medium, high

FakeCertifValidityDate : Nb of days for the fake-certificate validity

CaCustom : Enable 1 | Disable 0

CATrusted : Copy the Trusted CA to the verify directory

CA : The authority who sign the fake certificates

CAPassphrase : The passphrase of the authority

ApplyNat : Allow outbound connections from proxies to match any NAT rule instead of just dst-



only

HTTPCodeOnFail : HTTP Header code on fail: 202|403|451|...

CONFIG PROTOCOL SSL COMMON PROXY SSLPROTOCOL

Level

asq,modify

History

Appears in 1.2.0

TLSv1_3 appears in 4.3.0

Description

Configure the ssl protocol used in proxy ssl

Usage

[SSLv3=<on|off>] [TLSv1_0=<on|off>] [TLSv1_1=<on|off>] [TLSv1_2=<on|off>] [TLSv1_3=<on|off>]

Returns

Error code

Example

CONFIG PROTOCOL SSL COMMON PROXY SSLPROTOCOL SSLv3=off TLSv1_0=on TLSv1_1=on TLSv1_2=on

CONFIG PROTOCOL SSL COMMON SHOW

Level

base,asq

Usage

Description

Show SSL protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL SSL PROFILE

Level

base,asq

Description

SSL protocol's profile settings

CONFIG PROTOCOL SSL PROFILE ALARM

Level

base,asq

Description

Alarm commands for the SSL protocol

**CONFIG PROTOCOL SSL PROFILE ALARM DEFAULT****Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the SSL protocol

Returns

Error code

CONFIG PROTOCOL SSL PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the SSL protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile template|config template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL SSL PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the SSL protocol

Returns

Error code

CONFIG PROTOCOL SSL PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the SSL protocol

**Returns**

Config=00 ...

CONFIG PROTOCOL SSL PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a SSL protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL SSL PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset SSL protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL SSL PROFILE IPS**Level**

base,asq

Description

SSL protocol's IPS settings

CONFIG PROTOCOL SSL PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowORTT=On|Off] [AllowAnalysisAfterHandshake=On|Off] [AllowTCPUrg=On|Off]
[AllowUnknownValues=<0..3>] [Blacklist=<string>] [Cipherlevel=<1..63>] [Log=On|Off]
[MaxRenegotiate=<0..65535>] [PlainData=<1..3>] [Probe=On|Off] [SNIBuffer=<10..2048>]
[State=On|Off] [TLSInvalidCRLPolicy=Pass|Block] [TLSInvalidCertTypePolicy=Pass|Block]
[TLSOnFailedPolicy=Pass|Block] [TLSRevocCheckFailPolicy=Pass|Block]
[TLSSelfSignedCertPolicy=Pass|Block] [TLSServerCertAnalysis=On|Off]
[TLSServerCertTimeout=<1..10>] [TLSSniNotFoundPolicy=Pass|Block]
[TLSUntrustedCAPolicy=Pass|Block] [TLSValidityDatePolicy=Pass|Block]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the SSL protocol profile's IPS settings

Returns



Error code

CONFIG PROTOCOL SSL PROFILE LIST

Level

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the SSL protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL SSL PROFILE PROXY

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Commands to configure ssl profile settings

CONFIG PROTOCOL SSL PROFILE PROXY CONFIG

Level

asq,modify

History

RevocCheckFailPolicy appears in 1.0.0

BadDomainPolicy appears in 2.0.0

AllowIpInSNI appears in 2.0.0

Description

Configure the ssl profile

Usage

index=<profile_index> [BindAddr=<binding ip addr>] [OnFailedPolicy=<block|nodecrypt>]
[UntrustedCAPolicy=<block|pass|nodecrypt>] [SelfSignedCertifPolicy=<block|pass|filter>]
[ValidityDatePolicy=<block|pass|filter>] [OnInvalidType=<block|pass|filter>]
[FullTransparent=on|off] [ContentInspection=on|off] [OnInvalidName=<block|pass|filter>]
[RevocCheckFailPolicy=<block|pass|filter>] [AllowIpInSNI=<on|off>]
[BadDomainPolicy=<block|pass|filter>]

index : profile number

BindAddr : bind the source IP address

OnFailedPolicy : Block|Nodecrypt SSL policy for error cases

OnInvalidName : Block|Pass|Filter SSL policy for invalid name cases

UntrustedCAPolicy : Block|Pass|Nodecrypt SSL policy for untrusted CA

SelfSignedCertifPolicy : Block|Pass|Filter Auto signed certificate Policy

ValidityDatePolicy : Block|Pass|Filter Validity date Policy

RevocCheckFailPolicy : Block|Pass|Filter Revocation check fails policy



BadDomainPolicy : Block|Pass|Filter Certificate didn't match the requested domain
OnInvalidType : Block|Pass|Filter Certificate does not have a valid type
FullTransparent : Disable/enable full transparent mode
ContentInspection : Enable/disable content inspection, disable implies bypass inspection analysis
AllowIpInSNI : on/off Allow the use of IP in SNI (violation of RFC 6066)

Returns

Error code

Example

```
CONFIG PROTOCOL SSL PROFILE PROXY CONFIG index=1 OnFailedPolicy=block  
UntrustedCAPolicy=nodecrypt SelfSignedCertifPolicy=filter ValidityDatePolicy=block  
AllowIpInSNI=on
```

CONFIG PROTOCOL SSL PROFILE PROXY SSLFILTERING**Level**

asq, modify

History

Appears in Netasq 9.1.0

Description

Configure the SSLFiltering part of the SSL proxy

Usage

index=<profile index> OnFailedPolicy=<pass|block>
OnFailedPolicy : Pass means continue with the next sslfiltering rules

Returns

Error code

Example

```
CONFIG PROTOCOL SSL PROFILE PROXY SSLFILTERING index=1 OnFailedPolicy=block
```

CONFIG PROTOCOL SSL PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show SSL protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL SSL PROFILE UPDATE**Level**



asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the SSL protocol profile's informations

Returns

Error code

CONFIG PROTOCOL TCPUDP

Level

base,asq

Description

Commands for the TCPUDP protocol

CONFIG PROTOCOL TCPUDP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the TCPUDP protocol's configuration

Returns

Error code

CONFIG PROTOCOL TCPUDP COMMON

Level

base,asq

Description

TCPUDP protocol's common settings

CONFIG PROTOCOL TCPUDP COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset TCPUDP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL TCPUDP COMMON IPS

Level



base,asq

Description

TCPUDP protocol's IPS settings

CONFIG PROTOCOL TCPUDP COMMON IPS CONFIG

Level

asq,modify

Usage

[FastPathIPv4=<0..255>] [FastPathIPv6=<0..255>] [IpfixState=0n|Off]
[IpfixUpdateTimeout=<5..120>] [Pof=0n|Off] [PortScanRate=<0..16>]
[TCPReassemblyLimit=<0..4294967295>] [UserRemoveState=0n|Off]

Description

Set the TCPUDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL TCPUDP COMMON IPS CONNECTION

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure connection profile settings for tcp/udp

Usage

[HalfOpen=0n|Off] [PurgeTimeout=<2..172800>] [LogTCP=0n|Off] [LogUDP=0n|Off]
[UseAutoFastRoute=0n|Off]

Returns

Error code

Example

CONFIG PROTOCOL TCPUDP COMMON IPS CONNECTION LogTCP=0n LogUDP=Off

CONFIG PROTOCOL TCPUDP COMMON SHOW

Level

base,asq

Usage

Description

Show TCPUDP protocol's common settings

Returns

[Common]

...

[IPS]

...



CONFIG PROTOCOL TCPUDP PROFILE

Level

base,asq

Description

TCPUDP protocol's profile settings

CONFIG PROTOCOL TCPUDP PROFILE ALARM

Level

base,asq

Description

Alarm commands for the TCPUDP protocol

CONFIG PROTOCOL TCPUDP PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the TCPUDP protocol

Returns

Error code

CONFIG PROTOCOL TCPUDP PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the TCPUDP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL TCPUDP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description



Configure ASQ alarm (IPS alarm) for the TCPUDP protocol

Returns

Error code

CONFIG PROTOCOL TCPUDP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the TCPUDP protocol

Returns

Config=00 ...

CONFIG PROTOCOL TCPUDP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a TCPUDP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL TCPUDP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset TCPUDP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL TCPUDP PROFILE IPS**Level**

base,asq

Description

TCPUDP protocol's IPS settings

CONFIG PROTOCOL TCPUDP PROFILE IPS CONFIG**Level**

asq,modify

Usage



```
[AllowTCPUrg=On|Off] [KeepTCPUrg=On|Off] [State=On|Off]  
[TemplateAlarm=<low|medium|high|internet>]
```

Description

Set the TCPUDP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL TCPUDP PROFILE IPS CONNECTION**Level**

asq,modify

History

Appears in Netasq 9.0.0

MaxSrcConn, MaxSrcConnRateNumber and MaxSrcConnRateInterval appear in 2.0.0

TrackApp appears in 3.2.0

Description

Configure profile settings for tcp/udp IPS connection

Usage

```
[ClosedTimeout=<0..60>] [SecureTCP={On|Off}] [HalfCloseTimeout=<2..3600>]  
[MSSLimit=<0|100..65535>] [SeqRewrite={On|Off}] [SkeletonTimeout=<2..60>]  
[SYNTimeout=<2..60>] [TCPDataTimeout=<30..604800>] [UDPDataTimeout=<30..604800>]  
[TCPSmallWindowTimeout=<5..604800>] [TCPClosedFastReuse={On|Off}]  
[ProbeTimeout=<100..60000>] [StalledTimeout=<8..60480>]  
[MaxSrcConn=<0|1..2147483647>] [MaxSrcConnRateNumber=<0|1..2147483647>]  
[MaxSrcConnRateInterval=<1..3600>] [UseSACK={On|Off}] [DtrackAutoAdjust={On|Off}]  
[TrackApp={On|Off}]
```

Returns

Error code

Example

CONFIG PROTOCOL TCPUDP PROFILE IPS CONNECTION ClosedTimeout=42

CONFIG PROTOCOL TCPUDP PROFILE IPS SYNPROXY**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Configure profile settings for tcp/udp synproxy

Usage

```
[State=On|Off] [Sack=On|Off] [MSSLimit=<0|100..65535>] [AllConn=On|Off]
```

Returns

Error code

Example

CONFIG PROTOCOL TCPUDP PROFILE IPS SYNPROXY

**CONFIG PROTOCOL TCPUDP PROFILE LIST****Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the TCPUDP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL TCPUDP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show TCPUDP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL TCPUDP PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the TCPUDP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL TDS**Level**

base,asq

Description



Commands for the TDS protocol

CONFIG PROTOCOL TDS ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the TDS protocol's configuration

Returns

Error code

CONFIG PROTOCOL TDS COMMON

Level

base,asq

Description

TDS protocol's common settings

CONFIG PROTOCOL TDS COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set TDS protocol's common settings

Returns

Error code

CONFIG PROTOCOL TDS COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset TDS protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL TDS COMMON SHOW

Level

base,asq

Usage**Description**



Show TDS protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL TDS PROFILE**Level**

base,asq

Description

TDS protocol's profile settings

CONFIG PROTOCOL TDS PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the TDS protocol

CONFIG PROTOCOL TDS PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the TDS protocol

Returns

Error code

CONFIG PROTOCOL TDS PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the TDS protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL TDS PROFILE ALARM UPDATE**Level**



asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}]
[level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds>
emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the TDS protocol

Returns

Error code

CONFIG PROTOCOL TDS PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the TDS protocol

Returns

Config=00 ...

CONFIG PROTOCOL TDS PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a TDS protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL TDS PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset TDS protocol's profile settings to default

Returns

Error code



CONFIG PROTOCOL TDS PROFILE IPS

Level

base,asq

Description

TDS protocol's IPS settings

CONFIG PROTOCOL TDS PROFILE IPS CONFIG

Level

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the TDS protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL TDS PROFILE LIST

Level

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the TDS protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL TDS PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show TDS protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1



Probe=1

...

CONFIG PROTOCOL TDS PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the TDS protocol profile's informations

Returns

Error code

CONFIG PROTOCOL TELNET

Level

base,asq

Description

Commands for the TELNET protocol

CONFIG PROTOCOL TELNET ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the TELNET protocol's configuration

Returns

Error code

CONFIG PROTOCOL TELNET COMMON

Level

base,asq

Description

TELNET protocol's common settings

CONFIG PROTOCOL TELNET COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set TELNET protocol's common settings

**Returns**

Error code

CONFIG PROTOCOL TELNET COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset TELNET protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL TELNET COMMON SHOW**Level**

base,asq

Usage**Description**

Show TELNET protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL TELNET PROFILE**Level**

base,asq

Description

TELNET protocol's profile settings

CONFIG PROTOCOL TELNET PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the TELNET protocol

CONFIG PROTOCOL TELNET PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the TELNET protocol

**Returns**

Error code

CONFIG PROTOCOL TELNET PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the TELNET protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL TELNET PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the TELNET protocol

Returns

Error code

CONFIG PROTOCOL TELNET PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the TELNET protocol

Returns

Config=00 ...

CONFIG PROTOCOL TELNET PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

**Description**

Copy a TELNET protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL TELNET PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset TELNET protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL TELNET PROFILE IPS**Level**

base,asq

Description

TELNET protocol's IPS settings

CONFIG PROTOCOL TELNET PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the TELNET protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL TELNET PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the TELNET protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

**CONFIG PROTOCOL TELNET PROFILE SHOW****Level**

base,asq

Usage

index=<profile_idx>

Description

Show TELNET protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL TELNET PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the TELNET protocol profile's informations

Returns

Error code

CONFIG PROTOCOL TEREDO**Level**

base,asq

Description

Commands for the TEREDO protocol

CONFIG PROTOCOL TEREDO ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the TEREDO protocol's configuration

Returns

Error code



CONFIG PROTOCOL TEREDO COMMON

Level

base,asq

Description

TEREDO protocol's common settings

CONFIG PROTOCOL TEREDO COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set TEREDO protocol's common settings

Returns

Error code

CONFIG PROTOCOL TEREDO COMMON DEFAULT

Level

asq,modify

Usage**Description**

Reset TEREDO protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL TEREDO COMMON SHOW

Level

base,asq

Usage**Description**

Show TEREDO protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL TEREDO PROFILE

Level

base,asq

Description

TEREDO protocol's profile settings

**CONFIG PROTOCOL TEREDO PROFILE ALARM****Level**

base,asq

Description

Alarm commands for the TEREDO protocol

CONFIG PROTOCOL TEREDO PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the TEREDO protocol

Returns

Error code

CONFIG PROTOCOL TEREDO PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the TEREDO protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL TEREDO PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the TEREDO protocol

Returns

Error code

CONFIG PROTOCOL TEREDO PROFILE CHECK**Level**



base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the TEREDO protocol

Returns

Config=00 ...

CONFIG PROTOCOL TEREDO PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a TEREDO protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL TEREDO PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset TEREDO protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL TEREDO PROFILE IPS**Level**

base,asq

Description

TEREDO protocol's IPS settings

CONFIG PROTOCOL TEREDO PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the TEREDO protocol profile's IPS settings

Returns

Error code

**CONFIG PROTOCOL TEREDO PROFILE LIST****Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the TEREDO protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL TEREDO PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show TEREDO protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL TEREDO PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the TEREDO protocol profile's informations

Returns

Error code

CONFIG PROTOCOL TFTP**Level**

base,asq

Description



Commands for the TFTP protocol

CONFIG PROTOCOL TFTP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the TFTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL TFTP COMMON

Level

base,asq

Description

TFTP protocol's common settings

CONFIG PROTOCOL TFTP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>]

Description

Set TFTP protocol's common settings

Returns

Error code

CONFIG PROTOCOL TFTP COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset TFTP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL TFTP COMMON SHOW

Level

base,asq

Usage

Description



Show TFTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL TFTP PROFILE**Level**

base,asq

Description

TFTP protocol's profile settings

CONFIG PROTOCOL TFTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the TFTP protocol

CONFIG PROTOCOL TFTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the TFTP protocol

Returns

Error code

CONFIG PROTOCOL TFTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the TFTP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL TFTP PROFILE ALARM UPDATE**Level**



asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}]
[level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds>
emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>]
[qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the TFTP protocol

Returns

Error code

CONFIG PROTOCOL TFTP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the TFTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL TFTP PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a TFTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL TFTP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset TFTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL TFTP PROFILE IPS**Level**



base,asq

Description

TFTP protocol's IPS settings

CONFIG PROTOCOL TFTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[FileBuffer=<64..512>] [Log=0n|0ff] [PassOnFail=0n|0ff] [Probe=0n|0ff]
[SkeletonTimeout=<0..600>] [State=0n|0ff] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the TFTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL TFTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the TFTP protocol

Returns

[00]
name="default"
lastmod="2011-02-23 10:47:45"
...

CONFIG PROTOCOL TFTP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show TFTP protocol profile's settings

Returns

[Common]

[IPS]
State=1
Log=1
Probe=1
...

**CONFIG PROTOCOL TFTP PROFILE UPDATE****Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the TFTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL UTP**Level**

base,asq

Description

Commands for the UTP protocol

CONFIG PROTOCOL UTP ACTIVATE**Level**

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the UTP protocol's configuration

Returns

Error code

CONFIG PROTOCOL UTP COMMON**Level**

base,asq

Description

UTP protocol's common settings

CONFIG PROTOCOL UTP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset UTP protocol's common settings to default

Returns

Error code

**CONFIG PROTOCOL UTP COMMON SHOW****Level**

base,asq

Usage**Description**

Show UTP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL UTP PROFILE**Level**

base,asq

Description

UTP protocol's profile settings

CONFIG PROTOCOL UTP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the UTP protocol

CONFIG PROTOCOL UTP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the UTP protocol

Returns

Error code

CONFIG PROTOCOL UTP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the UTP protocol

Returns



context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL UTP PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the UTP protocol

Returns

Error code

CONFIG PROTOCOL UTP PROFILE CHECK

Level

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the UTP protocol

Returns

Config=00 ...

CONFIG PROTOCOL UTP PROFILE COPY

Level

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a UTP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL UTP PROFILE DEFAULT

Level

asq,modify

Usage

index=<profile_idx>

Description



Reset UTP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL UTP PROFILE IPS**Level**

base,asq

Description

UTP protocol's IPS settings

CONFIG PROTOCOL UTP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[Log=On|Off] [Probe=On|Off] [State=On|Off] [TemplateAlarm=<low|medium|high|internet>]

Description

Set the UTP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL UTP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the UTP protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL UTP PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show UTP protocol profile's settings

Returns

[Common]

[IPS]

State=1



Log=1
Probe=1
...

CONFIG PROTOCOL UTP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the UTP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL XMPP

Level

base,asq

Description

Commands for the XMPP protocol

CONFIG PROTOCOL XMPP ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the XMPP protocol's configuration

Returns

Error code

CONFIG PROTOCOL XMPP COMMON

Level

base,asq

Description

XMPP protocol's common settings

CONFIG PROTOCOL XMPP COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description



Set XMPP protocol's common settings

Returns

Error code

CONFIG PROTOCOL XMPP COMMON DEFAULT**Level**

asq,modify

Usage**Description**

Reset XMPP protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL XMPP COMMON SHOW**Level**

base,asq

Usage**Description**

Show XMPP protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL XMPP PROFILE**Level**

base,asq

Description

XMPP protocol's profile settings

CONFIG PROTOCOL XMPP PROFILE ALARM**Level**

base,asq

Description

Alarm commands for the XMPP protocol

CONFIG PROTOCOL XMPP PROFILE ALARM DEFAULT**Level**

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description



Reset to a default template alarms for the XMPP protocol

Returns

Error code

CONFIG PROTOCOL XMPP PROFILE ALARM SHOW**Level**

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the XMPP protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL XMPP PROFILE ALARM UPDATE**Level**

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the XMPP protocol

Returns

Error code

CONFIG PROTOCOL XMPP PROFILE CHECK**Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the XMPP protocol

Returns

Config=00 ...

CONFIG PROTOCOL XMPP PROFILE COPY**Level**

asq,modify

Usage



index=<profile_idx> to=<0..9>

Description

Copy a XMPP protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL XMPP PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset XMPP protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL XMPP PROFILE IPS**Level**

base,asq

Description

XMPP protocol's IPS settings

CONFIG PROTOCOL XMPP PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Probe=On|Off] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description

Set the XMPP protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL XMPP PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the XMPP protocol

Returns

[00]
name="default"



```
lastmod="2011-02-23 10:47:45"
```

```
...
```

CONFIG PROTOCOL XMPP PROFILE SHOW

Level

base,asq

Usage

index=<profile_idx>

Description

Show XMPP protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL XMPP PROFILE UPDATE

Level

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the XMPP protocol profile's informations

Returns

Error code

CONFIG PROTOCOL YMSG

Level

base,asq

Description

Commands for the YMSG protocol

CONFIG PROTOCOL YMSG ACTIVATE

Level

asq,modify

Usage

[CANCEL|NEXTBOOT]

Description

Activate the YMSG protocol's configuration

Returns



Error code

CONFIG PROTOCOL YMSG COMMON

Level

base,asq

Description

YMSG protocol's common settings

CONFIG PROTOCOL YMSG COMMON CONFIG

Level

asq,modify

Usage

[DefaultPort=<list of obj services>] [SSLDefaultPort=<list of obj services>]

Description

Set YMSG protocol's common settings

Returns

Error code

CONFIG PROTOCOL YMSG COMMON DEFAULT

Level

asq,modify

Usage

Description

Reset YMSG protocol's common settings to default

Returns

Error code

CONFIG PROTOCOL YMSG COMMON SHOW

Level

base,asq

Usage

Description

Show YMSG protocol's common settings

Returns

[Common]

...

[IPS]

...

CONFIG PROTOCOL YMSG PROFILE

Level

base,asq

Description



YMSG protocol's profile settings

CONFIG PROTOCOL YMSG PROFILE ALARM

Level

base,asq

Description

Alarm commands for the YMSG protocol

CONFIG PROTOCOL YMSG PROFILE ALARM DEFAULT

Level

asq,modify

Usage

index=<profile index> template={high|medium|low|internet|""} [reset=0|1]

Description

Reset to a default template alarms for the YMSG protocol

Returns

Error code

CONFIG PROTOCOL YMSG PROFILE ALARM SHOW

Level

base,asq

Usage

index=<profile_idx> [context={protocol|<ASQ context name>}] [extended=0|1]

Description

Dump the alarm configuration for the YMSG protocol

Returns

context={protocol|<ASQ context name>} id=<alarmid> action={block|pass} level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_template|new} [blacklist=on blduration=<int>] [email=on emailduration=<int> emailcount=<int>] msg=<alarm message> modify={0|1} sensible={0|1} legacy={0|1} category=<category> comment=<string> ...

CONFIG PROTOCOL YMSG PROFILE ALARM UPDATE

Level

asq,modify

Usage

index=<profile index> id=<int> context={protocol|<ASQ context name>} [action={pass|block}] [level={minor|major|ignore}] [dump={0|1}] [email=off | email=on emailduration=<seconds> emailcount=<int>] [blacklist=off | blacklist=on blduration=<minutes>] [comment=<string>] [qid=<Queue name>]

Description

Configure ASQ alarm (IPS alarm) for the YMSG protocol

Returns

Error code

**CONFIG PROTOCOL YMSG PROFILE CHECK****Level**

base,asq

Usage

index=<profile_idx>

Description

List all the config referring to the profile specified by index for the YMSG protocol

Returns

Config=00 ...

CONFIG PROTOCOL YMSG PROFILE COPY**Level**

asq,modify

Usage

index=<profile_idx> to=<0..9>

Description

Copy a YMSG protocol's profile to another profile

Returns

Error code

CONFIG PROTOCOL YMSG PROFILE DEFAULT**Level**

asq,modify

Usage

index=<profile_idx>

Description

Reset YMSG protocol's profile settings to default

Returns

Error code

CONFIG PROTOCOL YMSG PROFILE IPS**Level**

base,asq

Description

YMSG protocol's IPS settings

CONFIG PROTOCOL YMSG PROFILE IPS CONFIG**Level**

asq,modify

Usage

[AllowTCPUrg=On|Off] [Log=On|Off] [Probe=On|Off] [SkeletonTimeout=<0..600>] [State=On|Off]
[TemplateAlarm=<low|medium|high|internet>]

Description



Set the YMSG protocol profile's IPS settings

Returns

Error code

CONFIG PROTOCOL YMSG PROFILE LIST**Level**

base,asq

Usage

[index=<profile_idx>]

Description

List all available profiles or a specific profile for the YMSG protocol

Returns

[00]

name="default"

lastmod="2011-02-23 10:47:45"

...

CONFIG PROTOCOL YMSG PROFILE SHOW**Level**

base,asq

Usage

index=<profile_idx>

Description

Show YMSG protocol profile's settings

Returns

[Common]

[IPS]

State=1

Log=1

Probe=1

...

CONFIG PROTOCOL YMSG PROFILE UPDATE**Level**

asq,modify

Usage

index=<profile_idx> [name=<string>] [comment=<string>]

Description

Update the YMSG protocol profile's informations

Returns

Error code



CONFIG PVM

Level

base

History

Appears in Netasq 7.0.0

Description

Configure the proactive vulnerability management module

CONFIG PVM ACTIVATE

Level

pvm,modify

History

Appears in Netasq 7.0.0

Description

Activate or discard changes of the last configuration operations

Usage

[CANCEL]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

Example

```
> CONFIG PVM ACTIVATE  
100 code=00a00100 msg="Ok"
```

CONFIG PVM DATA

Level

base

History

Appears in Netasq 7.0.0

Description

Get informations about vulnerabilities of the proactive vulnerability management module

CONFIG PVM DATA FAMILY

Level

pvm

History

Appears in Netasq 7.0.0

Description

Return the list of vulnerability family names with their id

**Returns**

<family_id>=<family_name>

Example

```
> CONFIG PVM DATA FAMILY
101 code=00a01000 msg="Début"
1="web server"
2="web client"
...
100 code=00a00100 msg="Ok"
```

CONFIG PVM DATA SEVERITY**Level**

pvm

History

Appears in Netasq 7.0.0

Description

Return the list of vulnerability severity names with their id

Returns

<severity_id>=<severity_label>

Example

```
> CONFIG PVM DATA SEVERITYLIST
101 code=00a01000 msg="Début"
0=null
1=low
...
100 code=00a00100 msg="Ok"
```

CONFIG PVM DATA VULN**Level**

pvm

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

Return the list of informations about vulnerabilities of the proactive vulnerability management module

Usage

[PvmId=<vuln_id>]

Returns

id : vulnerability id
name : vulnerability's name
family : vulnerability's family id
severity : vulnerability's severity id
date : vulnerability's discovery date
targetclient : true if affected product is a client



targetserver : true if affected product is a server
remote : true if the vulnerability could be exploited remotely

Remark

if PvmId is not present, all vulnerabilities are returned

Format

section_line

Example

```
> CONFIG PVM DATA VULN
101 code=00a01000 msg="Début"
id=x name=x family=x severity=x date=x targetclient=x targetserver=x remote=x
id=x name=x family=x severity=x date=x targetclient=x targetserver=x remote=x
100 code=00a00100 msg="Ok"
```

CONFIG PVM EMAIL

Level

pvm

History

Appears Netasq 9.0.0

Description

Set the mailgroups to which the pvm emails will be sent (set to empty to disable email)

Usage

```
[mail1=<email_group>|"" ] [mail2=<email_group>|"" ]
```

Returns

Error code

Remark

CONFIG PVM HOSTLIST

Level

base

History

Appears in Netasq 7.0.0

Description

Configure monitored hosts and which profile must be used for them

CONFIG PVM HOSTLIST ADD

Level

pvm,modify

History

Appears in Netasq 7.0.0

Description



Associate a machine, network or group with a profile or exclude it from monitoring

Usage

Host=<host|network|group> [Type=included Profile=<profile_name> | Type=excluded]

Returns

Error code

Example

```
> CONFIG PVM HOSTLIST ADD Type=included Host=x Profile=x
100 code=00a00100 msg="Ok"
> CONFIG PVM HOSTLIST ADD Type=excluded Host=x
100 code=00a00100 msg="Ok"
```

CONFIG PVM HOSTLIST CLEAR**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Clear the monitored list or the excluded list

Usage

Type=included|excluded

Returns

Error code

Example

```
> CONFIG PVM HOSTLIST CLEAR Type=included
100 code=00a00100 msg="Ok"
```

CONFIG PVM HOSTLIST REMOVE**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Remove the object from the monitored list or the excluded list

Usage

Type=included|excluded Host=<host|network|group>

Returns

Error code

Example

```
> CONFIG PVM HOSTLIST REMOVE Type=included Host=x
100 code=00a00100 msg="Ok"
```



CONFIG PVM HOSTLIST SHOW

Level

base

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

Show the included list and the excluded list

Returns

host : object name that represent the host, the network or the group profile : profile name associated with the object

Format

section_line

Example

```
> CONFIG PVM HOSTLIST SHOW
101 code=00a01000 msg="Début"
[included] host=x profile=x
host=x profile=x
[excluded] host=x
host=x
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE

Level

base

History

Appears in Netasq 7.0.0

Description

Set profiles which associate actions with vulnerability criterias

CONFIG PVM PROFILE CLEAR

Level

pvm,modify

History

Appears in Netasq 7.0.0

Description

Remove all lines from a profile

Usage

Profile=<profile_name>

Returns

Error code

**Example**

```
> CONFIG PVM PROFILE CLEAR Profile=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE CREATE**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Create a new profile

Usage

Profile=<profile_name> [Comment=<any_comment>]

Returns

Error code

Example

```
> CONFIG PVM PROFILE CREATE Profile=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE LINE**Level**

base

History

Appears in Netasq 7.0.0

Description

Manage lines in profiles

CONFIG PVM PROFILE LINE ADD**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Add a line to a profile

Usage

Profile=<profile_name> LineId=<line_id> state=1|0 { vulnlist=1 | { [family=<family_id>]
[targetclient=1|0] [targetserver=1|0] [remote=1|0] [severity=x] } } [level=<minor|major>]
[mail1=<email_group>] [mail2=<email_group>] [comment=x]

Returns

Error code

Remark

LineId must be equal to the last line id + 1

**Example**

```
> CONFIG PVM PROFILE LINE ADD Profile=x LineId=x state=1 family=x level=minor  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE LINE REMOVE**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Remove a line from a profile

Usage

Profile=<profile_name> LineId=<line_id>

Returns

Error code

Remark

LineId must be equal to the last line id

Example

```
> CONFIG PVM PROFILE LINE REMOVE Profile=x LineId=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE LINE UPDATE**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Update a line in a profile

Usage

Profile=<profile name> LineId=<line id> state=1|0 { vulnlist=1 | { [family=<family_id>
[targetclient=1|0] [targetserver=1|0] [remote=1|0] [severity=x]] } [level=<minor|major>
[mail1=<email_group>] [mail2=<email_group>] [comment=x]

Returns

Error code

Remark

LineId must already exist

Example

```
> CONFIG PVM PROFILE LINE UPDATE Profile=x LineId=x state=1 family=x alertlevel=minor  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE LIST**Level**

base

**History**

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

List all defined profiles

Returns

profile : profile name comment : comment associated with the profile

Format

section_line

Example

```
> CONFIG PVM PROFILE LIST
101 code=00a01000 msg="Début"
profile=profile1 comment=x
profile=profile2 comment=x
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE REMOVE**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Remove a profile

Usage

Profile=<profile_name>

Returns

Error code

Example

```
> CONFIG PVM PROFILE REMOVE Profile=x
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE SHOW**Level**

pvm

History

Appears in Netasq 7.0.0

Description

Show a profile definition

Usage

Profile=<profile_name>

Returns



```
[<line_id>]
state=1|0
family=<family_id>
targetclient=1|0
targetserver=1|0
remote=1|0
severity=x
level=<minor|major>
mail1=<email_group>
mail2=<email_group>
comment=x
```

```
[<line_id>]
state=1|0
vulnlist=1
level=<minor|major>
mail1=<email_group>
mail2=<email_group>
comment=x
```

...

Remark

vulnerability criteria (family, targetclient, targetserver, remote and severity) not present means any

level not present means ignore

mail1 and mail2 not present means no mail

if vulnlist is present no vulnerability criteria could be present, vuln ids are retrieved by 'CONFIG PVM PROFILE VULN SHOW'

Example

```
> CONFIG PVM PROFILE SHOW Profile=x
```

```
101 code=00a01000 msg="Début"
```

```
[1]
```

```
state=1
```

```
family=21
```

```
level=minor
```

```
mail1=g1
```

```
[2]
```

```
state=1
```

```
vulnlist=1
```

```
level=major
```

```
mail1=g1
```

```
mail2=g1
```

```
[3]
```

```
state=1
```

```
severity=4
```

```
level=major
```

```
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE UPDATE

Level

pvm,modify

History



Appears in Netasq 7.0.0

Description

Modify a profile

Usage

Profile=<profile_name> Comment=<any_comment>

Returns

Error code

Example

```
> CONFIG PVM PROFILE CREATE Profile=x Comment=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE VULN**Level**

base

History

Appears in Netasq 7.0.0

Description

Manage vuln id explicitly associated with a line of a profile

CONFIG PVM PROFILE VULN ADD**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Associate a vulnerability id with a line of a profile

Usage

Profile=<profile_name> LineId=<line_id> PvmId=<vuln_id>

Returns

Error code

Remark

the profile line must have no vulnerability criteria set

Example

```
> CONFIG PVM PROFILE VULN ADD profile=x LineId=x PvmId=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE VULN CLEAR**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description



Remove all vulnerability ids associated with a line of a profile

Usage

Profile=<profile_name> LineId=<line_id>

Returns

Error code

Example

```
> CONFIG PVM PROFILE VULN CLEAR profile=x LineId=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE VULN REMOVE**Level**

pvm,modify

History

Appears in Netasq 7.0.0

Description

Remove a vulnerability id from the line of a profile association

Usage

Profile=<profile_name> LineId=<line_id> PvmId=<vuln_id>

Returns

Error code

Example

```
> CONFIG PVM PROFILE VULN REMOVE profile=x LineId=x PvmId=x  
100 code=00a00100 msg="Ok"
```

CONFIG PVM PROFILE VULN SHOW**Level**

pvm

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

Return the list of vulnerability id associated with a line of a profile

Usage

Profile=<profile_name> LineId=<line_id>

Returns

list of vulnerability id

Format

list

Example

```
> CONFIG PVM PROFILE VULN SHOW profile=x LineId=x  
101 code=00a01000 msg="Début"  
100221
```



```
122333
100 code=00a00100 msg="Ok"
```

CONFIG PVM SHOW

Level

base

History

Appears in Netasq 7.0.0

Description

Return the global proactive vulnerability management module configuration

Returns

state : the state of the module if there is no paramet eventttl : the value in seconds of the timeout of events

Example

```
> CONFIG PVM SHOW
101 code=00a01000 msg="Début"
[Result]
State=On
EventTTL=86400
mail1=<email_group>
mail2=<email_group>
100 code=00a00100 msg="Ok"
```

CONFIG PVM STATE

Level

pvm

History

Appears in Netasq 7.0.0

Description

Enable, disable or return the state of the proactive vulnerability management module

Usage

[On|Off]

Returns

return the state of the module if there is no parameter

Remark

Modify level is required to update the state value

Example

```
> CONFIG PVM STATE On
100 code=00a00100 msg="Ok"
> CONFIG PVM STATE
101 code=00a01000 msg="Début"
[Result]
```



State=On
100 code=00a00100 msg="Ok"

CONFIG PVM TIMEOUT

Level

pvm

History

Appears in Netasq 7.0.0

Description

Set how long vulnerabilities are stored in the proactive vulnerability management module

Usage

[EventTTL=<timeout_in_seconds>]

Returns

return the value in seconds of the timeout of events

Remark

Modify level is required to update value

Example

```
> CONFIG PVM TIMEOUT EventTTL=86400  
100 code=00a00100 msg="Ok"  
> CONFIG PVM TIMEOUT  
101 code=00a01000 msg="Début"  
[Result]  
EventTTL=86400  
100 code=00a00100 msg="Ok"
```

CONFIG RAID

Level

base

History

level base Appears in Netasq 6.0.0
level other deprecated in Netasq 6.0.0

Description

Command to manage raid

CONFIG RAID CREATE

Level

maintenance,modify

History

Appears in 8.1.0

Description



Create raid array if it is not done automatically. Reboot is needed after this operation.

CONFIG RAID HOTSPARE

Level

maintenance,modify

History

level maintenance Appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

Description

Force the hotspare's status to be optimal

Usage

physical number of the drive (min = 1)

CONFIG RAID REBUILD

Level

maintenance,modify

History

level maintenance Appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

Description

Rebuild the array

CONFIG REPORT

Level

base

Description

Configure reporting

CONFIG REPORT ACTIVATE

Level

report,modify

History

Appears in Netasq 9.1.0

Description

Activate report configuration changes

Usage

No arguments : changes are activated immediately

CANCEL : Changes are discarded

NEXTBOOT : Changes will be activated on next boot

**Example**

CONFIG REPORT ACTIVATE

CONFIG REPORT SHOW**Level**

base

History

Appears in Netasq 9.1.0

family appears in 3.0.0

Description

Display reports configuration

Usage

[report=<report_id> | family={report|linechart|all}] (default: family=report)
[useclone={0|1}] (default: 0)
[extra={0|1}] : if 1, will display additionnal informations that may take time to compute
(default: 0)

Returns

[Global]

State={0|1} : global state of the reporting functionality

Size=123456 : size of the report database

[<report id 1>] : report id

Comment="" : description of the report

State={0|1} : indicates if the report is enabled

[<report id 2>]

Comment=""

State={0|1}

[...]

Remark

if "report" is specified, only the configuration of this specific report will be displayed

Example

CONFIG REPORT SHOW

CONFIG REPORT SHOW report=top_ips_alarms

CONFIG REPORT SHOW extra=1

CONFIG REPORT STATE**Level**

base

History

Appears in Netasq 9.1.0

linecharts appears in 3.0.0

Description



Enable or disable reporting

Usage

[reports={on|off}] [linecharts={on|off}]

Returns

Reports={0|1} LineCharts={0|1}

Remark

If reporting is disabled, the report database will remain in place, untouched. You have to delete the report database yourselves if you don't want to keep the values (see REPORT RESET)

Example

```
CONFIG REPORT STATE
CONFIG REPORT STATE reports=off
```

CONFIG REPORT UPDATE

Level

report,modify

History

Appears in Netasq 9.1.0

Description

Change report configuration

Usage

report=<report_id> : report for which we want to update the configuration
state={0|1} : new report state (disabled/enabled)

Example

```
CONFIG REPORT UPDATE report=top_ips_alarms state=0
```

CONFIG RESTORE

Level

maintenance,modify

History

level maintenance Appears in Netasq 6.0.0

level admin deprecated in Netasq 6.0.0

usb Appears in Netasq 6.1.0

refresh appears in 8.1.4

force appears in 2.3.0

global_vpn appears in 2.5.0

global_cert appears in 3.0.0

CheckBeforeRestore appears in 3.0.0

fwserial deprecated in 3.5.0

usb disappears in 4.0.0

option secure for list disappears in 4.0.0

ennetwork appears in 4.2.2

Description



Restores full or partial configuration (complete list of available items is provided by SYSTEM BACKUP command)

Usage

```
list=<all|network|global|object|global_object|filter|filterslotxx|global_filter|global_filterslotxx|vpn|global_vpn|ldap|urlfiltering|sslfiltering|urlgroup|global|pattern|autoupdate|services|mailfiltering|dhcp|ntp|dns|snmp|pvm|cert|global_cert|securityinspection|vpn-ssl|vpn-pptp|event-rules|qos|auth|webadmin|statusweight|log|route|sysevent|bird|antispam|mailgroup|communication|system|serverd|reports|fwadmin|access_tickets|monitor> [refresh=0|1] [password=<password protection>] [force=0|1] [CheckBeforeRestore=0|1] [ennetwork=0|1]
```

Returns

Error code

Remark

refresh token (default 0), when set to 1, refresh all (except network) firewall configuration, and does not require user to reboot if services successfully restarted.

force set to 1 allows restore when a list item is missing in the backup file (default is 0)

ennetwork (default 0) automatically activates network configuration (if no reboot is needed)

Example

```
CONFIG RESTORE list=all password=adminadmin
```

```
CONFIG RESTORE list=all refresh=1
```

```
CONFIG RESTORE list=all
```

CONFIG SANDBOXING

Level

base

History

Appears in 2.3.0

Description

Sandboxing configuration

CONFIG SANDBOXING ACTIVATE

Level

contentfilter, modify

History

Appears in 2.3.0

Description

Copy all clones in real profiles.

Usage

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns



Error code

Example

```
CONFIG SANDBOXING ACTIVATE
CONFIG SANDBOXING ACTIVATE CANCEL
CONFIG SANDBOXING ACTIVATE NEXTBOOT
```

CONFIG SANDBOXING SET

Level

contentfilter,modify

History

Appears in 2.3.0

Description

Set sandboxing configuration.

Usage

[Upload=<0|1>] : Activate contexts and files uploads. Default to 1.
[LevelThreshold=<1-100>] : Score which will determine if a file is malicious, suspicious or clean - 0 [clean] < suspicious < X ≤ malicious ≤ 100
[Port=<object>] : Object port config for every sandboxing servers used. Default to 'https'.
[ConnectionTimeout=<int>] : [milliseconds] Opening connection to server timeout. Valid for Hash, context and upload.
[IdleTimeout=<int>] : [milliseconds] Timeout for inactivity during data transfer.
[HashTimeout=<int>] : [milliseconds] Timeout for response time to hash requests.
[UploadTimeout=<int>] : [milliseconds] Timeout for complete file upload.
[UploadBandwidth=<int>] : [bps] Limit bandwidth size on upload threads.
[CacheSize=<int>] : Midas lib cache size.
[HashRequestMaxCount] : Maximum hashes number during multiple requests. Default to 50.

Returns

Error code

Example

```
CONFIG SANDBOXING SET Upload=1 LevelThreshold=1
```

CONFIG SANDBOXING SHOW

Level

base

History

Appears in 2.3.0

Description

Show sandboxing config

Example

```
CONFIG SANDBOXING SHOW
```




CONFIG SECURE

Level

base

History

Appears in Netasq 6.0.0

Removed in 4.0.0

Description

Secure configuration with usb token configuration

CONFIG SECURE ADD

Level

maintenance,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Removed in 4.0.0

Description

Add configuration file in secure mode

Usage

<filename>

Returns

Error code

Remark

configuration must be loaded first

Example

CONFIG SECURE ADD "/usr/Firewall/ConfigFiles/key"

CONFIG SECURE BACKUP

Level

maintenance

History

Appears in Netasq 6.1.0

Removed in 4.0.0

Description

Create a backup [.na] of Secure Configuration

Usage

[comment=<a description>] [password=<password protection>]

Returns

The backup file

**Remark**

configuration must be loaded before

Example

```
CONFIG SECURE BACKUP comment="backup of usb token key"  
CONFIG SECURE BACKUP password="mypassword"
```

CONFIG SECURE INITIALIZE**Level**

maintenance,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Removed in 4.0.0

Description

Mount usb token (if found), initialize secure conf, generate and update key material on USB token

Returns

Error code

Remark

USB token is required

Example

```
CONFIG SECURE INITIALIZE
```

CONFIG SECURE LIST**Level**

base

History

Appears in Netasq 6.0.0

Removed in 4.0.0 Format Appears in Netasq 9.0.0

Description

List the file that may be added on secure mode

Returns

the list of file (on category) that may be secured

Format

list

Example

```
CONFIG SECURE LIST [network]  
/usr/Firewall/ConfigFiles/network  
/usr/Firewall/ConfigFiles/object  
/usr/Firewall/ConfigFiles/Global/object  
...
```



```
[ha]  
/usr/Firewall/ConfigFiles/highavailability  
...
```

```
[vpn]  
/usr/Firewall/ConfigFiles/key  
...
```

CONFIG SECURE LOAD

Level

maintenance,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Removed in 4.0.0

Description

Load configuration from usb token (if found)

Returns

Error code

Remark

USB token is required

Example

CONFIG SECURE LOAD

CONFIG SECURE REMOVE

Level

maintenance,modify

History

Appears in Netasq 6.0.0

all Appears in Netasq 6.1.0

level changes from other,modify to maintenance,modify in Netasq 9.0.0

Removed in 4.0.0

Description

Remove one or all file(s) from secure configuration mode

Usage

<filename>|all

Returns

Error code

Remark

configuration must be loaded first

Example



```
CONFIG SECURE REMOVE "/usr/Firewall/ConfigFiles/key"  
CONFIG SECURE REMOVE all
```

CONFIG SECURE RESTORE

Level

maintenance,modify

History

Appears in Netasq 6.1.0
Removed in 4.0.0

Description

Restore a backup (.na) of the Secure Configuration on usb token

Usage

[password=<password protection>]

Returns

Error code

Remark

USB token is required (restore is doing on it)

Example

```
CONFIG SECURE RESTORE
```

CONFIG SECURE SHOW

Level

base

History

Appears in Netasq 6.1.0
level changes from other to base in Netasq 9.0.0
Removed in 4.0.0

Description

Show the secured files and information of status

Returns

[Config]
IsLoaded=0|1
NbFile=<number of secure file>
UsbToken=NotInitialize|Initialize|NotFound
AutoSync=<number of minutes between each synchronisation>

[Files]
path of file 1
...
path of file n

Example

```
CONFIG SECURE SHOW  
[Config]
```



IsLoaded=0
UsbToken=NotFound
NbFile=0
AutoSync=0

[Files]

CONFIG SECURE STATE

Level

maintenance

History

Appears in Netasq 6.0.0
level changes from other to maintenance in Netasq 9.0.0
Removed in 4.0.0

Description

Activate or deactivate use of secure mode

Usage

[On|Off]

Returns

The current value (case of no arg) or error code

Remark

if some file are in secure mode and state is off, this file are not loaded Modify level is required to update the state value

Example

CONFIG SECURE STATE
CONFIG SECURE STATE on

CONFIG SECURE SYNC

Level

maintenance,modify

History

Appears in Netasq 6.0.0
auto Appears in Netasq 6.1.0
level changes from other,modify to maintenance,modify in Netasq 9.0.0
Removed in 4.0.0

Description

Synchronize file which are in secure mode (in automatic or manual mode)

Usage

[auto=0|<number of minutes>]

Returns

Error code

Remark



Configuration must be loaded first. To stop automatic mode call with auto=0 The number of minutes must be in [0, 1440[

Example

```
CONFIG SECURE SYNC
CONFIG SECURE SYNC auto=5
```

CONFIG SECURE USBCONF**Level**

maintenance

History

Appears in Netasq 6.0.0
level changes from other to maintenance in Netasq 9.0.0

Description

Activate or deactivate the installation of backup found on usb token

Usage

[On|Off]

Returns

The current value on token 'InstallUsbConf' (case of no arg) or error code

Remark

when backup file are found and install, the state is automatically set to off Modify level is required to update the state value

CONFIG SECURITYINSPECTION**Level**

base,asq

History

Appears in Netasq 9.0.0

CONFIG SECURITYINSPECTION ACTIVATE**Level**

asq,modify

Returns

Error code

History

Appears in Netasq 9.0.0

Description

Flush SecurityInspection configuration



CONFIG SECURITYINSPECTION COMMON

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Commands for global ASQ configuration

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST

Level

base,asq

History

Appears in Netasq 9.0.0

Description

Static address list management

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST ADD

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Add a host entry in the static address list

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude|SynProxyExclude
Name1=<object> [Name2=<object>]

Returns

Error code

Example

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST ADD Type=BlackList Name1=spamer

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST REMOVE

Level

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove a host entry from the static address list

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude|SynProxyExclude
Name1=<object> [Name2=<object>]

**Returns**

Error code

Example

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST REMOVE Type=BlackList Name1=spamer

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST SHOW**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Dump the static address list

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude|SynProxyExclude

Returns

list all members.

Format

list

Example

CONFIG SECURITYINSPECTION COMMON ADDRESSLIST SHOW Type=BlackList

CONFIG SECURITYINSPECTION COMMON ALARM**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Common alarms management

CONFIG SECURITYINSPECTION COMMON ALARM LIST**Level**

base

History

Appears in Netasq 9.0.0

Description

List all available signature contexts, classifications, or alarm categories

Usage

type={context|classification|category}

Returns

List of all available classifications, signature contexts or alarm categories

Format



list

Example

```
CONFIG SECURITYINSPECTION COMMON ALARM LIST type=context
CONFIG SECURITYINSPECTION COMMON ALARM LIST type=category
CONFIG SECURITYINSPECTION COMMON ALARM LIST type=classification
```

CONFIG SECURITYINSPECTION COMMON ALARM NEW

Level

base,asq

History

Appears in Netasq 9.0.0

Description

New alarms management

CONFIG SECURITYINSPECTION COMMON ALARM NEW CONFIG

Level

base,asq

History

Appears in 3.0

Description

List new alarms configuration

Usage

```
index=<securityinspection_index>
[category=<cat_id>] [classification=<classification_id>] [extended=0|1] [start=<int>]
[limit=<int>]
```

Returns

```
protocol=<proto> context=protocol|<asq_context name> id=<alarmid> action=(block|pass)
level=(major|minor|ignore) dump={0|1} new={0|1} origin=(user|profile_template|config_
template|new) [legacy={0|1}] [email=on emailduration=<seconds> emailcount=<int>]
[blacklist=on blduration=<minutes>] msg=<alarm message> [longmsg=<detailed message>]
[modify={0|1}] [sensible={0|1}] category={<empty string>|<cat_id[,cat_id]...>}
classification=<classification_id> [resource=<resource name>] [signatures=<number of
variants>]
```

Format

section_line CACHE_CATEGORY alarms

CONFIG SECURITYINSPECTION COMMON ALARM NEW LIST

Level

base,asq

History

Appears in Netasq 9.0.0

Description

List new alarms

Usage



[context=<ASQ context>]

Returns

context=<asq_context_name> id=<alarmid>

Format

section_line

CONFIG SECURITYINSPECTION COMMON ALARM NEW REMOVE**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove new state for new alarms

Usage

context={all|<ASQ context>} [id=<alarmid>]

Returns

Error code

Example

CONFIG SECURITYINSPECTION COMMON ALARM NEW REMOVE context=http:url:decoded id=48
CONFIG SECURITYINSPECTION COMMON ALARM NEW REMOVE context=all CACHE_CATEGORY
alarms

CONFIG SECURITYINSPECTION COMMON INIT**Level**

asq,modify

History

Appears in Netasq 9.0.0

UseSSE appears in 2.0.0 CustomPatternsMatching has been added in 3.0.0

Description

Configure ASQ init values

Usage

[FilterRuleLimit=<0..MODEL_LIMIT>] [ReservedHostLimit=<0..MODEL_LIMIT>]
[HostLimit=<0..MODEL_LIMIT>] [UserLimit=<0..MODEL_LIMIT>] [LogQueueSize=<0..MODEL_LIMIT>]
[DataTracking=<0|1>] [PatternMatching=<0|1>] [CustomPatternsMatching=<0|1>]
[UseSSE=<0|1>]

Returns

Error code

Example

CONFIG SECURITYINSPECTION COMMON INIT UserLimit=0 DataTracking=1

CONFIG SECURITYINSPECTION COMMON LOGALARM**Level**

asq,modify

**History**

Appears in 3.7.12

Description

Configure log alarm overflow settings

Usage

[BlockOverflow={0|1}] [BlockDrop=<0-100>]

- BlockOverflow : action to apply to the packet if the log is not created (0: PASS, 1: BLOCK)
- BlockDrop: percentage of log queue usage from which Drop action logs are no longer raised to favor Pass action logs
- No argument : show current settings

Returns

Error code

Example

CONFIG SECURITYINSPECTION COMMON LOGALARM BlockOverflow=0 BlockDrop=50

CONFIG SECURITYINSPECTION COMMON LOGFILTER**Level**

asq,modify

History

Appears in 3.7.12

Description

Configure log filter overflow settings

Usage

[BlockOverflow={0|1}] [BlockDrop=<0-100>]

- BlockOverflow : action to apply to the packet if the log is not created (0: PASS, 1: BLOCK)
- BlockDrop: percentage of log queue usage from which Drop action logs are no longer raised to favor Pass action logs
- No argument : show current settings

Returns

Error code

Example

CONFIG SECURITYINSPECTION COMMON LOGFILTER BlockOverflow=1 BlockDrop=30

CONFIG SECURITYINSPECTION COMMON PROBE**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Configuration of probe alarm

CONFIG SECURITYINSPECTION COMMON PROBE ADD**Level**



asq,modify

History

Appears in Netasq 9.0.0

Description

Add a probe

Usage

portproto=<integer/tcp|udp> category={0|1|2|3|4|5} msg=<string> state={0|1}

Returns

Error code

Example

```
CONFIG SECURITYINSPECTION COMMON PROBE ADD portproto=1214/tcp category=4  
msg="kazaa" state=1
```

CONFIG SECURITYINSPECTION COMMON PROBE MODIFY**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Modify a probe

Usage

portproto=<integer/tcp|udp> category={0|1|2|3|4|5} msg=<string> state={0|1}

Returns

Error code

Example

```
CONFIG SECURITYINSPECTION COMMON PROBE MODIFY portproto=1214/tcp
```

CONFIG SECURITYINSPECTION COMMON PROBE REMOVE**Level**

asq,modify

History

Appears in Netasq 9.0.0

Description

Remove a probe

Usage

portproto=<integer/tcp|udp>

Returns

Error code

Example

```
CONFIG SECURITYINSPECTION COMMON PROBE REMOVE portproto=1214/tcp
```

**CONFIG SECURITYINSPECTION COMMON PROBE SHOW****Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Dump the probe configuration

Returns

[PortProbe]

port=<port_number> proto={TCP|UDP} category={cat_id} msg=<probe message> state={0|1}

Format

section_line

Example

```
CONFIG SECURITYINSPECTION COMMON PROBE SHOW
port=111 proto=TCP category=2 msg="rpc.statd" state=1
port=137 proto=UDP category=1 msg="NetBios" state=1
port=1214 proto=TCP category=4 msg="Kazaa" state=1
```

CONFIG SECURITYINSPECTION COMMON SHOW**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Dump the ASQ configuration

Usage

[config=<config_index>]

Returns

[Init]

DataTracking=1

FilterRuleLimit=0

ReservedHostLimit=0

HostLimit=0

LogQueueSize=0

UserLimit=0

PatternMatching=1

[Stateful]

InspectMode=None, Ips, Ids, TptIds, Fw

Reload=1

ReloadNAT=0

IncomingConfig=00

OutgoingConfig=01

Verbose=0

VerboseType=Host, User, Connection, Plugin, AlarmBlock, AlarmPacket, Nat, Filter, Conf



NewPatternConf=block,major,dump
HostProperties=1

Remark

if config is not specified, the command dump the configuration for the default profile

Example

CONFIG SECURITYINSPECTION COMMON SHOW

CONFIG SECURITYINSPECTION COMMON STATEFUL**Level**

asq,modify

History

Appears in Netasq 9.0.0 HostProperties appears in 3.0.0 HostPropertiesOnFailPolicy

Description

Configure ASQ stateful settings

Usage

```
[Reload={0|1}] [NATReload={0|1}] [IncomingConfig=<0...9>] [OutgoingConfig=<0...9>]  
[StatelessLog={0|1}] [Verbose={0|1}]  
[VerboseType=All,Host,User,Connection,Plugin,AlarmBlock,AlarmPass,AlarmPacket,Nat,Filter,Bri  
dge,Packet,Conf,Script,Pof,Qos,NatPool,Dcerpc,Partial,Netsend,ConnectionDrop,Dynroute]  
[NewPatternConf={high|medium|low|internet}|[(pass|block),(major|minor|ignore)[,dump]]|""]  
[HostProperties={0|1}] [HostPropertiesOnFailPolicy={pass|block}]
```

Returns

Error code

Example

CONFIG SECURITYINSPECTION COMMON STATEFUL MTULimit=1492

CONFIG SECURITYINSPECTION CONFIG**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Command to configure ASQ

CONFIG SECURITYINSPECTION CONFIG ALARM**Level**

base,asq

History

Appears in Netasq 9.0.0

Description

Per configuration alarms configuration

**CONFIG SECURITYINSPECTION CONFIG ALARM LIST****Level**

base,asq

History

Appears in Netasq 9.0.0

context appears in Netasq 9.1.0

Added extended parameter and added tokens longmsg and signatures in response in Netasq 9.1.0

id appears in Netasq 9.1.0

Description

Per configuration alarm listing

Remark

if extended=0 or not specified, the command will not show the longmsg and signatures tokens

Usage

```
index=<securityinspection_index>  
[category=<cat_id>] [context=<context_id>] [classification=<classification_id>] [id=<id>]  
[extended=0|1]  
[start=<int>] [limit=<int>] [dir=<ASC|DESC>] [search=<pattern>] [searchfield=<token>]  
[sort=<token>] [refresh=<0|1>]
```

Returns

```
protocol=<proto> context=protocol|<asq_context name> id=<alarmid> action={block|pass}  
level={major|minor|ignore} dump={0|1} new={0|1} origin={user|profile_template|config_  
template|new} [legacy={0|1}] [email=on emailduration=<seconds> emailcount=<int>]  
[blacklist=on blduration=<minutes>] msg=<alarm message> [longmsg=<detailed message>]  
[modify={0|1}] [sensible={0|1}] category={<empty string>|<cat_id[,cat_id]...>}  
classification=<classification_id> [resource=<resource name>] [signatures=<number of  
variants>]
```

Format

section_line

Example

```
config securityinspection config alarm list index=1
```

```
[Alarm]
```

```
protocol=http context=protocol id=53 action=block level=major dump=0 new=0 origin=profile_  
template msg="Invalid HTTP protocol" modify=1 sensible=1
```

```
protocol=http context=http:client id=28 action=block level=minor dump=0 new=0  
origin=config_template msg="Apache: chunked encoding vulnerability" modify=1 sensible=0  
legacy=1 category="0,3" classification=1 resource="apache" CACHE_CATEGORY alarms
```

CONFIG SECURITYINSPECTION CONFIG ALARM TEMPLATE**Level**

asq,modify

Returns

Error code

History

Appears in Netasq 9.0.0

**Usage**

index=<securityinspection_index> [template={high|medium|low|internet}] [reset=0|1]

Description

Set the alarm template and remove overloaded alarms in profiles referenced by the configuration

Remark

activate is not required (the command checks that no changes are pending)
if template is not specified, the command apply the internet template to the specified config
if reset=0 or not specified, the command will not reset alarms already user defined

Example

```
CONFIG SECURITYINSPECTION CONFIG ALARM TEMPLATE index=1
CONFIG SECURITYINSPECTION CONFIG ALARM TEMPLATE index=1 template=internet
CONFIG SECURITYINSPECTION CONFIG ALARM TEMPLATE index=1 template=high reset=1 CACHE_
CATEGORY alarms
```

CONFIG SECURITYINSPECTION CONFIG COPY**Level**

asq,modify

Returns

Error code

History

Appears in Netasq 9.0.0

Usage

index=<securityinspection_index> to=<1-10>

Description

Configuration copy

CONFIG SECURITYINSPECTION CONFIG DEFAULT**Level**

asq,modify

Returns

Error code

History

Appears in Netasq 9.0.0

Usage

index=<securityinspection_index>

Description

Set securityinspection configuration back to default settings

CONFIG SECURITYINSPECTION CONFIG LIST**Level**

base,asq

**Returns**

Error code

History

Appears in Netasq 9.0.0

Usage

[index=<securityinspection_index>]

Description

Display name and last modification time. If index is omitted, display all Security Inspection profiles

CONFIG SECURITYINSPECTION CONFIG PROTOCOL**Level**

asq,modify

Returns

Error code

History

Appears in Netasq 9.0.0

Usage

index=<securityinspection_index> [allprotocol=<profile_index>|<protocol>=<profile_index>]

Description

Attribute protocol profile(s)

CONFIG SECURITYINSPECTION CONFIG SHOW**Level**

base,asq

Returns

Error code

History

Appears in Netasq 9.0.0

Usage

index=<securityinspection_index>

Description

Display configuration

CONFIG SECURITYINSPECTION CONFIG UPDATE**Level**

asq,modify

Returns

Error code

Usage

index=<securityinspection_index> [name=<string>] [comment=<string>]

**History**

Appears in Netasq 9.0.0

Description

Rename configuration

CONFIG SLOT**Level**

base

Description

Slot management commands

CONFIG SLOT ACTIVATE**Level**

filter,vpn,modify

History

type Appears in Netasq 6.0.0

config Appears in Netasq 6.0.0

nat and url types disappear in Netasq 9.0.0

level changes from base,modify to filter,vpn,modify in Netasq 9.0.0

Description

Activate a slot

Usage

type={filter|vpn} slot=<slotnumber> [global={0|1}]

Returns

Error code

Remark

Additional level flags may be needed (filter, vpn, globalfilter) according to the slot type

Example

CONFIG SLOT ACTIVATE type=filter slot=03

CONFIG SLOT COPY**Level**

filter,vpn,modify

History

Appears in Netasq 9.0.0 CACHE_CATEGORY filter,ipsec_pgateway,ipsec_pmobile CACHE_CATEGORY_CLONE filter,ipsec_pgateway,ipsec_pmobile

Description

Copy a slot

Usage



type={filter|vpn} slot=<slotnumber> [global={0|1}] to=<slotnumber>

Returns

Error code

Example

CONFIG SLOT COPY type=filter global=0 slot=1 to=7

CONFIG SLOT DEFAULT

Level

filter,vpn,modify

History

Appears in Netasq 9.0.0 CACHE_CATEGORY filter,ipsec_pgateway,ipsec_pmobile CACHE_CATEGORY_CLONE filter,ipsec_pgateway,ipsec_pmobile

Description

Replace a slot by its default value

Usage

type={filter|vpn} [global={0|1}] slot=<slotnumber>

Returns

Error code

Example

CONFIG SLOT DEFAULT type=filter slot=7

CONFIG SLOT DOWNLOAD

Level

filter_read

History

type Appears in Netasq 6.0.0
config Appears in Netasq 6.0.0
FORMAT Appears in Netasq 9.0.0
type disappears in Netasq 9.0.0: can only download a filter slot
level changes from base to filter_read in Netasq 9.0.0

Description

Download a filter slot file

Usage

slot=<slotnumber> [global={0|1}]

Returns

the file to download

Remark

Additional level flags may be needed {filter, globalfilter} according to the slot type

Format

raw

**Example**

```
CONFIG SLOT DOWNLOAD slot=02
```

CONFIG SLOT LIST**Level**

base

History

type Appears in Netasq 6.0.0

nat and url types disappear in Netasq 9.0.0

Description

List slot content

Usage

```
type={filter|vpn} [global={0|1}]
```

Returns

id : Slot identifier

name : Slot name

proptime : Slot activation time

progdays : Slot activation days (day number)

lastmod : Date of last modification

[Global]

active=active slot number

sync= active slot sync with conf?

[Slot number]

name=name of slot

lastmod=last modified date

Remark

Additional level flags may be needed (filter, vpn, globalfilter) according to the slot type

Example

```
CONFIG SLOT LIST type=filter
101 code=00a01000 msg="Begin"
[Global]
active=10
sync=1
[01]
name="block all"
lastmod="2003-03-31 14:47:09"
[08]
name="trend"
lastmod="2004-02-19 15:15:07"
[09]
name="log all"
lastmod="2004-01-13 16:51:44"
[10]
name="pass all"
lastmod="2003-03-31 14:47:09"
100 code=00a00100 msg="Ok"
```



CONFIG SLOT REMOVE

Level

filter,vpn,modify

History

type Appears in Netasq 6.0.0

config Appears in Netasq 6.0.0

nat and url types disappear in Netasq 9.0.0

level changes from base,modify to filter,vpn,modify in Netasq 9.0.0

CACHE_CATEGORY filter,ipsec_pgateway,ipsec_pmobile CACHE_CATEGORY_CLONE filter,ipsec_pgateway,ipsec_pmobile

Description

Remove a slot

Usage

type={filter|vpn} slot=<slotnumber>

Returns

Error code

Example

CONFIG SLOT REMOVE filter 04

CONFIG SLOT STATE

Level

filter_read,vpn_read

History

type Appears in Netasq 6.0.0

nat and url types disappear in Netasq 9.0.0

level changes from base to filter_read,vpn_read in Netasq 9.0.0

Description

Show slot status

Usage

type={filter|vpn} [global={0|1}]

Returns

active : Active slot number

sync : Synchronization flag

[Result] active=<number of active slot> sync={0|1}

Remark

Additional level flags may be needed (filter, vpn, globalfilter) according to the slot type

Example

CONFIG SLOT STATE type=filter

101

[Result]

active=10

sync=1



CONFIG SLOT UPDATE

Level

filter,vpn,modify

History

Appears in Netasq 9.0.0

Description

Change the information attached to a slot

Usage

type={filter|vpn} slot=<slotnumber> [global={0|1}] [name=<string>] [comment=<string>]

Returns

Error code

Example

CONFIG SLOT UPDATE type=filter slot=7 global=0 name="block all clone" comment="absolute security"

CONFIG SLOT UPLOAD

Level

filter,modify CACHE_CATEGORY filter CACHE_CATEGORY_CLONE filter

History

type disappears in Netasq 9.0.0: can only download a filter slot
level changes from base,modify to filter,modify in Netasq 9.0.0

Description

Upload a filter slot file

Usage

slot=<slotnumber> name=<name> [global={0|1}] [comment=<comment>]

Remark

Additional level flags may be needed (filter, globalfilter) according to the slot type

Example

CONFIG SLOT UPLOAD slot=02 name="log all"

CONFIG SMCROUTING

Level

base

History

Appears in 2.3.0

Description

Commands related to static multicast routing configuration



CONFIG SMCROUTING ACTIVATE

Level

network,modify

History

Appears in 2.3.0

Description

Activate multicast routing configuration

Usage

[CANCEL] : changes are discarded

Example

```
CONFIG SMCROUTING ACTIVATE
CONFIG SMCROUTING ACTIVATE CANCEL
```

CONFIG SMCROUTING DEFAULT

Level

network,modify

History

Appears in 2.3.0

Description

Update multicast routing configuration to default configuration

Example

```
CONFIG SMCROUTING DEFAULT
```

CONFIG SMCROUTING ROUTE

Level

base

Description

Command to manage routes

CONFIG SMCROUTING ROUTE ADD

Level

network,modify

History

Appears in 2.3.0

Description

Add a multicast route at a given position. Rule is off by default if pos is not specified, add to the end

Usage



[pos=<digit>] [state=<on|off>] srcif=<interface[,interface,...]> mgroup=<object>
dstif=<interface[,interface,...]> [comment=<comment>]

Example

```
CONFIG SMCROUTING ROUTE ADD pos=1 srcif=dmz1 mgroup=mreceivers dstif=dmz2,dmz3
```

CONFIG SMCROUTING ROUTE IPV6**Level**

base

History

Appears in 2.3.0

Description

Command to manage IPv6 routes

CONFIG SMCROUTING ROUTE IPV6 ADD**Level**

network,modify

History

Appears in 2.3.0

Description

Add an IPv6 multicast route at a given position. Rule is off by default
if pos is not specified, add to the end

Usage

[pos=<digit>] [state=<on|off>] srcif=<interface[,interface,...]> mgroup=<object>
dstif=<interface[,interface,...]> [comment=<comment>]

Example

```
CONFIG SMCROUTING ROUTE IPV6 ADD pos=1 srcif=gre1 mgroup=mreceivers dstif=dmz2,dmz3  
CONFIG SMCROUTING ROUTE IPV6 ADD srcif=dmz1 mgroup=mreceivers dstif=dmz2,dmz3
```

CONFIG SMCROUTING ROUTE IPV6 MOVE**Level**

network,modify

History

Appears in 2.3.0

Description

Move an IPv6 multicast route at a given position

Usage

pos=<digit>
to=<digit>

Example

```
CONFIG SMCROUTING ROUTE IPV6 MOVE pos=1 to=2
```

CONFIG SMCROUTING ROUTE IPV6 REMOVE**Level**

network,modify

**History**

Appears in 2.3.0

Description

Remove an IPv6 multicast route at a given position

Usage

pos=<digit>

Example

```
CONFIG SMCROUTING ROUTE IPV6 REMOVE pos=1
```

CONFIG SMCROUTING ROUTE IPV6 SHOW**Level**

base

History

Appears in 2.3.0

Description

List IPv6 multicast routes

Format

section_line

Example

```
CONFIG SMCROUTING ROUTE IPV6 SHOW
```

CONFIG SMCROUTING ROUTE IPV6 UPDATE**Level**

network,modify

History

Appears in 2.3.0

Description

Update an IPv6 multicast route at a given position

Usage

pos=<digit> [state=<on|off>] [srcif=<interface[,interface,...]>] [mgroup=<object>]
[dstif=<interface[,interface,...]>] [comment=<comment>]

Example

```
CONFIG SMCROUTING ROUTE IPV6 UPDATE pos=1 mgroup=mreceivers dstif=dmz2,dmz3
```

CONFIG SMCROUTING ROUTE MOVE**Level**

network,modify

History

Appears in 2.3.0

Description

Move a multicast route at a given position

**Usage**

pos=<digit>

to=<digit>

Example

CONFIG SMCROUTING ROUTE MOVE pos=1 to=2

CONFIG SMCROUTING ROUTE REMOVE**Level**

network,modify

History

Appears in 2.3.0

Description

Remove a multicast route at a given position

Usage

pos=<digit>

Example

CONFIG SMCROUTING ROUTE REMOVE pos=1

CONFIG SMCROUTING ROUTE SHOW**Level**

base

History

Appears in 2.3.0

Description

List multicast routes

Format

section_line

Example

CONFIG SMCROUTING ROUTE SHOW

CONFIG SMCROUTING ROUTE UPDATE**Level**

network,modify

History

Appears in 2.3.0

Description

Update a multicast route at a given position

Usagepos=<digit> [state=<on|off>] [srcif=<interface[,interface,...]>] [mgroup=<object>]
[dstif=<interface[,interface,...]>] [comment=<comment>]**Example**



CONFIG SMCROUTING ROUTE UPDATE pos=1 srcif=dmz1 mgroup=mreceivers dstif=dmz2,dmz3

CONFIG SMCROUTING SHOW

Level

base

History

Appears in 2.3.0

Description

Display multicast routing configuration

Returns

[Global]

State=1

Example

CONFIG SMCROUTING SHOW

CONFIG SMCROUTING UPDATE

Level

network,modify

History

Appears in 2.3.0

UpcallQueueLimit appears in 3.8.0

Description

Update multicast routing configuration

Usage

[state=<0|1>] : enable or disable multicast routing

[CacheMaxEntries=<int>] : maximum size of the multicast route cache

[CacheLifetime=<int>] : cache entry lifetime in seconds

[UpcallQueueLimit=<int>] : number of packets to bufferize while the daemon answer to a routing upcall query

Example

CONFIG SMCROUTING UPDATE state=0

CONFIG SNMP

Level

base

Description

Command to manage SNMP agent

CONFIG SNMP ACCESS

Level



base

Description

Set acces information to the SNMP agent

CONFIG SNMP ACCESS COMMUNITY**Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Set the community name to use for SNMP V1 and V2c (read only)

Usage

community=<community>

Returns

Error code

Example

CONFIG SNMP community=public

CONFIG SNMP ACCESS USERV3**Level**

log,modify

History

added AES in supported privtype in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Create a snmpV3 user (read only)

Usage

[clear] username=<username> authtype=(MD5|SHA) authpass=<passphrase> [privtype=(AES|DES)] [privpass=<passphrase>]

Returns

Error code

Remark

use clear to erase the current user

if privpass is'nt specify, then passphrase = authpass

privtype and privpass are optional

Example

CONFIG SNMP USERV3 clear

CONFIG SNMP USERV3 username=admin authtype=MD5 authpass=adminadmin privtype=DES

CONFIG SNMP USERV3 username=admin authtype=MD5 authpass=adminadmin privtype=DES
privpass=nimdanimda

CONFIG SNMP USERV3 username=admin authtype=MD5 authpass=adminadmin



CONFIG SNMP ACTIVATE

Level

log,modify

History

CANCEL/NEXTBOOT Appears in Netasq 9.0.0
level changes from other,modify to log,modify in Netasq 9.0.0

Description

Activate SNMP configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

CONFIG SNMP ACTIVATE CONFIG SNMP ACTIVATE cancel

CONFIG SNMP SHOW

Level

base,log_read

History

added V2cState and V3State in Netasq 9.0.0
level log_read added in Netasq 9.0.0

Description

Show SNMP configuration.

Returns

[Config]

State={0|1}

authtrapenable={0|1}

[System]

location=<string>

contact=<email adresse>

[Access]

username=<login>

authtype=SHA

AuthPass=<password>

privtype=des

PrivPass=<password>

Community=<string>

Example

CONFIG SNMP SHOW



CONFIG SNMP STATE

Level

base

Description

Get/set snmpd state.

Usage

[On|Off]

Returns

State={0|1} Error code

Remark

Changing state need Log level

Example

CONFIG SNMP STATE On

CONFIG SNMP SYSTEM

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Set system information (location, name and contact)

Usage

location=<systemlocation> contact=<string> [name=<string>]

Returns

Error code

Example

CONFIG SNMP SYSTEM location=Lille contact=admin@stormshield.eu

CONFIG SNMP SYSTEM location=Lille contact=admin@stormshield.eu name=MyFirewall

CONFIG SNMP TRAP

Level

base

History

Format Appears in Netasq 9.0.0

Description

Configure SNMP trap

Format

section_line



CONFIG SNMP TRAP AUTH

Level

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

If AUTH on, then send trap on authentication failure

Usage

{on | off}

Returns

Error code

Example

CONFIG SNMP TRAP AUTH on

CONFIG SNMP TRAP V1

Level

base

Description

Configure SNMP V1 trap

CONFIG SNMP TRAP V1 ADD

Level

log,modify

History

port became an obj_service on 6.1.1

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Add an host for sending SNMP V1 trap

Usage

host=<obj_host> community=<STRING> port=<obj_service>

Returns

Error code

Example

CONFIG SNMP TRAP host=trapV1 community=public port=162

CONFIG SNMP TRAP V1 MODIFY

Level

log,modify

History

port became an obj_service on 6.1.1

level changes from other,modify to log,modify in Netasq 9.0.0

Description



Modify a configuration for a host

Usage

host=<obj_host> community=<STRING> port=<obj_service>

Returns

Error code

Example

CONFIG SNMP TRAP ipaddr=trapV1 community=public port=162

CONFIG SNMP TRAP V1 REMOVE**Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Remove a destination host for SNMP v1 trap

Usage

host=obj_host

Returns

Error code

Example

CONFIG SNMP TRAP V1 REMOVE host=trapV1

CONFIG SNMP TRAP V1 SHOW**Level**

base,log_read

History

Format Appears in Netasq 9.0.0

level log_read added in Netasq 9.0.0

Description

Show SNMP configuration TRAP V1.

Returns

Host=<object> Port=<integer> Community=<string>

Format

section_line

CONFIG SNMP TRAP V2**Level**

base

Description

Configure SNMP V2 trap

**CONFIG SNMP TRAP V2 ADD****Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Specify the host and the port to send trap in V2

Usage

host=<obj_host> community=<STRING> port=<int>

Returns

Error code

Example

CONFIG SNMP TRAP ipaddr=trapV2 community=public port=162

CONFIG SNMP TRAP V2 MODIFY**Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Modify a configuration for a host

Usage

host=<obj_host> community=<STRING> port=<int>

Returns

Error code

Example

CONFIG SNMP TRAP ipaddr=trapV2 community=public port=162

CONFIG SNMP TRAP V2 REMOVE**Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Remove a destination host for SNMP V2 trap

Usage

host=obj_host

Returns

Error code

CONFIG SNMP TRAP V2 SHOW**Level**



base,log_read

History

Format Appears in Netasq 9.0.0

level log_read added in Netasq 9.0.0

Description

Show SNMP configuration TRAP V2.

Returns

Host=<object> Port=<integer> Community=<string>

Format

section_line

Example

Host=F-500 Port=162 Community=public

Host=F-501 Port=162 Community=public

Host=F-502 Port=162 Community=public

CONFIG SNMP TRAP V3**Level**

base

Description

Configure SNMP V3 trap

CONFIG SNMP TRAP V3 ADD**Level**

log,modify

History

added AES in supported privtype in Netasq 7.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

engineID becomes optional in Netasq 9.1.0

Description

Configure SNMP trap in V3

Usage

host=<obj_host> port=<INTEGER> SecurityName=<STRING> [engineID=<ENGINE_ID>]

SecurityLevel={noAuthNoPriv|authNoPriv|authPriv} [authtype=<SHA|MD5>]

[AuthPass=<STRING>] [privtype={AES|DES}] [PrivPass=<STRING>]

Returns

Error code

Example

CONFIG SNMP TRAP V3 ADD host=trapV3 port=162 AuthMethod=SHA AuthPass=passpass

SecurityName=James engineID=0x0102030405 SecurityLevel=authNoPriv

PrivMethod=DES PrivPass=passpass

CONFIG SNMP TRAP V3 MODIFY**Level**

log,modify

**History**

added AES in supported privtype in Netasq 7.0.0
level changes from other,modify to log,modify in Netasq 9.0.0
engineID becomes optional in Netasq 9.1.0

Description

Modify a configuration for a host

Usage

host=<obj_host> port=<INTEGER> SecurityName=<STRING> [engineID=<ENGINE_ID>]
SecurityLevel={noAuthNoPriv|authNoPriv|authPriv} [authtype={SHA|MD5}]
[AuthPass=<STRING>] [privtype={AES|DES}] [PrivPass=<STRING>]

Returns

Error code

Example

CONFIG SNMP TRAP V3 ADD host=trapV3 port=162 AuthMethod=SHA AuthPass=passpass
SecurityName=James engineID=0x0102030405 SecurityLevel=authNoPriv
PrivMethod=DES PrivPass=passpass

CONFIG SNMP TRAP V3 REMOVE**Level**

log,modify

History

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Remove a destination host for SNMP V3 trap

Usage

host=obj_host

Returns

Error code

Example

CONFIG SNMP TRAP V3 REMOVE host=trapV3

CONFIG SNMP TRAP V3 SHOW**Level**

base,log_read

History

Format Appears in Netasq 9.0.0
level log_read added in Netasq 9.0.0

Description

Show SNMP configuration TRAP V3.

Returns

Host=<object> Port=<int> authtype=SHA AuthPass=<password> SecurityName=<login>
EngineID=<engineID> SecurityLevel=noAuthNoPriv privtype=DES PrivPass=<password>

Format



section_line

Example

Host=F-500 Port=162 authtype=SHA AuthPass=adminadmin SecurityName=admin
EngineID=0x0102030405 SecurityLevel=noAuthNoPriv privtype=DES PrivPass=adminadmin

Host=F-501 Port=162 authtype=SHA AuthPass=adminadmin SecurityName=admin
EngineID=0x0102030405 SecurityLevel=noAuthNoPriv privtype=DES PrivPass=adminadmin

Host=F-502 Port=162 authtype=SHA AuthPass=adminadmin SecurityName=admin
EngineID=0x0102030405 SecurityLevel=noAuthNoPriv privtype=DES PrivPass=adminadmin

CONFIG SNMP VERSION**Level**

log,modify

History

Appears in Netasq 9.0.0

Description

Define the snmp version protocol to use

Usage

[v2cstate=0|1] [v3state=0|1]

Returns

Error code

Example

CONFIG SNMP STATE v2cstate=0 v3state=1

CONFIG SSH**Level**

base

Description

SSH access configuration

CONFIG SSH ACTIVATE**Level**

admin,modify

History

Appears in Netasq 6.0.0

Moved from CONFIG.CONSOLE.SSH in 4.2.0

Description

Activates console configuration

Usage



[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

```
CONFIG SSH ACTIVATE  
CONFIG SSH ACTIVATE NEXTBOOT
```

CONFIG SSH GETHOSTKEY

Level

base

History

Format Appears in Netasq 9.0.0
Moved from CONFIG.CONSOLE.GETHOSTKEY in 4.2.0

Description

Get firewall public key

Returns

the ssh firewall public key

Format

raw

Example

```
CONFIG SSH GETHOSTKEY
```

CONFIG SSH GETKEY

Level

admin

History

Format Appears in Netasq 9.0.0
Moved from CONFIG.CONSOLE.GETKEY in 4.2.0

Description

Get admin account private key

Returns

The ssh private key of admin

Format

raw

Example

```
CONFIG SSH GETKEY
```



CONFIG SSH REGENHOSTKEY

Level

admin,modify

History

Appears in 4.2.0

Description

Force regeneration of sshd host keys

Returns

Error code

Remark

This could affects the people/scripts accessing the firewall through ssh since the previous host key won't be used anymore.

CONFIG SSH SHOW

Level

base

History

Appears in 4.3.0

Description

Display SSH configuration

Returns

State=<state>

Userpass=<userpass>

Port=<port>

CLIShell=<clishell>

Example

CONFIG SSH SHOW

CONFIG SSH UPDATE

Level

admin

History

Userpass Appears in Netasq 6.0.0

Password deprecated in Netasq 6.0.0

Port Appears in Netasq 6.1.0

command was moved from CONFIG CONSOLE SSH to CONFIG SSH UPDATE in 4.2.0

CLIShell Appears in 4.3.0

LogAdmin Appears in 4.3.0

Description

Enable/disable SSH access

**Usage**

State=[0|1] Userpass=[0|1] Port=[object] CLIShell=[0|1] LogAdmin=[0|1]

Returns

Error code (if parameter) or :

State= : state of service

Userpass= : specify if password mode is on/off

Port= : port used by service

CLIShell= : specify if remote user login shell is nsrpc (1) or shell (0)

LogAdmin= : specify wether admin authentications should be logged to l_auth (1) or not (0)

Remark

Admin and Modify levels are required to update configuration

Example

CONFIG SSH UPDATE State=1 Userpass=1 Port=gopher

CONFIG SSLFILTERING

Level

base,contentfilter

History

Appears in Netasq 9.0.0

Description

URL rules and profile files management

CONFIG SSLFILTERING ACTIVATE

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Activate : Copy all clones in real profiles.

Usage

[CANCEL]

- no argument: changes are activated immediately;

- CANCEL: changes are discarded.

Returns

Error code

Example

CONFIG SSLFILTERING ACTIVATE

CONFIG SSLFILTERING ACTIVATE CANCEL



CONFIG SSLFILTERING COPY

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Copy profile X to Y

Usage

index=<profile_idx> to=<profile_idx>

Returns

Error code

Example

CONFIG SSLFILTERING COPY index=2 to=3

CONFIG SSLFILTERING DEFAULT

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Set profile X with the default rules

Usage

index=<profile_idx>

Returns

Error code

Example

CONFIG SSLFILTERING DEFAULT index=9

CONFIG SSLFILTERING LIST

Level

base

History

Appears in Netasq 9.0.0

Description

List the specified profile of SSL filtering rules. If profile is not specified, then list all the profiles.

Usage

[index=<profile_idx>]

Returns



Error code

Example

```
[index]  
name=<policy_name>  
lastmod=<last modified date>  
comment=blabla
```

CONFIG SSLFILTERING RULE**Level**

base,contentfilter

History

Appears in Netasq 9.0.0

Description

Manage sslfiltering rules of a profile

CONFIG SSLFILTERING RULE INSERT**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Insert new rule at given line or Insert at the end if no ruleid is defined.

Usage

```
index=<profile_idx> [ruleid=<digit>] state=on|off action=decrypt|nodecrypt|block  
cngroup=<cngroup object|cncategorygroup object> [comment=<string>]  
Insert at the end if no ruleid is defined.
```

state : enable or disable the rule

index : profile number

ruleid : rule line number

action : action to apply

cngroup : group name to use for filter

comment : comment for the rule

Example

```
CONFIG SSLFILTERING RULE INSERT index=0 ruleid=3 action=block cngroup=bank  
comment="block bank web site"
```

CONFIG SSLFILTERING RULE MOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Move rule from a line to another line

**Usage**

index=<profile_idx> ruleid=<digit> to=<digit>

index : profile number

ruleid : rule line number to move from

to : rule line number to move to

Example

```
CONFIG SSLFILTERING RULE MOVE index=0 ruleid=2 to=3
```

CONFIG SSLFILTERING RULE REMOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Remove a rule.

Usage

config=<profile_idx>

index : profile number

ruleid : {all|<digit>}

Example

```
CONFIG SSLFILTERING RULE REMOVE index=0 ruleid=3
```

CONFIG SSLFILTERING RULE SHOW**Level**

contentfilter

History

Appears in Netasq 9.0.0

Description

Show all rules of a profile.

Usage

index=<profile_idx>

Returns

ruleid=<nb> invalid=0|1 state=on|off action=decrypt|nodecrypt|block cngroup=<name>

comment="bla bla bla ..."

Format

section_line

Example

```
CONFIG SSLFILTERING RULE SHOW=9
```

```
101 code=00a01000 msg="Begin" format="section_line"
```

```
ruleid=1 invalid=0 state=on action=nodecrypt cngroup=bank comment="bla bla bla ..."
```

```
100 code=00a01000 msg="Ok"
```



CONFIG SSLFILTERING RULE UPDATE

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Modify a rule in configuration file at given line.

Usage

index=<profile_idx> ruleid=<digit> [state=on|off] [action=decrypt|nodecrypt|block]
[cngroup=<cngroup object|cncategorygroup object>] [comment=<string>]
state : enable or disable the rule
index : profile number
ruleid : rule line number
action : action to apply
cngroup : group name to use for filter
comment : comment for the rule

Example

CONFIG SSLFILTERING RULE UPDATE index=0 ruleid=3 action=block cngroup=bank
comment="block bank web site"

CONFIG SSLFILTERING UPDATE

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Change name and comment of profile X

Usage

index=<profile_idx> [name=<profile name>] [comment=<profile description>]

Returns

Error code

Example

CONFIG SSLFILTERING UPDATE index=9 name="pass all" comment="Just a pass all"

CONFIG STATUS

Level

base

History

Appears in 6.3.0

Description



Commands to check configuration integrity

CONFIG STATUS CHECK

Level

admin

History

Appears in 6.3.0

FORMAT Appears in Netasq 9.0.0

Description

Check if the configuration has been modified since last validation

Usage

[password=<password>]

Returns

The list of modified files:

[Files]

file1

file2

....

Example

CONFIG STATUS CHECK

Format

list

CONFIG STATUS REMOVE

Level

admin,modify

History

Appears in 6.3.0

Description

Uninstall integrity configuration

Returns

Error code

Example

CONFIG STATUS REMOVE

CONFIG STATUS SHOW

Level

admin

History



Appears in 6.3.0

Format Appears in Netasq 9.0.0

Description

Show all monitored configuration files

Returns

The list of checked files

[Files]

file1=hash1

file2=hash2

...

Format

list

Example

CONFIG STATUS SHOW

CONFIG STATUS VALIDATE

Level

admin, modify

History

Appears in 6.3.0

Description

Validate actual configuration

Usage

[password=<password>]

Returns

Error code

Example

CONFIG STATUS CHECK

CONFIG SYSEVENT

Level

base

History

Appears in Netasq 6.0.0

Description

Configuration of system events (level and action).

CONFIG SYSEVENT ACTIVATE

Level

log,modify

**History**

Appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Activate alarm configuration.

Returns

Error code

Example

CONFIG SYSEVENT ACTIVATE

CONFIG SYSEVENT DEFAULT**Level**

log,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

Description

Restore default settings for system events.

Returns

Error code

Example

CONFIG SYSEVENT DEFAULT

CONFIG SYSEVENT MODIFY**Level**

log,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to log,modify in Netasq 9.0.0

email and blacklist appear in Netasq 9.1.0

Description

Configure level and reactions for firewall events (ex : Firewall startup).

Usage

```
id=<INTEGER> [level={minor|major|ignore|system}]  
[email=off | email=on emailduration=<seconds> emailcount=<int>]  
[blacklist=off | blacklist=on blduration=<minutes>]
```

Returns

Error code

Example

CONFIG SYSEVENT EVENT id=1 level=major



CONFIG SYSEVENT SHOW

Level

base

History

Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0

id appears in Netasq 9.1.0

Description

Dump the system event configuration.

Usage

[id=<integer>]

Returns

[EventLevel]

id=<integer> Level={minor|major|system|ignore} msg="string" [email=on
emailduration=<seconds> emailcount=<int>] [blacklist=on blduration=<minutes>]

Format

section_line

Example

CONFIG SYSEVENT SHOW

CONFIG TELEMETRY

Level

base

History

Appears in 4.0.0

Description

Commands related to telemetry configuration

CONFIG TELEMETRY ACTIVATE

Level

admin,modify

History

Appears in 4.0.0

Description

Activate telemetry configuration

Usage

[CANCEL] : changes are discarded

Example



CONFIG TELEMETRY ACTIVATE
CONFIG TELEMETRY ACTIVATE CANCEL

CONFIG TELEMETRY SHOW

Level

base

History

Appears in 4.0.0

Description

Display the telemetry configuration

Returns

[Global]

State=1

Example

CONFIG TELEMETRY SHOW

CONFIG TELEMETRY UPDATE

Level

admin,modify

History

Appears in 4.0.0

Description

Update the telemetry configuration

Usage

[state=<on|off>] : enable or disable the telemetry

Example

CONFIG TELEMETRY UPDATE state=on

CONFIG UPLOAD

Level

base,modify

History

userauth.00 appears in 3.5.0
userauth.01 appears in 3.5.0
userauth.02 appears in 3.5.0
userauth.03 appears in 3.5.0
userauth.04 appears in 3.5.0
userauth.05 appears in 3.5.0
userauth.06 appears in 3.5.0
userauth.07 appears in 3.5.0
userauth.08 appears in 3.5.0



userauth.09 appears in 3.5.0
sshd-banner appears in 3.5.0

Description

Upload a file or reset a file (reset not available for all files)

Usage

```
<custom.css | index-logo.jpg | httpproxy_blockpage0 | httpproxy_blockpage1 | httpproxy_blockpage2 | httpproxy_blockpage3 | algorithm | vpntunnel | ldapmaps | app_user_req | rej_user_req | app_cert_req | rej_cert_req | keytab | wpad.dat | custom_disclaimer.html | disclaimer.pdf | sslvpn_connect.bat | sslvpn_disconnect.bat | bird.conf | bird6.conf | userauth.00 | userauth.01 | userauth.02 | userauth.03 | userauth.04 | userauth.05 | userauth.06 | userauth.07 | userauth.08 | userauth.09 | sshd-banner>  
RESET <index-logo.jpg | custom.css | custom_disclaimer.html | disclaimer.pdf | custom_login_disclaimer | sslvpn_connect.bat | sslvpn_disconnect.bat | bird.conf | bird6.conf | userauth.00 | userauth.01 | userauth.02 | userauth.03 | userauth.04 | userauth.05 | userauth.06 | userauth.07 | userauth.08 | userauth.09>
```

Returns

Error code

Remark

Additional rights may be needed to write files:

app_user_req, rej_user_req, ldapmaps, keytab: user

app_cert_req, rej_cert_req: pki

custom_disclaimer.html, disclaimer.pdf, custom_login_disclaimer, index-logo.jpg, custom.css: admin

wpad.dat, httpproxy_blockpage0, httpproxy_blockpage1, httpproxy_blockpage2, httpproxy_blockpage3: contentfilter

bird.conf, bird6.conf: network

Example

CONFIG UPLOAD custom_disclaimer.html CONFIG UPLOAD RESET index-logo.jpg

CONFIG URLD

Level

base

History

Appears in 4.1.0

Description

Commands related to URLd configuration

CONFIG URLD ACTIVATE

Level

admin, modify

History

Appears in 4.1.0

Description



Activate URLd configuration. Restarts urld.

Usage

[CANCEL] : changes are discarded

Example

```
CONFIG URLD ACTIVATE
CONFIG URLD ACTIVATE CANCEL
```

CONFIG URLD AUTORELOAD

Level

admin,modify

History

Appears in 4.1.0

Description

Update URLd failure detection and reload configuration

Usage

[BruteforceState=<on|off>] : enable or disable automatic reload
[TriesTime=<value>] : Interval of time (in seconds) between which automatic reloads are counted
[NbAttempt=<value>] : Maximum numbers of reloads allowed in the interval
[RestTime=<value>] : Time to wait after all reloads have been consumed
[FailedClassifies=<value>] : Number of consecutive failed classifies that trigger an auto reload

Example

```
CONFIG URLD AUTORELOAD BruteforceState=on TriesTime=300 NbAttempt=5 RestTime=900
FailedClassifies=10
```

CONFIG URLD SHOW

Level

base

History

Appears in 4.1.0

Description

Display URLd configuration

Usage

[useclone]<on|off> : show the last activated configuration (off, default value)

Returns

```
[AutoReloads]
BruteforceState=1
TriesTime=300
NbAttempt=5
RestTime=10
FailedClassifies=100
[Config]
BindAddr=foobar
```

**Example**

```
CONFIG URLD SHOW
```

CONFIG URLD UPDATE**Level**

admin,modify

History

appears in Stormshield 4.8.0

Description

Update the urld config parameters

Usage

```
bindaddr=<Firewall host or ip>  
curltimeout=<timeout in seconds>
```

Returns

When setting a base: Error code.

Remark

Bindaddr param set the interface used to send url classification request.

Example

```
CONFIG URLD UPDATE bindaddr=foobar  
CONFIG URLD UPDATE bindaddr=""  
CONFIG URLD UPDATE curltimeout=2
```

CONFIG URLFILTERING**Level**

base,contentfilter

History

Appears in Netasq 9.0.0

Description

URL rules and profile files management

CONFIG URLFILTERING ACTIVATE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Activate : Copy all clones in real profiles.

Usage



[CANCEL]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded.

Returns

Error code

Example

```
CONFIG URLFILTERING ACTIVATE
CONFIG URLFILTERING ACTIVATE CANCEL
```

CONFIG URLFILTERING BLOCKPAGE

Level

base,contentfilter

History

Appears in Netasq 9.1.0

Description

URL block pages configuration

CONFIG URLFILTERING BLOCKPAGE DEFAULT

Level

contentfilter,modify

History

Appears in Netasq 9.1.0

Description

Reset block pages to default

Usage

index=<blockpage idx>

Example

```
CONFIG URLFILTERING BLOCKPAGE RESET index=2
```

Returns

Error code

CONFIG URLFILTERING BLOCKPAGE LIST

Level

contentfilter,base

History

Appears in Netasq 9.1.0

Description

List available block pages

Example

```
CONFIG URLFILTERING BLOCKPAGE UPDATE index=2 name=blockpage1
```

Returns



Error code

CONFIG URLFILTERING BLOCKPAGE UPDATE

Level

contentfilter,modify

History

Appears in Netasq 9.1.0

Description

Update information about block pages

Usage

index=<profile_idx> [name=<profile name>] [comment=<profile description>]

Example

CONFIG URLFILTERING BLOCKPAGE UPDATE index=2 name=blockpage1

Returns

Error code

CONFIG URLFILTERING COPY

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Copy profile X to Y

Usage

index=<profile_idx> to=<profile_idx>

Returns

Error code

Example

CONFIG URLFILTERING COPY index=2 to=3

CONFIG URLFILTERING DEFAULT

Level

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Set profile X with the default rules

Usage

index=<profile_idx>

**Returns**

Error code

Example

CONFIG URLFILTERING DEFAULT index=9

CONFIG URLFILTERING LIST**Level**

base

History

Appears in Netasq 9.0.0

Description

List the specified profile of URL filtering rules. If profile is not specified, then list all the profiles.

Usage

[index=<profile_idx>]

Returns

Error code

Example

[index] name=<policy_name>
comment=blabla
lastmod=<last modified date>

CONFIG URLFILTERING RULE**Level**

base,contentfilter

History

Appears in Netasq 9.0.0

Description

Manage urlfiltering rules of a profile

CONFIG URLFILTERING RULE INSERT**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Insert new rule at given line or Insert at the end if no ruleid is defined.

Usage

index=<profile_idx> [ruleid=<digit>] state=on|off
action=pass|block|blockpage0|blockpage1|blockpage2|blockpage3 urlgroup=<urlgroup
object|urlcategory group object> [comment=<string>]
state : enable or disable the rule



index : profile number
ruleid : rule line number
action : action to apply
urlgroup : group name to use for filter
comment : comment for the rule

Example

```
CONFIG URLFILTERING RULE INSERT index=0 ruleid=3 action=block urlgroup=ecommerce  
comment="block ecommerce"
```

CONFIG URLFILTERING RULE MOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Move rule from a line to another line

Usage

```
index=<profile_idx> ruleid=<digit> to=<digit>  
index : profile number  
ruleid : rule line number to move from  
to : rule line number to move to
```

Example

```
CONFIG URLFILTERING RULE MOVE index=0 ruleid=2 to=3
```

CONFIG URLFILTERING RULE REMOVE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Remove a rule at a given line.

Usage

```
index=<profile_idx> ruleid=all|<digit>  
index : profile number  
ruleid : all or rule line number
```

Example

```
CONFIG URLFILTERING RULE REMOVE index=0 ruleid=3
```

CONFIG URLFILTERING RULE SHOW**Level**

contentfilter

History

Appears in Netasq 9.0.0

**Description**

Show all rules of a profile.

Usage

index=<profile_idx>

Returns

ruleid=<nb> invalid=0|1 state=on|off action=pass|block|blockpage urlgroup=<name>
comment="bla bla bla ..."

Format

section_line

Example

```
CONFIG URLFILTERING RULE SHOW=9
101 code=00a01000 msg="Begin" format="section_line"
ruleid=1 invalid=0 state=on action=pass urlgroup=group comment="bla bla bla ..."
100 code=00a01000 msg="Ok"
```

CONFIG URLFILTERING RULE UPDATE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Modify a rule in configuration file at given line.

Usage

index=<profile_idx> ruleid=<digit> [state=on|off]
[action=pass|block|blockpage0|blockpage1|blockpage2|blockpage3] [urlgroup=<urlgroup
object|urlcategorygroup object>] [comment=<string>]
state : enable or disable the rule
index : profile number
ruleid : rule line number
action : action to apply
urlgroup : group name to use for filter
comment : comment for the rule

Example

```
CONFIG URLFILTERING RULE UPDATE index=0 ruleid=3 action=block urlgroup=ecommerce
comment="block ecommerce"
```

CONFIG URLFILTERING UPDATE**Level**

contentfilter,modify

History

Appears in Netasq 9.0.0

Description

Change name and comment of profile X

**Usage**

index=<profile_idx> [name=<profile name>] [comment=<profile description>]

Returns

Error code

Example

CONFIG URLFILTERING UPDATE index=9 name="pass all" comment="Just a pass all"

CONFIG WEBADMIN

Level

base

Description

webadmin related functions.

CONFIG WEBADMIN ACCESS

Level

base

Description

access related functions.

CONFIG WEBADMIN ACCESS ADD

Level

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Add an object to the list of authorized IPs for webadmin.

Usage

<Object name>

Returns

Error code

Example

CONFIG WEBADMIN ACCESS ADD MyNetwork

CONFIG WEBADMIN ACCESS REMOVE

Level

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description



Remove an object from the list of authorized IPs for webadmin.

Usage

<Object name>

Returns

Error code

Example

CONFIG WEBADMIN ACCESS REMOVE MyNetwork

CONFIG WEBADMIN ACCESS SHOW**Level**

base

Description

Show the list of authorized objects for webadmin.

Returns

Error code

Example

CONFIG WEBADMIN ACCESS SHOW

Format

list

CONFIG WEBADMIN ACCESS SSLONLY**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Set if restricted mode is wanted (login/passwd authentication is then forbidden).

Usage

[0/1]

Returns

Error code

Example

CONFIG WEBADMIN ACCESS SSLONLY 0

CONFIG WEBADMIN ACTIVATE**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description



Reload sld daemon with latest configuration.

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next reboot.

Returns

Error code

Example

CONFIG WEBADMIN ACTIVATE

CONFIG WEBADMIN ADMINACCOUNT

Level

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Set if the admin account is authorized to access webadmin.

Usage

[0/1]

Returns

Error code

Example

CONFIG WEBADMIN ADMINACCOUNT 1

CONFIG WEBADMIN BRUTEFORCE

Level

admin,modify

Description

bruteforce related functions.

CONFIG WEBADMIN BRUTEFORCE NBATTEMPTS

Level

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Set the number of attempts per minute before banishing the IP.

Usage



[nb]

nb is the number of attempts per minute in the range of [1,20]

Returns

Error code

Example

```
CONFIG WEBADMIN BRUTEFORCE NBATTEMPTS 3
```

CONFIG WEBADMIN BRUTEFORCE NBBRUTEFORCEENTRIES**Level**

admin,modify

History

Appears in 3.5.0

Description

Set the number of IPs the bruteforce detection module can track.

Usage

[nb]

nb is the number of entries to track in the range [25, 200]

Returns

Error code

Example

```
CONFIG WEBADMIN BRUTEFORCE NBBRUTEFORCEENTRIES 50
```

CONFIG WEBADMIN BRUTEFORCE STATE**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Set the state of protection against bruteforce.

Usage

[0/1]

Returns

Error code

Example

```
CONFIG WEBADMIN BRUTEFORCE STATE 1
```

CONFIG WEBADMIN BRUTEFORCE TIME**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

**Description**

Set the time (in sec) of banishment after the number of attempts per minute is reached.

Usage

[nb]

nb is the time (in sec) of banishment in the range [60,3600]

Returns

Error code

Example

CONFIG WEBADMIN BRUTEFORCE TIME 12002

CONFIG WEBADMIN BRUTEFORCE TRIESTIME**Level**

admin,modify

History

Appears in Netasq 9.1.0

Description

Set the period (in sec) during which the attempt are counted

Usage

[nb]

nb is the period (in sec) of attempts in the range [1,3600]

Returns

Error code

Example

CONFIG WEBADMIN BRUTEFORCE TRIESTIME 30

CONFIG WEBADMIN IDLE**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

Raw idle time removed in 4.2.0

ServerTimeout appears in 4.2.0

ClientMaxTimeout appears in 4.2.0

Description

Set the idle timeout and client max timeout.

Usage

[ServerTimeout=nb1] [ClientMaxTimeout=nb2]

nb1 is the idle timeout (in sec) in the range [60, 3600]

nb2 is the GUI idle timeout (in sec, with 0 deactivated)

Returns

Error code

**Example**

CONFIG WEBADMIN IDLE ServerTimeout=300 ClientMaxTimeout=0

CONFIG WEBADMIN PORT**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Set the tcp port for webadmin service.

Usage

[port]

port is the value of the port for webadmin service (default is https)

Returns

Error code

Example

CONFIG WEBADMIN PORT https

CONFIG WEBADMIN SHOW**Level**

base

Description

Dump status of all webadmin parameters.

Returns

Error code

Example

CONFIG WEBADMIN SHOW

CONFIG WEBADMIN STATE**Level**

admin,modify

History

level maintenance removed in Netasq 9.0.0

Description

Set state for the web interface

Returns

Error code

Example

CONFIG WEBADMIN STATE



CONFIG WIFI

Level

base

History

Appears in 3.0.0 CipherAllowUnsafe appears in 3.1.0

Description

Wifi global configuration

CONFIG WIFI ACTIVATE

Level

network,modify

History

Appears in 3.0.0

Description

Activate wifi global configuration

Usage

[CANCEL] : changes are discarded

Example

```
CONFIG WIFI ACTIVATE
CONFIG WIFI ACTIVATE CANCEL
```

CONFIG WIFI LIST

Level

base

History

Appears in 3.1.0

Description

List some wifi related infos like available countrycodes and channels

CONFIG WIFI LIST CHANNELS

Level

base

History

Appears in 3.1.0

Description

List all available channels given a country, and a WIFI mode.

Usage

```
country=<country code>
mode=<a|b|g>
ht=<0|1|on|off> : highthroughput mode
```

**Format**

section_line

Remark

highthroughput is unavailable with mode b

Returns

Channel=1 TXPower=30
Channel=2 TXPower=30
Channel=3 TXPower=30
Channel=4 TXPower=30
Channel=5 TXPower=30
Channel=6 TXPower=30
Channel=7 TXPower=30
Channel=8 TXPower=30
Channel=9 TXPower=30
Channel=10 TXPower=30
Channel=11 TXPower=30
Channel=12 TXPower=30
Channel=13 TXPower=30

Example

CONFIG WIFI LIST CHANNELS country=fr mode=a ht=1

CONFIG WIFI LIST COUNTRYCODES**Level**

base

History

Appears in 3.1.0

Description

List all available country codes.

Format

section_line

Returns

IsoName=DEBUG Name=Debug Isocode=0
IsoName=ZW Name=Zimbabwe Isocode=716
IsoName=YE Name=Yemen Isocode=887
IsoName=VN Name=Viet Nam Isocode=704
IsoName=VE Name=Venezuela Isocode=862

Example

CONFIG WIFI LIST COUNTRYCODES

CONFIG WIFI SHOW**Level**

base

History

Appears in 3.0.0 CipherAllowUnsafe appears in 3.1.0

**Description**

Display wifi global configuration

Returns

```
[Global]
country=fr
txpower=30
state=0
CipherAllowUnsafe=0
schedule=wifitime
Mode=g
HT=1
ChannelModeA=100
ChannelModeBG=11
ChannelUsed=11
```

CONFIG WIFI UPDATE**Level**

network,modify

History

Appears in 3.0.0

Description

Update wifi global configuration

Usage

```
[state=on|off] [country=<country code>] [txpower=<power in db>] [schedule=<timerange
object name>]
[CipherAllowUnsafe=1|0] : Allow unsafe cipher suites like TKIP for pairwise encryption
[mode=a|b|g]
[ht=<0|1>] : highthrougput mode
[ChannelModeA=<channel for 5GHz mode>]
[ChannelModeBG=<channel for 2.4GHz mode>]
```

Example

```
CONFIG WIFI UPDATE state=0 country=us txpower=50 schedule=wifitime
```

CONFIG XVPN

VPN/SSL

Level

base

History

Appears in Netasq 6.0.0

Description

Xvpn related functions



CONFIG XVPN ACCESS

Level

vpn,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Set configuration for user access when using profile

Usage

action=pass|block | action=default profile=<profile name>

Returns

Error code

Remark

action : action we will proceed when user xvpn profile is not defined

profile name : xvpnd default profile in ldap

Example

CONFIG XVPN PROFILE ACCESS action=pass

CONFIG XVPN PROFILE ACCESS action=default profile="my server profile"

CONFIG XVPN ACTIVATE

Level

vpn,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Reload xvpn daemon with lastest configuration

Usage

[CANCEL]

- no argument: changes are activated immediately;

- CANCEL: changes are discarded.

Returns

Error code

Example

CONFIG XVPN ACTIVATE

CONFIG XVPN ADVANCED

Level

vpn,modify

History



Appears in Netasq 6.0.0
checkcert Appears in Netasq 6.1.0
basic_auth Appears in Netasq 6.1.0
owa_compat Appears in Netasq 6.1.0
basic_auth disAppears in Netasq 7.0.0
owa_compat disAppears in Netasq 7.0.0
startscript Appears in Netasq 6.1.0
endscript Appears in Netasq 6.1.0
level changes from other,modify to vpn,modify in Netasq 9.0.0
checkcert deprecated in Netasq 9.1.0

Description

Customize some option

Usage

[hide=<prefix tag used to hide original URL>] [login=<token used to send username information in http header>] [startscript=<command to execute on workstation when start client (base64 encoded)>] [endscript=<command to execute on workstation when stop client (base64 encoded)>]

Returns

Error code

Remark

accepted char for 'hide' and 'login' are : [a-z][A-Z][0-9][-][
startscript and endscript must be a base64 encoded command

Example

CONFIG XVPN ADVANCED hide="stormshield" (URL http://10.13.13.13/index.html may be rewrite in /stormshield0143/index.html)
CONFIG XVPN ADVANCED login="HttpStormshieldUserName" (add "HttpStormshieldUserName: login" in all HTTP header request"

CONFIG XVPN PROFILE**Level**

base

History

Appears in Netasq 6.1.0

Description

Profile configuration for xvpn server

CONFIG XVPN PROFILE ACTIVATE**Level**

vpn,modify

History

Appears in Netasq 9.0.0

Description

Activate the lastest configuration

Usage



[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Example

```
CONFIG XVPN PROFILE ACTIVATE  
CONFIG XVPN PROFILE ACTIVATE CANCEL
```

CONFIG XVPN PROFILE CREATE**Level**

vpn,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Create server template

Usage

<profile name>

Returns

Error code

Example

```
CONFIG XVPN PROFILE CREATE "OwaProfile"
```

CONFIG XVPN PROFILE LIST**Level**

base

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

level changes from other,user to base in Netasq 9.0.0

Description

List all server profile

Returns

Error code (if not found) or the list of profile

Format

list

Example

```
CONFIG XVPN PROFILE LIST  
NetasqIdXvpn=mail  
NetasqIdXvpn=web
```

CONFIG XVPN PROFILE REMOVE**Level**



vpn,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Remove server profile

Usage

<profile name>

Returns

Error code

Example

CONFIG XVPN PROFILE REMOVE "OwaProfile"

CONFIG XVPN PROFILE SHOW**Level**

vpn_read,user

History

Appears in Netasq 6.1.0

level changes from other,user to vpn_read,user in Netasq 9.0.0

Description

Show server on template

Usage

<profile name>

Returns

Error code or profile :

[XvpnProfile]

httpserver= : list of http server

xserver= : list of full access server

Example

CONFIG XVPN PROFILE SHOW "OwaProfile"

[XvpnProfile]

httpserver="howa"

xserver="xowa"

CONFIG XVPN PROFILE UPDATE**Level**

vpn,modify

History

Appears in Netasq 6.1.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Add|Update|Remove entry on profile {server...=<empty string> to remove}



CONFIG XVPN SERVER

Level

base

History

Appears in Netasq 6.0.0

Description

Xvpn server related functions

CONFIG XVPN SERVER HTTP

Level

base

History

Appears in Netasq 6.0.0

Description

Xvpn HTTP server related functions

CONFIG XVPN SERVER HTTP ADD

Level

vpn,modify

History

Appears in Netasq 6.0.0

hidden Appears in Netasq 6.1.0

whitelisturls Appears in Netasq 6.1.0

BasicAuth Appears in Netasq 7.0.0

OwaCompatibility Appears in Netasq 7.0.0

Owa Appears in Netasq 8.0.0

Zimbra Appears in 8.1.2

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Add HTTP server entry

Usage

name=<server name> host=<object> link=<name see in portal> [url=<specify url to load>]
[port=<service>] [hidden=0|1] [whitelisturls=<urlgroup>] [basic_auth=0|1] [Owa=0|1]
[OwaCompatibility=0|1] [Zimbra=0|1]

Returns

Error code

Remark

the hidden tag is used to hide server on web portal BasicAuth is used to remove Negotiate and NTLM authentication

OwaCompatibility is used to force OWA compatibility mode with Internet Explorer

Example



```
CONFIG XVPN SERVER HTTP ADD name=intranet host=intranet.test.int link="go to intranet"  
CONFIG XVPN SERVER HTTP ADD name=proxy_test host=intranet.test.int link="test proxy  
intranet" url="proxy/index.php" port http_proxy
```

CONFIG XVPN SERVER HTTP ALIAS

Level

base

History

Appears in Netasq 6.0.0

Description

Xvpn alias on HTTP server related functions

CONFIG XVPN SERVER HTTP ALIAS ADD

Level

vpn,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Add alias on HTTP server entry

Usage

name=<http server name> alias=<name of alias>

Returns

Error code

Remark

accepted char for alias are : [a-z][A-Z][0-9][_][.]

Example

```
CONFIG XVPN SERVER HTTP ALIAS ADD name=intranet alias="192.168.0.1"
```

CONFIG XVPN SERVER HTTP ALIAS REMOVE

Level

vpn,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Remove alias on HTTP server entry

Usage

name=<http server name> alias=<name of alias>

Returns

Error code

Example

```
CONFIG XVPN SERVER HTTP ALIAS REMOVE name=intranet alias="192.168.0.1"
```

**CONFIG XVPN SERVER HTTP REMOVE****Level**

vpn,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Remove HTTP server entry

Usage

name=<name of server to remove>

Returns

Error code

Example

CONFIG XVPN SERVER HTTP REMOVE name=intranet

CONFIG XVPN SERVER HTTP STATE**Level**

vpn_read

History

Appears in Netasq 6.0.0

level changes from base to vpn_read in Netasq 9.0.0

Description

Get/Set the status of the xvpn servers [http]

Usage

[On|Off]

Returns

The current value (case of no arg) or error code

Remark

Changing state of http servers need Vpn level

Example

CONFIG XVPN SERVER HTTP STATE

CONFIG XVPN SERVER HTTP UPDATE**Level**

vpn,modify

History

Appears in Netasq 6.0.0

hidden Appears in Netasq 6.1.0

whitelisturls Appears in Netasq 6.1.0

BasicAuth Appears in Netasq 7.0.0

OwaCompatibility Appears in Netasq 7.0.0

Owa Appears in Netasq 8.0.0

Zimbra Appears in 8.1.2

level changes from other,modify to vpn,modify in Netasq 9.0.0

**Description**

Update one or more value of HTTP server configuration

Usage

name=<server name> [host=<object>] [link=<name see in portail>] [url=<specify url to load>]
[port=<service>] [hidden=0|1] [whitelisturls=<urlgroup>] [BasicAuth=0|1] [Owa=0|1]
[OwaCompatibility=0|1] [Zimbra=0|1]

Returns

Error code

Example

CONFIG XVPN SERVER HTTP UPDATE name=intranet link="new link for server"

CONFIG XVPN SERVER OTHER**Level**

base

History

Appears in Netasq 6.0.0

Description

Xvpn no HTTP server related functions

CONFIG XVPN SERVER OTHER ADD**Level**

vpn,modify

History

Appears in Netasq 6.0.0

script Appears in Netasq 6.1.0

chost Appears in Netasq 6.2.0

citrix Appears in Netasq 7.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Add no HTTP server entry

Usage

name=<server name> host=<object> port=<service> [chost=<ip address>]
cport=<service|integer> [script=<command to execute on workstation (base64 encoded)>]
[citrix=<0|1>]

Returns

Error code

Remark

script must be a base64 encoded command

Example

CONFIG XVPN SERVER OTHER ADD name=ssh_intranet host=my_ssh_server port=ssh cport=2222

CONFIG XVPN SERVER OTHER ADD name=ssh_intranet host=my_ssh_server port=ssh
chost="127.0.0.2" cport=2222

**CONFIG XVPN SERVER OTHER REMOVE****Level**

vpn,modify

History

Appears in Netasq 6.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

Description

Remove no HTTP server entry

Usage

name=<name of server to remove>

Returns

Error code

Remark

need modify level

Example

CONFIG XVPN SERVER OTHER REMOVE name=ssh_intranet

CONFIG XVPN SERVER OTHER STATE**Level**

vpn_read

History

Appears in Netasq 6.0.0

level changes from base to vpn_read in Netasq 9.0.0

Description

Get/Set the status of the xvpn servers (no http)

Usage

[On|Off]

Returns

The current value (case of no arg) or error code

Remark

Changing state of no http servers need Vpn level

Example

CONFIG XVPN SERVER OTHER STATE

CONFIG XVPN SERVER OTHER UPDATE**Level**

vpn,modify

History

Appears in Netasq 6.0.0

script Appears in Netasq 6.1.0

chost Appears in Netasq 6.2.0

citrix Appears in Netasq 7.0.0

level changes from other,modify to vpn,modify in Netasq 9.0.0

**Description**

Update one or more value of no HTTP server configuration

Usage

name=<server name> [host=<object>] [port=<service>] [chost=<ip address>]
[cport=<service|integer>] [script=<command to execute on workstation (base64 encoded)>]
[citrix=<0|1>]

Returns

Error code

Remark

script must be a base64 encoded command

Example

CONFIG XVPN SERVER OTHER UPDATE name=ssh_intranet host=new_ssh_server

CONFIG XVPN SHOW**Level**

vpn_read

History

Appears in Netasq 6.0.0

Owa Appears in Netasq 8.0.0

level changes from base to vpn_read in Netasq 9.0.0

Description

Show xvpn config

Returns**[Config]**

State : xvpn daemon state

HttpServerState : http server state

XServerState : other server state

HttpRewriteURL : prefixe of tag to rewrite URL

HttpHeaderLoginTag : name of tag to send login of user to server

ProfileAccess : action we will proceed when user xvpn profile is not defined

Xvpnd : name of xvpnd default profile

XserverStartScript : command to lunch when xvpnd client start

XserverEndScript : command to lunch when xvpnd client stop

BasicAuth : force basic authentication

OwaCompatibility : activate OWA compatibility

[MaxValue]

XServer= : max number of other server

HttpServer= : max number of http server

HttpServerAlias= : max number of alias for http server

UrlsOnWhiteList= : max number of urls for whitelist

[HttpServer xxx]

Name : name of server

Host : server object to connect to

Port : server port to connect to

FwPort : firewall listen port



Hidden : specify if server is visible or not for user
URL : url of server to connect to
Link : link on web page to call url
Alias : list of alias for server
WhiteListUrls : urlgroup name for white list

[XServer_xxx]

Name : name of server
Host : server ip to connect to
Port : server port to connect to
CHost : local ip to listen to (client workstation)
CPort : local port to listen to (client workstation)
Script: command to lunch for this service

Example

CONFIG XVPN SHOW

[Config]

State=1
XServerState=1
HttpServerState=1
HttpRewriteURL=stormshield
HttpHeaderLoginTag=stormshield
ProfileAccess=Pass
XvpnlId=
XserverStartScript=
XserverEndScript=
Owa=0
OwaCompatibility=0
CheckClientCert=0

[MaxValue]

XServer=32
HttpServer=64
HttpServerAlias=24
UrlsOnWhiteList=32

[XServer_ssh_build]

Name=ssh_build
Host=build
Port=ssh
CHost=
CPort=11022
Script=lmM6XHwMjl=

[HttpServer_owa]

Name=owa
Host=owa
Port=http
FwPort=11235
Hidden=0
URL=exchange
Link="OWA server"
WhiteListUrls=owa
Alias=192.168.1.1



GLOBALADMIN

Level

base

Description

Global administration

GLOBALADMIN GETINFOS

Level

base

Description

Get system informations

Returns

[Information] ...

GLOBALADMIN GETSTATUS

Level

base

Description

Get system and security status

Returns

[Status]

System=<value> Total=<value>

Security=<value> Total=<value>

[Alarm]

Minor=<value>

Major=<value>



HA

Description

HA functions

HA CHECKSYNC

Level

base

History

HA CHECKSYNC appeared in Netasq 9.0.0

Description

Indicates if changes have been made to the local configuration since the last HA synchronisation (see HA SYNC).

Returns

Sync={0|1}

Example

```
HA CHECKSYNC
Sync=0
```

HA CLUSTER

Level

ha,base

Description

Manage HA cluster

HA CLUSTER ACTIVATE

Level

ha,base,modify

Description

Activate new HA cluster configuration

Example

```
HA CLUSTER ACTIVATE
```

HA CLUSTER ADD

Level

ha,base,modify

Description

Add a node in HA cluster

**Usage**

```
serial=U250-XXX  
[ip=<main link IP>]  
[ip2=<backup link IP>]  
priority=<firewall priority>  
sshkeytype=<ssh-dss|ssh-rsa>  
sshkey=<ssh public key>  
[sshkeylogin=<login corresponding to the key>]
```

Example

```
HA CLUSTER ADD serial=U250-XXX ip=192.168.0.2 ip2=192.168.1.2 priority=128  
sshkeytype=ssh-dss sshkey=ABCDEF0123456789 sshkeylogin=admin@peer_fw
```

Remark

IPs are optional, but some fonctionnalities (like file synchronization) may not work as long as they are not provided.

HA CLUSTER LIST

Level

base

Description

Give the list of firewalls in the HA cluster

Returns

HA

<serial> : fw serial

<serial> : fw serial

Format

list

Example

HA

F60-XA300110600101

F60-XA000010699999

HA CLUSTER REGENHOSTKEY

Level

ha,base,modify

History

Appears in 4.2.0

Description



regenerate the hostkey used for ha communications

Returns

Error code

Example

HA CLUSTER REGENHOSTKEY

HA CLUSTER REMOVE

Level

ha,base,modify

History

serial=remote appears in 3.9.0

Description

Remove a node in HA cluster

Usage

serial={SNXXX|remote}

Example

HA CLUSTER REMOVE serial=SNXXX HA CLUSTER REMOVE serial=remote

HA CLUSTER SHOW

Level

ha,base

Description

Show all nodes in HA cluster

Example

HA CLUSTER SHOW

HA CLUSTER UPDATE

Level

ha,base,modify

Description

Update node info in HA cluster

Usage

serial={U120-XXXXXX|local}

[ip=<main link IP>]

[ip2={|<backup link IP>}]

[priority=<firewall priority>]

[sync={0|1}] [immediate HA config sync ; default is 1]

Remark

If ip is specified, ip2 must also be, otherwise it will be removed.

**Example**

```
HA CLUSTER UPDATE serial=U250-XXXX ip2=192.168.3.2 HA CLUSTER UPDATE serial=U120-XXXX
priority=10
```

HA HALT**Level**

ha,maintenance,modify

History

level maintenance Appears in Netasq 6.0.0
level other deprecated in Netasq 6.0.0

Description

Halt firewall peer

Usage

serial=<serial>|local

Returns

Error code

Example

```
HA HALT
```

HA INFO**Level**

base

Description

Display firewall informations about the firewalls of the HA cluster

Usage

[serial={all|local|<peer serial>}]

Returns

[Notifications] level=<level> type=<type> code=<code> msg="<msg>" causedBy="<src1>
[,<src2>[...]]"
level=<level> type=<type> code=<code> msg="<msg>"
[...]

[serial]

Reply={0|1} : If the firewall replied (if 0, following fields will be missing)

Model=UXXX : Firewall model

Version=<build> : Firmware version

Supervisor={0|1} : Cluster supervisor

AsqDumpVersion={0-999} : Connections data version

ConnSyncVersion={0-999} : Connection synchronization protocol version

ClusterBalancingVersion={0-999} : Cluster balancing protocol version

Forced={No|Active|Passive} : Forced mode

Mode={Active|Passive} : Firewall mode

Licence={None|Master|Slave} : HA mode defined in the licence

ConnectedOn={0|1} : 1 if this is the firewall you're currently connected to



BackupActive=
BackupVersion=
BackupDate=
Quality=<factor> : Quality (in pourcent)
Priority=<0-9999> : HA priority
Boot="YYYY-MM-DD hh:mm:ss" : firewall boot time
LastConfigSync="YYYY-MM-DD hh:mm:ss" : Last time a full configuration sync has been done
LastModeChange="YYYY-MM-DD hh:mm:ss" : Last HA mode change
State={None|Starting|Waiting peer|Running|Ready|Reboot|Down|Initializing} : current state
Ip=<IP> : Firewall IP in HA cluster
Link=<status> : OK, Failed, Failing, Unknown
LinkStatusChanged="YYYY-MM-DD hh:mm:ss"
BackupIp=<IP> : Firewall backup IP in HA cluster
BackupLink=<status> : OK, Failed, Failing, Unknown
BackupLinkStatusChanged="YYYY-MM-DD hh:mm:ss"
SystemNodeName=<name> : Firewall system node name
FwadminRevision=<revision> : Firewall revision

Remark

Quality factor depends on various elements including interface status

Regarding notifications:

- They are identified by "code". "level" indicates the severity of the issue, and "type" is type of check that raised this notification.
- "causedBy" can be a list of firewall serial numbers, interface user names, etc. The type of value in this field depends of the type of check.

Example

HA INFO

[Notifications]

level=warning type=cluster code=13 msg="Degraded mode: Can't synchronize files"

causedBy="SN910A0123456A1"

level=warning type=net if code=20 msg="Some non-HA interfaces have no MAC address forced. This can make HA swaps less efficient" causedBy="out"

[SN910A0123456A1]

Reply=0

[SN910A0123456A2]

Reply=1

Model="SN910"

Version="4.1.0.dev"

Supervisor=1

AsqDumpVersion=24

ConnSyncVersion=7

ClusterBalancingVersion=14

Forced="No"

Mode="Active"

Licence="Slave"

ConnectedOn=1

BackupActive="Main"

BackupVersion="4.0.1.dev"

BackupDate="2020-01-11 17:44:20"

Quality=66

Priority=100

Boot="2020-04-15 13:15:24"



```
LastConfigSync="2020-04-15 14:38:00"  
LastModeChange="2020-04-15 15:18:58"  
State="Running"  
Ip="172.16.0.1"  
Link="FAULTY"  
LinkStatusChanged="2020-04-15 15:19:27"  
BackupIp="172.16.1.1"  
BackupLink="OK"  
BackupLinkStatusChanged="2020-04-15 15:19:27"  
SystemNodeName="My_Node"  
FwadminRevision="00014"
```

HA REBOOT

Level

ha,maintenance,modify

History

level maintenance Appears in Netasq 6.0.0
level other deprecated in Netasq 6.0.0

Description

Reboot firewall peer

Usage

serial=<serial>|local

Returns

Error code

Example

HA REBOOT

HA REMOTE

Level

ha,base

Description

Command to call Serverd commands remotely as user HA

HA REMOTE HACUSTERREMOVE

Level

ha,base

Description

Call HA CLUSTER REMOVE on a remote firewall

Usage

ip=<target firewall ip>
password=<password of user 'HA'>
<other tokens accepted by HA CLUSTER REMOVE>

**Example**

```
HA REMOTE HACUSTERREMOVE ip=172.16.0.1 password=hapassword serial=U120-XXX
```

Remark

Connect as user HA

HA REMOTE HAINFO

Level

ha,base

Description

Call HA INFO on a remote firewall

Usage

```
ip=<target firewall ip>  
password=<password of user 'HA'>  
<other tokens accepted by HA INFO>
```

Example

```
HA REMOTE HAINFO ip=172.16.0.1 password=hapassword serial=U120-XXX
```

Remark

Connect as user HA

HA SETMODE

Level

ha,base,modify

Description

Force a firewall as active or passive

Usage

```
mode={active|passive|normal} [serial=U250-XXX]
```

Returns

active|passive

Example

```
HA SETMODE  
HA SETMODE mode=active  
HA SETMODE mode=passive serial=U250-XXX
```

Remark

If another firewall has been previously forced, this will unforce it first.

HA SYNC

Level

ha,base,modify

History



Mode Appears in 6.0.7
Optenet Appears in Netasq 6.2.0
Vaderetro Appears in Netasq 6.2.0
Optenet disappears in Netasq 9.1.0
ennetwork appears in 4.2.3

Description

Sync firewall

Usage

```
[from=<serial>|active|local] [to=<serial>|local|all] [data=EVERYTHING|CONFIG|AU_CLAMAV|AU_
ADVANCEDAV|AU_ANTISPAM|AU_ROOTCERTIFICATES|AU_URLFILTERING|AU_PATTERNS|AU_
VADERETRO|AU_PVM|USERPREFS] [ennetwork=0|1]
```

Returns

[<serial>] : One per firewall impacted by the filesync PreCommandsSuccessful="abc,def,ghi" :
Optionnal (only displayed if there is actually a value) PreCommandsFailed="abc,def,ghi" :
Optionnal (only displayed if there is actually a value) FileSyncSuccessful="abc,def,ghi" :
Optionnal (only displayed if there is actually a value) FileSyncFailed="abc,def,ghi" : Optionnal
(only displayed if there is actually a value) ReactivationsSuccessful="abc,def,ghi" : Optionnal
(only displayed if there is actually a value) ReactivationsFailed="abc,def,ghi" : Optionnal (only
displayed if there is actually a value) PostCommandsSuccessful="abc,def,ghi" : Optionnal (only
displayed if there is actually a value) PostCommandsFailed="abc,def,ghi" : Optionnal (only
displayed if there is actually a value)

Remark

Default values:
from: local
to: all (source will be automatically excluded)
data: everything

Example

HA SYNC
HA SYNC data=au_Patterns

HA TPMSYNC

Level

tpm,modify

History

appears in 3.10.0

Description

Call SYSTEM TPM INIT or RESET on a remote firewall, according to local TPM status.

Usage

tpmpassword=<tpm password>

Example

HA TPMSYNC tpmpassword=password

Remark

Connect as user HA



HELP

History

Appears in V4.0

Description

Display the available commands.

Returns

Available help.

Example

HELP

AUTH : user authentication

CA : command to manage internal PKI

CHPWD : indicate if the password must be updated

CONFIG : firewall configuration functions

GLOBALADMIN : global administration

HA : HA functions

HELP : display the available commands

LIST : display the list of connected users, show user rights (Level) and rights for current session (SessionLevel)

LOG : log related functions. Every time a timezone is needed, if not specified, the command is processed with the firewall timezone setting

MODIFY : Get / loose the modify or the monitor_write right

MONITOR : monitor related functions

NOP : do nothing but avoid disconnection from server

QUIT : log off

SYSTEM : system commands

USER : user related functions

VERSION : display server version



LIST

Level

base

History

Format appears in Netasq 9.0.0

Description

Display the list of connected users, show user rights [Level] and rights for current session [SessionLevel].

Returns

List of connected users:

User=<login> Address=<Client address> Level=<user level> SessionID=<SessionNumber>
SessionLevel=<session level>

Remark

Without ADMIN level, list only the users with modify right and their session rights.

Format

section_line

Example

User="admin" Address=192.168.1.1

Level="modify,base,contentfilter,log,filter,vpn,pki,object,user,admin"

SessionID=16 SessionLevel="modify,base,contentfilter,log,filter,vpn,pki,object,user,admin"



LOG

Description

Log related functions. Everywhere a timezone is needed, if not specified the command is treated with firewall timezone setting.

LOG CLEAR

Level

log,modify

History

Format Appears in Netasq 9.0.0

Description

Clear the log file

Usage

<log name> <date>

Remark

With a date, delete from first log up to the given date.

Format

list

Example

LOG CLEAR alarm

LOG CLEAR server "2003-01-01 00:00:00"

LOG DATETOLINE

Level

log_read

History

level changes from log to log_read in Netasq 9.0.0

Description

Convert a date range to a number of lines. If 'tz' is specified, 'first' and 'last' use this timezone. Else, 'first' and 'last' use the firewall timezone.

Usage

name=<log name> first=<first date> last=<last date> [tz=<timezone offset of first and last>]

Example

LOG DATETOLINE name=connection first="2002-07-01 00:00:00" last="2002-07-02 23:59:59"

Dans la section "Result" Total=6520

LOG DATETOLINE name=connection first="2002-06-30 23:00:00" last="2002-07-02 22:59:59"

tz=+0000

Dans la section "Result" Total=8478



LOG DOWNLIMIT

Level

log_read

History

Format Appears in Netasq 9.0.0

level changes from log to log_read in Netasq 9.0.0

Description

Get log from date up to a number of lines. If 'tz' is specified, 'first' uses this timezone. Else, 'first' uses the firewall timezone.

Usage

name=<log name> [first=<first date> [tz=<timezone offset of first>]] number=<number>

Remark

Additional rights may be needed to read some files

if first date is not in a comprehensible format command will run in "last" mode

Format

list

Example

LOG DOWNLIMIT name=alarm first="2002-07-01 07:00:00" number=100 will return 100 lines starting to the date.

LOG DOWNLIMIT name=web number=100 will return last 100 lines in log web, (used by monitoring).

LOG DOWNLOAD

Level

log_read

History

Format Appears in Netasq 9.0.0

level changes from log to log_read in Netasq 9.0.0

Description

Get log file lines between the specified dates. If 'tz' is specified, 'first' and 'last' use this timezone. Else, 'first' and 'last' use the firewall timezone.

Usage

name=<log name> first=<first> last=<last> [tz=<timezone offset of first and last>]

Remark

Additional rights may be needed to read some files

server log require ADMIN level

Format

section_line

Example

LOG DOWNLOAD name=alarm first="2002-06-30 23:00:00" last="2002-07-01 12:00:00"



LOG INFO

Level

log_read

History

level changes from base to log_read in Netasq 9.0.0

Description

Get information on the log file

Usage

<log name>

Returns

[LogInfo]

Line=<Number of lines>

Size=<Size>

MaxSize=<Max Size>

Start=<Start date>

End=<End date>

Remark

Log names are : alarm, connection, smtp, filter, web, filterstat, count, auth, server

Example

LOG INFO connection [LogInfo]

Line=53277

Size=23927

MaxSize=40

Start="2003-05-27 06:29:13"

End="2003-07-21 09:02:38"

LOG PROPERTY

Level

log_read

History

level changes from base to log_read in Netasq 9.0.0

Syslog removed in 3.0.0

Description

Get state of the log module

Returns

State=<0|1>

List=<list of available logs>

DiskSize=<size>

DiskFree=<size>

Example

LOG PROPERTY State=1

List=filter,alarm,web,smtp,vpn,connection,system,plugin



DiskSize=8853504
DiskFree=7120896

LOG SEARCH

Level

log_read

History

Appears in 1.0.0

Description

Log search related functions. Everywhere a timezone is needed, if not specified the command is treated with firewall timezone setting

LOG SEARCH GET

Level

log_read

History

Appears in 1.0.0

Description

Get the current page, partial or complete.

Format

section_line

Example

LOG SEARCH GET

LOG SEARCH JUMP

Level

log_read

History

Appears in 1.0.0

Description

Set the Nth page as current and process it.

Usage

page_number

Example

LOG SEARCH JUMP 10

LOG SEARCH NEW

Level

log_read

**History**

Appears in 1.0.0

Description

Start a new paginated log research and set the first page as current. If 'tz' is specified, 'first' and 'last' use this timezone. Else, 'first' and 'last' use the firewall timezone.

Usage

```
[view=<view name>|file=<file name>] first=<date> [last=<date>] [tz=<timezone offset of first and last>] pagesize=<size> [pattern=<search pattern>]
```

Remark

The search pattern is a space separated string containing some criteria like '`<token><op><value>`' where:

- `<token>` is a log line token (or 'any')
- `<op>` is '=' or '!='
- `<value>` is a regular expression, optionally surrounded by single quotes

The 'any' token can be used in the search pattern to accept log lines containing the associated value in any token

Additional rights may be needed to read some files
server log require ADMIN level

Example

```
LOG SEARCH NEW view=server pagesize=20 first="2002-06-30 23:00:00" last="2002-07-01 12:00:00" tz="+0001" pattern="token!=foo token2='bar' any=foobar"
```

LOG SEARCH NEXT

Level

log_read

History

Appears in 1.0.0

Description

Set the next page as current and process it.

Example

```
LOG SEARCH NEXT
```

LOG SEARCH PREVIOUS

Level

log_read

History

Appears in 1.0.0

Description

Set the previous page as current and process it.

Example

```
LOG SEARCH PREVIOUS
```



LOG SEARCH RESUME

Level

log_read

History

Appears in 1.0.0

Description

Resume the search.

Example

LOG SEARCH RESUME

LOG SEARCH STOP

Level

log_read

History

Appears in 1.0.0

Description

Stop the search. It may be resumed later with LOG SEARCH RESUME.

Example

LOG SEARCH STOP



MODIFY

History

monitor appears in Netasq 6.0.0
level base appears in Netasq 6.0.1
level base deprecated in Netasq 6.1.0
modify appears in 3.0.0

Description

Get / loose the modify or the mon_write right.

Usage

[monitor] [modify] on|off

Returns

The operation result.

Example

MODIFY on



MONITOR

Description

Monitor related functions

MONITOR ADDRESSLIST

History

Appears in Netasq 6.0.0

Description

Dynamic address list management

MONITOR ADDRESSLIST ADD

Level

filter, mon_write

History

Appears in Netasq 6.0.0

Description

Add address in dynamic list (update timeout if already exists)

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude Name1=<object|ip>
[Name2=<object|ip>] Timeout=<timeout>

Remark

timeout is time in seconds

Filter and Modify levels are required for Type that are not BlackList

Example

MONITOR ADDRESSLIST ADD Type=BlackList Name1=10.2.16.1 Timeout=10

MONITOR ADDRESSLIST DELETE

Level

filter, mon_write

History

Appears in 2.0.0

Description

Delete address in dynamic list

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude Name1=<object|ip>
[Name2=<object|ip>]

Remark

Filter and Modify levels are required for Type that are not BlackList

**Example**

MONITOR ADDRESSLIST DELETE Type=BlackList Name1=10.2.16.1

MONITOR ADDRESSLIST SHOW**Level**

filter_read

History

Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0

Description

Dump the dynamic address list

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude

Returns

range1=10.2.16.3:10.2.16.3 range2=0.0.0.0:255.255.255.255 timeout=599

range1=10.2.23.3:10.2.23.10 range2=10.2.16.4:10.2.16.4 timeout=156

Remark

Filter level is required for Type that are not BlackList

Format

section_line

Example

MONITOR ADDRESSLIST SHOW Type=BlackList

MONITOR AGG**Level**

base

History

Appears in 1.0.0

Usage

[<Agg ifname>]

Description

Monitor Agg interfaces

Returns

[aggregation_username]

Port=<port number> Ifname=<ifusername> MACName=<ifmacname> connected=0|1

active=0|1

[...]



MONITOR ALARM

History

deprecated in Netasq 9.1.0

Description

Monitor alarm

MONITOR ALARM GET

Level

log_read

History

Format Appears in Netasq 9.0.0

deprecated in Netasq 9.1.0

Description

Get an alarm in the dispatch queue

Usage

lastid|all|<id>

Returns

LASTID :

return alarmid=<lastid>

ALL|<id> :

alarmid=<id> <welf alarm>

Remark

lastid return only the last alarm id

Format

section_line

Example

MONITOR ALARM GET all

MONITOR ALARM GET lastid
100 alarmid=8"

MONITOR ALARM GET 148

MONITOR ANTIVIRUS

Level

base

History

Appears in Netasq 6.1.0

Description

Monitor antivirus

**Returns**

[xx]
Name=<string> : Antivirus Name
Selected=<integer> : selected antivirus
DateUpd=<string> : date of the last database update
LicenceExp=<string> : licence expiration date
BaseReady=<integer> : state of the antiviral base
State=<integer> : 0[inactive], 1[supposed to be running], 2[same as 1 but the service is down]

Example

```
MONITOR ANTIVIRUS
101 code=00a01000 msg="Begin"
[00]
Name=clamav
Selected=1
DateUpd=2006-05-10 15:08:55
LicenceExp=2008-06-30
BaseReady=1
State=1
```

```
[01]
Name=AdvancedAV
Selected=0
DateUpd=
BaseReady=0
State=0
```

```
100 code=00a00100 msg="Ok"
```

MONITOR ASSOCIATION**Level**

log_read

History

Format Appears in 3.9.0

Description

List association information. No filter display all information

Usage

```
[host=<host_address_or_name>] [ifname=<interface>] [srcifname=<interface>]
[dstifname=<interface>] [slotlevel=<slot> ruleid=<rule>] [rulename=<rulename>]
[state=<all,recovery,init,data,close,closed>] [rtidname=<router name>] [srcmac=<macaddr>]
[dstport=<integer port|string port name>] [lastuse=<integer>] [maxcount=<integer>]
[confid=<integer>]
```

Returns

time : association creation time
id : unique identifier
src : primary source IP address
srcmultiomed : list of secondary source IP address
srcname : client object name, or miniDNS client name for source IP address
srcmac : source ETHERNET address



srcport : source port
srcportname : source port object name
dst : primary destination IP address
dstmultiomed : list of secondary destination IP address
dstname : destination object name, or miniDNS server name for destination IP address
dstport : destination port
dstportname : destination port object name
srcif : packets source interface
dstif : packets destination interface
sent : bytes sent
rcvd : bytes received
duration : duration in seconds
lastuse : time in seconds since last use
rtid : router ID
rtidname : router ID name
slotlevel : slot level
ruleid : rule ID
confid : configuration ID
state : state of SCTP connection
... : protocol dependent field

Format

section_line

MONITOR AUTOBACKUP

Level

base

History

Appears in 1.0.0

Description

Check autobackup status

Returns

[Autobackup] State={disabled|success|Never used|failed}

Last=<YYYY-MM-DD hh:mm:ss> : date of last successful backup

MONITOR AUTOUPDATE

Level

base

History

Appears in Netasq 6.0.0

Pvm Appears in Netasq 7.0.0

Description

Check autoupdate status or launch an update

Remark

Launching an update requires level "Maintenance AND (Mon_write OR Modify)"

**Usage**

```
[update=<on|Antispam|URLFiltering|Patterns|CustomPatterns|AdvancedAV|Clamav|Vaderetro|Pv  
m|RootCertificates|IPData>] [force={0|1}]
```

MONITOR BYPASS**Level**

base

Description

Display bypass hardware configuration

Returns

Bypass hardware configuration

Example

MONITOR BYPASS

MONITOR CERT**Level**

base

History

Appears in 3.9.0

Description

Dump a list of used certificates status

Usage

<none>

Example

MONITOR CERT

Returns

name="(config object name)" cn=(Common name) notbefore= notafter= elapsed=(days since
start of validity) remain=(days up to end of validity) revoked=(boolean) tpm=
{Unknown|Unusable|Unused|Used} status={n/a|unknown|good|minor|major} context=
{n/a|unknown|"module name"|Group membership|Router service|Router gateway|Router
hostcheck}

Format

section_line

MONITOR CRL**Level**

base

History



Appears in 3.9.0

Description

Dump a list of used CA CRLs status

Usage

<none>

Example

MONITOR CRL

Returns

caname="(config object name)" lastupdate=(date of last update) nextupdate=(date of next update) elapsed=(days since start of validity) remain=(days up to end of validity) status=(n/a|unknown|good|minor|major) context=(n/a|unknown|"module name"|Group membership|Router service|Router gateway|Router hostcheck) lastfetch=(never|"date of last fetch") lastfetchstatus=(ok|ko)

Format

section_line

MONITOR CRYPTOCARD

Level

base

History

Appears in Netasq 6.1.0

Description

Get information on status of cryptographic card

Usage

[all]

Returns

[Global] State= : state of card (0 or 1)

StateError= : error code of driver card (only if State=0)

LibraryVersion= : version of library (only for option 'all')

DriverVersion= : version of driver (only for option 'all')

StatsError= : error code of driver card (only if stats failed and option 'all')

SymError= : error code of driver card for symetric op (only if stats failed and option

'all')<NL>AsymError= : error code of driver card for asymetric op (only if stats failed and option 'all')

IntError= : error code of driver card (only if stats failed and option 'all')

[Flow]

RNG= : number of random byte generated

DES= : number of byte encrypted/decrypted with DES/3DES

[Request]

RNG= : number of request for random generation

DH= : number of request for Diffie-Hellman

RSA= : number of request for RSA

DES= : number of request for DES/3DES

**Remark**

the effect of 'all' is to get more information when an error occurs

Example

MONITOR CRYPTOCARD

MONITOR DHCP

Level

base

History

Appears in Netasq 9.1.0

Description

Display information on the dhcp leases

Format

section_line

Returns

```
[DHCP_Lease] IPAddress="<ip>" State="[free|active|expired|released|abandoned|reset]"
Start="YYYY-MM-DD hh:mm:ss" End="YYYY-MM-DD hh:mm:ss" MacAddress="xx:xx:xx:xx:xx:xx"
[Hostname="<hostname>"]
[...]
```

```
[Stat_Lease]
```

```
NBTotal=<total number of leases in the list>
```

```
NBActive=<number of activated leases>
```

Example

MONITOR DHCP

```
[DHCP_Lease]
```

```
IPAddress="172.16.4.10" State="active" Start="2012-05-07 18:14:12" End="2012-05-07
18:16:12" MacAddress="00:01:03:8a:d9:7f" Hostname="my-pc"
```

```
IPAddress="10.10.10.237" State="active" Start="2012-03-05 08:25:28" End="2012-03-06
08:25:28" MacAddress="d8:9e:3f:a2:ff:ff" Hostname="my-server"
```

```
IPAddress="10.10.9.217" State="active" Start="2012-03-05 08:15:06" End="2012-03-06
08:15:06" MacAddress="34:15:9e:44:eb:eb" Hostname="my-phone"
```

```
IPAddress="10.10.13.239" State="free" Start="2012-03-05 08:23:30" End="2012-03-05
08:24:19" MacAddress="88:c6:63:b6:dd:dd"
```

```
[Stat_Lease]
```

```
NBTotal=4
```

```
NBActive=3
```

MONITOR DISK

Level

base

History

Appears in 4.3.13

Description



Displays informations such as disk firmware version, disk model, disk serial number

Returns

101 code=00a01000 msg="Begin" format="section" [Common] SerialNumber=XXX

MONITOR ETHER

Level

log_read

History

Appears in 4.0.0

Description

List ether state connections information. No filter display all connections.

Usage

[srcmac=<macaddr>] [dstmac=<macaddr>] [srcifname=<interface>] [lastuse=<integer>]
[slotlevel=<slot> ruleid=<rule>] [rulename=<rulename>] [confid=<integer>] [plugin=
name>] [host=<macaddr>] [maxcount=<integer>]

Returns

time : connection creation time
id : unique identifier
etherproto : ether protocol name
proto : protocol name
srcmac : source MAC address
dstmac : destination MAC address
srcif : interface name
sent : bytes sent
rcvd : bytes received
duration : duration in seconds
lastuse : time in seconds since last use
slotlevel : slot level
ruleid : rule ID
rulename : rule name
confid : configuration ID
srcname : source object name
dstname : destination object name
... : protocol dependent field

Format

section_line

MONITOR FAN

Level

base

History

Appears in 3.7.0

Description

Monitor FAN speed on SN2100, SN3100 and SN6100

**Usage**

[serial=SNXXX]

Example

MONITOR FAN

MONITOR FAN serial=SNXXX

Returns

[FANO]

[SPEED|FAILURE|MISSING]

MONITOR FILTER

Level

filter_read

History

Appears in Netasq 6.0.0

level filter Appears in 6.0.2

level log deprecated in 6.0.2

Format Appears in Netasq 9.0.0

host, shost, dhost, port, sport, dport, iface, siface, diface, proto, iptype, rtid, qid appear in 1.0.0

Description

Dump current filter rules

Format

list

Example

MONITOR FILTER

Usage

[host=<host_address>] [shost=<host_address>] [dhost=<host_address>] [port=<port>]

[sport=<port>] [dport=<port>] [iface=<interface>] [siface=<interface>] [diface=<interface>]

[proto=<tcp|udp>] [iptype=<4|6>] [rtid=<router_name>] [qid=<qidname>]

MONITOR FILTERTABLE

History

Appears in 3.0.0

Description

Filters table management

MONITOR FILTERTABLE SHOW

Level

filter_read

History

Appears in 3.0.0

**Description**

Dump a filter table

Usage

Name=<table_name>

Format

list

Example

MONITOR FILTERTABLE SHOW Name=hosts_table

MONITOR FLUSH

Description

Flush firewall information

MONITOR FLUSH ADDRESSLIST

Level

filter, mon_write

History

Appears in Netasq 6.0.0

Description

Flushes an object in the dynamic address list, or flush all entries in the dynamic if 'all' given as argument

Usage

Type=BlackList|BlackListExclude|WhiteList|WhiteListExclude Name1=<object>|all
[Name2=<object>]

Remark

Filter and Modify levels are required for Type that are not BlackList

Example

MONITOR FLUSH ADDRESSLIST Type=BlackList Name1=10.2.16.1
MONITOR FLUSH ADDRESSLIST Type=BlackList Name1=all

MONITOR FLUSH HOSTREP

Level

log,mon_write

History

Appears in 3.0.0

ip=any appears in 3.2.0

Description

Flush the host reputation of a given IPv4 address

Usage



ip={<IP4>|any}

Example

```
MONITOR FLUSH HOSTREP ip=10.11.12.13  
MONITOR FLUSH HOSTREP ip=any
```

MONITOR FLUSH INFO

Level

base, mon_write

History

Appears in 1.0.0

Description

Get flush informations

Returns

[rulestat]

last_global_reset=<secs> time in secs since the last global slot reset

last_local_reset=<secs> time in secs since the last local slot reset

Example

```
MONITOR FLUSH INFO  
[rulestat]  
last_global_reset=150  
last_local_reset=654
```

MONITOR FLUSH PVM

Level

pvm, mon_write

History

Appears in Netasq 7.0.0

Description

Clear the whole PVM knowledge base or all data of a host

Usage

{All | HostId=<host>}

Returns

Error code

MONITOR FLUSH RULEMATCH

Level

filter,mon_write,modify

History

Appears in 1.0.0

Description



Reset filter rulematch counters

Usage

<global={0|1}>

Example

MONITOR FLUSH RULEMATCH global=0

MONITOR FLUSH SA

Level

vpn_read,mon_write

History

Appears in Netasq 6.0.0

Description

Flushes an SA identified by it's SPI, or flush all SAs if 'all' given as SPI

Usage

<SA SPI>|'all'

Example

MONITOR FLUSH SA 456303451
MONITOR FLUSH SA 0x1b32a35b
MONITOR FLUSH SA all

MONITOR FLUSH STAT

Level

log,mon_write

History

level mon_write Appears in Netasq 6.0.0
level modify deprecated in Netasq 6.0.0

Description

Reset ASQ statistics

MONITOR FLUSH STATE

Level

log,mon_write

History

level mon_write Appears in Netasq 6.0.0
level modify deprecated in Netasq 6.0.0
rtstate appears in 4.3.0

Description

Flush ASQ state (host, connection, fragment, ...)

Usage

<ip> [rtstate=<UP|DEGRADED|DOWN>]



MONITOR FLUSH USER

Level

log,mon_write

History

level mon_write Appears in Netasq 6.0.0

level modify deprecated in Netasq 6.0.0

Normalized in 3.0.0

DomainName appears in 3.0.0

Filter split to Name and Address in 3.3.0

Description

Flush authenticated user

Usage

address=any | [address=<ip>] [name=<name>] [domainname=<domain>]

MONITOR FWADMIN

Level

base

History

Appears in 2.2.0

Description

Read CAD connection's informations

Returns

Error code

Example

MONITOR FWADMIN

MONITOR GETIKESA

Level

vpn_read

History

Appears in 4.2.0

Description

List IPsec IKE SA

Returns

id=<id> : IKE_SA unique id

rulename=<name> : IKE_SA rule name

src=<ip> : source IP address

srcname=<name> : source object name

dst=<ip> : destination IP address

dstname=<name> : destination object name

localid=<id> : local identifier



peerid=<id> : remote identifier
 side=initiator|responder : local side
 cookiei=<id> : initiator cookie
 cookier=<id> : responder cookie
 nat=none|local|remote|both : NAT detection
 enc=<algo> : encryption algorithm
 auth=<algo> : authentication algorithm
 prf=<algo> : PRF algorithm
 pfs=<algo> : DH group in use
 state=<state> : IKE_SA state: created|connecting|established|rekeying|destroying
 lifetime=<secs> : time count
 maxlifetime=<secs> : delay between rekeys

Format

section_line

Example

```

101 begin
rulename="Site_fw_vm_2" ike=2
src=192.168.10.1 srcname=Firewall_in dst=192.168.11.1 dstname=fw_vm_2
state="established" side="responder" cookiei=0x7b5a38c03059959a
cookier=0xd0763b6d58a30150
localid="lid" peerid="pid" nat="none" enc="aes/256" auth="sha256" prf="sha256" pfs="14"
lifetime=127 maxlifetime=21251
.
  
```

MONITOR GETSA**Level**

vpn_read

History

Format Appears in Netasq 9.0.0

Behavior changed in 4.2.0

Description

List IPsec SA

Returns

id=<id> : CHILD_SA unique id
 rulename=<name> : CHILD_SA rule name
 ikeid=<id> : IKE_SA unique id
 ikerulename=<name> : IKE_SA rule name
 src=<ip> : source IP address
 srcname=<name> : source object name
 dst=<ip> : destination IP address
 dstname=<name> : destination object name
 type=ah|esp : SA type
 mode=<mode> : IPSec mode: tunnel|drop|pass
 spiin=<id> : identifier
 spiout=<id> : identifier
 reqid=<id> : identifier
 enc=<algo> : cypher algo in use
 auth=<algo> : authentication in use
 prf=<algo> : PRF algorithm



pfs=<algo> : DH group in use
 state=<state> : SA state: created|installed|rekeying|destroying
 bytesin=<count> : byte count
 bytesout=<count> : byte count
 packetsin=<count> : packet count
 packetsout=<count> : packet count
 lifetime=<secs> : time count
 maxlifetime=<secs> : delay between rekeys

Format

section_line

Example

```

101 begin
rulename="ba6c3194672da4df9590d7ff827384b4" ikerulename="Site_fw_vm_2"
src=192.168.10.1 srcname=Firewall_in dst=192.168.11.1 dstname=fw_vm_2
type="esp" mode="tunnel" encap=0 esn=0 reqid=1
spiout=3439867777 spiin=3485712767 enc="aes/256" auth="hmac_sha256"
state=installed bytesin=0 bytesout=864 packetsin=0 packetsout=8 lifetime=134
maxlifetime=3601
.

```

MONITOR GETSPD**Level**

vpn_read

History

Appears in Netasq 6.1.0
 Behavior changed in 4.2.0
 Format Appears in Netasq 9.0.0

Description

List IPsec SPD policy

Returns

rulename=<name> : CHILD_SA rule name
 ikerulename=<name> : IKE_SA rule name
 src=<ip> : source IP address
 srcname=<name> : Optionnal source object name
 srcmask=<masklen> : the value of src mask len in bits
 srcport=<port> : Optionnal source port
 dst=<ip> : destination IP address
 dstname=<name> : Optionnal destination object name
 dstmask=<masklen> : the value of dst mask len in bits
 dstport=<port> : Optionnal destination port
 localid=<id> : local identifier
 peerid=<id> : remote identifier
 proto=<protocol> : Optionnal protocol name
 srcgw=<ip> : source Gateway IP
 srcgwname=<name> : Optionnal source Gateway name
 dstgw=<ip> : destination Gateway IP
 dstgwname=<name> : Optionnal destination Gateway name
 ike=<version> : IKE version
 enc=esp|ah|ipcomp : encapsulation mode



policy=<policy> : IPSec mode: tunnel|pass|drop
maxlifetime=<secs> : max time count

Format

section_line

Example

```
101 begin
rulename="Site_fw_vm_2" src=192.168.74.4 srcmask=32 srcname=vm_base
dst=0.0.0.0 dstmask=0 dstname=any srcgw=192.168.10.1 srcgwname=Firewall_in
dstgw=192.168.11.1 dstgwname=fw_vm_2 localid="lid" peerid="pid"
ike=2 enc="esp" policy="tunnel" maxlifetime=2880
.
```

MONITOR GPRS

Level

base

History

appears in Netasq 9.0.2

Description

show GPRS network and signal quality

Returns

```
[<name of GPRS interface>]
operator="<network operator>"
signal_quality=<signal quality in bars {0-5}>
```

MONITOR HEALTH

Level

base

History

Appears in 3.6.0

Description

Monitor a synthetic health indicator

Usage

<none>

Example

MONITOR HEALTH

Returns

```
[<serial>] hamode={none|active|passive} cpu={n/a|unknown|good|minor|major} cpu_temp=
{n/a|unknown|good|minor|major} disk={n/a|unknown|good|minor|major} fans=
{n/a|unknown|good|minor|major} mem={n/a|unknown|good|minor|major} powerstatus=
{n/a|unknown|good|minor|major} raid={n/a|unknown|good|minor|major} cert=
{n/a|unknown|good|minor|major} crl={n/a|unknown|good|minor|major} passwd=
```



(n/a|unknown|good|minor|major) router=(n/a|unknown|good|minor|major) [MAIN] status=
(unknown|good|minor|major)

MONITOR HOST

Level

log_read

History

argument addr appears in 3.0.0
argument iface appears in 3.0.0
argument bandwidth appears in 3.0.0
argument maxcount appears in 3.0.0
Format Appears in Netasq 9.0.0
mac_addr, byte_count and throughput_out appears in 1.0.0
conn disappears in 1.0.0
hostrep appears in 3.0.0
state appears in 3.0.0
geo, iprep appears in 3.8.0

Description

List host informations and statistics

Usage

[addr=<host address or range>] [iface=<interface name>] [bandwidth=<integer_with_metric>]
[maxcount=<integer>] [hostrep=<integer>] [geo=<geo>] [iprep=any|none|<string>]
[state=<host_state>[,<host_state>[[...]]]]

Returns

addr : host IP address
mac_addr : ethernet address
name : host name
interface : host interface
packet : total accepted packet count
byte : total incoming byte count
byte_count : total outgoing byte count
throughput : current incoming throughput (current,max)
throughput_out : current outgoing throughput (current,max)
hostrep : current reputation for that protected host
geo : current geolocation for that public host
iprep : current reputation for that public host
state : host state

Format

section_line

Example

```
101 begin
addr=10.3.0.1 name=10.3.0.1 interface=FwTunnel_OUT packet=0 byte=0 conn=0
throughput=0,0 hostrep=0
addr=10.3.1.1 name=10.3.1.1 interface=FwTunnel_OUT packet=4 byte=916 conn=0
throughput=0,71 hostrep=234
...
```




MONITOR HOSTREP

Level

base

History

appears in 3.0.0

Description

Get the host reputation score of a given IPv4 address

Format

section

Usage

ip=<IPv4>

Remark

Hosts that are not monitored are given a 0 score

Returns

hostrep=<integer> : Host reputation score, between 0 and 65535

Example

MONITOR HOSTREP ip=10.11.12.13

[Result]

hostrep=54

MONITOR INTERFACE

Level

log_read

History

Format Appears in Netasq 9.0.0 argument name appears in 3.0.0

Description

Display interface information

Usage

[name=<comma-separated list of interface names>]

Returns

name=user interface name,real interface name

type=ethernet|dialup|vlan|pptp

addr=address/mask

color=rgb

throughput=interface in : mac,current,max,userdefined in bits

throughput_out=interface out : mac,current,max,userdefined in bits

packet=accepted,blocked,fragmented,tcp,udp,icmp

byte=incomming : total,tcp,udp,icmp

byte_out=outgoing : total,tcp,udp,icmp

tcpconn=nb of tcp connection since last stat reset

udpconn=nb of udp connection since last stat reset

tcpconncount=nb of current tcp connection inside ASQ



udpconncount=nb of current udp connection inside ASQ
state=0|1 : interface down | interface up
plugged=0|1 : Passive | Active
protected=0|1 : Non protected | Protected
fullduplex=0|1 : Half duplex | Full duplex

Remark

Without interface name, return information from all interfaces. All values are in bits

Format

section_line

Example

MONITOR INTERFACE in
100 name=in,ethernet1 addr=10.2.0.1/255.0.0.0 type=ethernet color=A040FF

MONITOR IPGEOLOC

Level

base

History

appears in 3.0.0

Description

Get the geolocation of a given IP address

Format

section

Usage

ip=<IP>

Returns

[Continent] code=[continent_code] : Empty if not available name=[localized_name] : Empty if not available
[Country] code=[country_code] : Empty if not available name=[localized_name] : Empty if not available

Example

MONITOR IPGEOLOC ip=111.111.111.111
[Continent]
code=as
name=Asia
[Country]
code=jp
name=Japan

MONITOR IPREP

Level

base

History

appears in 3.0.0

**Description**

Get the reputation of a given IP address

Format

section

Usage

ip=<IP>

Returns

[Result] iprep=[rep1,[rep2[,...]]] : Empty if not available

Example

MONITOR IPGEOLOC ip=121.18.238.19 [Result]
iprep=botnet,scanner

MONITOR LOG

Level

log_read

History

appears in Netasq 9.0.0

Description

Get last log lines from the dispatch queue

Usage

<logname> lastid|all|<id>

Remark

lastid return only the last alarm id

Format

section_line

Example

MONITOR LOG connection all

MONITOR MISC

Level

base

History

Appears in 4.2.0

Description

Display miscellaneous information about the UTM

Usage

<none>

Example



MONITOR MISC

Returns

One message per occurring status, using the following tokens:

code : internal ID for the message
class : severity ('Info', 'Warning' or 'Alert')
module : relevant module
message : status information

Format

section_line

MONITOR OPENVPN

Level

base

History

Appears in 1.0.0

Description

OpenVPN monitor commands

MONITOR OPENVPN LIST

Level

base

History

Appears in 1.0.0
protocol appears in 3.2.0

Usage

[ipproto=<all|tcp|udp>]

Description

Display currently connected users

Format

section_line

MONITOR OPENVPN REMOVE

Level

base

History

Appears in 1.0.0
domain appears in 3.0.0
protocol appears in 3.2.0

Description

Remove connected user

**Usage**

user=<all|username> : client username
 domain=<all|domainname> : client domain
 [ip=<ip>|<all>] : real ip of client
 [port=<port>|<all>] : port of client
 [protocol=<all|tcp|udp>]

Returns

Error code

Example

```
MONITOR OPENVPN REMOVE domain=all user=all
MONITOR OPENVPN REMOVE domain=company user=test ip=all
MONITOR OPENVPN REMOVE domain=all user=test ip=all port=all
MONITOR OPENVPN REMOVE DOMAIN=company USER=test ip=192.168.0.1
MONITOR OPENVPN REMOVE DOMAIN=OTHER USER=test ip=192.168.0.1 port=4242
```

MONITOR POLICY**Level**

base

History

Appears in Netasq 6.0.0

Description

List active slot and sync status

Usage

[host=<host address or name>] [ifname=<interface>] [srcifname=<interface>]
 [dstifname=<interface>] [slotlevel=<slot> ruleid=<rule>] [rulename=<rulename>]
 [rtstate=<UP,DOWN,DEGRADED>] [state=<all,recovery,skel,open,c_syn,s_ syn,data,close,closed,hopen,reset>] [natslotlevel=<slot> natruleid=<rule>] [rtidname=<router_ name>] [qidname=<qidname>] [ackqidname=<qidname>] [srcmac=<macaddr>]
 [username=<user>] [dstport=<integer port|string port name>] [plugin=<plugin_name>]
 [bytes=<integer_with_metric>] [lastuse=<integer>] [maxcount=<integer>] [confid=<integer>]
 [geo=<geo>] [iprep=any|none|<string>]

Returns

time : connection creation time
 id : unique identifier
 parentid : parent unique identifier for protocol like ftp or 0 if not used
 proto : protocol (tcp, udp, http, ...)
 src : source IP address
 srcname : client object name, or miniDNS client name for source IP address
 srcmac : source ETHERNET address
 srcport : source port
 srcportname : source port object name
 dst : destination IP address
 dstname : destination object name, or miniDNS server name for destination IP address
 dstport : destination port
 dstportname : destination port object name
 srcif : packets source interface
 dstif : packets destination interface



sent : bytes sent
rcvd : bytes received
duration : duration in seconds
lastuse : time in seconds since last use
rtid : router ID
rtidname : router ID name
slotlevel : slot level
ruleid : rule ID
confid : configuration ID
natslotlevel : nat slot level
natruleid : nat rule ID
state : state of TCP connection
qidname : Qos ID name
rtstate : route state
ackqidname : Qos ID name for acks
username : username for the connexion
... : protocol dependent field

Format

section_line

MONITOR POWER

Level

base

History

Appears in 1.2.0

Serial argument appears in 3.5.0

Description

Monitor power states

Usage

[serial=SNXXX]

Example

MONITOR POWER

MONITOR POWER serial=SNXXX

Returns

[Power0]

{OK|FAILED|NOTFOUND}

[Power1]

{OK|FAILED|NOTFOUND}

MONITOR PROXYCACHE

Level

base

History



Appears in 1.0.0 Deprecated in 4.3.0

Description

Monitor Proxy-Cache

Returns

[Cache]

RequestHitRatios=<percentage_value_for_last_hour>

ByteHitRatios=<percentage_value_for_last_hour>

RequestMemoryHitRatios=<percentage_value_for_last_hour>

RequestDiskHitRatios=<percentage_value_for_last_hour>

Example

MONITOR PROXYCACHE

MONITOR PVM

Level

base

History

Appears in Netasq 7.0.0

Description

Display information of the proactive vulnerability management module

MONITOR PVM FORCE

Level

base

History

Appears in Netasq 7.0.0

Description

Manage user forced os/service values

MONITOR PVM FORCE CHECK

Level

pvm

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

Test user defined value and return real PVM value

Usage

[Type=os Name=<user_os> | Type=service Name=<user_service>]

Returns

the nearest valid name

**Format**

list

Example

```
MONITOR PVM FORCE CHECK Type=service Name="Apache 1.3"  
101 code=00a01000 msg="Début"  
Apache_1.3.x 100 code=00a00100 msg="Ok"
```

MONITOR PVM FORCE LIST**Level**

pvm

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

List products or product families that can be forced by the user

Usage

Type=os|service

Returns

name : name of the product family : is it a product family or not (a product family could be set followed by a version)

Format

section_line

Example

```
MONITOR PVM FORCE LIST Type=os  
101 code=00a01000 msg="Début"  
name=Linux family=1  
name=Windows_XP family=0  
...  
100 code=00a00100 msg="Ok"
```

MONITOR PVM FORCE SET**Level**

pvm, mon_write

History

Appears in Netasq 7.0.0

Description

Set a user forced value for os/service

Usage

HostId=<host> [Name=<pvm_os> | Port={<obj_port>|<port_num/iproto>}] Name=<pvm_service>]

Returns

Error code



MONITOR PVM HOST

Level

pvm

History

Appears in Netasq 7.0.0

product Appears in Netasq 8.0.0

osname Appears in Netasq 8.0.0

Format Appears in Netasq 9.0.0

Description

Return all hosts which have some informations stored in proactive vulnerability management module

Returns

hostid : id use to join this other monitor requests

addr : ip address of the affected host

name : name of the host

info : number of information detected on the host

vuln : number of vulnerability detected on the host

port : number of open port detected on the host

product : number of product detected on the host

service : number of service (product that hold an open port) detected on the host

lastevent : date of the last even seen on the host

osname : operating system without version of the host

os : operating system of the host

detectedos : operating system of the host as detected by the proactive vulnerability management module

Format

section_line

Example

```
> MONITOR PVM VULN HOST
```

```
101 code=00a01000 msg="Début"
```

```
hostid=x addr=x name=x info=x vuln=x product=x service=x port=x lastevent=x osname=x
```

```
os=x detectedos=x
```

```
hostid=x addr=x name=x info=x vuln=x product=x service=x port=x lastevent=x osname=x
```

```
os=x detectedos=x
```

```
100 code=00a00100 msg="Ok"
```

MONITOR PVM HOSTBYOS

Level

pvm

History

Appears in Netasq 8.0.0

Format Appears in Netasq 9.0.0

Description

Return all hosts on which the os have been found

Usage



OsName=<pvm_os>

Returns

hostid : id use to join this other monitor requests

addr : address of the host

name : name of the host

os : real os (with version)

Format

section_line

Example

```
> MONITOR PVM HOSTBYPRODUCT OsName=Linux
101 code=00a01000 msg="Début"
hostid=x addr=x name=x os=x
hostid=x addr=x name=x os=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM HOSTBYPRODUCT

Level

pvm

History

Appears in Netasq 8.0.0

Format Appears in Netasq 9.0.0

Description

Return all hosts on which the product have been found

Usage

ProductName=<pvm_product>

Returns

hostid : id use to join this other monitor requests

addr : address of the host

name : name of the host

os : operating system of the host

product : real detected product (with version)

Format

section_line

Example

```
> MONITOR PVM HOSTBYPRODUCT ProductName=Firefox
101 code=00a01000 msg="Début"
hostid=x addr=x name=x os=x product=x
hostid=x addr=x name=x os=x product=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM HOSTBYPVMID

Level

pvm

**History**

Appears in Netasq 7.0.0

product Appears in Netasq 8.0.0

Format Appears in Netasq 9.0.0

Description

Return all hosts on which the vulnerability|information have been found

Usage

PvmId=<pvm_id>

Returns

hostid : id use to join this other monitor requests

addr : address of the affected host

name : name of the host

os : operating system of the host

port : port of the service on which the vulnerability|information has been found (if any)

productname : product name without version on which the vulnerability|information has been found (if any)

product : product name on which the vulnerability|information has been found (if any)

servicename : service without version (product with an open port) name on which the vulnerability|information has been found (if any)

service : service (product with an open port) name on which the vulnerability|information has been found (if any)

affecteddate : date when the vulnerability|information has been found on the host

detail : additional vulnerability|information data (if any)

Format

section_line

Example

```
> MONITOR PVM HOSTBYPVMID PvmId=12002
```

```
101 code=00a01000 msg="Début"
```

```
hostid=x addr=x name=x os=x port=x/tcp servicename=x service=x affecteddate=x detail=x
```

```
hostid=x addr=x name=x os=x port=x/udp servicename=x service=x affecteddate=x detail=x
```

```
100 code=00a00100 msg="Ok" > MONITOR PVM HOSTBYPVMID PvmId=12005
```

```
101 code=00a01000 msg="Début"
```

```
hostid=x addr=x name=x os=x productname=x product=x affecteddate=x detail=x
```

```
100 code=00a00100 msg="Ok" > MONITOR PVM HOSTBYPVMID PvmId=12007
```

```
101 code=00a01000 msg="Début"
```

```
hostid=x addr=x name=x os=x affecteddate=x detail=x
```

```
100 code=00a00100 msg="Ok"
```

MONITOR PVM HOSTBYSERVICE**Level**

pvm

History

Appears in Netasq 8.0.0

Format Appears in Netasq 9.0.0

Description

Return all hosts on which the service have been found

**Usage**

ServiceName=<pvm_service>

Returns

hostid : id use to join this other monitor requests
addr : address of the host
name : name of the host
os : operating system of the host
port : port on which the service has been found
service : real detected service (with version)

Format

section_line

Example

```
> MONITOR PVM HOSTBYSERVICE ServiceName=Apache
101 code=00a01000 msg="Début"
hostid=x addr=x name=x os=x port=x service=x
hostid=x addr=x name=x os=x port=x service=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM HOSTDATA**Level**

pvm

History

Appears in Netasq 7.0.0
product stuffs Appears in Netasq 8.0.0
servicename Appears in Netasq 8.0.0
osname Appears in Netasq 8.0.0
service family Appears in Netasq 8.0.0

Description

Return informations, services and vulnerabilities of a host

Usage

HostId=<host_id>

Format

section_line

Returns

[Host]

hostid : id use to join this other monitor requests
addr : ip address of the host
name : name of the host
port : number of open port
product : number of product
service : number of service (product that hold an open port)
osname : operating system without version of the host
os : operating system of the host
detectedos : operating system of the host as detected by the proactive vulnerability management module
info : number of informations detected by the proactive vulnerability management module



vuln : number of vulnerabilities detected by the proactive vulnerability management module

[Product]

productname : product without version

product : product name

family : product's family id

[Service]

port : port of the service

servicename : service without version

service : service name

detectedservice : service name as detected by the proactive vulnerability management module

family : service's family id

[Info]

id : information id

name : information's name

family : information's family id

level : alarm level of the information on the host (ignore, minor or major)

port : port of the service on which the information has been found (if any)

product : product name on which the information has been found (if any)

service : service (product with an open port) name on which the information has been found (if any)

affecteddate : date when the information has been found on the host

detail : additional data (if any)

[Vuln]

id : vulnerability id

name : vulnerability's name

family : vulnerability's family id

severity : vulnerability's severity id

remote : true if the vulnerability could be exploited remotely

solution : true if the vulnerability could be corrected

level : alarm level of the vulnerability on the host (ignore, minor or major)

port : port of the service on which the vulnerability has been found (if any)

product : product name on which the vulnerability has been found (if any)

service : service (product with an open port) name on which the vulnerability has been found (if any)

affecteddate : date when the vulnerability has been found on the host

detail : additional data (if any)

Example

```
> MONITOR PVM HOSTDATA HostId=x
```

```
101 code=00a01000 msg="Début"
```

```
[Host]
```

```
hostid=x
```

```
addr=x
```

```
name=x
```

```
info=x
```

```
vuln=x
```

```
port=x
```

```
osname=x
```

```
os=x
```

```
detectedos=x
```

```
[Product]
```



```
productname=x product=x family=x
productname=x product=x family=x
[Service]
port=x/tcp servicename=x service=x detectedservice=x family=x
port=x/tcp servicename=x service=x detectedservice=x family=x
port=x/tcp servicename=x service=x detectedservice=x family=x
[Info]
id=x name=x family=x level=x port=x/tcp service=x detail=x
id=x name=x family=x level=x port=x/udp service=x
id=x name=x family=x level=x product=x detail=x
id=x name=x family=x level=x detail=x
[Vuln]
id=x name=x family=x severity=x remote=x solution=x level=x port=x/tcp service=x detail=x
id=x name=x family=x severity=x remote=x solution=x level=x port=x/udp service=x
id=x name=x family=x severity=x remote=x solution=x level=x product=x detail=x
id=x name=x family=x severity=x remote=x solution=x level=x detail=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM INFO

Level

pvm

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

Return all informations detected by the proactive vulnerability management module

Returns

id : information id

name : information's name

family : information's family id

affectedhost : number of hosts which are affected by this vulnerability

Format

section_line

Example

```
> MONITOR PVM INFO
```

```
101 code=00a01000 msg="Début"
```

```
id=x name="x" family=x affectedhost=x
```

```
id=x name="x" family=x affectedhost=x
```

```
100 code=00a00100 msg="Ok"
```

MONITOR PVM OS

Level

pvm

History

Appears in Netasq 8.0.0

Format Appears in Netasq 9.0.0

**Description**

Return all operating systems detected by the proactive vulnerability management module

Returns

osname : operating system without version
family : os' family id
count : number of instance of this os

Format

section_line

Example

```
> MONITOR PVM INFO
101 code=00a01000 msg="Début"
osname=x family=x count=x
osname=x family=x count=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM PRODUCT**Level**

pvm

History

Appears in Netasq 8.0.0
Format Appears in Netasq 9.0.0

Description

Return all products detected by the proactive vulnerability management module

Returns

productname : product without version
family : product's family id
count : number of instance of this product

Format

section_line

Example

```
> MONITOR PVM INFO
101 code=00a01000 msg="Début"
productname=x family=x count=x
productname=x family=x count=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM SERVICE**Level**

pvm

History

Appears in Netasq 8.0.0
Format Appears in Netasq 9.0.0

**Description**

Return all services (products with an open port) detected by the proactive vulnerability management module

Returns

servicename : service without version
family : service's family id
count : number of instance of this service

Format

section_line

Example

```
> MONITOR PVM INFO
101 code=00a01000 msg="Début"
servicename=x family=x count=x
servicename=x family=x count=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM STAT**Level**

pvm

History

Appears in Netasq 7.0.0

Description

Return statistics on vulnerabilities|informations found by the proactive vulnerability management module

Returns

[LastQuarter]

info : number of informations detected in the last quarter
vuln : number of vulnerabilities detected in the last quarter
host : number of hosts seen by the proactive vulnerability management module in the last quarter

[Info]

total : total number of information detected
less12h : number of information detected in the last 12 hours
less1d : number of information detected in the last day
less2d : number of information detected in the last 2 days
less7d : number of information detected in the last 7 days
less30d : number of information detected in the last 30 days

[Vuln]

total : total number of vulnerability detected
less12h : number of vulnerability detected in the last 12 hours
less1d : number of vulnerability detected in the last day
less2d : number of vulnerability detected in the last 2 days
less7d : number of vulnerability detected in the last 7 days
less30d : number of vulnerability detected in the last 30 days

Example

```
> MONITOR PVM STAT
101 code=00a01000 msg="Début"
```




```
[LastQuarter]
info=x
vuln=x
host=x
[Info]
total=x
less_12h=x
less_1d=x
less_2d=x
less_7d=x
less_30d=x
[Vuln]
total=x
less_12h=x
less_1d=x
less_2d=x
less_7d=x
less_30d=x
100 code=00a00100 msg="Ok"
```

MONITOR PVM VULN

Level

pvm

History

Appears in Netasq 7.0.0

Format Appears in Netasq 9.0.0

Description

Return all vulnerabilities detected by the proactive vulnerability management module

Returns

id : vulnerability id
name : vulnerability's name
family : vulnerability's family id
severity : vulnerability's severity id
date : vulnerability's discovery date
targetclient : true if affected product is a client
targetserver : true if affected product is a server
remote : true if the vulnerability could be exploited remotely
solution : true if the vulnerability could be corrected
affectedhost : number of hosts which are affected by this vulnerability

Format

section_line

Example

```
> MONITOR PVM VULN
101 code=00a01000 msg="Début"
id=x name="x" family=x severity=x date=x targetclient=x targetserver=x remote=x solution=x
affectedhost=x
id=x name="x" family=x severity=x date=x targetclient=x targetserver=x remote=x solution=x
affectedhost=x
100 code=00a00100 msg="Ok"
```



MONITOR QOS

Level

log_read

History

Appears in Netasq 6.1.0

Format Appears in Netasq 9.0.0

qid appears in 3.0.0

Description

List QoS queues informations and statistics

Usage

[qid=<queue_name_list>] [ifname=<interface>]

Returns

qid : queue name

interface : interface name

byte : total byte count

conn : current connection count

throughput : current throughput (current,max)

Format

section_line

MONITOR RADIUS

Level

base

History

Appears in 4.3.0

Description

Display RADIUS servers status

Usage

<none>

Example

MONITOR RADIUS

Returns

RADIUS servers connection status

MONITOR RAID

Level

base

History

Serial argument appears in 3.5.0

**Description**

Give the RAID's status

Example

```
MONITOR RAID
MONITOR RAID serial=SNXXX
```

Returns

```
[DISK_0]
Address=1
Status="Optimal"
Type=RAID_DISK
```

```
[DISK_1]
Address=3
Status="Optimal"
Type=RAID_DISK
```

```
[RAID_ARRAY_0]
Address=1
Status="Optimal"
Type=RAID-1
Children=DISK_0,DISK_1
```

```
[DISK_2]
Address=2
Status="Optimal"
Type=HOTSPARE
```

MONITOR REVRT**Level**

log_read

History

Appears in 3.2.0

Format

section_line

Description

List reverse routing information

Returns

```
revrtid : reverse router id
IP : IP address of the reverse router
MAC : MAC address of the reverse router
if : interface of the reverse router
used : number of packets processed
learning : the MAC address is in learning mode
```

Example

```
revrtid="1" IP="10.2.57.254" MAC="00:0d:b4:0e:bf:59" if="out" used="0" learning="no"
```



MONITOR ROUTE

Level

log_read

History

Appears in 1.0.0

Format

section_line

Description

List routing information

Returns

```
[ASQRoute]
name=<name>
gateway=<ip> : gateway IP addr
rtid=<id> : route id
used=<count> : number of packet processed
type=<Interface|LB|Filter> : route type
status=<0|1> : 0=disabled, 1=enabled
[Gateways]
type=<PrincipalGateway|BackupGateway>
name=<name>
lastip=<ip>
state=<UP|DOWN>
```

Example

```
[ASQRoute]
name="dmz13" gateway="10.200.35.200" rtid=0 used=0 type="Interface" enabled=1
name="fw_labo" gateway="10.2.0.1" rtid=1 used=0 type="Filter" enabled=1
name="gm_fw_system" gateway="10.200.0.1" rtid=2 used=0 type="LB" enabled=1
name="gm_fw_u450_test" gateway="10.200.35.254" rtid=3 used=0 type="LB" enabled=1
[Gateways]
type="PrincipalGateway" name="fw_system" lastip="10.200.0.1" result="UP"
type="PrincipalGateway" name="dummy_gateway" lastip="10.200.35.50" result="DOWN"
type="PrincipalGateway" name="fw_u450_test" lastip="10.200.35.254" result="UP"
```

MONITOR ROUTER

Level

log_read

History

Appears in 4.3.4

Description

Display the measures used to compute the metrics for the gateways of the given router

Usage

name=<router name> [gateways=<comma separated list of gateway>]

Example



```
MONITOR ROUTER name=router1 gateways=host1
101 code=00a01000 msg="Begin" format="section_line"
[host1/ipv4]
index=0 latency=1 packet_loss=0 unreachable=no canceled=no state=up datetime="2022-01-19 06:58:20"
index=1 latency=1 packet_loss=0 unreachable=no canceled=no state=up datetime="2022-01-19 06:58:25"
index=2 latency=1 packet_loss=0 unreachable=no canceled=no state=up datetime="2022-01-19 06:58:30"
```

Returns

a section for each gateway containing the liste of measure as follow

```
[ <gateway_name>/<ip_version> ]
index=<measure number> latency=<integer> packet_loss=<integer> unreachable=<yes|no>
canceled=<yes|no> state=<up|down|degraded> datetime=<date>
```

Format

section_line

MONITOR SANDBOXING

Level

base

History

Appears in 2.5.0

Description

Sandboxing commands

MONITOR SANDBOXING MISCLASS

Level

base

History

Appears in 2.5.0

Description

Send misclassify request about false-positive/negative to sandboxing infrastructure.

Usage

- hash: hash file;
- message: message to explain proposition.

Returns

Error code

Example

```
MONITOR SANDBOXING MISCLASS
hash=1e3fae9f3b66aca7c03b35bc3fea2471161f68327656079adbe690a9832b1ebb
message="nasty malware"
```



MONITOR SERVICES

Level

log_read

History

Format Appears in Netasq 9.0.0

output syntax changed in 3.0.0

Description

Displays the list of all services, with their state, uptime and CPU use

Returns

[Service]

name=asqd state=1 uptime=236194 cpu=1.0

name=dhclient state=0 uptime=236202

name=dhcpd state=0 uptime=236202

name=dns state=0 uptime=236202

name=eventd state=1 uptime=236182 cpu=0.0

name=sld state=1 uptime=236180 cpu=0.0

name=httpproxy state=0 uptime=46

name=smtpproxy state=0 uptime=46

name=pop3proxy state=0 uptime=46

name=ftpproxy state=0 uptime=46

name=sslproxy state=0 uptime=46

Format

section_line

MONITOR SMART

Level

base

History

Appears in 1.0.0

Serial argument appears in 3.5.0

Usage

[serial=SNXXX]

Description

Monitor the health and attributes of each S.M.A.R.T. devices

Example

MONITOR SMART

MONITOR SMART serial=SNXXX

MONITOR SSOAGENT

Level

base

History



Appears in 4.1.0

Description

Dump the SSO Agent status

Usage

<none>

Example

MONITOR SSOAGENT

Returns

status of ssoAgent

MONITOR STAT

Level

log_read

History

Serial argument appears in 3.5.0

Description

List firewall informations and statistics

Usage

[serial=SNXXX]

Example

MONITOR STAT

MONITOR STAT serial=SNXXX

Returns

time=<%Y-%m-%d %T> : current system date

uptime=<day:hour:min:sec> : system running for

mem=<host,frag,icmp,conn,dtrack,dyn> : memory left for in percent

statime= :

temperature= : current cpu[s] temperature in celsius (NA if not available)

CPU=<user+sys+nice,intr,sys>: CPU load informations

Example

date="2002-08-08 12:54:55"

uptime=1:3:14:29

mem=1,0,0,0

statime="2002-08-08 12:01:00"

temperature=40,48

CPU=25,4,15

MONITOR SYSLOG

Level

base

History



Appears in 4.1.0

Description

Display syslog profiles status

Returns

Syslog profiles status

MONITOR SYSTEM

Level

base

History

Appears in 3.5.0

Description

Dump multiple system status in one command

Usage

[serial=SNXXX]

Example

MONITOR SYSTEM

MONITOR SYSTEM serial=SNXXX

Returns

[STAT_Result]

time=<%Y-%m-%d %T> : current system date

uptime=<day:hour:min:sec> : system running for

mem=<host,frag,icmp,conn,dtrack,dyn> : memory left for in percent

stattime= :

temperature= : current cpu(s) temperature in celsius (NA if not available)

CPU=<user+sys+nice,intr,sys>: CPU load informations [POWERSUPPLY_PowerX]

status={OK|FAILED|NOTFOUND}

[SMART_diskX]

DiskHealth={PASSED|FAILED}

[FANS_fanX]

status={RPM|MISSING}

[BYPASS_Result]

SystemOff={Enable|Disable}

JustOn={Enable|Disable}

RunTime={Enable|Disable}

RunTimeWatchdogTimeStatus={Start|Stop}

[RAID XXX] Status={unknown|optimal|degraded|missing} Address={top|bottom} Type=

(DISK|RAID-DISK) AtaPort=XXX

MONITOR THIND

Level

base

History

Appears in 2.3.0

**Description**

Check thind status

Returns

[Sandboxing] Status=<UP|DOWN|LIMITED|DISABLED> Msg=<server message>

MONITOR TPM**Level**

base

History

Appears in 3.10.0

Description

Dump the TPM status

Usage

<none>

Example

MONITOR TPM

Returns

installed={0|1} self_test={0|1} onchip_init={0|1} ondisk_init={0|1} autobackup=
(Unknown|Disabled|Unprotected|Protected)

MONITOR USER**Level**

log_read

History

argument name appears in 3.0.0

argument addr appears in 3.0.0

argument auth appears in 3.0.0

argument maxcount appears in 3.0.0

argument domain appears in 3.0.0

Format Appears in Netasq 9.0.0

Description

List authenticated user

Usage

[name=<username>] [addr=<user address or range>] [auth=<method>]
[domain=<userdomain>] [maxcount=<integer>]

Returns

name : user name

domain : user domain

addr : host IP address

timeout : time left in seconds

group : user group name

authmethod : authentication method



multiuser : is multiuser ip
admin : user has admin right
sslvpn : user has sslvpn right
sslrdr : user has sslrdr right
openvpn : user has openvpn right
sponsoring : user has sponsoring right

Format

section_line

Example

```
101 begin
name="auth1d" domain="userdomain.eu" group="" addr=10.2.13.80 timeout=2633
authmethod=PLAIN multiuser=0 admin=0 sslvpn=1 sslrdr=0 openvpn=0 sponsoring=0
name="guillaumed" domain="userdomain.eu" group="laboSYS" addr=10.2.3.1 timeout=4828
authmethod=PLAIN multiuser=0 admin=0 sslvpn=1 sslrdr=0 openvpn=1 sponsoring=0
name="yvanv" domain="userdomain.eu" group="laboIHM" addr=10.2.2.1 timeout=4744
authmethod=PLAIN multiuser=0 admin=0 sslvpn=0 sslrdr=0 openvpn=0 sponsoring=0
```



NOP

Description

Do nothing but avoid disconnection from server.

Returns

Error code

Remark

Used to reset idle time-out.

Example

NOP



PKI

Level

base

History

Appears in Netasq 9.0.0

Description

show or update the pki

PKI ACTIVATE

Level

base,modify

History

Appears in 3.9.0

Description

Activate PKI configuration changes

Usage

<none>

Example

PKI ACTIVATE

Returns

<none>

PKI CA

Level

base

History

Appears in Netasq 9.0.0

Description

show or update the pki ca

PKI CA CHECK

Level

pki

History

Appears in Netasq 9.0.0

Description

Check if the authority is used

**Format**

section_line

Usage

caname=<name>

PKI CA CHECKCRL**Level**

base

History

Appears in Netasq 9.0.0

Description

show or update the checkcrl utility configuration

PKI CA CHECKCRL ADD**Level**

pki,modify

History

Appears in Netasq 9.0.0

scope appears in 3.7.0

Format

section

Description

Add a new URI to the checkcrl list. CACHE_CATEGORY pki

Usage

caname=<name> uri=<uri> state=<enabled|disabled> [scope=<both|local|global>]

PKI CA CHECKCRL REMOVE**Level**

pki,modify

History

Appears in Netasq 9.0.0

scope appears in 3.7.0

Description

Remove an entry in the checkcrl utility CACHE_CATEGORY pki

Usage

caname=<name> id=<number> [scope=<both|local|global>]

PKI CA CHECKCRL SHOW**Level**

base

History



Appears in Netasq 9.0.0
scope appears in 3.7.0

Format

section_line

Description

Show the checkcrl configuration

Usage

caname=<name> [scope=<both|local|global>]

PKI CA CHECKCRL UPDATE**Level**

pki,modify

History

Appears in Netasq 9.0.0
scope appears in 3.7.0

Description

Update an entry in the checkcrl utility CACHE_CATEGORY pki

Usage

caname=<name> id=<number> [state=<enabled|disabled>] [uri=<uri>]
[scope=<both|local|global>]

PKI CA CHECKOCSP**Level**

base

History

Appears in 4.1.0

Description

show or update the OCSP servers configuration

PKI CA CHECKOCSP ADD**Level**

pki,modify

History

Appears in 4.1.0

Format

section

Description

Add a new URI to the OCSP servers list. CACHE_CATEGORY pki

Usage

caname=<name> uri=<uri> state=<enabled|disabled> [scope=<both|local|global>]



PKI CA CHECKOCSP REMOVE

Level

pki,modify

History

Appears in 4.1.0

Description

Remove an entry in the OCSP servers list CACHE_CATEGORY pki

Usage

caname=<name> id=<number> [scope=<both|local|global>]

PKI CA CHECKOCSP SHOW

Level

base

History

Appears in 4.1.0

Format

section_line

Description

Show the OCSP servers configuration

Usage

caname=<name> [scope=<both|local|global>]

PKI CA CHECKOCSP UPDATE

Level

pki,modify

History

Appears in 4.1.0

Description

Update an entry in the OCSP servers list CACHE_CATEGORY pki

Usage

caname=<name> id=<number> [state=<enabled|disabled>] [uri=<uri>]
[scope=<both|local|global>]

PKI CA CONFIG

Level

base

History

Appears in Netasq 9.0.0

Description

show or update the authority configuration



PKI CA CONFIG CRLDP

Level

base

History

Appears in Netasq 9.0.0

Description

show or update a CRLDP configuration

PKI CA CONFIG CRLDP ADD

Level

pki,modify

History

Appears in Netasq 9.0.0

Description

Add a new URI to the CRL distribution points list.

The new URI will be added to the next certificates created CACHE_CATEGORY pki

Usage

caname=<name> uri=<uri>

PKI CA CONFIG CRLDP REMOVE

Level

pki,modify

History

Appears in Netasq 9.0.0

Description

Remove an entry in the CRLDP. CACHE_CATEGORY pki

Usage

caname=<name> id=<number>

PKI CA CONFIG CRLDP SHOW

Level

base

History

Appears in Netasq 9.0.0

scope appears in 4.1

Format

section_line

Description

Show the CRLDP of a authority.

Usage

caname=<name> [scope=<local|global|both>]



PKI CA CONFIG SHOW

Level

base

History

Appears in Netasq 9.0.0

scope appears in 4.1

Format

section_line

Description

Show the authority parameters.

Usage

caname=<name> [scope=<local|global|both>]

PKI CA CONFIG UPDATE

Level

pki,modify

History

Appears in 9.0.0

userreq_type, serverreq_type, careq_type appear in 3.10.0

Description

Update the authority parameters.

Usage

caname=<name>

[crl_days=<days>] : How many days the CRL remain valid

[crl_hours=<days>] : How many hours the CRL remain valid (in addition of days)

[user_size=<size>] : The key size to generate

[user_days=<days>] : How many days the certificate remain valid

[userreq_digest=<digest name>] : The digest to use for user request signature

[userreq_type=<RSA|SECP|Brainpool>] : The algorithm type to use for user request signature

[user_digest=<digest name>] : The digest to use for user certificate signature

[smartcard_size=<size>] : The key size to generate

[smartcard_days=<days>] : How many days the certificate remain valid

[smartcardreq_digest=<digest name>] : The digest to use for user request signature

[smartcardreq_type=<RSA|SECP|Brainpool>] : The algorithm type to use for user request signature

[smartcard_digest=<digest name>] : The digest to use for user certificate signature

[server_size=<size>] : The key size to generate

[server_days=<days>] : How many days the certificate remain valid

[serverreq_digest=<digest name>] : The digest to use for user request signature

[serverreq_type=<RSA|SECP|Brainpool>] : The algorithm type to use for user request signature

[server_digest=<digest name>] : The digest to use for user certificate signature

[ca_size=<size>] : The key size to generate

[ca_days=<days>] : How many days the certificate remain valid

[careq_digest=<digest name>] : The digest to use for user request signature

[careq_type=<RSA|SECP|Brainpool>] : The algorithm type to use for user request signature

[ca_digest=<digest name>] : The digest to use for user certificate signature

Valid digests are: md2 md4 md5 mdc2 rmd160 sha1 sha224 sha256 sha384 sha512



Valid sizes are:

RSA: 1024 1536 2048 4096

SECP: 256 384 521

Brainpool: 256 384 512

PKI CA CREATE

Level

pki,modify LICENCE PKI

History

Appears in 9.0.0

keytype appears in 3.10.0

Description

Create a new CA in the tree

for create a sub-authority, you must precise the topca and topcapass.

by default, it creates a root authority CACHE_CATEGORY pki

Usage

passphrase=<pass>

CN=<name>

C=<country>

ST=<state>

O=<organization>

OU=<unit>

[keytype=<RSA|SECP|Brainpool>]

[size=<key size>]

[topca=<name>]

[topcapass=<pass>]

[default=<0|1>]

[nbdays=<days>]

[shortname=<name>]

[L=<locality>]

[E=<email>]

[S=<serial>]

[UA=<unstructuredAddress>]

[UN=<unstructuredName>]

Valid sizes are:

RSA: 1024 1536 2048 4096

SECP: 256 384 521

Brainpool: 256 384 512

Format

section

PKI CA GET

Level

pki

History

Appears in Netasq 9.0.0

**Description**

Download the CA. This command does not send the private key.

This command sends you the complete chain of authorities in p12 or pem format but single object in der one.

Usage

caname=<name> format=<p12|pem|der> [password=<P12_password>]

PKI CA LIST**Level**

base

History

Appears in Netasq 9.0.0

Description

List all of the CAs under the authority specified or ROOT authority.

Format

section_line

Usage

[caname=<name>]

PKI CA PUBLISH**Level**

pki, modify

History

Appears in Netasq 9.0.0

Description

Try to publish the default authority into the configured LDAP

PKI CA PURGE**Level**

pki, modify

History

Appears in 1.0.0

scope appears in 3.7.0

tmpassword appears in 4.2.0

Description

Remove a CA with all certificates without password

If child certificates are protected by TPM (onchip), tmpassword is required.

Usage

caname=<name> [scope=<both|local|global>] [tmpassword=<TPM password>]



PKI CA RENAME

Level

pki,modify

History

Appears in Netasq 9.0.0

Description

Rename the specified object

Use the force token if you want to rename the in-use authority. CACHE_CATEGORY pki

Usage

caname=<name> newname=<name> [force=<0|1>]

PKI CA REVOKE

Level

pki,modify

History

Appears in Netasq 9.0.0

scope appears in 3.7.0

tpmpassword appears in 4.1.0

Description

Remove a CA and revoke all the certificates under (but not its sub-CAs) CACHE_CATEGORY pki

Usage

caname=<name>

[passphrase=<pass>] (mandatory if the CA has a private key)

[format=<pem|der>] (for output CRL, mandatory if the CA has a private key)

[reason=<unknown|keyCompromise|CACompromise|affiliationChanged|superseded|cessationOf
Operation|certificateHold|privilegeWithdrawn|AACompromise>]

[topcapass=<pass>] (mandatory if the CA has a top-CA which has a private key)

[force=<0|1>] (used to remove an in-use CA)

[scope=<both|local|global>] (default is both)

[tpmpassword=<TPM password>]

Returns

a CRL file in the specified format, or an error code

PKI CA SHOW

Level

base

History

Appears in Netasq 9.0.0

scope appears in 4.1

Description



Show all of the information in the certificate.
The full parameter gives you the same output as a openssl one.

Format

section_line

Usage

caname=<name> [full=<0|1>] [scope=<local|global|both>]

PKI CERTIFICATE

Level

base

History

Appears in Netasq 9.0.0

Description

show update or create a certificate request

PKI CERTIFICATE CHECK

Level

pki

History

Appears in Netasq 9.0.0

Description

Check if the specified certificate is in use (If no authority name is given, the default one is taken)

Format

section_line

Usage

name=<name> [caname=<name>]

PKI CERTIFICATE COMMENT

Level

pki,modify

History

Appears in Netasq 9.0.0

Description

Add a small comment on the given certificat. If no authority name is given, the default one is taken. CACHE_CATEGORY pki

Usage

name=<name> comment=<comment> [caname=<name>]



PKI CERTIFICATE CREATE

Level

pki,modify LICENCE PKI

History

Appears in 9.0.0

tpm, tpmpassword, keytype appears in 3.10.0

force appears in 4.3.0

Description

Create a new certificate. You must have the authority private key.

For a server certificate, the CN must be a FQDN

For a user, you must precise an email.

For a SmartCard type, you must have an email and have define the CRLDP of the authority.
You can also specify the UPN (UserPrincipalName) used to login in Windows environment.
If no authority name is given, the default one is taken. Will return an error if a certificate with the same DN already exists. Use force=1 to bypass the error and overwrite the pre-existing cert.
CACHE_CATEGORY pki

Example

```
PKI CERTIFICATE CREATE type=smartcard CN="John Doe" passphrase="secret"
```

```
E=j.doe@company.com UPN="john.doe@COMPANY.DOMAIN"
```

```
PKI CERTIFICATE CREATE type=server CN="www.companie.com" passphrase="secret"
```

```
ALTNAMES="*.companie.com;companie.com;12.34.56.78;98.76.54.32"
```

Usage

```
type=<user|server|smartcard>
```

```
CN=<name>
```

```
passphrase=<pass>
```

```
[caname=<name>]
```

```
[shortname=<name>]
```

```
[keytype=<RSA|SECP|Brainpool>]
```

```
[size=<key size>]
```

```
[nbdays=<days>]
```

```
[C=<country>]
```

```
[ST=<state>]
```

```
[L=<locality>]
```

```
[O=<organisation>]
```

```
[OU=<unit>]
```

```
[E=<email>]
```

```
[UA=<unstructuredAddress>]
```

```
[UN=<unstructuredName>]
```

```
[S=<serial>]
```

```
[UPN=<userPrincipalName>]
```

```
[ALTNAMES=<list of ip or fqdn name separated by ;>]
```

```
[tpm=<none|ondisk>]
```

- none: Do not use a TPM

- ondisk: Store the private key on disk but encrypts it with a symmetric key on the TPM.

Requires a firewall with a TPM

```
[tpmpassword=<password>]
```

```
[force=<0|1>]
```

Valid sizes are:

RSA: 768 1024 1536 2048 4096



SECP: 256 384 521
Brainpool: 256 384 512

PKI CERTIFICATE DROPKEY

Level

pki,modify

History

Appears in 1.2.0

Description

Drop the private key of the certificate CACHE_CATEGORY pki

Example

PKI CERTIFICATE DROPKEY caname=myca name=mycert

Usage

name=<name> [caname=<name>] [force=<0|1>]

PKI CERTIFICATE GET

Level

base

History

Appears in Netasq 9.0.0

tpmpassword appears in 3.10.0

pkey appears in 3.10.0

Description

Download the certificate. If the certificate have a private key, you must precise a password for crypt the private key.

If no authority name is given, the default one is taken.

If private key is protected by TPM (ondisk), tpmpassword is required.

If pkey set to 0 and format set to pem, no private key will be exported.

Usage

name=<name> format=<p12|pem|der> [password=<exportpassword>] [caname=<name>]
[tpmpassword=<tpmpassword>] [pkey=0|1]

PKI CERTIFICATE LIST

Level

base

History

Appears in Netasq 9.0.0

Format

section_line

Description



List all of the certificates under the specified authority.
If no authority name is given, the default one is taken.

Usage

[caname=<name>]

PKI CERTIFICATE PROTECT

Level

pki,modify

History

Appears in 3.10.0

Description

Modify the protection mode the private key of the certificate.
Token tpmpassword is required when the level of protection is changed from ondisk to none.
If no authority name is given, the default one is used. CACHE_CATEGORY pki

Example

PKI CERTIFICATE PROTECT caname=myca name=mycert tpm=ondisk

Usage

name=<name> tpm=<none|ondisk> [caname=<name>] [tpmpassword=<tpmpassword>]

PKI CERTIFICATE PUBLISH

Level

pki, modify

History

Appears in Netasq 9.0.0

Description

Try to publish a certificat of the default authority into the configured LDAP.
You can precise the uid of an user or the complete DN of the location to publish.
If the certificate have a private key, you must precise a password to crypt the P12 file in LDAP.

Usage

name=<name> [dn=<dn> | uid=<uid>] [password=<p12password>]

PKI CERTIFICATE RENAME

Level

pki,modify

History

Appears in Netasq 9.0.0

Description

Rename the specified object
Use the force token if you want to rename the in-use certificate. CACHE_CATEGORY pki

Usage



name=<name> newname=<name> [caname=<name>] [force=<0|1>]

PKI CERTIFICATE REVOKE

Level

pki,modify LICENCE PKI

History

Appears in Netasq 9.0.0

scope appears in 3.7.0

tpmpassword appears in 4.2.0

Description

Revoke the certificate if have the authority private key. Else, just drop it.

Format

section CACHE_CATEGORY pki

Usage

name=<name>

[caname=<name>] (If not given, the default one is taken)

[passphrase=<pass>]

[reason=<unknown|keyCompromise|CACompromise|affiliationChanged|superseded|cessationOf
Operation|certificateHold|privilegeWithdrawn|ACompromise>]

[force=<0|1>] (used to remove an in-use certificate)

[scope=<both|local|global>] (default is both)

[tpmpassword=<TPM password>]

PKI CERTIFICATE SHOW

Level

base

History

Appears in Netasq 9.0.0

appears in 4.1

Format

section

Description

Show all of the information in the certificate. The full parameter give you the same output as a openssl one.

If no authority name is given, the default one is taken.

Usage

name=<name> [caname=<name>] [full=<0|1>] [scope=<local|global|both>]

PKI CONFIG

Level

base

**History**

Appears in Netasq 9.0.0

Description

show or update the pki configuration

PKI CONFIG SHOW**Level**

base

History

Appears in Netasq 9.0.0

checkcrlperiod appears in 3.1.0

Format

section

Description

Show the parameters.

PKI CONFIG UPDATE**Level**

pki,modify

History

Appears in Netasq 9.0.0

checkcrlperiod appears in 3.1.0

checkcrlbindaddr appears in 4.2.0

Description

Update a parameter

Usage

[default=<name>] [sendmail=<0|1>] [checkcrl=<0|1>] [scephash=<hash_algorithm>]
[scepcipher=<cipher_algorithm>] [checkcrlperiod=<seconds>] [checkcrlbindaddr=<bindaddr>]

Valid digests are: md2 md4 md5 mdc2 rmd160 sha1 sha224 sha256 sha384 sha512

Valid ciphers are: des-ede3-cbc aes-128-cbc aes-256-cbc

Checkcrlperiod from 3600 to 604800 (1h to 1w)

PKI CRL**Level**

base

History

Appears in Netasq 9.0.0

Description

show or update the pki crl



PKI CRL CREATE

Level

pki,modify LICENCE PKI

History

Appears in Netasq 9.0.0

Description

Create a new CRL for the specified CA. You must have the private key of the authority.
If no authority name is given, the default one is taken. CACHE_CATEGORY pki

Usage

passphrase=<pass> [caname=<name>]

PKI CRL GET

Level

pki

History

Appears in Netasq 9.0.0

Description

Download the CRL. If no authority name is given, the default one is taken.

Usage

format=<pem|der> [caname=<name>]

PKI CRL PUBLISH

Level

pki, modify

History

Appears in Netasq 9.0.0

Description

Try to publish the CRL of the default authority into the configured LDAP

PKI CRL REMOVE

Level

pki,modify

History

Appears in 2.0.0

Description

Remove the CRL.

Usage

caname=<name>



PKI CRL SHOW

Level

base

History

Appears in Netasq 9.0.0

Description

Show up to 1000 entries of the information in the CRL. If no authority name is given, the default one is taken.

The full parameter gives you the same output as a openssl one, and is uncapped.

Format

section_line

Usage

[caname=<name>] [full=<0|1>]

PKI EST

Level

base

History

Appears in 3.10

Description

EST protocol handler

PKI EST GETCACERT

Level

pki,modify LICENCE PKI

History

Appears in 3.10.0

Description

Import the root CA for EST certificates CACHE_CATEGORY pki

Usage

url=<HTTPS base URL>

TLSCa=<CA name for TLS server trust>

caname=<EST CA name on SNS side>

[alias=<alias>] EST alias if server provides multiple CAs

[bindaddr=<host or IP>]

[bindport<port>]

Example

PKI EST GETCACERT TLSCa="CN=ManagementCA O=EJBCA Sample C=SE" alias=ecdsa_est

caname=ECDSA_EST_CA url=https://managementca:8442/

PKI EST GETCACERT TLSCa="CN=estExampleCA" url=https://testtrfc7030.com:8443/

**Format**

section

Returns

In case of success :

101 code=00a01000 msg="Begin" format="section"

[Result]

CA=<CA name>

100 code=00a00100 msg="Ok"

110 code=02c02600 msg="Duplicated names"

In case of error (example):

200 code=02c06700 msg="EST server does not respond correctly"

PKI EST QUERY**Level**

pki,modify LICENCE PKI

History

Appears in 3.10

force appears in 4.2

Description

Generate a private key locally and query a new certificate on the remote host.

Example

PKI EST QUERY TLSCa="CN=ManagementCA O=EJBCA Sample C=SE" alias=ecdsa_est
caname=ECDSA_EST_CA url=https://managementca:8442/ login=estuser password=estpw
keytype=secp keysize=256 CN=TestEnrollSDp2561 name=TestEnrollSDp2561

PKI EST QUERY TLSCa="CN=ManagementCA O=EJBCA Sample C=SE" alias=ecdsa_est
caname=ECDSA_EST_CA url=https://managementca:8443/ renew=TestEnrollSDp2561

Usage

url=<HTTPS base URL>

TLSCa=<CA name for TLS server trust>

caname=<EST CA name on SNS side>

[alias=<alias>] EST alias if server provides multiple CAs

[bindaddr=<host or IP>]

[bindport<port>]

[login=<login>]

[password=<password>] : HTTPS basic credentials

[keytype=<RSA|SECP|Brainpool>]

[keysize=<key size>]

[renew=<cert name>]

[type=<server|user|smartcard>] server by default.

[UPN=<userPrincipalName>]

[ALT NAMES=<list of ip or fqdn name separated by ;>]

[name=<Desired cert name on SNS side>]

[CN=<name>] : required on creation. Optional for renewal

[C=<country>]

[ST=<state>]

[L=<locality>]



[O=<organisation>]
[OU=<unit>]
[E=<email>]
[UA=<unstructuredAddress>]
[UN=<unstructuredName>]
[S=<serial>]
[tpm=<none|ondisk>]
[force=<0|1>] force request and import in DR mode even if cert appears not to be compliant
Valid sizes are:
RSA: 1024 1536 2048 4096
SECP: 256 384 521
Brainpool: 256 384 512

PKI IMPORT

Level

pki,modify

History

Appears in Netasq 9.0.0
global appears in 3.7.0
usb appears in 3.9.0
tpm appears in 3.10.0
usb disappears in 4.0.0
force behavior changed in 4.1.0

Description

Import an item into the PKI (The global PKI cannot import requests nor private keys.) If an existing certificate is to be replaced and no tpm parameter is given, the same security level is used.

Usage

format=<p12|pem|der>
type=<req|cert|pkey|crl|ca|all>
[password=<pass>]
[force=<0|1>]
[global=<0|1>]
[tpm=<none|ondisk>]

- none: Do not use a TPM

- ondisk: Store the private key on disk but encrypts it with a symmetric key on the TPM.

Requires a firewall with a TPM chip

If force=1 is used and the certificate already exists, replace the old certificate

If force=0 or isn't specified and the certificate already exists, do not import the certificate

PKI REQUEST

Level

base

History

Appears in Netasq 9.0.0

Description



show update or create a certificate request

PKI REQUEST CREATE

Level

pki,modify LICENCE PKI

History

Appears in 9.0.0

keytype appears in 3.10.0

Description

Create a new certification request for the given authority. If no authority name is given, the default one is taken.

The email is mandatory for a user request. The name must be a fqdn or an IP for a server one.

CACHE_CATEGORY pki

Usage

type=<user|server|smartcard|ca>

CN=<name>

passphrase=<pass>

[caname=<name>]

[shortname=<name>]

[keytype=<RSA|SECP|Brainpool>]

[size=<key size>]

[nbdays=<days>]

[C=<country>]

[ST=<state>]

[L=<locality>]

[O=<organisation>]

[OU=<unit>]

[E=<email>]

[UA=<unstructuredAddress>]

[UN=<unstructuredName>]

[S=<serial>]

[UPN=<userPrincipalName>]

[ALT NAMES=<list of ip or fqdn name separated by ;>]

[tpm=<none|ondisk>]

- none: Do not use a TPM

- ondisk: Store the private key on disk but encrypts it with a symmetric key on the TPM.

Requires a firewall with a TPM

[tpmpassword=<password>]

Valid sizes are:

RSA: 768 1024 1536 2048 4096

SECP: 256 384 521

Brainpool: 256 384 512

PKI REQUEST GET

Level

base

History



Appears in Netasq 9.0.1

Description

Download only the certificate request. The private key remain in the PKI. The file format remain the same as origin.

Usage

name=<name> format=<pem|der>

PKI REQUEST LIST

Level

base

History

Appears in Netasq 9.0.0

Description

List all of the pending request

Format

section_line

PKI REQUEST REMOVE

Level

pki,modify

History

Appears in Netasq 9.0.0

tpm, tpm password appear in 3.10.0

Description

Remove a pending certification request CACHE_CATEGORY pki

Usage

name=<name> [tpm password=<TPM password>]

PKI REQUEST SHOW

Level

base

History

Appears in Netasq 9.0.0

Description

Display the content of the certification request.

The full parameter gives you the same output as a openssl one.

Format

section

Usage



name=<name> [full=<0|1>]

PKI REQUEST SIGN

Level

pki,modify LICENCE PKI

History

Appears in Netasq 9.0.0

Description

Sign the request with the specified authority. You must have the private key of the authority.
If no authority name is given, the default one is taken.

For a SmartCard type, you must have an email and have define the CRLDP of the authority.
You can also specify the UPN (UserPrincipalName) used to login in Windows environment.
For a server certificate you can specify ALT NAMES with a semicolon separated list of IP or FQDN names. CACHE_CATEGORY pki

Example

```
PKI REQUEST SIGN type=smartcard name="request_1" CN="John Doe" passphrase="secret"  
UPN="john.doe@COMPANY.DOMAIN"  
PKI REQUEST SIGN type=server name="request_2" CN="www.companie.com"  
passphrase="secret" ALT NAMES="*.companie.com;companie.com;12.34.56.78;98.76.54.32"
```

Usage

```
type=<user|server|smartcard|ca>  
name=<name>  
passphrase=<pass>  
[caname=<name>]  
[shortname=<name>]  
[nbdays=<days>]  
[UPN=<userPrincipalName>]  
[ALT NAMES=<list of ip or fqdn name separated by ;>]
```

Format

section

PKI SCEP

Level

base

History

Appears in 9.0.2

Description

SCEP protocol handler

PKI SCEP ACTIVATE

Level

pki,modify

**History**

Appears in 3.9.0

Description

Activate SCEP configuration changes

Usage

No arguments : changes are activated immediately

CANCEL : Changes are discarded

NEXTBOOT : Changes will be activated on next boot

Example

PKI SCEP ACTIVATE

PKI SCEP CHECK**Level**

pki LICENCE PKI

History

Appears in Netasq 9.0.2

caname appears in 3.9.0

Profile loading appears in 3.9.0

Description

Check the remote status of a SCEP query and import certificate if signed.

Usage

caname=<profile name>

[transaction=<name>] (default: the last transaction) CACHE_CATEGORY pki

Example

PKI SCEP CHECK caname=scep-ca transaction=U250XXXXXX-1548632651

Format

section

Returns

In case of success :

[Result]

status=SUCCESS

name=<certificate name>

In case of failure :

200 code=00602400 msg="Certificate request rejected"

In case of pending result :

[Result]

status=PENDING

transaction=<transactionID>

PKI SCEP GETCACERT**Level**



pki,modify LICENCE PKI

History

Appears in 3.9.0

Description

Check/Display and/or import the root CA for SCEP certificates CACHE_CATEGORY pki

Usage

url=<SCEP server's URL>

[fingerprint=<SCEP CA's hash>]

[caname=<user ID for installed CA>]

[post=ON|off]

Display the fingerprint if only the url is supplied

Compare to the given fingerprint if the url AND a finger print is provided

Import the CA under caname if its fingerprint match the given one.

Example

Get the CA's SHA256 fingerprint from a SCEP server

PKI SCEP GETCACERT url="http://192.168.1.1/scep_service/" post=on

101 code=01101000 msg="CA's Fingerprint" format="section_line"

[Result]

url="http://192.168.1.1/scep_service/"

fingerprint="XXXXXXXXXXXXXXXXXXXX"

100 code=00a00100 msg="Ok"

Check the fingerprint of a SCEP server

PKI SCEP GETCACERT url="http://192.168.1.1/scep_service/"

fingerprint="XXXXXXXXXXXXXXXXXXXX" post=off

101 code=01101000 msg="CA's Fingerprint" format="section_line"

[Result]

url="http://192.168.1.1/scep_service/"

input_fingerprint="XXXXXXXXXXXXXXXXXXXX"

fingerprint="XXXXXXXXXXXXXXXXXXXX"

100 code=00a00100 msg="Ok" / 200 code=00a00100 msg="Failed" [depend if the fingerprints matches]

Import the CA if it matches the given fingerprint

- The url parameter can be read from the configuration file [PKI SCEP UPDATE]

PKI SCEP GETCACERT fingerprint="XXXXXXXXXXXXXXXXXXXX" caname="My_scep_ca"

[url="http://192.168.1.1/scep_service/"]

Returns

The server url and its CA's fingerprint

The import name if required.

PKI SCEP QUERY

Level

pki,modify LICENCE PKI

History

Appears in Netasq 9.0.2

renew appears in 2.5.0

post appears in 3.9.0



Profile loading appears in 3.9.0

tpm appears in 3.10.0

force appears in 4.2.0

Description

Generate a private key locally and query a new certificate on the remote host.

Example

```
PKI SCEP QUERY type=user caname=remote_authority password="SCEP_challenge"
url="http://microsoftPKI/certsrv/mscep/mscep.dll" CN="John Doe" E=j.doe@company.com
UPN="john.doe@COMPANY.DOMAIN"
PKI SCEP QUERY type=server CN="www.company.com" size=1024 caname=remote_authority
password="SCEP_challenge" url="http://ciscoPKI/cgi-bin/scep/scep"
ALTNAMES="*.company.com;company.com;10.1.2.3"
PKI SCEP QUERY type=server size=1024 caname=remote authority password=
url="http://ciscoPKI/cgi-bin/scep/scep" renew="remote_authority:previous_certificate"
```

Usage

```
type=<user|server|smartcard|ca>
password=<The SCEP password to use, leave blank if none>
caname=<name>
url=<HTTP URL>
[bindaddr=<host or IP>]
[bindport<port>]
[post=ON|off]
[UPN=<userPrincipalName>]
[ALTNAMES=<list of ip or fqdn name separated by ;>]
[renew=<pki_ca:pki_certificate>]
[scepcaname=<pki_ca: used to communicate with server if different of the signing one>]
[CN=<name>] : required on creation. Optional for renewal
[C=<country>]
[ST=<state>]
[L=<locality>]
[O=<organisation>]
[OU=<unit>]
[E=<email>]
[UA=<unstructuredAddress>]
[UN=<unstructuredName>]
[S=<serial>]
[tpm=<none|ondisk>]
[force=<0|1>] force request and import in DR mode even if cert appears not to be compliant
```

Format

section

Returns

In case of success :

```
[Result]
status=SUCCESS
name=<certificate name>
```

In case of failure :

```
[Result]
status=REJECT
reason=<reason string>
```



In case of pending result :
[Result]
status=PENDING
transaction=<transactionID>

PKI SCEP SHOW

Level

pki LICENCE PKI

History

Appears in 3.9.0

Usage

caname=<name>
[useclone=on|OFF]

Description

Display a SCEP configuration's informations by CA's name CACHE_CATEGORY pki

PKI SCEP UPDATE

Level

pki,modify LICENCE PKI

History

Appears in 3.9.0

Description

Update SCEP configuration's informations

Usage

caname=<name [Also used as profile name]>
[type=<user|server|smartcard|ca>
[password=<The SCEP password to use, leave blank if none>
[url=<HTTP URL>
[bindaddr=<host or IP>
[bindport<port>
[post=ON|off]
[UPN=<userPrincipalName>
[ALT NAMES=<list of ip or fqdn name separated by ;>
[renew=<pki_ca:pki_certificate>
[scep caname=<pki_ca: used to communicate with server if different of the signing one>
[retry=<retry count>
[waittime=<waittime>
[CN=<name>] : required on creation. Optional for renewal
[C=<country>
[ST=<state>
[L=<locality>
[O=<organisation>
[OU=<unit>
[E=<email>
[UA=<unstructuredAddress>
[UN=<unstructuredName>



[S=<serial>]
CACHE_CATEGORY pki

Example

```
PKI SCEP UPDATE type=user caname=remote_authority password="SCEP_challenge"
url="http://microsoftPKI/certsrv/mscep/mscep.dll" CN="John Doe" E=j.doe@company.com
UPN="john.doe@COMPANY.DOMAIN"
PKI SCEP UPDATE type=server CN="www.company.com" size=1024 caname=remote_authority
password="SCEP_challenge" url="http://ciscoPKI/cgi-bin/scep/scep"
ALTNAMES="*.company.com;company.com;10.1.2.3"
PKI SCEP UPDATE type=server size=1024 caname=remot
```

Returns

Error code

PKI SEARCH

Level

base

History

Appears in Netasq 9.0.0
scope appears in 4.0.0

Description

Search objects who are matching the filter

Format

section_line CACHE_CATEGORY pki

Usage

```
[name=<search patern>] [type=<req|ca|user|server|smartcard|all>] [cert=<0|1>]
[pkey=<0|1>] [crl=<0|1>] [crl dp=<0|1>] [start=<int> [limit=<int>] [dir=<ASC|DESC>]
[search=<pattern>] [searchfield=<token>] [sort=<token>] [refresh=<0|1>]]
[scope=<local|global|both>]
```

If cert=1 is used, all objects which have a certificate are displayed. Else, print all.

If pkey=1 is used, all objects with private key are displayed.

If pkey=0 is used, all objects without private key are displayed.

If pkey is not specified, all objects with or without private key are displayed.

If crl=1 is used, all objects which have a crl are displayed (only applicable to authorities). Else, print all.

If crl dp=1 is used, all objects which have a crl dp are displayed (only applicable to authorities). Else, print all.



QUIT

Description

Log off.

Returns

Error code

Example

QUIT



REPORT

Level

base

Description

Handling of reports

REPORT GET

Level

base

Description

Access to report results

REPORT GET DAY

Level

report_read

History

Appears in Netasq 9.1.0
content appears in 3.0.0
ip appears in 3.0.0

Format

section_line

Description

Get report results regarding a specific day.

Remark

These results always cover a period starting at midnight.

Usage

report=<report_id> : Report for which we want the results
[offset=<nb_days>] : Which day must be covered by the results (0 = today, 1 = yesterday, etc).
Up to 7 on small firewalls without SD card (SN160(W), SN210(W), SN310, ...).
Up to 30 on bigger firewalls or small firewalls with SD card (SN160(W), SN210(W), SN310, ...).
Default is 0.
[format=[section line|csv]] : output format:
- section_line [default] : Usual Serverd output format
- csv : export the results in a CSV file
[content=<list of expected data, works in linechart only>]
[ip=<wanted ip> (mandatory and only works for hostrep reports)]

Returns

see REPORT GET LASTHOUR

Example



```
REPORT GET DAY report=top_ips_alarms  
REPORT GET DAY report=top_webdomains offset=3  
REPORT GET DAY report=top_webdomains offset=3 format=csv
```

REPORT GET LAST30DAYS

Level

report_read

History

Appears in Netasq 9.1.0
content appears in 3.0.0
ip appears in 3.0.0

Format

section_line

Description

Get report results regarding the last 30 days.

Remark

These results always cover a period starting at D-30 at midnight and ending today at midnight (-> today is excluded). If there is no /log on the firewall, this command will always return an error.

Usage

report=<report_id> : Report for which we want the results
[format=[section_line|csv]] : output format:
- section_line [default] : Usual Serverd output format
- csv : export the results in a CSV file
[content=<list of expected data, works in linechart only>]
[ip=<wanted ip> (mandatory and only works for hostrep reports)]

Returns

see REPORT GET LASTHOUR

Example

```
REPORT GET LAST30DAYS report=top_ips_alarms  
REPORT GET LAST30DAYS report=top_webdomains format=csv
```

REPORT GET LAST7DAYS

Level

report_read

History

Appears in Netasq 9.1.0
content appears in 3.0.0
ip appears in 3.0.0

Format

section_line

Description



Get report results regarding the last 7 days.

Remark

These results always cover a period starting at D-7 at midnight and ending today at midnight (-> today is excluded).

Usage

report=<report id> : Report for which we want the results
[format={section_line|csv}] : output format:
- section_line [default] : Usual Serverd output format
- csv : export the results in a CSV file
[content=<list of expected data, works in linechart only>]
[ip=<wanted ip> (mandatory and only works for hostrep reports)]

Returns

see REPORT GET LASTHOUR

Example

REPORT GET LAST7DAYS report=top_ips_alarms
REPORT GET LAST7DAYS report=top_webdomains format=csv

REPORT GET LASTHOUR

Level

report_read

History

Appears in Netasq 9.1.0
content appears in 3.0.0
ip appears in 3.0.0

Format

section_line

Description

Get report results regarding the last 60 minutes

Usage

report=<report id> : report for which we want the results
[format={section_line|csv}] : output format:
- section_line [default] : Usual Serverd output format
- csv : export the results in a CSV file
[content=<list of expected data, works in linechart only>]
[ip=<wanted ip> (mandatory and only works for hostrep reports)]

Returns

[Info] : report infos

creationDate="YYYY-MM-DD" : date at which the report has been created
periodBegin="YYYY-MM-DD hh:mm" : beginning of the period covered by the report
periodEnd="YYYY-MM-DD hh:mm" : end of the period covered by the report

[Data] : results

position="1" value="www.stormshield.eu" count=705536
position="2" value="gw" count=204800
position="3" value="safebrowsing.cache.l.google.com" count=109568
position="4" value="172.16.1.1" count=72704



```
position="5" value="weather.noaa.gov" count=41984
position="6" value="musicbrainz.org" count=32768
position="7" value="dns_b" count=30720
position="8" value="clients.l.google.com" count=22528
position="9" value="fo-anyycs-l.ay1.b.yahoodns.net" count=20480
position="10" value="api.mywot.com" count=16384
position="11" count=999999 : "others"
```

Example

```
REPORT GET LASTHOUR report=top_ips_alarms
REPORT GET LASTHOUR report=top_webdomains format=csv
```

REPORT RESET

Level

report,modify

History

Appears in Netasq 9.1.0
ip appears in 3.0.0

Description

Delete reports data.

Usage

report=[<report_id>|all] : Report for which we want to drop its data.
[ip=<wanted ip> {only works for hostrep reports}]

Remark

report=all can be used also to destroy a corrupted database by a new (empty) one.

Example

```
REPORT RESET report=all
REPORT RESET report=top_ips_alarms
```



SYSTEM

Level

base

Description

System commands

SYSTEM BACKUP

Level

base

History

Appears in Netasq 6.2.0

Description

Return the list of files that will be copied during backup

Returns

[Config]

list= : list of categories for Config

list_adv= : list of advanced categories for Config

[Data]

list= : list of categories for data

Example

SYSTEM BACKUP

[Config]

list=network,object,nat,filter,vpn,ldap,url,global,secure,autoupdate,proxies,services

list_adv=network,object,global_object,nat,filter,filterslotxx,global_filter,global_filterslotxx,ldap,url,global,secure,autoupdate,proxies,cert,asq,vpn-ssl,vpn-pptp,event-slots,event-rules,qos,auth,statusweight,dhcp,ntp,dns,snmp,log,route,sysevent,bird,antispam,communication,access_tickets

[Data]

list=data,urlgroup,pattern

SYSTEM BYPASS

Level

base

Description

Bypass configuration

SYSTEM BYPASS ACTIVATE

Level

base

Description



Apply bypass configuration and reload bypass service with this new configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Warning/Error messages or ok

Example

SYSTEM BYPASS ACTIVATE

SYSTEM BYPASS CONFIG

Level

base

Description

Display bypass configuration file or update bypass configuration file (clone file)

Usage

[SafetyMode={On|Off}] [BypassOnWatchdog=<seconds>]

- no argument: display status
- SafetyMode: activate or deactivate Safety Mode (System-off, Just-On Bypass and Run-time Watchdog)
- BypassOnWatchdog: configure bypass watchdog for Run-Time

Returns

Warning/Error messages or ok

Example

SYSTEM BYPASS CONFIG SafetyMode=Off BypassOnWatchdog=90

SYSTEM BYPASS REARM

Level

maintenance,modify

Description

Rearm bypass

Returns

Warning/Error messages or ok

SYSTEM CHECKCRL

Level

maintenance

Description

Check the validity of stored crl certificates

**Usage**

[verbose=0|1] [nodns=0|1] [warn=1-30] [timeout=0-3600] [scope=<scope_to_check>]
[bind=<bind_address>]

Returns

[Section] : The main section

return : The checkcrl command return code

output : The string output of checkcrl command

Example

SYSTEM CHECKCRL verbose=1

SYSTEM CLONE

Level

base

Description

Show information about backup partition or dump firewall image to inactive slot

Usage

[type={none|dump|bootdump|forcedump}] [fwserial={all|local|passive|active|<serial>}]
fwserial specifies a firewall in the HA cluster on which this operation must be done. With
type=dump, type=bootdump or type=forcedump, also dump firewall image to inactive slot
fwserial=local and type=none by default
type=none can only be used with fwserial=local

Returns

Error code, just ok if working only on a remote firewall, or backup info:

[BackupInfo]

Active= : partition actually active

BackupVersion= : firmware version on backup

BackupBranch= : firmware branch on backup

Boot= : partition used for boot

Date= : firewall date

Remark

With type=bootdump argument, dump is scheduled to next reboot.

With type=forcedump argument, dump is executed regardless of an ongoing autoupdate.

Maintenance and Modify levels needed for bootdump

fwserial argument is only valid if the HA is activated (or if serial=local)

Backupinfo of other HA firewalls can be obtained using HA INFO

Example

SYSTEM CLONE

SYSTEM CLONE type=dump

SYSTEM CHECKVERSION

Level

maintenance,modify

History



Appears in 4.3.0

Description

activate checkversion event

Usage

state=[0|1]

Returns

Error code

Example

SYSTEM CHECKVERSION state=1

SYSTEM DATE

Level

base

Description

Get/set firewall date

Usage

[yyyy-mm-jj hh:mm:ss]

Returns

Date="2002-08-07 16:32:50"

Example

SYSTEM DATE

SYSTEM DATE "2002-08-07 16:32:50"

SYSTEM DEFAULTCONFIG

Level

maintenance,modify

History

level maintenance Appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

Usage

[reset]

when reset specified only marks the configuration as not being the default one (does not restore any configuration)

Description

Restore default configuration and reboot

Returns

Error code

Example

SYSTEM DEFAULTCONFIG

SYSTEM DEFAULTCONFIG reset



SYSTEM ETHERCOUNT

Level

maintenance

Description

show the number of ethernet interfaces counted in HA quality factor, and reset it if asked

Usage

reset=[0|1]

Returns

Error code

Example

SYSTEM ETHERCOUNT reset=1

SYSTEM FWADMIN

Level

base

History

Will appear with FWADMIN

Description

Print fwadmin daemon configuration

Returns

[Server] : Server's information section

State : Daemon's state

Address : The centralized administration server address (empty by default)

Address6 : The centralized administration server IPv6 address (empty by default)

Port : The centralized administration server port (default is 8080)

PingValidity : Beyond this value (in seconds) without ping or any data from the client,
: the centralized administration will disconnect the websocket connection (default is 60)

PingInterval : In seconds (default is 30)

PongTimeout : In seconds. PongTimeout must be always lower than PingInterval (default is 15)

RetryInterval : Socket establishment try when cad is disconnected (in seconds) (default is 30)

[Certificate] : Certificate information section

IssuerHash

SubjectHash

Issuer

Subject

Version="3"

SerialNumber

NotBefore

NotAfter

PublicKeyAlgorithm

SignatureAlgorithm

[Subject]

countryName

stateOrProvinceName



organizationName
organizationalUnitName
commonName

[Issuer]
countryName
stateOrProvinceName
organizationName
organizationalUnitName
commonName

Example

SYSTEM FWADMIN

Format

section_line

SYSTEM HALT

Level

ha,maintenance,modify

History

level maintenance Appears in Netasq 6.0.0
level other deprecated in Netasq 6.0.0

Description

Halt firewall

Usage

[force]

Returns

Error code

Example

SYSTEM HALT

SYSTEM IDENT

Level

base

Description

Get/set the firewall identity

Usage

[[SystemName=<name>] [SystemFqdn=<fqdn>]
[SystemAccess=<IP|NAME|FQDN|CERTIFICATE>] [SystemNodeName=<name>]]
IP: Build URL with IP
NAME: Build URL with firewall system name
FQDN: Build URL with firewall FQDN
CERTIFICATE: Build URL with the first CN in portal certificate

**Returns**

Error code or current value:

Name=

Remark

Maintenance and Modify levels needed to update value

Example

```
SYSTEM IDENT "My_Firewall"  
100 code=00a00100 msg="Ok"  
SYSTEM IDENT  
SystemName="My_Firewall"  
SystemAccess="URL"  
SystemFqdn="firewall.compagnie.com"  
SystemNodeName="My_Node"
```

SYSTEM INFormatION**Level**

maintenance

History

Appears in Netasq 6.0.0

Format Appears in Netasq 9.0.0

Description

Return a file which contains the result of system information command

Returns

information on system

Format

raw

Example

```
SYSTEM INFormatION
```

SYSTEM INITIALIZE**Level**

admin

History

Appears in 8.1.0

Description

initialize the product. Retrieve the GUID of the product required to obtain the final init package

Example

```
SYSTEM INITIALIZE
```



SYSTEM LANGUAGE

Level

base

History

Arguments format changed in Netasq 9.0.0

Keyboard layout configuration is forbidden under XEN in Netasq 9.0.0

Warning when keyboard is available but not language Appears in Netasq 6.2.3

Description

Get/set the firewall default language

Usage

[language=[us|fr]] [keyboard=[us|fr|de|it|es|ch|pl]]

Returns

the actual language set and keyboard map.

A warning will be returned if Language does not match keyboard and requested language.

Remark

Maintenance and Modify levels needed to update value

Example

SYSTEM LANGUAGE

SYSTEM LANGUAGE keyboard=es

SYSTEM LANGUAGE language=fr keyboard=us

SYSTEM LANGUAGE language=us

SYSTEM LED

Level

maintenance,modify

History

level maintenance Appears in Netasq 6.0.0

level other deprecated in Netasq 6.0.0

deprecated in Netasq 9.0.0

Description

Clear/test firewall's LEDs

Usage

ack|test

Returns

Error code

Example

SYSTEM LED test

SYSTEM LED ack



SYSTEM LICENCE

Level

base

Description

Manage firewall licence

SYSTEM LICENCE DUMP

Level

base

Description

Display firewall licence

Usage`[new={0|1}] [fwserial=<serial>|passive|active|local]`

new option is used to dump the licence uploaded but not active yet

fwserial option is used to do the operation on HA peer firewall. By default, the local licence will be dumped

Returns

Error code

Example

SYSTEM LICENCE DUMP

SYSTEM LICENCE DUMP new=1

SYSTEM LICENCE UPDATER

Level

base

Description

Manage firewall licence updater

SYSTEM LICENCE UPDATER CONFIG

Level

maintenance,modify

Description

Configure the licence updater module

Remark

State : activate or deactivate the module

Period : time in hours (≥ 12) between two licence check

Auto : automatically activate (or not) the licence if a new one was found

Usage

State=[0|1] Period=<nb_hours> Auto=[0|1]

Returns



Error code

Example

SYSTEM LICENCE UPDATER CONFIG State=1 Period=13 Auto=0

SYSTEM LICENCE UPDATER DIFF**Level**

base

Description

Show diff between firewall licence and uploaded licence

Usage

[fwserial={<serial>|active|passive|local}]

fwserial option is used to do the operation on another firewall in the HA cluster (unless fwserial=local).

By default the operation is done on the local firewall.

Returns

Error code

Example

SYSTEM LICENCE UPDATER DIFF

SYSTEM LICENCE UPDATER GET**Level**

maintenance

History

force appears in 1.0.0

Description

Manually get licence from the server

Usage

[force={0|1}]

force option is used to force downloading a licence (default: force=0)

Returns

Error code

Example

SYSTEM LICENCE UPDATER GET

SYSTEM LICENCE UPDATER GET force=1

SYSTEM LICENCE UPDATER INSTALL**Level**

maintenance,modify

History

force disappears in 1.0.0

Description

Install uploaded licence

**Usage**

[fwserial={<serial>|active|passive|local}]

fwserial option is used to do the operation on another firewall in the HA cluster (unless fwserial=local).

By default the operation is done on the local firewall.

Returns

Error code

Example

SYSTEM LICENCE UPDATER INSTALL

SYSTEM LICENCE UPDATER SHOW**Level**

base

Description

Show updater config and state

Returns

101 code=00a01000 msg="Begin"

[Config]

State=1

Period=24

Auto=0

[Check]

last=

Standby=1

StandbyPeer=0

NeedReboot=0

NeedRebootPeer=0

100 code=00a00100 msg="Ok"

Example

SYSTEM LICENCE UPDATER SHOW

SYSTEM LICENCE UPLOAD**Level**

base

Description

Upload firewall licence

Usage

[fwserial={<serial>|passive|active|local}]

fwserial option is used to do the operation on another firewall in the HA cluster (unless fwserial=local).

By default the operation is done on the local firewall.

Returns

Error code

Remark



Ha or Maintenance and Modify levels needed to upload licence

Example

SYSTEM LICENCE UPLOAD

SYSTEM LOGDISK

Level

base

Description

Manage log partition

SYSTEM LOGDISK FORMAT

Level

maintenance,modify

Description

Format log partition or whole disk (Log writing is disabled during operation)

Usage

dev=<disk or partition name>

Returns

Warning/Error messages or ok

Example

SYSTEM LOGDISK FORMAT dev=mmcsd0

SYSTEM LOGDISK FORMAT dev=mmcsd0s1g

SYSTEM LOGDISK LIST

Level

base

Description

List available disks or partitions for logs

Remark

formatted token specify if device is a partition or an empty disk. We consider that a formatted disk have always a formatted partition.

Returns

[Result]

disk=internal size="67904774144" formatted="1" dev="ad0s1g"

disk="SDCard" size="7948197888" formatted="0" dev="mmcsd0"

Format

section_line



SYSTEM LOGDISK SELECT

Level

maintenance,modify

Description

Select new partition for log writing (Log writing is disabled during operation)

Usage

dev=<partition name>

Returns

Warning/Error messages or ok

Example

SYSTEM LOGDISK SELECT dev=mmc0s1g

SYSTEM LOGDISK STATE

Level

base

Remark

Modifying state requires Maintenance and Modify levels

Description

Display or modify logs writing state

Usage

[on|off]

- no argument : display status
- on : mount current log partition
- off : unmount log partition

Returns

[Result]

state=<USED|UNUSED|INCONSISTENT> # log partition status
device=<device> # device used as log partition

SYSTEM NSLOOKUP

Level

maintenance,modify

History

Appears in Netasq 9.0.1
type appears in 1.0.0

Format

section_line

Usage

host=<host> [type={ipv4|ipv6|all}]

Description



Hostname lookup

Returns

[IPv4]

<list of IPv4>

[IPv6]

<list of IPv6>

Example

SYSTEM NSLOOKUP host=www.stormshield.eu

SYSTEM PCAP

Level

maintenance,modify,log

History

Appears in 4.3

Description

Pcap Webgui handling functions

SYSTEM PCAP DOWNLOAD

Level

maintenance,modify,log

History

Appears in 4.3

Description

Download a pcap file from the firewall.

Usage

File name

SYSTEM PCAP LIST

Level

maintenance,modify,log

History

Appears in 4.3

Description

List all the pcap files stored on the firewall.

Returns

List of all the pcap files stored on the firewall.

Format

section_line



SYSTEM PCAP REMOVE

Level

maintenance,modify,log

History

Appears in 4.3

Description

Delete a single pcap file.

Usage

filename=<string> : name of the pcap file that will be deleted

SYSTEM PCAP START

Level

maintenance,modify,log

History

Appears in 4.3

Description

Start the network capture.

Usage

iface=<string> : Name of the network interface used for the capture

[maxpkt=1-2147483647] : Max number of packets allowed to be captured (default: 1000)

[maxtime=1-172800] : Time in seconds after which the capture will stop (default: 60)

[snaplen=0-262144] : Snarf snaplen bytes of data from each packet rather than the default of 262144 bytes. (default: 262144)

[filter=<string>] : Filters to be used by the capture

Example

SYSTEM PCAP START iface=in maxtime=180 maxpkt=100000 filter="icmp and src 192.168.30.1"

SYSTEM PCAP STATUS

Level

maintenance,modify,log

History

Appears in 4.3

Description

Give informations about an ongoing network capture.

Usage

Interface name

Format

section_line



SYSTEM PCAP STOP

Level

maintenance,modify,log

History

Appears in 4.3

Description

Stop the network capture on the given network interface

Usage

interface=<string> : name of the network interface used by the capture that will be stopped

SYSTEM PING

Level

maintenance

History

Appears in Netasq 9.0.1

type appears in 1.0.0

Format

section

Usage

host=<host> [source=<ip>] [type={ipv4|ipv6|any}]

<host> : destination host

<source> : the source ip address to be used

<type> : explicitly force IPv4 or IPv6 name resolving (default value is any)

Description

Calls the system's ping command

Returns

Error code

Example

SYSTEM PING host=update1-sns.stormshieldcs.eu

SYSTEM PING host=update1-sns.stormshieldcs.eu source=192.168.0.254

SYSTEM PING host=dns1.google.com type=ipv6 source=fd01::1

SYSTEM PROPERTY

Level

base

History

Bridge count appears in Netasq 6.2.0

MTUmax appears in Netasq 9.0.0

DefaultConfig appears in Netasq 9.0.1

PaygModel and AutoSizing tokens appear in 3.8

TPM, TpmInit appear in 3.10.0

**Description**

Get firewall information. This command is used to enumerate the firewall capabilities.

Returns

Type : type of product
Model : firewall model
Version : software revision
SerialNumber : serial number
MTUmax : maximum MTU allowed
Bridge : bridge number count
Ethernet : ethernet interface count
VLAN : vlan interface count
WIFI : wireless interface count
Dialup : dialup interface count
PPTP : PPTP interface count
Serial : serial line interface count
Loopback : loopback interface count
Watchdog : hardware watchdog available
Led : status LED available
Clone : clone partition available
HADialup : HA on dialup interface
Raid : RAID is active
Usb : USB port available
Antiviral : an antivirus is available
HighAvail : HA is available
SwitchPort : switch port count (0 if no switch available)
CryptoCard : a crypto card is available
TPM : a TPM is available
Tpmlnit : TPM is initialized (1 if initialized, else 0)
DefaultConfig : a default config has just been done
Amazon : VM type (Amazon or not)
Init : 0 means the product has to be activated
AutoSizing : Product adapts itself to the amount of RAM and CPU
AutoSizingModel : Equivalent running model
AutoSizingCurMem: Running memory for this model
AutoSizingMinMem: Minimum memory for this model
AutoSizingMaxMem: Maximum memory for this model
PaygEnrolled : PAYG VM has been enrolled
PaygWebcode : PAYG VM MyStormshield password
PaygCustomerId : PAYG customer identifier
PaygExpiration : PAYG licence expiration date
CurCPU : Running CPU number
MaxCPU : CPU number limit or 0 if unlimited

Example

```
SYSTEM PROPERTY
101 code=00a01000 msg="Begin" format="section" Type="Firewall"
Model="U120-A"
Version="9.0.0"
SerialNumber="U120XA5H1021960"
MTUmax=1500
Bridge=8
Ethernet=6
VLAN=64
WIFI=0
```



Dialup=8
PPTP=32
Serial=0
Loopback=7
Watchdog=0
Led=0
Clone=1
HADialup=1
Raid=0
Antiviral=1
HighAvail=1
Usb=1
SwitchPort=6
CryptoCard=0
TPM=0
TpmlInit=0
DefaultConfig=0
Amazon=0
Init=1
PaygEnrolled=0
PaygWebcode=""
PaygCustomerId=""
100 code=00a00100 msg="Ok"

SYSTEM REBOOT

Level

ha,maintenance,modify

History

force Appears in Netasq 6.0.0
level maintenance Appears in Netasq 6.0.0
level other deprecated in Netasq 6.0.0

Description

Reboot firewall

Usage

[force]

Returns

Error code

Example

SYSTEM REBOOT

SYSTEM REGISTER

Level

maintenance

History



Appears in Netasq 9.0.1
Deprecated in SNS 4.1.0

Description

Register online a new UTM

SYSTEM RIGHT**Level**

base

History

Appears in Netasq 9.0.0

Description

Display and update the user rights on the system

SYSTEM RIGHT ACTIVATE**Level**

admin,modify

History

Appears in Netasq 9.0.0

Description

Activate the new ruleset

Usage

[CANCEL | NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

SYSTEM RIGHT INSERT**Level**

admin,modify

History

Appears in Netasq 9.0.0

Description

Add a new rule in the set

Usage

[DomainName=<domain>] <user=<uid>|group=<cn>> manage=<rights> [ruleid=<number>]

SYSTEM RIGHT LIST**Level**

admin

**History**

Appears in Netasq 9.0.0

Description

Display the list of rules

Format

section_line

Returns

[Result]

ruleid=1 user="titeuf" manage="base,pki,modify"

ruleid=2 group="Comics Book" manage="base,ha,modify"

SYSTEM RIGHT MOVE**Level**

admin,modify

History

Appears in Netasq 9.0.0

Description

Change the order of a rule

Usage

ruleid=<number> to=<number>

SYSTEM RIGHT REMOVE**Level**

admin,modify

History

Appears in Netasq 9.0.0

Description

Remove a rule of the set

Usage

ruleid=<number>

SYSTEM RIGHT TICKET**Level**

base

History

Appears in 3.4.0

Description

Handle tickets



SYSTEM RIGHT TICKET ACQUIRE

Level

base

History

Appears in 3.4.0

Description

Use a ticket to get the access right in order to view restricted data. Only admin with unrestricted log access don't need a ticket.

Usage

passphrase=<passphrase>

Returns

Error or OK

SYSTEM RIGHT TICKET ACTIVATE

Level

modify,privacy

History

Appears in 3.4.0

Description

Apply ticket modification

Usage

[CANCEL | NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

SYSTEM RIGHT TICKET DELETE

Level

modify,privacy

History

Appears in 3.4.0

Description

Delete a ticket: this disconnects the users which are using it

Usage

id=<id>

Returns

Error or OK

SYSTEM RIGHT TICKET LIST

Level

privacy

History



Appears in 3.4.0

Description

List all created tickets

Returns

```
[ID1]
passphrase=<passphrase>
start=<start>
expire=<expire>
[ID2]
passphrase=<passphrase>
start=<start>
expire=<expire>
```

SYSTEM RIGHT TICKET NEW**Level**

modify,privacy

History

Appears in 3.4.0

Description

Create a new ticket

Usage

```
start=<yyyy-mm-dd hh:mm:ss> expire=<yyyy-mm-dd hh:mm:ss>
[passphrase=<passphrase>]
```

Returns

```
id=id
passphrase=<passphrase>
```

Example

```
SYSTEM RIGHT TOKEN NEW start="2017-10-10 10:10:10" expire="2017-12-12 12:12:12"
SYSTEM RIGHT TOKEN NEW start="2017-10-10 10:10:10" expire="2017-12-12 12:12:12"
passphrase=A1B2C3D4E5F6G7H8
```

SYSTEM RIGHT TICKET RELEASE**Level**

base

History

Appears in 3.4.0

Description

Release the ticket currently used

Returns

Error or OK

SYSTEM RIGHT UPDATE**Level**



admin,modify

History

Appears in Netasq 9.0.0

DomainName appears in 3.3.0

Description

Update a rule

Usage

ruleid=<number> [manage=<new rights>] [user=<uid> | group=<cn>] [comment=<comment>]
[domainname=<domainname>]

SYSTEM SESSION

Level

base

History

Appears in Netasq 9.0.0

Description

Set/show specific language for current session

Usage

[language=us|fr]

Example

SYSTEM SESSION language=fr

SYSTEM SETBOOT

Level

maintenance, modify

History

Appears in Netasq 6.2.0

Description

Set/show the boot partition

Usage

[boot=Main|Backup]

Returns

Error code or current value if no parameter :

[BackupInfo]

boot= : current partition

Example

SYSTEM SETBOOT

[BackupInfo]

boot=Main



```
SYSTEM SETBOOT boot=Backup  
100 code=00a00100 msg="Ok"
```

SYSTEM SETBRANCH

Level

maintenance, modify

History

Appears in 8.0.3

Description

Set the security branch (licence)

Usage

EUROPE|EXPORT1|EXPORT2|EXPORT3

Example

```
SYSTEM SETBRANCH EXPORT2
```

SYSTEM STATUS

Level

base

Description

Get 'NeedReboot' status (indicates if reboot is necessary to complete the configuration process)

Returns

```
101 code=00a01000 msg="Begin" format="section"  
NeedReboot=0  
100 code=00a00100 msg="Ok"
```

Example

```
SYSTEM STATUS
```

SYSTEM TPM

Level

base

Description

TPM password configuration

History

appears in 3.10.0

SYSTEM TPM CHANGE

Level

tpm,modify

**Description**

Change TPM password

Usage

currentpassword=<current_password> newpassword=<new_password>

- currentpassword : current TPM password
- newpassword : new TPM password

History

appears in 3.10.0

Returns

Warning/Error messages or ok

Example

SYSTEM TPM CHANGE

SYSTEM TPM INIT**Level**

tpm,modify

Description

Initialize TPM (password, masterkey generation)

Usage

tpmpassword=<password> [derivekey=on|off]

- tpmpassword : TPM password
- derivekey : 'on' to derive symmetric key from password

History

appears in 3.10.0

Returns

Warning/Error messages or ok

Example

SYSTEM TPM INIT

SYSTEM TPM PCRSEAL**Level**

tpm,modify

Description

Rehash TPM PCR

Usage

tpmpassword=<password> [serial={<serial>|passive|active|local}]

- tpmpassword : TPM password
- serial option is used to do the operation on HA peer firewall. By default the operation is done on the local firewall.

History



appears in 4.4.0

Returns

Warning/Error messages or ok

Example

SYSTEM TPM PCRSEAL tpmpassword=password

SYSTEM TPM RENEW

Level

tpm,modify

Description

Renew TPM symmetric key

Usage

tpmpassword=<password> derivekey=<on|off>

- tpmpassword : TPM password
- derivekey : 'on' to derive symmetric key from password

History

appears in 3.10.0

Returns

Warning/Error messages or ok

Example

SYSTEM TPM RENEW

SYSTEM TPM RESET

Level

tpm,modify

Description

Reset TPM

Usage

tpmpassword=<password> [force=<on|off>]

- tpmpassword : TPM password
- force : if token force is set to on, then private keys protected by TPM (ondisk) will be deciphered

History

appears in 3.10.0

Returns

Warning/Error messages or ok

Example

SYSTEM TPM RESET



SYSTEM TPM STATUS

Level

tpm

Description

Display TPM status information

Usage

```
tpmpassword=<password>  
- tpmpassword : TPM password
```

History

appears in 3.10.0

Returns

```
device_exists={0|1}  
onchip_init={0|1}  
ondisk_init={0|1}  
derived_key={0|1}
```

Example

SYSTEM TPM STATUS tpmpassword=password

SYSTEM TIMEZONE

Level

base

Description

Firewall timezone informations

SYSTEM TIMEZONE GET

Level

base

Description

Get current timezone

Returns

```
timezone= : fullname of timezone  
abbr= : abbreviation for current zone  
offset= : GMT +/- offset
```

Example

```
SYSTEM TIMEZONE GET  
timezone="Europe/Paris"  
abbr="CEST"  
offset="GMT+02:00"
```



SYSTEM TIMEZONE LIST

Level

base

History

Format Appears in Netasq 9.0.0

Description

Show list of timezones

Usage

[<pattern which occurred in zone name>]

Returns

<full timezone name> | <general timezone name>/<precise timezone name>

Format

list

Example

SYSTEM TIMEZONE LIST

Africa/

Africa/Algiers

Africa/Luanda

Africa/Porto-Novo

Africa/Gaborone

...

SYSTEM TIMEZONE LIST europe

Europe/

Europe/London

Europe/Belfast

Europe/Dublin

...

SYSTEM TIMEZONE SET

Level

maintenance, modify

History

level maintenance Appears in Netasq 6.0.0

level admin deprecated in Netasq 6.0.0

Description

Set firewall timezone (timezone name is case sensitive)

Usage

zone=<full timezone name>|<general timezone name>/<precise timezone name>

[force=<0|1>]

Returns

Error code

**Remark**

timezone names are case sensitive

Example

SYSTEM TIMEZONE SET "Europe/Paris"

SYSTEM TRACEROUTE

Level

maintenance

History

Appears in Netasq 9.0.1
type appears in 1.0.0

Format

section_line

Usage

host=<host> [pause=<milliseconds>] [source=<ip>] [type={ipv4|ipv6|any}]
<pause> : the delay between probes (allow bypassing packet rate limitation)
<ip> : the source ip address to be used
<type> : explicitly force IPv4 or IPv6 tracerouting. 'any' means IPv4 is preferred if both IPv4 and IPv6 addresses are available.

Description

Calls the system's traceroute or traceroute6 command

Example

SYSTEM TRACEROUTE host=www.stormshield.eu
SYSTEM TRACEROUTE host=update1-sns.stormshieldcs.eu source=10.0.0.254 pause=500

SYSTEM UPDATE

Level

base

Description

Firewall update functions

SYSTEM UPDATE ACTIVATE

Level

ha,maintenance,modify

History

level maintenance Appears in Netasq 6.0.0
level admin deprecated in Netasq 6.0.0
fwserial Appears in Netasq 9.0.0

Description

Install MAJ file

**Usage**

[fwserial={<serial>|all|local|active|passive}]

Returns

Error code

Example

SYSTEM UPDATE ACTIVATE

SYSTEM UPDATE ACTIVATE fwserial=U120-XXXX

SYSTEM UPDATE CHECK**Level**

base

History

Appears in Netasq 9.0.0

force appears in 1.0.0

ItsbOnly appears in 3.7.13

Description

Check new versions of firmware. Need access to internet and so, if necessary, a configured HTTP proxy.

Usage

[force=0|1] : specify if cache must be updated or not

[ItsbOnly=0|1] : specify if we want LTSB version only

Remark

HTTP proxy can be configured with CONFIG COMMUNICATION HTTPPROXY

if ItsbOnly is not specified, checkversion will choose itself according to the current firmware version.

Format

section_line

Example

SYSTEM UPDATE CHECK

SYSTEM UPDATE LOAD**Level**

ha,maintenance,modify

History

Appears in Netasq 7.0.0

Description

Load MAJ from file (on firewall or usb token). Use token force to install complete maj

Usage

file=<path of maj file> [force={0|1}] [fwserial={<serial>|all|local|active|passive}]

Remark



fwserial valid only in a HA cluster token force is used to force complete maj

SYSTEM UPDATE RESULT

Level

base

Description

Show the result of the last update

Usage

[clear]

Returns

[State]

Status= : result of maj

From= : previous firmware version

To= : current firmware version

Remark

Maintenance and Modify levels needed to clear

Example

SYSTEM UPDATE RESULT

[State]

Status=1

From="6.2.0"

To="6.2.1"

SYSTEM UPDATE STATUS

Level

base

History

Appears in Netasq 9.0.0

Description

Indicates if a firmware update has been uploaded and gets the firmware version provided by the update

Usage

[fwserial={<serial>|all|local|active|passive}]

Example

SYSTEM UPDATE HASUPD fwserial=all 101 code=00a01000 msg="Début" format="section"

[U120XXXXXXX] HasUpdate=1 UpdateVersion="9.0.0.beta-23" [U120XXXXXXX] HasUpdate=0
100 code=00a00100 msg="Ok"

SYSTEM UPDATE UPLOAD

Level

ha,maintenance,modify

**History**

level maintenance Appears in Netasq 6.0.0

level admin deprecated in Netasq 6.0.0

Description

Upload MAJ file to firewall

Usage

[force={0|1}] [fwserial={<serial>|all|local|active|passive}]

Returns

Error code

Remark

token force is used to force complete maj

Example

SYSTEM UPDATE UPLOAD

SYSTEM WATCHDOG**Level**

base

Description

Get/set the firewall watchdog

Usage

[<time>]

Returns

If no parameter is set, return information about the watchdog (current timeout, maximum timeout)

If the timeout parameter is set, return the new applied value:

timeout=

Remark

Time values are included in 10-max_timeout secs, and 0 used to stop watchdog

Maintenance and Modify levels needed to update value

Example

SYSTEM WATCHDOG 100

101 code=00a01000 msg="Début" format="section"

timeout=100

100 code=00a00100 msg="Ok"

SYSTEM WATCHDOG

101 code=00a01000 msg="Début" format="section"

timeout=100

max_timeout=900

100 code=00a00100 msg="Ok"



USER

Level

base

Description

User related functions.

USER ACCESS

Level

base

Description

User access control configuration

USER ACCESS ACTIVATE

Level

user,modify

History

Appears in Netasq 9.0.0

Description

Activate UAC configuration

Usage

[CANCEL|NEXTBOOT]

- no argument: changes are activated immediately;
- CANCEL: changes are discarded;
- NEXTBOOT: changes will be activated on next boot.

Returns

Error code

Example

USER ACCESS ACTIVATE

USER ACCESS DEFAULT

Level

base

History

Appears in Netasq 9.0.0

Description

show or update the default authentication rule

USER ACCESS DEFAULT SHOW

Level



base

History

Appears in Netasq 9.0.0

Description

Print the default authentication rule

Returns

The default rule for user access

Format

section_line

USER ACCESS DEFAULT UPDATE

Level

user,modify

History

Appears in Netasq 9.0.0 sponsoring Appears in 3.0.0

Description

Update the default authentication rule.

Returns

Error code

Usage

```
[auth=<pass|block>]
[authmethod=<plain|ssl|radius|kerberos|...>]
[sponsoring=<pass|block>]
[ipsec=<pass|block>]
[openvpn=<pass|block>]
[xvpn=<default|pass|profile|block>]
[xvpnprofile=<default|profile name>]
```

USER ACCESS INSERT

Level

user,modify

History

Appears in Netasq 9.0.0

src appears in Netasq 9.1.0

Description

Insert a rule at the end of the set. If id is specified the rule is insert at the specified position

Src parameter is a comma ',' separated list of objects or interfaces. Keyword ipsec can be used to configure XAUTH

authmethod is a ordered comma separated list of authentication method to be applied to the user

guest authentication method cannot be mixed with another method nor be used with a username

sponsor authentication method cannot be mixed with another method nor be used with a



username.

sponsor method is stricly linked to sponsor domain and vice-versa.

Returns

Error code

Usage

```
state=<on|off>
user=<uid>|group=<cn>
auth=<default|pass|block>
authmethod=<default,plain,ssl,radius,kerberos,spnego,agent,guest,voucher,sponsor>
src={any|<objectname>[,<interfacename>[,ipsec[,...]]]}
domainName=<domain>
[position=<digit>]
[comment=<string>]
```

For a separator:

```
separator=<Color>
collapse=<0|1>
[comment=<string>]
[position=<digit>]
```

USER ACCESS LIST

Level

base

History

Appears in Netasq 9.0.0

network appears in Netasq 9.1.0

Description

List the authentication rules

Returns

[Ruleset]

Usage

[useclone=<0|1>]

Format

section_line CACHE_CATEGORY uac

USER ACCESS MOVE

Level

user,modify

History

Appears in Netasq 9.0.0

Description

Move a new rule in the set. If a rule exists with the destination id, we increment all of the sub-id

Returns



Error code

Usage

position=<digit> to=<digit>

USER ACCESS REMOVE

Level

user,modify

History

Appears in Netasq 9.0.0

Description

Remove a rule from the specified set. All of the sub-id are re-numbered

Returns

Error code

Usage

position=<digit>

USER ACCESS RIGHT

Level

base

History

Appears in Netasq 9.1.0

Description

manage user access rights

USER ACCESS RIGHT INSERT

Level

user,modify

History

Appears in Netasq 9.1.0 sponsoring Appears in 3.0.0

Description

Insert a rule at the end of the set. If id is specified the rule is insert at the specified position
If xvpn parameter is set to profile and no profile is given. the programs take the profile in the default rule

Returns

Error code

Usage

[DomainName=<a_domain>]
state=<on|off>
user=<uid>|group=<cn>
sponsoring=<default|pass|block>
xvpn=<default|pass|profile|block>



```
ipsec=<default|pass|block>  
openvpn=<default|pass|block>  
[position=<digit>]  
[xvpnprofile=<profile name|{NOTHING for default}>]  
[comment=<string>]
```

For a separator:

```
separator=<Color>  
collapse=<0|1>  
[comment=<string>]  
[position=<digit>]
```

USER ACCESS RIGHT LIST

Level

base

History

Appears in Netasq 9.1.0

Description

List the right rules

Returns

[Ruleset]

Usage

[useclone=<0|1>]

Format

section_line CACHE_CATEGORY uac_right

USER ACCESS RIGHT MOVE

Level

user,modify

History

Appears in Netasq 9.1.0

Description

Move a new rule in the specified set. If a rule exists with the destination id, we increment all of the sub-id

Returns

Error code

Usage

position=<digit> to=<digit>

USER ACCESS RIGHT REMOVE

Level

user,modify

History

Appears in Netasq 9.1.0

**Description**

Remove a rule from the set. All of the sub-id are re-numbered

Returns

Error code

Usage

position=<digit>

USER ACCESS RIGHT UPDATE**Level**

user,modify

History

Appears in Netasq 9.1.0

sponsoring Appears in 3.0.0

Description

Update a rule in the specified set.

If xvpn parameter is set to profile and no profile is given. the programs take the profile in the default rule

Returns

Error code

Usage

position=<digit>
[state=<on|off>]
[user=<uid>|group=<cn>]
[sponsoring=<default|pass|block>]
[ipsec=<default|pass|block>]
[openvpn=<default|pass|block>]
[xvpn=<default|pass|profile|block>]
[xvpnprofile=<profile name|{NOTHING for default}>]
[comment=<string>]

For a separator:

position=<digit>
[separator=<Color>]
[collapse=<0|1>]
[comment=<string>]

USER ACCESS UPDATE**Level**

user,modify

History

Appears in Netasq 9.0.0

src appears in Netasq 9.1.0

Description

Update a rule in the set.

authmethod is a ordered comma separated list of authentication method to be applied to the



user
guest authentication method cannot be mixed with another method nor be used with a username
sponsor authentication method cannot be mixed with another method nor be used with a username.
sponsor method is stricly linked to sponsor domain and vice-versa.

Returns

Error code

Usage

```
position=<digit>
[state=<on|off>]
[user=<uid>|group=<cn>]
[src={any|<objectname>|,<interfacename>[,ipsec[,...]]}]
[auth=<default|pass|block>]
[authmethod=<default,plain,ssl,radius,kerberos,spnego,agent,guest,sponsor>]
[comment=<string>]
```

For a separator:

```
position=<digit>
[separator=<Color>]
[collapse=<0|1>]
[comment=<string>]
```

USER CERTIFICATE

Level

base

Description

Download the user certificate from LDAP directory. You must specify the output format of the certificate.

The format must be PEM, DER or P12.

Usage

```
<User ID>|<User DN> <format>
```

Returns

The file found in the LDAP directory.

USER CHECK

Level

user

History

Appears in Netasq 6.1.0

Format appears in Netasq 9.0.0

DomainName appears in 3.0.0

Description

Check if a user ID is used in the configuration.

**Usage**

name=<username> [domainname=<domain>]

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>
section=<string>]

Format

section_line

USER CREATE

Level

user,modify

History

DomainName appears in 3.4.0

Description

Create a new user.

Usage

uid=<uid> name=<name> [gname=<givenname>] [domainname=<ldap>]

Returns

The DN of the new user, or an error message (internal error / LDAP error).

Remark

"uid" is the LDAP reference for user login.
Some uids are forbidden (admin,ha...).
Check duplicated user (DN, login...).

Example

```
USER CREATE jd "DUPONT" Jean  
100 Dn="cn=Jean DUPONT,ou=users,o=stormshield,dc=int" CACHE_CATEGORY user
```

USER GROUP

Level

base

Description

User groups functions.

USER GROUP ADDTO

Level

user,modify

History

Named arguments and domainName appear in 3.4.0

**Description**

Add a user or a group to a group.

Usage

group=<group name>|<Group DN> member=<User Id>|<User DN>|<Group Id>|<Group DN>
[domainName=<ldap>]

Returns

Error code

Example

USER GROUP ADDTO group="end_user" member="cn=Jean
DUPONT,ou=users,o=stormshield,dc=int"

USER GROUP ADDUSER

Level

user,modify

Description

Add a user to a group.

Usage

<group name>|<group DN> <UserId>|<User DN>

Returns

Error code

Example

USER GROUP ADDUSER "end_user" "cn=Jean DUPONT,ou=users,o=stormshield,dc=int"

USER GROUP CHECK

Level

user

History

Appears in Netasq 6.1.0

Format appears in Netasq 9.0.0

DomainName appears in 3.0.0

Description

Check if a user group ID is used in the configuration.

Usage

name=<hostname> [domainname=<domain>]

Returns

[Configuration]

module=<string> [slot=<00-10> line=<int>| section=<string>|profile=<00-03>

section=<string>]

Format

section_line



USER GROUP CREATE

Level

user,modify

Description

Create a user group.

Usage

<group name> <User ID>|<User DN>

Returns

The DN of the new group, or an error message (internal error / LDAP error).

Example

```
USER GROUP CREATE "end_user" "fd" Dn="cn=end_user, ou=groups,o=Example,dc=COM"
```

USER GROUP DELUSER

Level

user,modify

Description

Remove a user from a group.

Usage

<group name>|<group DN> <UserId>|<User DN>

Returns

Error code

Example

```
USER GROUP DELUSER "end_user" "cn=Jean DUPONT,ou=users,o=stormshield,dc=int"
```

USER GROUP DESCRIPTION

Level

user

History

Named arguments and domainName appear in 3.4.0

Description

Get/Set a description for a user group.

Usage

group=<group name>|<group DN> [description=<comment>] [domainName=<ldap>]

Returns

Error code

Remark

Modify level is needed to set a description.

Example



```
USER GROUP DESCRIPTION "end_user" "Standard Users group"
USER GROUP DESCRIPTION "end_user"
[Group]
description="Standard Users group"
```

USER GROUP LIST

Level

base

History

level base appears in Netasq 6.1.0
level user deprecated in Netasq 6.1.0
Format appears in Netasq 9.0.0
Named arguments and domainName appear in 3.4.0

Description

List user groups.

Usage

```
[search=<search pattern>] [domainname=<domain>]
```

Returns

A list of matching DNs, or an error code.

Remark

List all groupofnames entries in the LDAP database.
Search pattern is used in CN, and "*" may be used as a wildcard.

Example

```
USER GROUP LIST
USER GROUP LIST search="*group*" domainname=ad_ldap
USER GROUP LIST search="*group*"
cn=testgroup1,ou=groups,o=Example,dc=COM cn=group2,ou=groups,o=Example,dc=COM
```

Format

list

USER GROUP NEW

Level

user,modify

History

Named arguments appears in 3.1.0
DomainName appears in 3.4.0

Description

Create a user group.

Usage

```
name=<group name> member=<User Id>|<User DN>|<Group Id>|<Group DN>
[domainname=<ldap>]
```

Returns



The DN of the new group, or an error message (internal error / LDAP error).

Example

```
USER GROUP NEW name="end_user" member="cn=end_user, ou=groups,o=Example,dc=COM"
```

USER GROUP REMOVE

Level

user,modify

Description

Remove a user group.

Usage

```
group=<group name>|<group DN> [domainName=<ldap>]
```

Returns

Error code

Example

```
USER GROUP REMOVE "end_user"
```

USER GROUP REMOVEFROM

Level

user,modify

Description

Remove a user from a group.

Usage

```
group=<group name>|<Group DN> member=<User Id>|<User DN>|<Group Id>|<Group DN>
```

Returns

Error code

Example

```
USER GROUP REMOVEFROM group="end_user" member="cn=Jean  
DUPONT,ou=users,o=stormshield,dc=int"
```

USER GROUP SHOW

Level

user

Description

Show a user group.

Usage

```
group=<group name>|<group DN> [domainname=<domain>]
```

Returns

```
[Group] objectClass="top"  
objectClass_2="groupofnames"  
description=<description>
```



```
cn=<group CN>  
member=<DN 1>  
member_2=<DN 2>  
member_x=<DN x>
```

Example

```
USER GROUP SHOW group="end_user"  
[Group]  
objectClass="top"  
objectClass_2="groupofnames"  
description="Groupe du personnel"  
cn="Personnel"  
member="cn=Ludovic MENTFLA,ou=users,o=stormshield,dc=eu"  
member_2="cn=Daniel QUETTECO,ou=users,o=stormshield,dc=eu"  
member_3="cn=Fabien MASTHO,ou=users,o=stormshield,dc=eu"  
member_4="cn=Raphael BAULTRAIM,ou=users,o=stormshield,dc=eu"  
Manage="modify,base,contentfilter,log,filter,vpn,pki,object,user"  
Access="pptp"
```

USER LIST

Level

base

History

NetasqAllowed-Access appears in Netasq 6.0.0
NetasqAllowed-Manage appears in Netasq 6.0.0
Format appears in Netasq 9.0.0
pagination appears in Netasq 9.0.0
NetasqAllowed-Access disappears in Netasq 9.0.0
NetasqAllowed-Manage disappears in Netasq 9.0.0

Description

List users from internal or external LDAP databases.

Usage

```
[[cn|uid|sn|description|all]=<search pattern>] [start=<int> [limit=<int>] [dir=<ASC|DESC>]  
[search=<pattern>]  
[sort=1] [refresh=<0|1>]] [domainname=<domain>]
```

Returns

A list of DNs.

Remark

List all inetOrgPerson entries in the LDAP database.
May take a while with huge LDAP databases.

Example

```
USER LIST  
cn=Foo,ou=users,o=Example,dc=COM  
cn=Bar,ou=users,o=Example,dc=COM  
USER LIST "cn=*"  
USER LIST uid=jd
```

Format



section_line CACHE_CATEGORY user

USER PASSWORD

Level

base,modify

History

dn appears in Netasq 6.0.0

password appears in Netasq 6.0.0

method appears in Netasq 6.0.0

hash appears in Netasq 6.0.0

method disappears in Netasq Netasq 9.1.0

DomainName appears in 3.4.0

Description

Update a user password.

Usage

```
dn=<User ID>|<User DN> password=<newpassword> [hash=<[S]MD5|[S]SHA|[S]SHA256|
[S]SHA384|[S]SHA512|PBKDF2|PBKDF2-SHA1|PBKDF2-SHA256|PBKDF2-
SHA512|CRYPT|NONE>] [domainName=<ldap>]
```

Returns

Error code

Remark

All users with MODIFY right can update their own passwords.

USER and MODIFY rights are needed to update passwords for users who are not administrators.

ADMIN and MODIFY rights are needed to update an administrator's password.

Arguments are not logged.

Example

```
user password dn=jd password=foo
100 Password updated for user jd
```

```
user password dn=jd password=bar method=SRP_LDAP
100 Password updated for user jd
```

```
user password dn=jd password=bar method=SRP_LDAP hash=SSHA
100 Password updated for user jd
```

USER REMOVE

Level

user,modify

Description

Delete a user.

Usage

```
<User ID>|<User DN>
```

Returns



Error code

Remark

ADMIN rights needed to revoke admin users.
The user cannot be removed if it is the last member of a group.

Example

```
USER REMOVE jd
USER REMOVE "cn=Jean DUPONT,ou=users,o=stormshield,dc=int" CACHE_CATEGORY user
```

USER REQUEST

Service/Enrolment

Level

base

Description

Command to manage User Request.

USER REQUEST APPROVED

Level

user,modify

Description

Validate the user request, the user is added in LDAP.

Usage

<id>

Returns

Error code

Remark

If a certificate request is attached to the user request,
this certificate request is saved in /usr/Firewall/ConfigFiles/PKI/work/ with format: email.csr.
The index file [/usr/Firewall/ConfigFiles/PKI/work/pending.csr] is updated.

Example

```
USER REQUEST APPROVED 106
```

USER REQUEST FORMAT

Level

base

Description

Manage uid format.

USER REQUEST FORMAT SET

Level

user

**History**

Appears in samoa.1

Description

Used to specify the format of user identifiers.

Usage

uid=<format>: uid format to apply during user enrollment

Returns

The current value (case of no arg) or error code

Remark

User requests are saved in /usr/Firewall/ConfigFiles/pending.enrollment

Example

```
USER REQUEST FORMAT SET uid=%F.%L
100 Success
```

USER REQUEST FORMAT SHOW**Level**

base

History

Appears in samoa.1

Description

Used to get the format of user identifiers.

Returns

The current value or error code.

Remark

The user identifier format is saved in /usr/Firewall/ConfigFiles/pending.enrollment

Example

```
USER REQUEST FORMAT SHOW
100 Uid="%F.%L"
```

USER REQUEST LIST**Level**

base

History

Format appears in Netasq 9.0.0
level changes from user to base in Netasq 9.0.0

Description

List all requests sent by users.

Returns

The list of pending LDAP requests (if found), or error code.

Remark



The user requests are saved in /usr/Firewall/ConfigFiles/PKI/work/pending.lap

Format

list

Example

USER REQUEST LIST

cn=jean DUPONT,email=jean.dupont@stormshield.eu,id=106 cn=jean
DURAND,email=jean.durand@stormshield.eu,id=107

USER REQUEST REMOVE

Level

user,modify

Description

Delete a user request.

Usage

<id>

Returns

Error code

Example

USER REQUEST REMOVE 106

USER REQUEST SENDMAIL

Level

user

Description

Specify if an email is sent to the user when the request is approved or removed.

Usage

[On|Off]

Returns

The current value (case of no arg) or error code.

Remark

We can upload two files with the subject and body of the email.

If no file is uploaded, the default subject and body are used.

If there is no argument, the command prints the actual value of the Send parameter.

The Modify level is needed to update the value.

Example

USER REQUEST SENDMAIL on

100 Success

USER REQUEST SENDMAIL

100 sendmail=0



USER REQUEST SHOW

Level

user

Description

Show the information about a specific request.

Usage

<id>

Returns

[Request]

RequestId= : request identifier

sn= : surname

givenName= : givenname

mail= : email address

description= : comment

telephoneNumber= : telephone number

UserPassword=None|Present : user has a password or not

uid= : user login

reqtype=None|Present : user has a request or not

Remark

Before the request is approved, it must set the value for 'uid'.

Example

USER REQUEST SHOW 106

[Request]

RequestId=106

sn="DUPONT"

givenName="jean"

mail="jean.dupont@stormshield.eu"

description="Test labo pour doc"

telephoneNumber="000"

UserPassword="Present"

uid=""

date="2006-05-18 07:50:27"

reqtype="Present"

USER REQUEST UPDATE

Level

user,modify

Description

Update the value of a token in a user request.

Usage

id=<id> token=<token> value=<value>

Returns

Error code

Remark



If the token does not exist on request, it is impossible to update.

Example

```
USER REQUEST UPDATE id="106" token="uid" value="jean.dupont"
```

USER SEARCH

Level

base

History

Appears in Netasq 9.0.0

DomainName appears in 3.0.0

Description

Search users and groups from internal or external LDAP databases.

Usage

```
filter=<search pattern> [DomainName=<domain|any>] [type=<user|group|any>] [start=<int>  
[limit=<int>] [dir=<ASC|DESC>]  
[search=<pattern>] [sort=1] [refresh=<0|1>]]
```

Returns

A result section with type=DN line.

Remark

List all inetOrgPerson entries in the LDAP database.

May take a while with huge LDAP databases.

Scan all LDAP databases if no domain is specified.

Example

```
USER SEARCH domainname=any filter="*toto*"
DomainName=domainA user="cn=Foo,ou=users,o=Example,dc=COM"
DomainName=domainA user_2="cn=Foo Bar,ou=users,o=Example,dc=COM"
DomainName=domainA group="cn=Bar,ou=groups,o=Example,dc=COM"
DomainName=domainB group_2="cn=Bar Foo,ou=groups,o=Example,dc=COM"
USER SEARCH filter="*toto*" type=user
DomainName=a_domain user="cn=Foo,ou=users,o=Example,dc=COM"
DomainName=a_domain user_2="cn=Foo Bar,ou=users,o=Example,dc=COM" USER SEARCH
domainname=internal.eu filter="*toto*" type=user
DomainName=internal.eu user="cn=Foo,ou=users,o=Example,dc=COM"
DomainName=internal.eu user_2="cn=Foo Bar,ou=users,o=Example,dc=COM"
```

Format

section_line CACHE_CATEGORY user

USER SHOW

Level

base

Description

Show a user's information.

**Usage**

user=<User ID>|<User DN> [attribute=<attribute>] [domainname=<domain>]

Returns

[User]

attribute=value

If an attribute has many values, they will be indexed:

attribute=value

attribute_2=value

attribute_3=value

Remark

USER or ADMIN rights needed for most attributes, except for UID, MAIL, SN, CN and givenname.

Example

USER SHOW "cn=Jean DUPONT,ou=users,o=stormshield,dc=int" mail

[User]

mail="jean.dupont@stormshield.eu"

USER SHOW jd

[User]

givenName="Jean"

objectClass="top"

objectClass_2="person"

objectClass_3="organizationalPerson"

objectClass_4="inetOrgPerson"

objectClass_5="StormshieldPerson"

uid="jd"

mail="jean.dupont@stormshield.eu"

cn="Jean DUPONT"

telephoneNumber="63"

sn="DUPONT"

USER UPDATE

Level

user,modify

History

Named arguments and domainName appear in 3.4.0

Description

Update value in a user attribute.

Usage

user=<User ID>|<User DN> operation={add|mod|del} attribute=<attribute> [value=<value>]
[domainname=<ldap>]

The list of attributes that can be updates is:

mail

description

uid

telephoneNumber

Returns



Error code

Remark

Some update operations may require specific rights:
Access requires ADMIN right to change other administrator access.
Some update operations (like password) must use specific commands.

Example

```
USER UPDATE USER="cn=Jean DUPONT,ou=users,o=stormshield,dc=int" OPERATION=add  
ATTRIBUTE=mail VALUE=jean.dupond@stormshield.eu  
100 code=00f01400 msg="Attribute updated"
```

```
USER UPDATE USER=jd OPERATION=mod ATTRIBUTE=mail VALUE=jean.dupont@stormshield.eu  
100 code=00f01400 msg="Attribute updated"
```

```
USER UPDATE USER=jd OPERATION=del ATTRIBUTE=mail  
100 code=00f01400 msg="Attribute updated" CACHE_CATEGORY user
```

USER VOUCHER

Level

user,guest_admin

Description

Manage voucher user pool

Usage

account

Returns

Error code

Example

```
USER VOUCHER ACCOUNT status
```

USER VOUCHER ACCOUNT

Level

user,guest_admin

Description

Manage a user pool.

Usage

create | revoke | clean | status

Returns

Error code

Example

```
USER VOUCHER ACCOUNT create  
USER VOUCHER ACCOUNT delete  
USER VOUCHER ACCOUNT clean  
USER VOUCHER ACCOUNT status
```




USER VOUCHER ACCOUNT CREATE

Level

user,guest_admin

Description

Create a user account.

Usage

```
firstname=<firstname> lastname=<lastname> [[company=<company>]  
[email=<email>]] starting_date=<yyyy-mm-dd> ending_date=<yyyy-mm-dd>
```

Returns

Error

Example

```
USER VOUCHER ACCOUNT CREATE firstname="John" lastname="Carthy" company="Lisp" starting_  
date="1972-09-04"  
ending_date="2011-10-24"  
USER VOUCHER ACCOUNT CREATE firstname="Alan" lastname="Kay" company="Smalltalk"  
starting_date="1972-09-04"  
ending_date="2011-10-24"
```

USER VOUCHER ACCOUNT DELETE

Level

user,guest_admin

Description

Delete a user from the guest LDAP.

Usage

```
uid=<uid>
```

Returns

Error code

Example

```
USER VOUCHER ACCOUNT DELETE uid="JohnMcCarthy"
```

USER VOUCHER ACCOUNT LIST

Level

user,guest_admin

Description

Print voucher user list.

Usage**Returns**

Error code

Example

```
USER VOUCHER ACCOUNT LIST uid="a1.a2" firstname="a1" lastname="a2" email="a3"  
company="a4" starting_date="1994030300Z" ending_date="19940303235959Z"
```



```
password="A6DAKbW" uid="john.mccarthy" firstname="john" lastname="mccarthy"  
email="j.m@mit.eud" company="mit" starting_date="1970030300Z" ending_  
date="20010303235959Z" password="A6DAKbW"
```

Format

section_line

USER VOUCHER ACCOUNT RESETPASSWORD**Level**

user,guest_admin

Description

Reset the guest user password.

Usage

uid=<uid>

Returns

Error code

Example

```
USER VOUCHER ACCOUNT RESETPASSWORD uid="JohnMcCarthy"
```

USER VOUCHER ACCOUNT STATUS**Level**

user,guest_admin

Description

Return user account status.

Usage

uid=<uid>

Returns

Error code

Example

```
USER VOUCHER ACCOUNT STATS uid="JohnMcCarthy"
```

USER VOUCHER ACCOUNT UPDATE**Level**

user,guest_admin

Description

Manage private LDAP server.

Usage

```
uid=<uid> [ firstname=<firstname>  
| lastname=<lastname>  
| company=<company>  
| email=<email>  
| startingdate=<yyyy-mm-dd>  
| endingdate=<yyyy-mm-dd> ]
```



Returns

Error code

Example

USER VOUCHER ACCOUNT UPDATE uid="JohnMcCarthy" company="MIT"



VERSION

Description

Display server version.

Returns

The version of the protocol and/or command.

Example

VERSION

Protocol=3

Command=4



STORMSHIELD

documentation@stormshield.eu

All images in this document are for representational purposes only, actual products may differ.

Copyright © Stormshield 2024. All rights reserved. All other company and product names contained in this document are trademarks or registered trademarks of their respective companies.