



**STORMSHIELD**



GUIDE

**STORMSHIELD NETWORK SECURITY**

# CLI CONSOLE / SSH COMMANDS REFERENCE GUIDE

Version 4.8.16 LTSB

Document last update: May 18, 2026

Reference: [sns-en-cli\\_console\\_ssh\\_commands\\_reference\\_guide-v4](#)



# Table of contents

- Introduction ..... 5
  - CONTENTS ..... 5
- CHAPTER1: Category Description ..... 6
  - HARDWARE ..... 6
  - LOW LEVEL CONFIGURATION ..... 6
  - FUNCTIONALITIES ..... 6
  - HIGH LEVEL CONFIGURATION MANAGEMENT ..... 7
  - FACTORY TOOLS ..... 8
  - DAEMON ..... 8
  - MISCELLANEOUS ..... 9
- CHAPTER2: Commands Description ... 12
  - ALIVECTL ..... 12
  - ALIVED ..... 15
  - ARKEEPALIVE ..... 15
  - ARPRESET ..... 16
  - ARPSYNC ..... 16
  - ASQD ..... 17
  - ASQSTART ..... 17
  - AUTHD ..... 18
  - AUTOBACKUP.SH ..... 18
  - AUTOUPDATE ..... 18
  - AVCTL ..... 19
  - AVD ..... 21
  - BACKUPINFO ..... 21
  - BACKUPRESTORE ..... 22
  - BIRD4 ..... 22
  - BIRD6 ..... 23
  - BIRD ..... 23
  - BIRDC ..... 23
  - BIRDC4 ..... 24
  - BIRDC6 ..... 24
  - BUILDDHCPD ..... 24
  - BUILDDIALUP ..... 25
  - BUILDDNS ..... 25
  - BUILDEVENT ..... 26
  - BUILDFILTER ..... 26
  - BUILDHA ..... 27
  - BUILDIPSEC ..... 27
  - BUILDLDAPCONF ..... 28
  - BUILDNTP ..... 28
  - BUILDOPENVPN ..... 29
  - BUILDSNMP ..... 29
  - BUILDSSH ..... 30
  - BUILDWIFI ..... 30
  - CAD ..... 30

- CERTENROL ..... 31
- CERTINFO ..... 32
- CERTREQCTL ..... 33
- CERTREQD ..... 34
- CHECK\_DOWNGRADE\_VERSION ..... 34
- CHECKCRL ..... 35
- CHECKDB ..... 35
- CHECKFS ..... 37
- CHECKFW ..... 37
- CHECKINTEGRITY ..... 38
- CHECKINTERNET ..... 38
- CHECKPIM ..... 39
- CHECKVERSION ..... 39
- CHPWD ..... 40
- CLAMAVD ..... 40
- CLAMDEFAULT ..... 41
- CLASSIFYHOST ..... 41
- CLASSIFYURL ..... 42
- CLEANFW ..... 42
- CLEANPATTERN ..... 43
- CLEARLOG ..... 43
- CLEARUNWANTEDFILES ..... 44
- COLLECTORCTL ..... 44
- COLLECTORD ..... 45
- CONFBYPASS ..... 45
- CONFTUNING ..... 46
- COROSYNC ..... 46
- CRLINFO ..... 47
- CURLTOOL ..... 47
- DATE ..... 48
- DDNSCLIENT ..... 49
- DECBACKUP ..... 49
- DEFAULTCONFIG ..... 50
- DHCLIENT ..... 51
- DHCLIENT-SCRIPT ..... 52
- DHCPD ..... 52
- DHCPINFO ..... 53
- DHCRELAY ..... 53
- DHLEASE-SCRIPT ..... 54
- DIALUPSTATE ..... 54
- DKILL ..... 54
- DMIDECODE ..... 55
- DNSCACHE ..... 55
- DSTAT ..... 56
- DUMPROOT ..... 57
- ENALIVED ..... 57
- ENANTIVIRUS ..... 58
- ENASQ ..... 58
- ENAUTH ..... 59
- ENAUTHD ..... 59



ENBIRD .....	60	GATEWAYCTL .....	84
ENBYPASS .....	60	GATEWAYD .....	85
ENCBACKUP .....	61	GETALARMCONF .....	86
ENCONSOLE .....	61	GETCONF .....	86
ENDHCP .....	62	GETLICENCE .....	87
ENDHCRELAY .....	62	GETLICENCE_TOKEN .....	88
ENDIALUP .....	63	GETMODEL .....	89
ENDNS .....	63	GETPCI .....	90
ENEVENT .....	63	GETVERSION .....	91
ENFILTER .....	64	GLOBALGEN .....	91
ENGATEMON .....	65	HAACTIVE .....	92
ENHA .....	65	HADIFF .....	92
ENKEYBOARD .....	65	HAINFO .....	93
ENLDAP .....	66	HALT .....	93
ENLOCK .....	66	HAMODE .....	94
ENLOG .....	67	HAPASSIVE .....	94
ENMULTICAST .....	67	HARDWARECTL .....	94
ENNETWORK .....	68	HARDWARED .....	95
ENNTP .....	69	HARESET .....	95
ENOBJECT .....	69	HASCP .....	96
ENOPENVPN .....	70	HASSH .....	96
ENPATTERN .....	70	HASYNC .....	97
ENPROXY .....	71	HASYNCTEST .....	97
ENREFRESH .....	71	HOSTCHECK .....	97
ENREPORT .....	71	IFINFO .....	98
ENROLL .....	72	IOCTLFW .....	99
ENSERVICE .....	72	KEEPALIVE .....	99
ENSL .....	73	LAUNCHCTL .....	100
ENSNMP .....	73	LAUNCHD .....	101
ENSSO .....	74	LAUNCHER_LOG .....	101
ENSWITCH .....	74	LDAPCHECK .....	102
ENTELEMETRY .....	74	LDAPMANAGER .....	102
ENTHIND .....	75	LICENCEDIAG .....	103
ENTIMEZONE .....	75	LICENCEUPDATE .....	104
ENTS .....	76	LOGCTL .....	104
ENURL .....	76	LOGD .....	105
ENUSERPREFS .....	77	LOGDISK .....	106
ENUSERREQD .....	77	MEMCHECK .....	106
ENVOUCHER .....	78	MEMLIMIT .....	107
ENVPN .....	78	MODCHECK .....	107
ENWEBSERVICES .....	79	MODEMCTL .....	108
ENWIFI .....	79	MONITORCTL .....	109
ESTENROLL .....	80	MPD .....	109
EVENTD .....	81	NDMSG .....	110
EXPORTCONF .....	81	NEWLDAPBASE .....	110
FWINIT .....	82	NGSTAT .....	111
FWPASSWD .....	82	NHUP .....	111
FWSHUTDOWN .....	83	NKILL .....	111
FWSOUND .....	83	NRAID .....	112
FWUPDATE .....	84	NRELOAD .....	112



NRESTART .....	113	SLOTINFO .....	146
NSBSDSTART .....	113	SMARTCK .....	147
NSBSDSTOP .....	113	SMARTCTL .....	147
NSRPC .....	114	SMCROUTERD .....	149
NSTART .....	115	SNMPD .....	149
NSTOP .....	115	SSLINIT .....	150
NTPD .....	116	SSOD .....	151
NTPQ .....	117	STATECTL .....	151
NVERBOSE .....	118	STATED .....	153
NVMCHECK .....	118	STRONGSWAN_AUTH .....	153
OBJECTSYNC .....	119	STRONGSWAN_SSO .....	154
OCSPCHECK .....	119	SWANINFO .....	154
OPENVPN .....	120	SWITCHCTL .....	155
OPENVPN_AUTH .....	120	SWITCHD .....	155
OPENVPN_CLEAN_USERTABLE .....	121	SYSDBG .....	156
OPENVPN_CONNECT .....	121	SYSINFO .....	156
OPENVPN_DISCONNECT .....	122	SYSUTIL .....	157
OPENVPN_PROXYCTL .....	122	TCPICK .....	158
OPENVPN_PROXYD .....	123	TELEMETRYD .....	158
P12IMPORT .....	123	TESTLDAPBASE .....	159
PAYGPREP .....	124	THIND .....	159
PIMCTL .....	124	TOPIC_MONITOR .....	160
PIMD .....	126	TOPIC_READER .....	160
PKICTL .....	126	TOPIC_SENDER .....	161
POWERSTATUS .....	127	TPMCTL .....	161
PPPDOWN .....	127	TPROXYD .....	162
PPPDOWN2 .....	128	TSD .....	163
PPPUP .....	128	UDPSYNC .....	164
PPPUP2 .....	129	URLCTL .....	164
PVMGENCONF .....	129	URLD .....	165
REBOOT .....	130	USERREQD .....	165
REMOTE_SHELL .....	130	VMREPORT .....	166
ROUTERCTL .....	131	WIZARDINIT .....	166
ROUTERD .....	132		
SECADM .....	133		
SENDALARM .....	133		
SENDFILE .....	134		
SENDLOG .....	135		
SERVERD .....	135		
SERVICE_CLIENT .....	136		
SERVICE_SERVER .....	136		
SETBOOT .....	137		
SETCONF .....	137		
SETKEY .....	138		
SETPERMISSIONS .....	138		
SETSAREPLAYCOUNTER .....	139		
SETURL .....	139		
SFCTL .....	140		
SLAPD .....	145		
SLD .....	146		



## Introduction

This document details all the Stormshield Network commands of the firewall for the release version 4.8.16 LTSB.

### ! IMPORTANT

- This command list is dedicated to the partners that have been certified by Stormshield and who realize some support to their customers.
- These commands are normally called by "high level" configuration commands to activate parts of the configuration.

No verification is made about coherency when calling directly those commands. A direct call to those commands can put the firewall in an unstable state.

## CONTENTS

The command list is in alphabetical order but organized by category. The categories are:

- Hardware
- Low level configuration
- Functionalities
- High level configuration management
- Factory tools
- Daemon
- Miscellaneous



# CHAPTER1: Category Description

## HARDWARE

### Description

This category groups all the commands used to communicate and to manage the hardware.

### Index

The alphabetic list of each command of this category is the following:

hardwarectl  
powerstatus

## LOW LEVEL CONFIGURATION

### Description

This category groups all the commands used to manage configuration at low level.

### Index

The alphabetic list of each command of this category is the following:

arpreset  
arpsync  
arpkeepalive  
builddhcpd  
builddialup  
builddns  
buildevent  
buildfilter  
buildipsec  
buildha  
builldapconf  
buildntp  
buildopenvpn  
checkpim  
buildsnmp  
buildssh  
buildwifi  
ioctlfw

## FUNCTIONALITIES

### Description

This category groups all the commands which use functionalities of the IPS-Firewall.

### Index

The alphabetic list of each command of this category is the following:

alivectl  
autoupdate



checkcrl  
certenrol  
curltool  
ddnsclient  
dhclient  
dhclient-script  
dhlease-script  
dumproot  
estenroll  
gatewayctl  
hacheckstatus  
hastart  
keepalive  
launchctl  
ldapcheck  
newldapbase  
objectsync  
ocspcheck  
setkey  
setsareplaycounter  
sfctl  
smartctl  
statectl

## HIGH LEVEL CONFIGURATION MANAGEMENT

### Description

This category groups all the commands used to manage the configuration at high level.

### Index

The alphabetic list of each command of this category is the following:

alivectl  
avctl  
backupinfo  
certreqctl  
date  
defaultconfig  
dialupstate  
enalived  
enantivirus  
enasq  
enauth  
enbird  
enbypass  
enconsole  
endhcp  
endhcrelay  
endialup  
endns  
enevent  
enfilter  
enha  
enkeyboard



enldap  
enlock  
enlog  
enmulticast  
ennat  
ennetwork  
ennntp  
enobject  
enopenvpn  
enpattern  
enproxy  
enrouterd  
enservice  
ensl  
ensnmp  
ensso  
enswitch  
entelemetry  
enthind  
entimezone  
enurl  
enuserreqd  
envpn  
enwifi  
ifinfo  
launcher\_log  
monitorctl  
pimctl  
routerctl  
setboot  
slotinfo  
urlctl

## FACTORY TOOLS

### Description

This category groups all the commands used by the factory. It is not recommended to launch these commands on your IPS-Firewall.

### Index

The alphabetic list of each command of this category is the following:

checkintegrity  
cleanfw  
fwinit  
kldbgload.sh  
udpsync

## DAEMON

### Description

This category groups all the daemons of the IPS-Firewall.



## Index

The alphabetic list of each command of this category is the following:

alived  
asqd  
avd  
bird  
bird4  
bird6  
cad  
clamavd  
collectord  
dhclient  
dhcpcd  
dhcrelay  
dnscache  
eventd  
gatewayd  
hardwaredd  
launchd  
logd  
mpd  
ntpd  
openvpn  
pimd  
routerd  
serverd  
sld  
smcrouterd  
snmpd  
stated  
switchd  
telemetryd  
thind  
tproxyd  
urld  
userreqd

## MISCELLANEOUS

### Description

This category groups all the commands that are not in a particular category.

### Index

The alphabetic list of each command of this category is the following:

certinfo  
checkdb  
checkfs  
checkintegrity  
checkinternet  
checkversion  
chpwd



clamdefault  
cleanunwantedfiles  
clearlog  
crlinfo  
decbackup  
dhcpinfo  
dkill  
dstat  
dumpcert  
encbackup  
enroll  
exportconf  
formatdisk  
fwpasswd  
fwshutdown  
fwsound  
fwupdate  
getalarmconf  
getconf  
getlicence\_token  
getlicense  
getmodel  
getpci  
getversion  
globalgen  
haactive  
hainfo  
halt  
hapassive  
haret  
hasync  
hostcheck  
imish  
licencediag  
licenceupdate  
licensemanager  
logtools  
modemctl  
ndmesg  
ngstat  
nhup  
nkill  
nreload  
nverbose  
nrestart  
nsbsdstart  
nsbsdstop  
nsrpc  
nstart  
nstop  
paygprep  
ntpq  
pppdown  
pppdown2  
pppup



pppup2 check\_downgrade\_version  
memcheck  
certreqctl  
certreqd  
pvmdbsync  
pvmgenconf  
reboot  
remote\_shell  
secadm  
sendalarm  
sendlog  
service\_client  
service\_server  
setconf  
setpermissions  
seturl  
strongswan\_sso  
swaninfo  
swapethernet  
sysdbg  
sysinfo  
sysutil  
tcpick  
testldapbase  
topic\_collector  
topic\_emitter  
topic\_monitor  
topic\_reader  
topic\_sender  
vmreport



## CHAPTER2: Commands Description

---

Following is the description of every CLI/SSH command:

### ALIVECTL

#### Description

Client application used to access to information provided by the icmp monitoring daemon (alived)



## Command

```
alivectl [-h] [-B] [-d] [-o] [-v] -s <hostname> | -l | -r  
<arg> | --dump-config
```

-h, --help : display this message

-B, --background : execute in background (will not print the results)

-d, --debug : enable debug mode

-o, --libxo <output format> : specify the output format, <output format> may be "text|html|xml|json[,pretty]" (default is "text,pretty")

-m, --force-hamode <arg> : Force alived to reload its configuration with the given ha mode <arg>. Exclusive with other queries. Arg must be one of: "active","passive"

-l, --list <arg> : list hosts monitored by alived. <arg> can be used to filter hosts to display

-s, --show-measure <arg> : show measurements published by alived. <arg> can be used to filter measurements to display with the following values :

1. "host" : show the measurements for all links (gateway/ha link) of the specified router object or a HA peer.
2. "host":"link" : show measurements for the link of the specified router object or a HA peer.
3. ":"link" : show measurements for the specified link regardless of the router object or a HA peer.

-c, --show-measure-counter <arg=5> : Number of measurements published by alived to show. To use in combination of -s option. <arg> can't be equal to 0.

-t, --show-measure-timeout <arg=60> : Timeout in seconds to show the measurements published by alived. To use in combination of -s option. <arg> can't be equal to 0.

-r, --reload-config <arg> : make alived reload its configuration. Exclusive with other queries. <arg> must be one of: "verbose", "objects", "all"

--dump-config : dump alived current configuration. Exclusive with other queries

## Results

The statistics, the real-time measure and the list of monitored hosts.



## Example

```
VMSNSX00Z0000A0>alivectl -l my_second_router --libxo
json,pretty
{
  "RequestStatus": {
    "Status": "ok"
  },
  "Host": {
    "Status": "ok",
    "Result": {
      "my_second_router": [
        {
          "name": "dmz2_other_in",
          "ipAddress": "192.168.61.102",
          "enableMonitoring": 1,
          "endpoints": [
            {
              "target": "192.168.202.254"
            }
          ]
        },
        {
          "name": "target_network2_out",
          "ipAddress": "192.168.202.254",
          "enableMonitoring": 1,
          "endpoints": [
            {
              "target": "8.8.8.8"
            }
          ]
        }
      ],
      "name": "dmz2_other_out",
      "ipAddress": "192.168.202.101",
      "enableMonitoring": 1,
      "endpoints": [
        {
          "target": "204.13.248.112"
        },
        {
          "target": "216.146.43.70"
        },
        {
          "target": "8.8.8.8"
        },
        {
          "target": "8.8.4.4"
        },
        {
          "target": "192.168.202.254"
        }
      ]
    }
  ]
}
```



```
}  
  ]  
  }  
  }  
}
```

## ALIVED

### Description

ICMP monitoring daemon. Monitor both PBR route and HA links.

### Command

```
alived [-d] [-D] [-h] [-l] [-v]  
-D : will daemonize  
-d : debug mode  
-h : show help message  
-l : print the list of hosts to be monitored then exit  
-v : verbose mode
```

### Results

### Example

```
alived -l  
host my_router:dmz1_other_in  
host my_router:target_network_in  
host my_second_router:dmz2_other_in  
host my_second_router:target_network2_out  
host my_second_router:dmz2_other_out
```

## ARKEEPALIVE

### Description

Run an ARP request for each entry in the ConfigFiles/arpkeepalive file.

### Command

```
arpkeepalive [-v] [-h]
```

### Options

-v : verbose mode -h : help



## Results

## Example

## ARPRESET

### Description

Sends ARP packets to the interfaces in order to update the ARP tables and to get the MAC adress for macless return routes.

### Command

```
arpreset
```

### Options

<-a|-A> | <interface> -a -A : all interfaces

### Options

-r : send arp request on macless return routes -d : daemonize -c <count> : send reset count times -i <wait> : wait milliseconds between each reset

## Results

## Example

## ARPSYNC

### Description

Synchronize the local ARP table.

### Command

```
arpsync -a|u|d -[4|6] [-n] [-v] [-h]  
-a: setup ARP/NDP table (deprecated)  
-d: cleanup ARP/NDP table (deprecated)  
-u: update ARP/NDP table  
-4: only setup the ARP table  
-6: only setup the NDP table  
-n: setup/cleanup only NAT entry
```



-v: verbose mode  
-h: help  
Remarks :  
By default, both ARP and NDP (if IPv6 is enabled) tables are setup, unless -4 or -6 option is specified.  
The -a and -d option have been deprecated since the introduction of the -u option.

## Results

## Example

## ASQD

### Description

Daemon of configuration and supervising ASQ.

### Command

```
asqd [-r user] [-D] [-d] [-v]  
-r user : Run as the specified user.  
-D : Daemon.  
-d : Activate debug for the current running asqd (pvm debug).  
-v : Display asqd version.
```

## Results

## Example

## ASQSTART

### Description

### Command

```
asqstart (no argument)
```

## Results



## Example

## AUTHD

### Description

Authentication daemon

### Command

```
authd [-d] [-v] [-h]
```

-d, --daemonize: will daemonize

-v, --verbose : verbose mode

-h, --help : show this help

### Results

## Example

## AUTOBACKUP.SH

### Description

Automatic backup the configuration files.

### Command

```
autobackup.sh [-d]
```

-d: debug

### Results

## Example

## AUTOUPDATE

### Description

Updates data for the modules listed below.



## Command

```
autoupdate [-b] [-f] [-s] [-d] [-n] [-v] [-t <module>] | [-?]  
-b Build data directories  
-f Force a master update  
-d Launch autoupdate in the background  
-n Accept non-signed updates  
-v Enable debug verbose to stdout  
-s Show config  
-t  
(Antispam|URLFiltering|Patterns|CustomPatterns|AdvancedAV|Clam  
av|Vaderetro|Pvm|RootCertificates|IPData) module to update
```

## Results

Database of the corresponding modules has been updated.

## Example

## AVCTL

### Description

Manages antivirus daemon.

### Command

```
avctl [-v] [-o] [-q] [-B] [-r <reload flags>] [-R <reason>] [-  
s <filepath>] [-b] [--sbx-profile-file <profile>] [--sbx-ctx-  
file <context>] [-d] [-i] [-l]  
-h [ --help ] : Display this message  
-v [ --verbose ] : Enable verbosity  
-q [ --quiet ] : Do not print the results to standard output  
-B [ --background ] : Execute in background (will not print  
the results)  
-s [ --scan-file ] <file_path> : Scan the given file  
-b [ --sandboxing ] : Perform a sandboxing analysis (apply  
only when action is scan-file)  
--sbx-ctx-file <context> : File containing the sandboxing  
context parameters  
--sbx-ctx-src-addr <ip> : sandboxing context source address  
--sbx-ctx-src-port <port> : sandboxing context source port  
--sbx-ctx-dst-addr <ip> : sandboxing context destination  
address  
--sbx-ctx-dst-port <port> : sandboxing context destination  
port  
--sbx-ctx-dst-name <dtsname> : sandboxing context destination  
name ( only used in ftp and pop3 case )  
--sbx-ctx-src-mac <mac> : sandboxing context source mac  
address
```



```
--sbx-ctx-user <user> : sandboxing context user
--sbx-ctx-is-ssl (0|1) : sandboxing context indicates if the
connection is SSL
--sbx-ctx-blocked-by (av_filtering|sbx_filtering|antispam) :
sandboxing context "blocked by" information
--sbx-ctx-media-type (ex: application/pdf) : the media-type of
the file
--sbx-ctx-submit-file (0|1) : allow sending file to sandboxing
--sbx-ctx-proto (HTTP|FTP|SMTP|POP3) : sandboxing context
protocol
--sbx-ctx-http-method (GET|POST|...) : sandboxing context HTTP
method
--sbx-ctx-http-url-path-query <url> : sandboxing context HTTP
encoded url path and query(ex:
"/download.php%3Fparam1%3Dval1%26param2%3Dval2")
--sbx-ctx-http-dst-name <destname> : sandboxing context HTTP
destination name
--sbx-ctx-http-filename <filename> : sandboxing context HTTP
file name
--sbx-ctx-ftp-command (GET|PUT|...) : sandboxing context FTP
command
--sbx-ctx-ftp-filename <filename> : sandboxing context FTP
file name
--sbx-ctx-ftp-filepath <filepath> : sandboxing context FTP
file path
--sbx-ctx-ftp-is-download (0|1) : sandboxing context FTP
indicates if this is a download
--sbx-ctx-smtp-sender <sender> : sandboxing context SMTP
sender
--sbx-ctx-smtp-recipients <recipients> : sandboxing context
SMTP recipients list (ex: "foo@domain.com,bar@domain.org")
-r [ --reload-config ] (all|verbose|av_engine|av_settings|sbx_
settings) : Make avd reload partially or totaly its
configuration
-d [ --dump-config ] : dump avd current configuration
-i [ --dump-db-info ] : dump information about currently
loaded Database
-l [ --dump-license-info ] : dump information about currently
loaded license
-R [ --reload-reason ] <reason> : Text to explain why the
reload was made
-o [ --libxo ] (text|html|xml|json)[,pretty] : specify the
output format (default is "text,pretty")
--pause : pauses avd scans
--resume : resumes avd scans
--dump-file <filename> : Ask for a response dump, written to
the specified file in json format
--include-dir <directory> : Directory hosting flatbuffer
definitions (optional)
--schema-file <filepath> : Main flatbuffers definition file
```



## Results

A command is sent to avd. Execution will hold until a response is received from avd, unless a background execution is asked.

## Example

## AVD

## Description

Antivirus daemon for advanced antivirus and Sandboxing analysis.

## Command

```
avd [-d] [-D] [-h]
-h Help
-d If an other process is already running, send it a signal to
switch its verbose mode, otherwise start with verbose mode
enabled.
-D Daemonize, run in background.
```

## Results

## Example

## BACKUPINFO

## Description

Display some information about the backup partition. Display an information about active partition : main or backup.

## Command

```
Backupinfo [-s | -l ]
-s : Print "[BackupInfo]" to the stdout
-l : Internal option.
```

## Results



## Example

```
SN910A17A1711A7>backupinfo
Active=Main
BackupVersion="4.1.5"
BackupBranch=""
Date="2021-04-20 14:59:59"
Boot=Main
BootPartitionFileMissing=1
```

## BACKUPRESTORE

### Description

Restore backup from file passed as argument.

### Command

```
backuprestore -f <file path> [-P] [-p <password>] [-u] [-v]
-v : verbose mode
-r : refresh after restore
-p : password associated with backup file
-P : prompt for a password
-f : backup file to restore
```

### Results

## Example

## BIRD4

### Description

Version 1 of Bird for IPv4, a fully functional dynamic IP routing daemon for IPv4.

### Command

```
bird4 [--version] [--help] [-c <config-file>]
```



## Results

## Example

## BIRD6

### Description

Fully functional dynamic IP routing daemon for IPv6.

### Command

```
bird6 [--version] [--help] [-c <config-file>]
```

## Results

## Example

## BIRD

### Description

Fully functional dynamic IP routing daemon for IPv4.

### Command

```
bird [--version] [--help] [-c <config-file>]
```

## Results

## Example

## BIRDC

### Description

Bird command-line interface client for IPv4.

### Command

```
birdc [-s <control-socket>] [-v] [-r] [-l]
```



## Results

## Example

## BIRDC4

### Description

Command-line interface client for Bird version 1 for IPv4.

### Command

```
birdc4 [-s <control-socket>] [-v] [-r] [-l]
```

## Results

## Example

## BIRDC6

### Description

Bird comand-line interface client for IPv6.

### Command

```
birdc6 [-s <control-socket>] [-v] [-r] [-l]
```

## Results

## Example

## BUILDDHCPD

### Description

Converts the configuration files of DHCP to the config file for the daemon dhcpd. This binary is called by endhcp.



## Command

```
builddhcpd [-4|-6] [-r] [-t] [-o config-file]  
-4 : IPv4  
-6 : IPv6  
-r : Setup dhcp relay configuration and exit  
-t : Make dhcpd tests after build  
-o config-file : Set configuration file
```

## Results

## Example

## BUILDDIALUP

### Description

Converts the configuration files of mpd-netgraph to the config file for the daemon mpd. Dialup access (RTC, RNIS, PPPoE, PPTP). This binary is called by endialup.

### Command

```
buildpdialup [-x <if> ]  
-x : doesn't modify config files for the interfaces listed in  
<if>
```

## Results

## Example

## BUILDDNS

### Description

Converts the configuration files of DNS to the config file used by the dnscache. This binary is called by endns.

### Command

```
builddns [-c]  
-c : update only clients information. This doesn't require a  
daemon restart to be effective.
```



## Results

## Example

## BUILDEVENT

### Description

Converts the configuration files of the events to the config file for the daemon eventd. This binary is called by eventd.

### Command

```
buildevent [-s | -c <eventfile> | -f <output file>] [-v] [-h] [-?]
```

```
-h, -? help  
-s show only the valid events but don't write them to disk  
-c <event file> strict validation of the content of an event file  
-f <output file> generate the eventd configuration in a specific file  
-v display verbose on stdout
```

## Results

## Example

## BUILDFILTER

### Description

Converts the configuration files of filtering slot to the config file. This binary is called by enfilter.

### Command

```
buildfilter -h -v -s | -m [-x] | [-i] [-f <Global FilterFile> <FilterFile>] [-x] [-w] [-e] [-a <ASQ filter rules>] [-p <Proxy filter rules>]  
-f <Global Filterfile> <Local Filterfile> : input  
-a <ASQ filter rules> : output  
-p <Proxy filter rules> : output  
Possible outputs: 'none', 'stdout', 'stderr', <filename>  
Default for ASQ filter rules: 'stdout'
```



```
Default for Proxy filter rules: 'none'  
-h help  
-i implicit filtering rules  
-m minimal filtering rules  
-v verbose  
-s display warning and error messages in a more easy-to-parse  
manner  
-x XML output  
-w suppress warning messages  
-e enforce rule checking policy, some warning are now  
considered errors
```

## Results

## Example

## BUILDHA

### Description

### Command

```
buildha:  
-o : Check HA config and build Corosync config (default  
action)  
-b : Do actions that must be done at boot (create cluster or  
join cluster)  
-c <HA config file> : Create a cluster starting from the given  
HA config file  
-j <HA config file> : Joins an existing HA cluster  
-v : verbose
```

## Results

## Example

## BUILDIPSEC

### Description

Converts the configuration files of the VPN IPSEC to the config file for the daemon Charon. This binary is called by envpn.



## Command

```
buildipsec <action> --global=<file> --local=<file><action> is  
one of the following:  
--check : check the configuration  
--dumpconf : dump the parsed configuration  
--build : build configuration
```

## Results

## Example

## BUILDLDAPCONF

### Description

Converts the configuration files of the LDAP to the config file for the daemon ldapd. This binary is called by enldap.

### Command

```
buildldapconf [-a] [-v] [-h]  
-a : activate HA  
-v : verbose  
-h : help
```

## Results

## Example

## BUILDNTP

### Description

Converts the configuration files of NTP to the config file for the daemon ntpd. Sanity limit is set to 1 second. This binary is called by enntp.

### Command

```
buildntp [-h]
```

## Results



## Example

## BUILDOPENVPN

### Description

Converts the configuration files of OpenVPN to the config file for the daemon openvpn. This binary is called by enopenvpn.

### Command

```
buildopenvpn [-d <dir>] [-h] [-v]
-d : set directory to write the config to <dir> (default is
'/var/tmp/Openvpn/')
-v : set verbose level to debug
-h : display this help
```

### Results

## Example

## BUILDSNMP

### Description

Converts the configuration files of net-snmp to the config file for the daemon snmpd. This binary is called by ensnmp.

### Command

```
Buildsnmp (no argument)
```

### Results

## Example



## BUILDSSH

### Description

Converts the configuration files of SSH to the config file for the daemon sshd. This binary is called by enservice.

### Command

```
buildssh [-d] [-v]  
-d : defaultconfig mode (force ssh key mode!)  
-v : activate verbose
```

### Results

### Example

## BUILDWIFI

### Description

Converts the configuration files of Wifi and Network to the config file for the daemon hostapd. This binary is called by enwifi. Note: Only available on wifi models.

### Command

```
buildwifi [-h] [-t]  
-h : display help message  
-t : will print 1 on stdout if wifi is activated, regarding  
configuration and timeobject, 0 otherwise
```

### Results

### Example

## CAD

### Description

SMC agent daemon



## Command

```
cad [-v] [-h]
-h : display help message
-v : display cad version
```

## Results

## Example

```
VMSNSX01A2083A9>cad -v
cad 4.7.0.dev
```

## CERTENROL

### Description

Perform the SCEP operation for certificate enrolment.

### Command

```
certenrol -o
<"viewca"|"addca"|"getcert"|"checkcert"|"compca"|"cleanup"> [-
p <profile>] [-u <URL>] [-m <POST|GET>] [-t <transaction ID>]
[-r <retry_count>] [-f <CA's fingerprint>] [-s
<"none"|"ondisk">]
-o - Operation
    "viewca" view the root CA\'s fingerprint
    "addca" install the CA\'s from the SCEP server if it match
the given fingerprint
    "compca" compare the CA\'s fingerprint with the given one
    "getcert" query for a certificate [renewal]
    "checkcert" check for a previously pending certificate
request
    "cleanup" purge transaction IDs of previously
accepted/rejected requests
-p - Profile: The profile to use for this QUERY
-u - Server URL: SCEP server entry point
-m - Mode: HTTP Request mode (GET|POST)
-t - The transaction ID from a previous pending certificate
request
-r - Number of attempt(s) left for a pending query
-f - Fingerprint: The fingerprint to compare ("compca").
-s - Seal TPM: ("none"|"ondisk").
```

## Results







```
AltName1="*.facebook.net"  
AltName2="*.fbcdn.net"  
AltName3="*.fbstatic.com"  
AltName4="*.m.facebook.com"  
AltName5="*.messenger.com"  
AltName6="*.xx.fbcdn.net"  
AltName7="*.xy.fbcdn.net"  
AltName8="*.xz.fbcdn.net"  
AltName9="facebook.com"  
AltName10="messenger.com"  
Diagnostic="OK"  
ALPN="h2"
```

## CERTREQD

### Description

Certificate Request Daemon used (via userreqd) by ASQ to retrieve certificates from TLS 1.3 servers

### Command

```
userreqd [-d] [-D] [-h]  
-h: Display this message.  
-D: Daemonize, run in background.  
-d: If an other process is already running, send it a signal to switch its verbose mode, otherwise start with verbose mode enabled.
```

### Results

### Example

## CHECK\_DOWNGRADE\_VERSION

### Description

Check if we can downgrade to the target version from the current version Print an error message with the pivot version to use if the downgrade is not possible

### Command

```
check_downgrade_version <target_version>RESULT  
return 0 if the downgrade can be done  
return 1 and print an error message with the current pivot version to use before doing the downgrade
```



## Example

```
check_downgrade_version 3.2.0
Can't downgrade to target version, downgrade to the following
pivot version before downgrading to the desired version:
4.3.10
```

## CHECKCRL

### Description

Check the validity of CRL. Return minor or major alarm (via alarmd) if CRL has expired or will expire in 3 days or less

### Command

```
checkcrl [-h] [-?] [-d] [-i] [-v] [-s] [-w <days>] [-t
<timeout>] [-g <authority name> -p <password>] [-b <bindaddr>]
[-f <minutes>] [-c <scope>]
-d toggle debug mode
-i show information of the currently running checkcrl
-s do not use dns name resolution
-w [1-30] number of days to warn the expiration. default : 3
-t [0-3600] second before timeout, 0 is for unlimited. default
: 300
-g <authority name> Disable check and generate the CRL for the
given authority
-p <password> Give the passphrase of the authority in CRL
generation mode
-f <minutes> number of minutes before the expiration of the
current CRL to fetch a new CRL
-c <scope> Allow to specify the scope of the CRLs we want to
check. Can be 'local' (default) or 'global'
-b <bindaddr> Set the bind address for CRL download
-h -? this help
-v version
During the run can use [CTRL]-t to show current taskset
```

### Results

### Example

## CHECKDB

### Description

Perform an integrity check on the given database.



## Command

```
Usage: checkdb [-BRv] [-C] DBPATH
       checkdb [-BRv] -c DBPATH
       checkdb [-BRv] -r DBPATH
       checkdb -h
```

### Actions:

- c Check the database integrity and update its backup if not corrupted.
- C Check the database integrity, attempt to repair it if corrupted and update its backup if not corrupted.
- r Restore the database from its backup. DBPATH must not exist.

Default action is -C.

### Options:

- B : Don't create a backup of the database even if it pass the integrity check.
- R : Don't restart daemons once done.
- v : Be verbose.

### Exit Status:

- 64 (USAGE) Bad usage. Use -h to get some help.
- 65 (DATAERR) The database is corrupted and/or cannot be repaired.
- 69 (UNAVAILABLE) Unable to restart some daemons.
- 70 (SOFTWARE) An internal error occurred.
- 74 (IOERR) Unable to empty the backup.
- 75 (TEMPFAIL) Lock prevent operating on the live database.
- 78 (CONFIG) Missing live database file. Or unable to create the backup directory.

## Results

### Example

```
foo>checkdb -C /var/db/reports/reports.db
Now running: 57360
reports: Checking integrity of the live database...
Executing: enlock -s reporting -c trylock -p 57360
Executing: enlock -s reporting -c unlock -p 57360
reports: Integrity check passed.
reports: Updating backup database...
Executing: mkdir -p /data/Main/Reports//var/db/reports
Executing: mv /data/Main/Reports//var/db/reports/reports.db
/data/Main/Reports//var/db/reports/reports.db.orig
Executing: enlock -s reporting -c trylock -p 57360
Executing: enlock -s reporting -c unlock -p 57360
```



```
Executing: rm
/data/Main/Reports//var/db/reports/reports.db.orig
reports: Backup database written to
/data/Main/Reports//var/db/reports/reports.db.
foo>
```

## CHECKFS

### Description

Checks if the file system is clean or not. Must be used **ONLY** on **UNMOUNTED** filesystems !

### Command

```
checkfs [-v] [-d] [-r] [-h] | <device> -v : Verbose mode
-d : Dump mode
-r : Root check
-h : Help
```

### Results

### Example

## CHECKFW

### Description

Check firewall configuration

### Command

```
checkfw [-a] [-v | --verbose] [-n | --nocolor] [-i | --
fileintegrity] [-s | --section <section_name>] [-h | --help]

-a, to all checks (all sections and integrity)

-v, --verbose

-n, --nocolor

-i, --fileintegrity

-s, --section <section_name>\t section_name: all (default),
firmware, hard, health, asq, ipsec, cert, ips, verbose, proto,
licence, proxy, filter, network, log, conf, ha, remotesrv,
nvm, cryptotest
```



-h, --help

## Results

## Example

# CHECKINTEGRITY

## Description

Check integrity of programs and files, based on MD5 file hashing

## Command

```
checkintegrity :  
-h : this help  
-q : quiet mode
```

## Results

## Example

```
U250XA0A0803770>checkintegrity < toto  
All checked files are correct  
U250XA0A0803770>
```

# CHECKINTERNET

## Description

Checks if the firewall has an Internet access.

## Command

```
checkinternet (no argument)
```

## Results

Nothing if OK. Error message if KO.

## Example



## CHECKPIM

### Description

Check the configuration files of PIM.

### Command

```
checkpim [-h] [-v] [-i <dynamic_cfg_fn,interfaces_cfg_fn>]
-h [ --help ] : Display this message.
-v [ --verbose ] : Enable verbosity
-i [ --input-files ] [=arg
(=/usr/Firewall/ConfigFiles/Multicast/dynamic,/usr/Firewall/Co
nfigFiles/Multicast/interfaces)]
: Set the pim SNS configuration files to read.
```

### Results

### Example

## CHECKVERSION

### Description

Checks if a new firmware version is available on the Stormshield servers. If so, an alarm is sent.

### Command

```
checkversion [-c][-l][-h]
-c : launch checkversion in command mode
-l : Show LTSB versions only
-h : display this help
```

### Results

Nothing.

### Example



## CHPWD

### Description

Mount the root device in rw access (if error perform a filesystem check and try to mount it again). Run script "enkeyboard" in order to set the language. Run "fwpasswd" program which change the SRP/SSH password for admin. Then finally reboot the firewall.

### Command

Chpwd (no argument)

### Results

New password is set for admin. 8 characters min. The firewall will reboot after password confirmation.

### Example

```
U2504C099999999999999>chpwd
You are now with the keyboard language configured on Firewall
#####
## Change SRP/SSH password for admin ##
#####
setting password for admin
enter password:
verify:
Modify SRP/SSH password of user 'admin' successful
Firewall Rebooting !
Shutdown NOW!
shutdown: [pid 738]
*** FINAL System shutdown message from
admin@U2504C099999999999999
***
System going down IMMEDIATELY
```

## CLAMAVD

### Description

Daemon of the antivirus clamav.

### Command

```
clamavd [-gdnvxh?]
-d : debug
-h -? : help
-n <timeout in ms> : noscan
-v : version
```



```
-g : full verbose for debug  
-x : unpack cvd
```

## Results

## Example

## CLAMDEFAULT

### Description

Restore the clamav default configuration.

### Command

```
clamdefault
```

## Results

## Example

## CLASSIFYHOST

### Description

Classifies an host based on his IP address.

### Command

```
classifyhost [-vht] <host_address>-v : verbose mode  
-h : show this help message  
-t : types of information to look for (geo, iprep, hostrep or  
all)
```

## Results

Properties attached to this host

## Example

```
Fw > classifyhost 8.8.8.8  
GEOLOC: na:us  
HOSTREP: 0
```



```
IPREP:  
Fw > classifyhost -t geo 8.8.4.4  
GEOLOC: na:us
```

## CLASSIFYURL

### Description

Classifies an url.

### Command

```
classifyurl [-v] <URL>-v:verbose mode
```

### Results

Categories where url is classified

### Example

```
Fw > classifyurl www.google.fr  
oemgroup=Search Engines & Portals
```

## CLEANFW

### Description

Clean some files in the firewall.

### Command

```
cleanfw [-cls]  
-c : Clean the firewall after the script fwtest :  
      Kill all test processes in progress : burnP6, bonnie++,  
      netserver  
      Restore default configuration, clear History  
-l : Remove all log in /log  
-s : Remove exclusives secrets of the firewall : CA, SSH keys,  
      SMC information, SSL keys
```

### Results

If -c option is used, the firewall must be rebooted.



## Example

```
U2504C099999999999999>cleanfw -c  
Kill all test process  
Remove all log  
Restore default configuration  
Restoration done, reboot recommended  
Clear History  
U2504C099999999999999>
```

## CLEANPATTERN

### Description

Remove obsolete files or directories related to the patterns.

### Command

```
cleanpattern [-v][-h]  
-v : Verbose mode  
-h : Help
```

### Results

### Example

## CLEARLOG

### Description

Clear log files.

### Command

```
clearlog -a|<logname> [date]  
-a : clear all logs  
<logname> : clear <logname> file  
[date] : delete logs before this date  
Date format is "YYYY-mm-dd HH:MM:SS"
```

### Results

### Example



## CLEARUNWANTEDFILES

### Description

Removes files from the Firewall, only applies to Kaspersky and Bitdefender library files for the moment. A warning is displayed if High Availability is enabled for this Firewall.

### Command

```
clearunwantedfiles:  
-f: skips all usage controls of the Kaspersky or Bitdefender  
libraries and forces the removal.  
-h: displays a help message with examples  
Kaspersky: Name for the Kaspersky files to remove.  
Bitdefender: Name for the Bitdefender files to remove.
```

### Results

Kaspersky or Bitdefender library files are removed from the Firewall and a flag is set in the configuration files to prevent any recurrence (e.g. after an update).

### Example

```
U2504C099999999999999>clearunwantedfiles -f Kaspersky  
Warning: HA is enabled, this action should be done on the  
passive UTM too.
```

## COLLECTORCTL

### Description

collectorctl can communicate with collectord to change its configuration.

### Command

```
collectorctl  
Options:  
-h [ --help ]           Display this message.  
-B [ --background ]    Execute in background (will not  
print the  
results).  
-v [ --verbose ]       Enable client verbose mode.  
-o [ --libxo ] arg     Specify the output format, arg  
may be  
"text|html|xml|json[,pretty]"  
(default is  
"text,pretty").  
-r [ --reload-config ] arg Reload collectord configuration  
and verbose
```



## Results

Result of the commands.

## Example

```
$> collectorctl -r all  
[RequestStatus]  
Status="ok"
```

## COLLECTORD

### Description

Collect all kind of informations on the firmware and send them to telemetryd.

### Command

```
collectord [-D] [-h]  
-D: will daemonize  
-h: show help message
```

## Results

## Example

```
$> collectord -d  
collectord (pid 2444) is already running  
Signal SIGINFO was sent to current process  
Verbose status is modified
```

## CONFBYPASS

### Description

Add the Bypass section in ConfigFiles/system if a bypass extension module has been detected.  
Add the token Bypass and set its value to 1 on the interfaces that can do Bypass on the file ConfigFiles/network.

### Command

```
confbypass
```



## Results

Always returns 0

## Example

```
confbypass
```

## CONFTUNING

### Description

Configuration tuning with CSV file.

### Command

```
conftuning file.csv directory_path
List of supported operations:
setconf : set new configuration value to token
delconf : remove token or section
setglobal : set new global value
createHA : create HA cluster
joinHA : join HA cluster
initTPM : initialize TPM
p12import : import PKCS#12 file
sethostname : set UTM system name and system node name
```

## Results

## Example

## COROSYNC

### Description

Corosync cluster engine.

### Command

```
corosync:
-f : Start application in foreground.
-p : Do not set process priority.
-v : Display version and SVN revision of Corosync and exit.
```

## Results



## Example

## CRLINFO

### Description

Display the information related to the CRL defined by the file in the argument.

### Command

```
crlinfo <crlfile>
```

### Results

This command display the result of the Hash function, the CRL version, the algorithm for signature and revoked certificates. [SignatureAlgorithm, RevokedCertificates...]

## Example

```
U2504C099999999999999>crlinfo stormshield_network_crl.pem  
[Global]  
Hash=99b2031a  
Version=02  
Issuer="/C=FR/ST=NORD/O=Stormshield/OU=NPI/L=VDA"  
LastUpdate="Feb 18 15:08:45 2004 GMT"  
NextUpdate="Mar 20 15:08:45 2004 GMT"  
SignatureAlgorithm=md5WithRSAEncryption  
[RevokedCertificates]  
U2504C099999999999999>
```

## CURLTOOL

### Description

Simple wrapper for the libfwcurl.

### Command

```
curltool: -r <GET|POST> -u <URI(http://XXXXXXX)> [-a <User  
Agent>] [-p <POST parameters>] [-o (output filename)] -h  
-r Request : Send a GET or POST request  
-u URI : Uniform Resource Identifier (protocole + server +  
param)  
http://www.stormshield.eu/mapage.html?param1=value1&m2=value  
2...)  
-a User Agent : User Agent used for this request. Default  
agent is:<model>-<serial> : curltool (1.0)
```



```
-p The POST parameters : post_param1=post_value1&post_param2=post_value2...  
-o Output File : Path to file for storing the output (!!! file is overwrite !!!)  
-h Help : Display this help
```

## Results

## Example

## DATE

### Description

Get or set the current date and time of the Firewall. The date cannot be changed if the NTP is running.

### Command

```
date [-u] | [-d] | [-e] | [-n] | [-b] "YYYY-MM-DD hh:mm:ss"  
date : display system date in Stormshield format  
date "YYYY-MM-DD hh:mm:ss" : set new date in Stormshield Network format  
    Remark : ntp daemon must be off  
-b : (for boot) do not send signal of date change to daemons  
-u : display date in UNIX format  
-d : display date in Stormshield Network format without timezone  
-e : display date in seconds since Epoch  
-n : display date in nanoseconds since Epoch
```

## Results

## Example

```
U2504C0999999999999>date  
"2004-01-15 15:37:29" zone=GMT tz=+0000 ntp=Off  
U2504C0999999999999>date -u  
Thu Jan 15 15:37:32 GMT 2004  
U2504C0999999999999>date -d  
2004-01-15 15:37:34  
U2504C0999999999999>date "2004-01-16"  
"2004-01-16 15:37:47" zone=GMT tz=+0000 ntp=Off  
U2504C0999999999999>date -n && date -e && date -n  
1676022185398334475  
1676022185  
1676022185423613131
```



## DDNSCLIENT

### Description

Updates the input of the dynamic DNS.

### Command

```
ddnsclient: [-t -vvv] {-i <interface>|-r} -a <ipaddress>-h :  
print this usage message and exits  
-i : interface name to check  
-o : set offline  
-r : parse every configuration to do renew and retry  
operations  
-a : IP address  
-f : run as a background daemon  
-t : test mode : do not send request  
-v : verbose level 1: print basic update steps  
-vv : verbose level 2: more verbose, add steps and request  
-vvv : verbose level 3: most verbose, add structure dump and  
different codes
```

### Results

### Example

## DECBACKUP

### Description

Decypher a .na file (which is the save format of the configurations) to a .tgz file.

### Command

```
decbackup -i <backup> -o <output archive> [-p <password>] [-d  
]  
-i <backup> : name of encrypted backup input file  
-o <output archive> : name of decrypted backup output file  
-p <password> : password used for backup encryption  
-d : Dump backup header
```

### Results

### Example



## DEFAULTCONFIG

### Description

Reset the configuration with the default one. The current configuration is saved in the file "ConfigFiles.old"

### Command

```
defaultconfig [options]
-f: Force
-r: Reboot after defaultconfig
-D: Only Restore the data partition
-u: Check usb token boot restoration
-d: Dump root partition after defaultconfig
-k: Keep autoupdate data (Pattern, Pvm, Clamav, AdvancedAV,
URLFiltering), default SSL proxy authority, default sslvpn
full authority and ssh host keys
-l: Keep network configuration file
-c: No backup files (.old)
-L: Remove logs
-t: Reset TPM (TPM password is required)
```

### Results

"Replacing current configuration with the default configuration": The default configuration has been restored, the firewall must be rebooted to activate the modifications. The admin password is not modified. "Previous defaultconfig found... remove it manually": enter the following command :`"rm -R /Firewall/ConfigFiles.old"` and restart the procedure.

### Example

```
VMSNSX01B2085A9>defaultconfig -f -r -p
replacing current configuration with the default
configuration...
deleting Pattern database...
deleting Custom Patterns database...
deleting IP databases...
deleting Protocols Templates...
deleting Pvm database...
deleting RootCertificates...
deleting antivirus database...
deleting URLFiltering URL group database...
cleaning /usr/Firewall/var...
deleting ssh host keys...
deleting ssh ha key...
deleting ssh authorized_keys...
Reinitializing secret file...
[2021-04-29 13:54:33] [INFO] Creating links to /data
directories
[2021-04-29 13:54:33] [INFO] Creating real directories
[2021-04-29 13:54:33] [INFO] Creating data specific
```



```
directories
[2021-04-29 13:54:33] [INFO] Changing owner of specific
directories
[2021-04-29 13:54:33] [INFO] Setting pattern version for Main
partition to 6.1.amd64
Reboot the VM to launch install wizard
restoring default password...
#####
## Restore default SRP/SSH password for admin ##
#####
Modify SRP/SSH password of user 'admin' successful
reset urlgroup versions...
deploy plugin.def and create default configuration for dynamic
plugins (based on plugin.def)
recompiling pattern database...

Generate the default SSL proxy authority.
| Key generation in progress. Please wait...
SSL proxy default authority done.

Generate the default sslvpn full authority.

Generate the server certificate of default sslvpn full
authority.
\ Key generation in progress. Please wait...
Generate the user certificate of default sslvpn full
authority.
/ Key generation in progress. Please wait...
sslvpn-full-default-authority done.
- Key generation in progress. Please wait...
```

## DHCLIENT

### Description

The client DHCP.

### Command

```
dhclient [-4|-6] [-SNTPRIldvrxi] [-nw] [-p <port>] [-D LL|LLT]
[--dad-wait-time seconds] [-s server-addr] [-cf config-file]
[-df duid-file] [-lf lease-file] [-pf pid-file] [--no-pid] [-e
VAR=val] [-sf script-file] [interface]*
```

### Results

### Example



## DHCLIENT-SCRIPT

### Description

Called to modify the configuration DHCP client with the new IP address.

### Command

```
dhclient-script (no argument)
```

### Results

### Example

## DHCPD

### Description

DHCP server.

### Command

```
dhcpd [-p <UDP port#>] [-f] [-d] [-q] [-t|-T] [-4|-6] [-cf  
config-file] [-lf lease-file] [-tf trace-output-file] [-play  
trace-input-file] [-pf pid-file] [--no-pid] [-s server] [if0  
[...ifN]]
```

### Results

### Example

```
IPAddress="192.168.3.101" State="free" Start="2021-04-28  
10:33:37" End="2021-04-29 10:33:37"  
MacAddress="00:90:f5:c0:d6:e8"  
IPAddress="192.168.3.102" State="active" Start="2021-04-29  
07:40:24" End="2021-04-30 07:40:24"  
MacAddress="34:48:ed:34:78:e8" Hostname="mypc"  
[Stat_Lease]  
NBTotal=2  
NBActive=1
```



## DHCPINFO

### Description

Dump dhcp leases and return a section list.

### Command

```
dhcpinfo [-v] [-h]  
-h : help  
-v : verbose
```

### Results

### Example

```
U30SXA02L2173A7>dhcpinfo
```

## DHCRELAY

### Description

DHCP relay.

### Command

```
dhcrelay [-4] [-d] [-q] [-a] [-D] [-A <length>] [-c <hops>] [-p <port>] [-b <BindAddr>] [-pf <pid-file>] [--no-pid] [-m append|replace|forward|discard] [-i interface0 [ ... -i interfaceN] [-iu interface0 [ ... -iu interfaceN] [-id interface0 [ ... -id interfaceN] [-U interface] server0 [ ... serverN]  
dhcrelay [-6] [-d] [-q] [-I] [-c <hops>] [-p <port>] [-pf <pid-file>] [--no-pid] [-s <subscriber-id>] -l lower0 [... -l lowerN] -u upper0 [... -u upperN] lower (client link):  
[address%]interface[#index] upper (server link):  
[address%]interface
```

### Results

### Example



## DHLEASE-SCRIPT

### Description

This script is executed in synchronous mode by DHCP server.

### Command

```
dhlease-script (commit|release|expiry) <lease address>  
[<ethernet address> [<client hostname option>]]
```

### Results

### Example

## DIALUPSTATE

### Description

Display current state of dialups. Short delay exists between dialup state and link effective state. Called during dialup boot and stop processes.

### Command

```
dialupstate [-h]  
-h : Help
```

### Results

### Example

## DKILL

### Description

Kill all daemons present in /var/supervise/ except the sshd daemon.

### Command

```
dkill (no argument)
```





## Command

dnscache (no argument)

## Results

## Example

## DSTAT

### Description

Display the list of each daemon, with information of state (up or down) and with time duration from last change of the state.

### Command

```
dstat [-h] [up|down|<daemon>] set -h option to show uptime in  
sns duration format (ex: 1w 2d 5h 20m 59s) only show numbers  
if > 0 (except for seconds which can be 0)
```

### Results

"asqd" : daemon name. "/var/supervise/asqd" : path of the daemon. "up / down" : daemon state.  
"pid xxx" : service number affected to the daemon. "xxx seconds" : time duration since the latest  
change of the state.

### Example

```
V50XXA3E0000000>dstat  
asqd : /var/supervise/asqd: up (pid 913) 4992 seconds  
bird : /var/supervise/bird: down 4993 seconds  
clamavd : /var/supervise/clamavd: down 4993 seconds  
corosync : /var/supervise/corosync: down 4993 seconds  
dhclient : /var/supervise/dhclient: down 4993 seconds  
dhcpd : /var/supervise/dhcpd: down 4993 seconds  
dhcrelay : /var/supervise/dhcrelay: down 4993 seconds  
dns : /var/supervise/dns: down 4993 seconds  
eventd : /var/supervise/eventd: up (pid 1012) 4989 seconds  
hardwared : /var/supervise/hardwared: up (pid 911) 4992  
seconds  
ldap : /var/supervise/ldap: down 4993 seconds  
logd : /var/supervise/logd: up (pid 906) 4993 seconds  
mpd : /var/supervise/mpd: down 4993 seconds  
ntp : /var/supervise/ntp: down 4993 seconds  
rtadvd : /var/supervise/rtadvd: down 4993 seconds  
serverd : /var/supervise/serverd: up (pid 916) 4992 seconds  
sld : /var/supervise/sld: up (pid 1214) 4987 seconds
```



```
snmpd : /var/supervise/snmpd: down 4993 seconds
sshd : /var/supervise/sshd: up (pid 930) 4991 seconds
stated : /var/supervise/stated: up (pid 1126) 4987 seconds
switchd : /var/supervise/switchd: down 4993 seconds
tproxyd : /var/supervise/tproxyd: down 4993 seconds
```

## DUMPROOT

### Description

Do a backup of the file system to the backup partition.

### Command

```
dumproot [-b] [-f] [-v]
-b : Executes dumproot at the next reboot
-f : Executes dumproot regardless of an ongoing autoupdate
-v : Enables verbose
```

### Results

Return nothing if OK Return error message related to the error type.

### Example

## ENALIVED

### Description

Active/Reload the alived daemon. If HA is not active, launch alived if there is an object to monitor If HA is active, always launch alived

### Command

```
enalived [-m <ha_mode>]
-m : Reloads the daemon by forcing it into the given <ha_
mode>. Accept only "active" and "passive" parameters.
```

### Results

### Example



## ENANTIVIRUS

### Description

Active the antivirus configuration.

### Command

```
enantivirus [-a] [-v] [-e] [-s] [-u] [-t [clamav]
[,advancedav]] [-R reason] [-h?]
-a : Launch autoupdate if base is missing
-v : Verbose mode activated
-e : reload engine of selected antivirus
-s : reload scan settings of selected antivirus
-u : Force a complete reload of antivirus
-R : arg arg is the reason explaining why enantivirus was
executed
-t : By default all antivirus are selected
-t clamav : Select Clamav
-t advancedav : Select advancedav
-t clamav,advancedav : In order to cumulate antivirus
```

### Results

### Example

```
U2504C099999999999999> enantivirus -d -t clamav,advancedav
enantivirus: clamav init successful
enantivirus: advancedav init successful
U2504C099999999999999>
```

## ENASQ

### Description

Activates ASQ configuration.

### Command

```
enasq [-b] [-f] [--no-pvm] [--no-icmp] [--no-userreq] [--no-
pattern] [--no-stealth]
-b : boot mode (asqd will reload object db)
-f : force asqd to reload (asqd will restart)
--no-pvm : Don't reload pvm db
--no-userreq : Don't launch/reload userreqd daemon
--no-pattern : Don't reload asq pattern
--no-icmp : Don't update net.inet.ip.redirect(6) sysctl's
flags
```



`--no-stealth` : Don't update net.inet.ip.stealth/icmpreply  
sysctl's flags

## Results

## Example

## ENAUTH

### Description

Activates authentication daemon according to it's configuration. enauth is an alias to "ensl"

### Command

See `ensl` command

## Results

## Example

## ENAUTHD

### Description

Activates authd daemon according to its configuration.

### Command

`enauthd [-u]`  
`-u`: reload the daemon configuration

## Results

## Example



## ENBIRD

### Description

Starts or stops bird according to its state.

### Command

```
enbird [-f] [-v] [--no-asq]
-f: restarts BIRD instead of sending SIGHUP
-v : verbose mode
--no-asq : do not reload asqd
```

### Results

### Example

## ENBYPASS

### Description

Activates/deactivates the hardware bypass or get its configuration.

### Command

```
enbypass [-r][-i][-v][-h]
-r : rearm Run-time Bypass watchdog
-i : return Bypass status (from Bypass hardware registers)
-v : set verbose level to info
-h : print this help message
without option, activate/deactivate Bypass according to
configuration file.
```

### Results

### Example

```
SNI40A18A1607A5>enbypass -i
FW major version: 1
FW minor version: 6
Module capability:
System-Off bypass supported
Just-On bypass supported
Run-Time bypass supported
Run-Time Watchdog1 timer supported
Run-Time watchdog1 timer capability: 1~255 seconds
```



```
System-Off Bypass setting: Enable
Just-On Bypass setting: Enable
Run-Time Bypass setting: Disable
Run-Time watchdog1 timer status: Timer Running
Run-Time watchdog1 pair setting:
bypass will Enable while timeout
Run-Time watchdog1 timer count: 60 seconds
I2C Address: 55
SNI40A18A1607A5>
```

## ENCBACKUP

### Description

Encrypt backup file.

### Command

```
encbackup -i <archive to protect> -o <backup> -t <backup
content> [-c comment] [-p password]
-i : input file
-o : output file
-t : backup content list
-c : backup comment
-p : encryption password
```

### Results

### Example

```
encbackup -i backup.network.tgz -o backup.network.na -t
network
```

## ENCONSOLE

### Description

Activates the console configuration. Sends SIGHUP to init and reloads tty configuration.

### Command

```
enconsole [ modem | nomodem ]
modem :
nomodem :
modem and nomodem parameters are set by builddialup
```



## Results

## Example

## ENDHCP

### Description

Activates DHCP daemon according to its configuration.

### Command

```
endhcp [-4|-6] [-b] [--no-asq]
-4 activates dhcpd configuration for IPv4 only.
-6 activates dhcpd configuration for IPv6 only.
--no-asq: do not reload asq
When no IP version is specified, both IPv4 and IPv6 dhcpd
configurations are activated.
-b for boot process
```

## Results

## Example

## ENDHCRELAY

### Description

Activates DHCP relay according to its configuration.

### Command

```
endhcrelay [-4|-6]
-4 enable only dhcrelay on IPv4.
-6 enable only dhcrelay on IPv6.
When no IP version is specified, both IPv4 and IPv6 dhcrelays
are configured.
```

## Results

## Example



## ENDIALUP

### Description

Activates the dialups configuration.

### Command

```
Endialup [-u]  
-u : reload only if conf files did change
```

### Results

All the dialup connections are re-negotiated. Warning, the internet connection, the NAT filtering and the VPN tunnels in progress are re-initialized.

### Example

## ENDNS

### Description

Activates DNS daemon according to its configuration. Reload NAT and Filter slot if configuration has been modified. Flush nated DNS connections if authorized clients list have changed.

### Command

```
endns [-b] [-u]  
-b : Boot process  
-u : Update clients list. Don't restart dnscache : cache isn't  
flushed.
```

### Results

### Example

## ENEVENT

### Description

Activates events daemon according to its configuration.





## ENGATEMON

### Description

Activates the configuration of the advanced routing. Removes host memory. Call `enevent` to build hostcheck rules. Call `endialup` to update dialup configuration. Call `ennetwork` to update routing.

### Command

```
engatemon (no argument)
```

### Results

### Example

## ENHA

### Description

Rebuilds corosync. If configuration differs, stops `stated` then restarts corosync, then starts `stated`. Else simply restarts `stated`.

### Command

```
enha [-w] [-u] [-v] [-f]  
-w : don't wait for the HA cluster to be ready  
-u : soft reload (won't rebuild Corosync configuration)  
-v : verbose  
-f : force Corosync and Gatewayd restart
```

### Results

"ha is disabled!": This message indicates that the "high availability" is not available on your IPS-Firewall.

### Example

## ENKEYBOARD

### Description

Activates the configuration parameters for the keyboard language from file `/usr/Firewall/ConfigFiles/language`.



## Command

enkeyboard (no argument)

## Results

## Example

## ENLDAP

### Description

Activates LDAP daemon according to its configuration.

### Command

```
enldap [-h] [-n] [-f] [-v]
-h: prints this help and exit
-n: generates a new internal base
-f: forces refresh
-v : verbose
```

### Results

### Example

## ENLOCK

### Description

Lock or unlock a script for a duration time.

### Command

```
enlock -s <scriptname> [-c (lock|unlock|trylock)] [-d
<timeout>] [-p <pid>]
-s <scriptname> : used to deduce the name of the lock
-c <action> :
    -c lock : wait for the lock to be available and take it
    -c unlock : release the lock
    -c trylock : try to take the lock, but abort immediatly if
it's held by another process
-c : Default action = lock
-d <timeout> : maximum time to wait to get the lock
```



-v : verbose  
Only valid for '-c lock' and between 0 and 300  
-l = forever (default)  
-p <caller pid> : pid written in the lock file (by default, getppid())

## Results

## Example

## ENLOG

### Description

Restart logd.

### Command

enlog (no argument)

## Results

## Example

## ENMULTICAST

### Description

Activates multicast daemon (static/dynamic) according to its configuration.

### Command

```
enmulticast [-r|-f] [-v] [-h]"  
-r : quick restart of the active multicast daemon  
(static/dynamic)  
-f : force restart of the active multicast daemon  
(static/dynamic)  
-v : verbose mode  
-h : help
```

## Results



## Example

## ENNETWORK

### Description

Reload the configuration parameters from the file /usr/Firewall/ConfigFiles/network: - generate new object in case of option "-b" is not set: - synchronize tty status - update stateful structure - load ARP entries - update filter rules because dynamic rule have not been updated with the new IP address - update NAT because dynamic rule have not been updated with the new IP address - update VPN because dynamic rule have not been updated with the new IP address - update events because dynamic dns might have been changed - update authentication because interfaces might have been changed - update snmp because interfaces speed might have been changed - try to reset arp entry of hosts for Firewall IP addresses - notify switch of configuration change in case of option "-b" is set : - notify switch of configuration change

### Command

```
ennetwork
[-b]
[-c <old_network_file> [<old_hacluster_file>] [<old_ha_conf_
file>]]
[-C <new_network_file> [<new_hacluster_file>] [<new_ha_conf_
file>]]
[-d] [-f] [-v [<ERROR|WARN|INFO|DEBUG>]] [-r] [-h] [-z] [-i]
[-H]
-b boot
-c <old_network_file> [<old_hacluster_file>]
[<old_ha_conf_file>] : old network configuration file Defaults
are :
    /var/tmp/network
    /var/tmp/hacluster
    /var/tmp/highavailability
-C <new_network_file> [<new_hacluster_file>]
[<new_ha_conf_file>] : new network configuration file Defaults
are :
    /usr/Firewall/ConfigFiles/network
    /usr/Firewall/ConfigFiles/HA/hacluster
    /usr/Firewall/ConfigFiles/HA/highavailability
-d dry-run mode (display the operations that would be executed
but
do not execute them, imply -v)
-f force : refresh all interfaces even if configuration has
not
changed
-H no HA
-h dhcp
-r route
-s check static routes
-v verbose
```



```
-z dad  
-i only updates interfaces configuration  
-w check if new network file requires a reboot, imply -d and -  
v
```

## Results

## Example

## ENntp

### Description

Activates NTP daemon according to its configuration.

### Command

```
enntp [-u | off] [-h]  
-h : help  
-u : starts ntpd  
off : stops ntpd
```

## Results

## Example

## ENobject

### Description

Synchronize the object base (protocols, hosts, network, services).

### Command

```
enobject [-a] [-h] [--no-asq] [--no-log]  
-a: Do NOT synchronize ARP table (do not call 'arpsync -a')  
--no-asq: Do not reload asqd  
--no-log: Do not reload logd  
-h: Help
```

## Results



## Example

## ENOPENVPN

### Description

Generate OpenVPN configuration from configuration files.

### Command

```
enopenvpn [-v]  
-v : activate verbose
```

### Results

## Example

## ENPATTERN

### Description

Compiles the signatures files of the ASQ.

### Command

```
enpattern [options]
```

### Options

-h : print this help message -r : generate resource language file and ASQ template -c <ctx> : process only the specified context <ctx>-a : same as -r + compile context -p : generate dynamic plugin configuration based on plugin.def -l : list all available ASQ pattern contexts -n : display the version of the downloaded files and the version of generated .match separated by a dot [<download version>.<.match version>] -f : force mode -v : verbose mode -t <filename> : test Patterns input file, results will be produced into "/usr/Firewall/Data/CustomPatterns/Download/" directory. -z : generate an active-update archive for Custom Patterns

### Results

## Example



## ENPROXY

### Description

Activates the proxy daemon according to its configuration for HTTP, POP3, SNMP and FTP.  
Warning: 'enproxy' (without -u) is obsolete, use 'enfilter -u' instead.

### Command

```
enproxy [-u] [-c] | [-r]  
-u refresh tproxyd  
-c clear ssl fake certificates
```

### Results

### Example

## ENREFRESH

### Description

Refresh all modules.

### Command

```
enrefresh
```

### Results

### Example

## ENREPORT

### Description

Reporting module management:

### Command

```
Usage: enreport [-v] [-r]  
enreport [-v] -H  
enreport [-v] -m  
enreport [-v] -u
```

**Actions:**

- H: Synchronize the reports on the HA cluster and exit.
- m: Mount the memory disk and exit.
- r: Reload the daemons and exit.
- u: Umount the memory disk and exit.

Default action is -r.

**Options:**

- v : Be verbose.

**Results****Example****ENROLL****Description**

PAYG virtual machine enrollment utility.

**Command**

```
enroll [-h] [-q] [-v] -e  
enroll [-h] [-q] [-v] [-f] -r
```

- h, --help : show this help
- e, --enroll : enroll PAYG Virtual Machine on the online service
- r, --renew : renew the PAYG licence (if needed)
- f, --force : force the renew
- q, --quiet : disable output
- v, --verbose : verbose in console

**ENSERVICE****Description**

Activates serverd daemon according to its configuration.



## Command

```
enservice [-h] [-b] [-s]  
-h: print this help and exits  
-b: don't reload filter slot  
-s: secure mode
```

## Results

## Example

## ENSL

### Description

Activates sld daemon according to its configuration.

## Command

```
ensl [-u] | [-b]  
-u : soft update  
-b : boot
```

## Results

## Example

## ENSNMP

### Description

Activates snmpd daemon according to its configuration.

## Command

```
ensnmp [-u]  
-u : Only send a SIGHUP to net-snmp
```

## Results

## Example



## ENSSO

### Description

Activates sso daemon according to its configuration.

### Command

```
ensso [-u]  
-u : soft update
```

### Results

### Example

## ENSWITCH

### Description

Reload the configuration and active the daemon which manages the ports of the switch.

### Command

```
enswitch [-v]  
-v : verbose
```

### Results

### Example

## ENTELEMETRY

### Description

Activates the telemetryd and collectord daemons.

### Command

```
entelemetry
```

### Results







## Command

```
enurl [--copyonly]
--copyonly : allow bypassing call enproxy -u
```

## Results

## Example

## ENUSERPREFS

### Description

Save and load the user preferences

### Command

```
enuserprefs [-s] [-r]
-s: Save the userprefs to ConfigFiles
-l: Load the userprefs from ConfigFiles
```

### Results

### Example

## ENUSERREQD

### Description

Activates the userreqd daemon.

### Command

```
enuserreqd
```

### Results

### Example



## ENVOUCHER

### Description

Activates voucher LDAP daemon according to its configuration.

### Command

```
envoucher [-h] [-n] [-f]
-h: prints this help and exit
-n: generates a new internal base
-f: forces refresh
```

### Results

### Example

## ENVPN

### Description

Activate specified VPN configuration. Special slot 00 deactivates VPN configuration. Note: envpn -u without changes in slot does NOTHING.

### Command

```
envpn [-u | on | off | -h | slotnumber | -g globalslotnumber]
[--dry-run]
-h : Help
-u|on : re-activate the current slot
off : deactivate the current slot
slotnumber : activate the local filtering slot
(00<=slot<=10)
-g globalslotnumber: activate the global filtering slot
(00<=slot<=10)
--dry-run: perform a trial run with no changes made (checks
are run)
```

### Results

### Example

```
U2504C099999999999999>envpn 01
Activating new VPN tunnel...
Done.
current global slot =
```





## Results

## Example

## ESTENROLL

### Description

Perform EST operations for certificate enrolment.

### Command

```
estenroll --operation <cacerts|simpleenroll|simplereenroll> --
url <URL> --httpsca <caname> [--alias
<alias>] [--bindaddr <addr/host/interface>] [--bindport
<port>] [--httpslogin <login>]
[--httpspassword <password>] [--promptpassword] [--keytype
<RSA|SECP|Brainpool>] [--keysize <size>] [--reqtype
<user|server|smartcard>] [--subj <X509 name>] [--upn <upn>] [-
-altnames <altnames>] [--caname <caname>] [--name <certname>]
[--tpm <none|ondisk>]
--operation :
    cacerts Retrieve and import the EST CA
    simpleenroll Enroll a certificate
    simplereenroll Renew a certificate
--url - Server URL: EST server base URL
(https://<host>:<port>/)
--alias - EST server alias (when server provides multiple CAs)
--bindaddr - addr/host/interface to bind the connection to
--bindport - port to bind the connection to
--httpsca - TLS Server CA certificate
--httpslogin - HTTPS basic auth login
--httpspassword - HTTPS basic auth password
--promptpassword - prompt for the HTTPS password
--keytype - Requested keytype ("RSA"|"SECP"|"Brainpool")
--keysize - Requested keysize
--reqtype - CSR type ("server"|"user"|"smartcard")
--subj - Requested X509 name ("/C=value0/ST=value1/S=...")
--upn - Requested X509v3 UPN (for smartcard requests)
--altnames - Requested X509v3 altnames (semi-colon separated
IP Address/DNS list)
--caname - CA for the requested certificate (for
simpleenroll/simplereenroll)
--name - Desired import name (for simpleenroll) or certificate
to be renewed (for simplereenroll)
--tpm - TPM seal: (none|ondisk) (for simpleenroll)
--dr_force - force import in DR mode on non-compliant cert
--help - This help
```



## Results

## Example

## EVENTD

### Description

Events scheduler.

### Command

```
eventd (no argument)
```

## Results

## Example

## EXPORTCONF

### Description

This program exports type of configuration to a file stored in /tmp by default.

### Command

```
exportconf -t filter -s index_number -g index_number [-o  
output_file_format] [-d directory_name ] [-v] [-h]  
This program exports type of configuration to a file stored in  
/tmp by default.  
-t|--type filter : type of configuration to  
export  
-s|--slot index_number : export rules of the slot  
index of the local policy (default is slot index equal to 0)  
-g|--global index_number : export rules of the slot  
index of the global policy (default is slot index equal to 0)  
-o|--output output_file_format : output format of the  
created file (default is : csv)  
-d|--directory directory_name : indicate a directory to  
store the created file  
-v|--verbose : enable verbose  
-h|--help : print this help message
```



## Results

### Example

```
SNI40A16B0743A8>exportconf -t filter
Creating file: /tmp/SNI40A16B0743A8_policy0_filter_nat_rules_
local_2017-04-18_1200.csv
SNI40A16B0743A8>SNI40A16B0743A8>exportconf -t filter -g 10 -d
/data/tmp
Creating file: /data/tmp/SNI40A16B0743A8_policy10_filter_nat_
rules_global_2017-04-18_1100.csv
SNI40A16B0743A8>
```

## FWINIT

### Description

Generate firewall key

### Command

```
fwinit -f file
```

## Results

### Example

## FWPASSWD

### Description

Change SRP and SSH password for admin.

### Command

```
fwpasswd [-d] [-u] [-h] [-p newpassword -c currentpassword]
By default : changes only SRP/SSH password for admin
-d : Restore default SRP/SSH password for admin
-u : Change UNIX password for admin
-p newpassword : Set new password non-interactively (requires
-c option)
-c currentpassword : Set current password (has no effect
without -p option)
-h : Print help
```



## Results

### Example

```
U2504C099999999999999>fwpasswd
#####
## Change SRP/SSH password for admin ##
#####
setting password for admin
enter password:
verify:
Modify SRP/SSH password of user 'admin' successful
U2504C099999999999999>
```

## FWSHUTDOWN

### Description

This command does a virtual shutdown of the Firewall. The following commands are launched :  
enfilter 00 enservice -s

### Command

fwshutdown (no argument)

## Results

### Example

## FWSOUND

### Description

Play sound on the Firewall speaker.

### Command

```
fwsound [1 | 2 | 3 | 4]
1 : Start sound
2 : Stop sound
3 : Play predefined sound 1
4 : Play predefined sound 2
```



## Results

## Example

## FWUPDATE

### Description

Install or update the Firewall.

### Command

```
fwupdate [-r] [-F] (-f <file path> | -s)
-r : reboot at the end, if no error
-F : Force install (same version)
-f : install one maj given by <file path>-s : install one maj
given from stdin
```

## Results

## Example

## GATEWAYCTL

### Description

Gatewayctl can communicate with gatewayd to change its configuration.

### Command

```
gatewayctl
-h [ --help ] Display this message
-v [ --verbose ] Enable verbosity
--update_peer <peer_uid>:<peer_ip> Update a member in the
cluster with a serial number and the new --remove_peer <peer_
uid> IPv4. If it didn't exist in the cluster already, it will
be added automatically.
--remove_peer <peer_uid> Remove a member in the cluster with a
serial number.
--refresh_peers Refreshes connections to peers in the cluster
--list_peers
List members in the cluster.
--update_channel <channel_name>:<channel_type>:<channel_prio>
Update replication of a channel. It needs the channel name,
```



its type ('topic' or 'service') and a priority ('high' or 'low'). If the replication of the channel didn't exist, it will be added.

```
--remove_channel <channel_name>:<channel_type> Remove a replication of a channel. It need the channel name, its type ('topic' or 'service')
```

```
--list_channels  
    List replication of channels.
```

## Results

Result of the commands.

## Example

```
$> gatewayctl --list_channels  
[test/topic-low_prio]  
type=topic  
priority=low  
[test/topic-high_prio]  
type=topic  
priority=high  
  
$> gatewayctl --remove_channel test/topic-high_prio:topic  
[Result]  
OK  
  
$> gatewayctl --list_channels  
[test/topic-low_prio]  
type=topic  
priority=low
```

## GATEWAYD

### Description

Gatewayd replicates messages from internal messaging to members of an HA cluster.

### Command

```
gatewayd [-h] [-D] [-d]  
-h [ --help ]: Display this message.  
-D [ --daemonize ]: Daemonize, run in background.  
-d [ --debug ]: If another process is already running, send it a signal to switch its verbose mode, otherwise start with verbose mode enabled.
```

### Results



## Example

## GETALARMCONF

### Description

Display alarm configuration.

### Command

```
getalarmconf -i <config_index> [-p <protocol>] [-c  
"protocol|<ASQ context>"] [-a <alarm id>] [-v]
```

### Results

#### Example

```
U250XA0A0803770>getalarmconf -i 1  
protocol=dns context=protocol id=32 action=block level=major  
dump=0  
new=0 origin=profile_template msg="RÃ©cursion de label  
DNS" modify=0 sensible=0 category=""  
protocol=dns context=protocol id=38 action=block level=major  
dump=0  
new=0 origin=profile_template msg="DNS id spoofing" modify=0  
sensible=0 category=""  
U250XA0A0803770>
```

## GETCONF

### Description

Return the field value of the specified "file + section + item".

### Command

```
getconf [-i <index>] <file> <section> [<item>] [<default>]  
-i <index> :  
<file>: Path+name of the configuration file  
<section>: Section name inside the conf file  
<item>: Item inside the section  
<default>: Default value  
  
getconf -l <section> <item> [<default>]  
-l :  
<section>: Section name inside the conf file
```



<item>: Item inside the section  
<default>: Default value

getconf -d <licencedateitem><licencedateitem> : One item of the following list :

- Update
- Pattern
- VulnBase
- URLFiltering
- URLVendor
- AntiVirus
- VirusVendor
- AntiSPAM
- SPAMVendor
- NotBefore
- NotAfter
- Warranty
- ExpressWarranty

getconf -y <section> <item> [<default>]  
-y :  
<section> : Section name inside the payg licence  
<item> : Item inside the section  
<default> : Default value

getconf -p  
REMARKS  
getconf -i <index> <file> <section> returns the index-th "token=value" or only "token" (if no value)  
getconf -i <index> <file> <section> <item> returns the index-th value for <item>, values must be coma separated  
getconf -y <section> <item> [<default>]  
returns the PAYG licence item value  
getconf -p  
checks if the PAYG licence is valid

## Results

## Example

```
U2504C099999999999999>getconf /usr/Firewall/ConfigFiles/network  
ethernet1 address 10.X.X.X  
U2504C099999999999999>
```

## GETLICENCE

### Description

Display licence information.



## Command

```
getlicence
```

## Results

List of all information and dates related to the licenses.

## Example

```
V50XXA3E0000000>getlicence
[Global]
Version=9
Temporary=0
Comment=
[Flags]
PKI=1
...
ExpressWarranty=2037-12-31
NotBefore=2002-05-14
NotAfter=2037-12-31
V50XXA3E0000000>
```

## GETLICENCE\_TOKEN

### Description

Return the field value of the specified "section + item" in the licence.

### Command

```
getlicence_token -l <section> <item> [<default>]
-l:
<section>: Section name inside the conf file
<item>: Item inside the section
<default>: Default value
```

```
getlicence_token -d <licencedateitem><licencedateitem>: One
item of the following list:
```

```
Update
Pattern
VulnBase
URLFiltering
URLVendor
AntiVirus
VirusVendor
AntiSPAM
SPAMVendor
NotBefore
NotAfter
```



```
Warranty
ExpressWarranty
```

```
getlicence_token -y <section> <item> [<default>]
-y:
<section>: Section name inside the payg licence
<item>: Item inside the section
<default>: Default value
```

```
getlicence_token -p
```

```
getlicence_token -h
```

```
REMARKS
```

```
getlicence_token -y <section> <item> [<default>]
    returns the PAYG licence item value
```

```
getlicence_token -p
    checks if the PAYG licence is valid
```

```
getlicence_token -h
    print help
```

## Results

## Example

```
VMSNSX00Z0000A0>getlicence_token Proxy HTTPProxy
```

## GETMODEL

### Description

Display information about type and version number of the Firewall.

### Command

```
getmodel [-a | -b | -t | -m | -p | -A | -B | -H | -S | -s | -n
| --libxo]
-a : Display all version numbers and type of the Firewall.
-b : Display Build model.
-t : Display type value.
-m : Display main model value.
-p: Display equivalent running model for VM.
-A: Display the generic model used.
-B : Display branch name.
-H : Display hardware type.
-S : Display product serial number.
-s : Display manufacturer serial.
-n : Display hardware type name.
--libxo : Pass parameters to libxo (see libxo doc)
```





```
rev=0x10 hdr=0x00
fxp2@pci0:10:0: class=0x020000 card=0x020011d6 chip=0x12098086
rev=0x10 hdr=0x00
fxp3@pci0:11:0: class=0x020000 card=0x020011d6 chip=0x12098086
rev=0x10 hdr=0x00
none1@pci1:0:0: class=0x030000 card=0x85001023 chip=0x85001023
rev=0x6a hdr=0x00
U2504C099999999999999>
```

## GETVERSION

### Description

Display Firewall software version.

### Command

```
getversion [-a|-b|-v|-d|--libxo]
By default, displays Firewall software name version
-a : Display ASQ name version
-b : Display build version
-d : Display devel branch, git SHA and the timestamp of the
build
-v : Display revision number
--libxo : pass parameters to libxo (see libxo doc)
```

### Results

### Example

```
SN910A17A1711A7>getversion
Firewall software version 4.1.5
```

## GLOBALGEN

### Description

Generate mapping between real network interface name and internal name and compute model limits.

### Command

```
globalgen [-m <model> -o <file>]
-m: model name
-o: output file
```



-m and -o options are used together to launch a globalgen dry run.

## Results

## Example

```
VMSNSX08K0011A9>globalgen
globalgen: 4 ethernet interfaces detected
globalgen: 0 WIFI interfaces detected
VMSNSX08K0011A9>
```

## HAACTIVE

### Description

Force the local firewall to become the active member of the cluster, overriding any previous forced state.

### Command

```
haactive
```

## Results

## Example

## HADIFF

### Description

Compare local and peer configuration files.

### Command

```
hadiff <filter to diff>
```

## Results

## Example



## HAINFO

### Description

Display the status of all nodes in the HA cluster.

### Command

```
hainfo
```

### Results

### Example

## HALT

### Description

Stops the IPS-Firewall. Warning ! No confirmation is required. This action stops the HA monitoring.

### Command

```
When HA is enabled :  
Halt [-f] [-v] [-r]  
-f : Force  
-v : Verbose  
-r : Reboot
```

### Results

### Example

```
1003D011690200701>halt  
Shutdown NOW!  
shutdown: [pid 829]  
*** FINAL System shutdown message from  
admin@U2504C0999999999999  
***  
System going down IMMEDIATELY
```



## HAMODE

### Description

Display ha mode [active or passive fw].

### Command

```
hamode
```

### Results

### Example

```
V50XXA3E0000000>hamode  
HA Mode : Active
```

## HAPASSIVE

### Description

Force the local firewall to become the passive member of the cluster, overriding any previous forced state.

### Command

```
hapassive
```

### Results

### Example

## HARDWARECTL

### Description

Send command to hardware, like setting the front panel lights or setting the watchdog timer.

### Command

```
hardwarectl -c <command> [-a <command_arg>]  
command_arg must be an integer between 0 and 255  
Commands list :
```



```
HWD_STATE_WARNING
HWD_STATE_NORMAL
HWD_STATE_READY
HWD_STATE_HA_READY
HWD_STATE_SHUTTING_DOWN
HWD_STATE_SYSTEM_OFF
HWD_STATE_AMNESIAC
HWD_CMD_STOPWATCHDOG
HWD_CMD_SETWATCHDOG (argument needed)
HWD_CMD_KEEPWATCHDOG
HWD_CMD_STOPREFRESHBYPASSHW
HWD_CMD_STARTBYPASSHW
HWD_CMD_TOGGLEREFRESHBYPASSHW
```

## Results

## Example

## HARDWARED

### Description

Single point of communication with hardware addon. Wait for button state change and react accordingly. Animate minor/major LED. Restore default configuration when button is pressed.

### Command

```
hardwared [-s] [-S on|off|blink] [-o on|off|blink] [-v]
-s: print status
-S: on|off|blink: status led test mode
-o: on|off|blink: online led test mode
-v: print hardware version
```

## Results

## Example

```
SN910A17A1711A7>hardwared -v
hardwared 4.1.5
```

## HARESET

### Description

Cancel any previous forced state for all members of the cluster.



### Command

hareset

### Results

### Example

## HASCP

### Description

Scp to ha peer.

### Command

hascp

### Results

### Example

## HASSH

### Description

Ssh ha peer.

### Command

hassh

### Results

### Example



## HASYNC

### Description

Synchronizes all configuration files between the local firewall and the HA cluster members.

### Command

```
hasync
```

### Results

### Example

## HASYNCTEST

### Description

Tests rsync of hasync in dry mode.

### Command

```
hasynctest
```

### Results

### Example

## HOSTCHECK

### Description

Test the availability of a specified host. This binary is deprecated.

### Command

```
Hostcheck [-h|i|o] [-v] [-c <CheckHost>] [-t <Type>] <Host>  
<MaxWait> <MaxTries>-h: The host address must be resolved  
using hosts file  
-i: The host address is an IP address  
-o: The host address must be resolved using the object  
database  
-v: Force Verbosity to stdout
```



-c: Check <CheckHost> through <Host> instead of <Host>-t: set a type of check (string used in the state file name, must not contain '/')  
-q: Do not raise a system alarm  
<Host>: The host to check. Can be an IP address, a resolvable host or an object depending on the configuration parameter Resolve in ConfigFiles/route at section [Config]  
<MaxWait>: maximum time to wait for the response to the "ping" test before considering it a failure. Must be >=1 and <=10 (expressed in seconds)  
<MaxTries>: maximum number of "ping" tries before returning that the host is considered DOWN or inactive. Must be >=1 and <=10

## Results

Returns 0|1|2|3  
0 : if there has been NO change in the state of the checked host  
1 : if there HAS been a change in the state of the checked host and it is UP  
2 : if there HAS been a change in the state of the checked host and it is DOWN  
3 : for invalid argument

## Example

## IFINFO

### Description

Gives the information of the network interfaces configurations.

### Command

```
ifinfo <name> <command> [<index>]
<name> :
in
out
dialup
pptp
ethernet
vlan
ipsec
gretun
gretap
loopback
<command> :
mac_name : get the name of the network interface
mac_address : get the MAC address of the network interface
mac_throughput : get the maximum media throughput
ip_address : get the configured IP address
ip_netmask : get the network address
ip_broadcast : get the broadcast address
ip_network : get the network address
```



count : get the count of interface type ( <name> = dialup, pptp, ethernet, vlan, ipsec, gretun, gretap, loopback)  
ip\_config : get the configured IP address/mask  
bridge\_name : if bridged, return bridgename  
peer\_address : get the peer address of P2P interface  
[<index>] : optional.

## Results

## Example

```
U2504C099999999999999>ifinfo
interface list:
bridge0
10.2.32.254/255.255.0.0
out (fxp1)
in (protected,fxp0)
dmz1 (protected,fxp2)
dmz2 (protected,fxp3)
ipsec (enc0)
U2504C099999999999999>
```

## IOCTLFW

### Description

Get and set the ASQ ioctl privileges

### Command

```
ioctlfw [-h] [-v] [-l] [-d]<br/>-h: display help<br/>-v: enable debug verbose<br/>-l: load the configuration into ASQ<br/>-d: dump the current ASQ configuration
```

## Results

## Example

## KEEPALIVE

### Description

Sends IPSec keepalive packets



## Command

```
Keepalive [time_value]
time_value : 30, 60, 120, 300, 600, 0
```

## Results

## Example

# LAUNCHCTL

## Description

launchd interface for daemons management.

## Command

```
launchctl <subcommand>help This help output.
load Load configuration files and/or directories.
unload Unload configuration files and/or directories.
remove Remove/stop specified job.
resetsigabrt [daemon_list] reset sigabort counter for
specified daemon (all daemons if daemon_list is empty)
status [-h] [up|down|<daemon_name>] Show information about
daemons (set -h option to show uptime in SNS format (ex: 1w 2d
5h 20m 59s or 10m 2s))
list List jobs and information about jobs.
sig Send a signal to a specified job.
-u Start the specified job (will be restarted on exit).
-o Start the specified job (will not be restarted on exit).
-d Stop specified job.
-p Send a STOP signal to the service.
-c Send a CONT signal to the service.
-h Send a HUP signal to the service.
-a Send a ALRM signal to the service.
-i Send a INT signal to the service.
-t Send a TERM signal to the service.
-k Send a KILL signal to the service.
-l Send a USR1 signal to the service.
-2 Send a USR2 signal to the service.
-x Prepare for launchd shutdown.
wd Svcwaitdown -k.
wu Svcwaitup.
```

## Results



## Example

## LAUNCHD

### Description

Daemon which manages other daemons.

### Command

```
launchd [-d | -f | -h ]  
-d: Daemonize.  
-h: This usage statement.  
-f: Force.
```

### Results

## Example

## LAUNCHER\_LOG

### Description

Log in verbose file which processes have called the process with PID passed as argument.

### Command

```
launcher_log [-b | --begin] [-e | --end] [-p | --pid ] [-s | -  
-section] [-c | --category ] [-h | --help]
```

-b, --begin : log that the process with the PID passed as the argument has begun

-e, --end : log that the process with the PID passed as argument has terminated

-p, --pid : PID

-s, --section : section to load

-c, --category : category to use when logging

-h, --help : print this help and exit



## Results

### Example

```
VMSNSX08K0013A9>launcher_log -b -s "enlaunchers" -c  
"ENANTIVIRUS" -p "1664"  
VMSNSX08K0013A9>
```

## LDAPCHECK

### Description

Command line program to check information in a ldap

### Command

```
ldapcheck --user <userid>[ --domain <domain>][ --group  
<group>] --check <command>--user : id of the user to be  
checked  
--domain : domain used for the check, default one if not  
specified  
--group : group used for the check  
--check : the kind of check you want like 'belongs-to-group'  
* 'belongs-to-domain': check if the user belongs to the domain  
passed in parameters  
* 'belongs-to-group': check if the user belong to the group  
passed in parameters
```

### Results

```
[ldapcheck] Result=ko|ok
```

### Example

```
ldapcheck --user "test" --group "testgroup" --check "belongs-  
to-group"
```

## LDAPMANAGER

### Description

Manage an internal LDAP base.



## Command

```
ldapmanager
ldapmanager -m export -f <LDIF output file path>ldapmanager -m
import -f <LDIF input file path>ldapmanager -m adduser -u
<uid> -n <name> [-g <gname>]
ldapmanager -m remuser -u <uid>ldapmanager -m listuser
ldapmanager -m raz
Remark :default action is equivalent to "objecttest -d all"
ldapmanager -m export : Export the LOCAL LDAP base to LDIF
file
ldapmanager -m import : Import a LDIF file to the LOCAL LDAP
ldapmanager -m adduser : Add an user to the LOCAL LDAP
ldapmanager -m remuser : Remove an user from the LOCAL LDAP
ldapmanager -m listuser : List the user(s) in the LOCAL LDAP
ldapmanager -m raz : Remove ALL UER(S) from the LOCAL LDAP
```

## Results

## Example

```
ldapmanager -m export -f ~/Configfiles/data/base.ldif
ldapmanager -m import -f ~/Configfiles/data/base.ldif
ldapmanager -m adduser -u user_uid -n user_name -g user_gname
ldapmanager -m remuser -u user_uid
ldapmanager -m listuser
ldapmanager -m raz
```

## LICENCEDIAG

### Description

Command line program to troubleshoot licence issues

### Command

```
licencediag [--help] [--file <licence>] [--cert <certificate>]
--key <key>] [--text] [--force_display]
```

### Results

### Example



## LICENCEUPDATE

### Description

Command line program to download and activate the firewall license

### Command

```
licenceupdate [-d|-D] [-a|-A] [-v] [-t <n>] [ñ-o] [-c]
-d: download new licence
-D: force download new licence
-a: activate licence
-A: force activate licence
-c: check if a new licence has been downloaded
-v: activate the verbose
-t: number of retries per licence
-o: activate licence only if the current licence is temporary,
use with a or A option
<no arg> : use configuration file
```

### Results

### Example

```
VMSNSX08K0011A9>licenceupdate -D -A
VMSNSX08K0011A9>cat /log/verbose.licenceupdate
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Prepare
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Download
/usr/Firewall/Data/Licence/VMSNSX08K0011A9.licence from
licence1-sns.stormshieldcs.eu (try 1)
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Download
complete
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] No new licence
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Checking
licence /usr/Firewall/Data/Licence/VMSNSX08K0011A9.licence
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Finalize
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Activate
licence (forced)
[2020-03-26 10:19:06] [INFO ] [LICENCEUPDATE ] Activated
licence diff:
```

## LOGCTL

### Description

Display information logs and reports.



## Command

```
logctl [-c [-ri]] [-h] [-t <log_id>] [-T <log_id>] [-p <log_id>] [-q] [-v]
-h: this help.
-c [-ri]: print information about SHM and failure counters.
-r: reset information after printing them
-i: print information on one line
-t <log_id>: Test reports regex. Read fake log lines from stdin
-T <log_id>: Send log lines to Logd. Read log lines from stdin
-p <log_id>: Write log disk properties on stdout
+ Valid values for log_id are:
l_alarm, l_connection, l_filter, l_web, l_smtp, l_date, l_ftp,
l_system, l_plugin, l_vpn, l_auth, l_server, l_pop3, l_xvpn,
l_monitor, l_pvm, l_count, l_filterstat, l_ssl
-o <report> <period> : Get the requested report.
Unable to load reports configuration: Nothing to do (State=0?)
+ Possible periods are:
lasthour, day-0, day-1, day-2, day-3, day-4, day-5, day-6,
day-7, last7days, last30days, all
-q: Quiet, don't insert info in log files
-v: Verbose (-vv enables debug)
```

## Results

## Example

## LOGD

## Description

Log daemon.

## Command

```
logd [-t] [-d] [-D] [-h?] [-v]
-t: check if logd is ready
-d: activate verbose mode
-D: daemonize
-h -?: help
-v: version
```



## Results

```
U2504C099999999999999>logd -d LOGD starts in verbose mode. 2011-04-11 16:26:34 | logd_
config_deb | LOGD verbose ON 2011-04-11 16:26:34 | logd_config_deb | Verbose=0, no verbose
activated. Please put the wanted debug level into this token (between 1 and 3) 2011-04-11
16:26:34 | logd_config_deb | LOGD verbose OFF
```

## Example

## LOGDISK

### Description

Manage partition logs.

### Command

```
logdisk ( -s | -l | -f [<disk/partition> [-w]] | -m
[<partition>] | -u | -c | -b | -h ) [-v]
-s : Display log partition status
-l : List all available disks/partitions.
-f [<disk/partition>] : Format current/specified log
disk/partition.
For current partition, unmount, format and mount it
automatically.
-w option forces the add of a swap partition even if model
does not require it
-m [<partition>] : Mount current/specified partition. Unmount
last partition if necessary.
-u : Unmount current partition.
-c : Do sanity checks on log partition. Try to mount back
partition in case of problem.
-b : Used during boot to mount log partition if necessary.
Skip daemons interaction.
-h : Display this usage.
-v : Verbose mode
```

## Results

## Example

## MEMCHECK

### Description

Restart a daemon if it takes more than 1Gb of memory



## Command

```
memcheck <daemon_name> <memory_limit> [verbose_path]
```

## Example

```
memcheck serverd 1000000 /log/dbg
```

## MEMLIMIT

### Description

execute a process with both its memory limits set and malloc config set

### Command

```
memlimit path [args...]  
path: path of the process to be executed  
args: args passed to the executed process
```

### Results

the executed process result

### Example

## MODCHECK

### Description

Modcheck command Update configuration related to objects given as parameter

### Command

```
modcheck -t <OBJ_TYPE_NAME> -o <OBJ_NAME> [-g] [-f] [-v]  
modcheck -i <OBJ_TYPE_ID> -o <OBJ_NAME> [-g] [-f] [-v]  
-t : mandatory (or -i), object type name  
-i : mandatory (or -t), object type id  
-o : mandatory, object name  
-g : object type id  
-f : set OBJCHK_FIND_FLAGS to OBJCHK_FIND_FLAGS_IGNORE_  
GENERATED_GROUP_MEMBERSHIP  
-v : verbose
```

### Results



## Example

```
modcheck -t certificate -o full_renew
modcheck -t host -o hello
```

## MODEMCTL

### Description

Configuration helper for usb modem.

### Command

```
modemctl ( devinfos [<device>] | eject <device> | reset
<device> ) [-v]
A device is referenced by its unit address with the
ugen<unit>.<addr> form (ugen4.2)
devinfos          : Display information about all plugged USB
devices.
eject             : Power off <device> to eject safely.
reset            : Restart <device>. Useful to trigger probing by
the kernel.
-v --verbose     : Verbose mode
-h --help       : This help
```

### Results

#### Example

```
./modemctl devinfos
ugen4.2: <Mass Storage Generic> at usb4, cfg=255 md=HOST
spd=HIGH (480Mbps) pwr=OFF (200mA)
VendorId=058f
ProductId=6387

ugen4.3: <USB Modem USB Modem> at usb4, cfg=0 md=HOST
spd=HIGH (480Mbps) pwr=ON (500mA)
VendorId=1c9e
ProductId=9603

ugen4.4: <HUAWEIMOBILE HUAWEIMOBILE> at usb4, cfg=0 md=HOST
spd=HIGH (480Mbps) pwr=ON (2mA)
VendorId=12d1
ProductId=15cf
./modemctl eject ugen4.4
ugen4.4 has been powered off and can be ejected safely
```



## MONITORCTL

### Description

Monitord client

### Command

```
monitorctl [options]
```

Options:

```
-h [ --help ]           Display this message.  
-o [ --libxo ] arg     Specify the output format, arg may be  
                        "text|html|xml|json[,pretty]" (default is  
                        "text,pretty").  
-r [ --reload-config ] request monitord to reload its  
configuration  
-f [ --force-refresh ] request monitord to refresh its  
monitoring information
```

### Results

### Example

## MPD

### Description

Multi network protocol daemon.

### Command

```
mpd [options] [system]
```

Options:

```
-b, --background : Run as a background daemon  
-d, --directory config-dir : Set config file directory  
-k, --kill : Kill running mpd process before start  
-f, --file config-file : Set configuration file  
-o, --one-shot : Terminate daemon after last link shutdown  
-p,  
--pidfile filename : Set PID filename  
-s, --syslog-ident ident : Identifier to use for syslog
```



-m, --pam-service service : PAM service name  
-v, --version : Show version information  
-h, --help : Show usage information

## Results

## Example

## NDMESG

### Description

Print the kernel ring buffer with date

### Command

ndmesg (no argument)

## Results

## Example

## NEWLDAPBASE

### Description

Generate an LDAP base. Called by enldap.

### Command

Usage: newldapbase [ -o Orgname -d DC [-p tmppass][-P][-v]  
-o Orgname : organization name  
-d DC : domain component  
-p tmppassword : temporary password  
-P : prompt for the temporary password  
-v : verbose  
-h : displays help

## Results



## Example

## NGSTAT

### Description

Gives information on the interfaces generated by mpd daemon.

### Command

```
ngstat [name] [protocol]
name : netgraph interface name listed in /var/run/mpd.pid
protocol :
<PPTP | pptp><PPPOE | PPPoE | pppoe>
```

### Results

## Example

## NHUP

### Description

Sends SIGHUP signal to specified daemon (must be a daemon from /var/ supervise).

### Command

```
nhup <daemon name>With <daemon_name> a daemon listed by dstat
command
```

### Results

## Example

## NKILL

### Description

Kill the specified daemon (must be a daemon listed in /var/ supervise).



## Command

nkill <daemon name>With <daemon\_name> a daemon listed by dstat command

## Results

## Example

## NRAID

### Description

Creates and rebuilds raid.

### Command

```
nraid -h | -c | -s | -z | -a | -w <disk> | -r  
-h : print this help and exit  
-c : create the RAID array  
-s: show current disks status  
-z: reset raid ata port and probe new plugged disk  
-w: wipe disk info and make it blank  
-r : rebuild raid if one disk has failed  
-a: try to create automaticaly RAID silently
```

## Results

## Example

## NRELOAD

### Description

Reload the specified daemon into launchd, allowing to switch to another version of the startup script.

### Command

```
nreload [-f ] <daemon> [<version>]  
-f : force to reload the daemon, even if the version is  
unchanged.
```



## Results

## Example

## NRESTART

### Description

Restart the specified daemon (must be a daemon listed in /var/supervise).

### Command

```
nrestart <daemon name>With <daemon_name> a daemon listed by  
dstat command
```

## Results

## Example

## NSBSDSTART

### Description

Called during boot to set up some system values.

### Command

```
nsbsdstart (no argument)
```

## Results

## Example

## NSBSDSTOP

### Description

Updates /boot/loader.conf according to the configuration. Called during shutdown.



## Command

```
nsbsdstop [-d]  
-d : Activate debugging
```

## Results

Information written in file /boot/loader.conf

## Example

## NSRPC

### Description

This command is used to have access to the serverd commands. The -f option is used to force the "admin" connection. The -r option is used to specify the access rights of the user. The list of access rights is written as a string with each right separated by a comma. The rights that can be specified are the following : modify, base, other, log, filter, vpn, url, pki, object, user, admin. Encoding depend on the locale LC\_ALL

### Command

```
nsrpc [-a|-d|-f] [-C connection timeout] [-R reading timeout]  
[(-4|-6)] [-c command file] [-l log file] [-r rights] user  
[:password]@server[:port]  
nsrpc [-d|-f] [-C connection timeout] [-R reading timeout] [(-  
4|-6)] -t targets file -c command file [-l log file] [-r  
rights]  
-a: automatically connect with default password  
-c: set file with firewall commands  
-C: set connection timeout (min: 5 ; max: 600 ; default: 600)  
-d: activate debug  
-f: force login  
-l: set file to output commands and firewall results  
-r: set rights  
-R: set reading timeout (min: 5 ; max: 600 ; default: 600)  
-t: set file with target firewalls ("IP[;port];login;password"  
on each line)  
-h: this usage  
-4: connect using IPv4 (default)  
-6: connect using IPv6  
WARNING : stormshield_network.ca file must be in the same path  
as nsrpc
```

### Results



## Example

```
U2504C09999999999999>nsrcpc admin@127.0.0.1
Welcome to Cipher/SRP client
Enter password:
Connecting to 127.0.0.1...
Using SRP authentication only.
User=admin
Level="modify,mon_
write,base,other,log,filter,vpn,url,pki,object,user,admin,netw
ork,route,maintenance,asq,pvm,globalobject,globalfilter,global
other"
SessionLevel="modify,mon_
write,base,other,log,filter,vpn,url,pki,object,user,admin,netw
ork,route,maintenance,asq,pvm,globalobject,globalfilter,global
other"
Srpclient>
```

## NSTART

### Description

Start the specified daemon (must be a daemon listed in /var/supervise).

### Command

```
nstart <daemon name>With <daemon_name> a daemon listed by
dstat command
```

### Results

## Example

## NSTOP

### Description

Stop the specified daemon (must be a daemon listed in /var/supervise).

### Command

```
nstop <daemon name>With <daemon_name> a daemon listed by dstat
command
```



## Results

## Example

## NTPD

### Description

NTP daemon program.

### Command

```
ntpd [ -<flag> [<val>] | --<name>[={| }<val>] ].. [<server1>
... <serverN>] novirtualips
Do not listen to virtual interfaces
Flag Arg Name Description
-4 no ipv4 Force IPv4 DNS name resolution - prohibits the
option 'ipv6'
-6 no ipv6 Force IPv6 DNS name resolution - prohibits the
option 'ipv4'
-a no authreq Require crypto authentication - prohibits the
option 'authnreq'
-A no authnreq Do not require crypto authentication -
prohibits the option 'authreq'
-b no bcstsync Allow to sync to broadcast servers
-c Str configfile Configuration file name
-d no debug-level Increase output debug message level - may
appear multiple times
-D Str set-debug-level Set the output debug message level -
may appear multiple times
-f Str driftfile Frequency drift file name
-g no panicgate Allow the first adjustment to be Big - may
appear multiple times
-G no force-step-once Step any initial offset correction.
-i no jaildir Built without --enable-clockctl or --enable-
linuxcaps or --enable-solarisprivs
-I Str interface Listen to an interface name or address - may
appear multiple times
-k Str keyfile Path to symmetric keys
-l Str logfile Path to log file
-L no
-n no nofork Do not fork - prohibits the option 'wait-sync'
-N no nice Run at high priority
-p Str pidfile Path to PID file
-P Num priority priority Process priority
-q no quit Set the time and quit - prohibits these options:
saveconfigquit wait-sync
-r Str Str propagationdelay saveconfigquit
Broadcast/propagation delay Save parsed configuration and quit
```



- prohibits these options: quit wait-sync
- s Str statsdir Statistics file location
- t Str trustedkey Trusted key number
- u --- user built without --enable-clockctl or --enable-linuxcaps or --enable-solarisprivs
- U Num Str Str updateinterval var dvar interval in seconds between scans for new or dropped interfaces make ARG an ntp variable (RW). May appear multiple times. make ARG an ntp variable (RW|DEF). May appear multiple times.
- w Num wait-sync Seconds to wait for first clock sync - prohibits these options: nofork quit saveconfigquit
- x no slew Slew up to 600 seconds opt version Output version information and exit
- ? no help Display extended usage information and exit
- ! no more-help Extended usage information passed thru pager

Options are specified by doubled hyphens and their name or by a single hyphen and the flag character.

The following option preset mechanisms are supported:

- examining environment variables named NTPD\_\*

## Results

## Example

## NTPQ

## Description

Standard NTP query program

## Command

```
ntpq [ -<flag> [<val>] | --<name>[={|}<val>] ]... [ host ... ]
```

- 4 no ipv4 Force IPv4 DNS name resolution - prohibits the option 'ipv6'
- 6 no ipv6 Force IPv6 DNS name resolution - prohibits the option 'ipv4'
- c Str command run a command and exit - may appear multiple times
- d no debug-level Increase output debug message level - may appear multiple times
- D Str set-debug-level Set the output debug message level - may appear multiple times
- i no interactive
- i no interactive Force ntpq to operate in interactive mode - prohibits these options: command peers
- n no no opt numeric old-rv version numeric host addresses

Always output status line with readvar Output version information and exit



```
-p no peers Print a list of the peers -prohibits the option  
'interactive'  
-w no opt wide version Display the full 'remote' value output  
version information and exit  
-? no help Display extended usage information and exit  
-! no more-help Extended usage information passed thru pager  
-> opt save-opts Save the option state to a config file  
-< Str load-opts Load options from a config file
```

## Results

## Example

## NVERBOSE

### Description

Activate/deactivate verbose on the specified daemon. If the given daemon isn't started or doesn't support verbose, an error will be reported.

### Command

```
nverbose <daemon>
```

## Results

## Example

## NVMCHECK

### Description

Check NVM version of Intel XL card

### Command

```
nvmcheck [-h] [-v]  
-h : display help  
-i : display information about update  
-f : do not check last update status  
-u : exec nvmupdate if some NVM should be updated  
-v : verbose mode
```



## Results

0 if all cards NVM are up to date 1 if some cards NVM should be updated 2 reboot is required by nvmupdate exec

## Example

## OBJECTSYNC

### Description

Synchronize the dynamic objects.

### Command

```
objectsync [-v] [-c] [-t <host> | -4 <host> | -6 <host>]
-h: this help
-v: turn verbose on
-c: use the cached value of the dynamic object, if it doesn't
exist, then perform a DNS query
-t <host>: resolve the IPv4 and IPv6 address of host <host>-4
<host>: resolve the IPv4 address of host <host>-6 <host>:
resolve the IPv6 address of host <host>
```

## Results

## Example

## OCSPCHECK

### Description

Check OCSP server connectivity for a given certificate

### Command

```
ocspcheck --name <certname> --caname <caname> [--bindaddr
<addr/host/interface>] [--bindport <port>] [--dgst
<algorithm>] [--method <GET|POST>] [--uri <URI>] [--no-verify]
[--no-conf] [--dump-files] [--no-nonce] [--verbose] [--quiet]
--name          : certificate to be checked (must be
present in local PKI dir)
--caname        : CA for the certificate to be checked
(must be present in local or global PKI dir)
--bindaddr <addr> : address/host/interface to bind the
```



```
connection to
--bindport <port>      : port to bind the connection to
--dgst <algorithm>    : hash algorithm to be used for
certificate IDs in OCSP request (default SHA1)
--method <GET|POST>   : HTTP method to use (default POST)
--uri <URI>           : URI to use (overrides URIs found in cert
and conf)
--no-verify           : bypass response verification step
--no-conf             : do not retrieve CA and ocsp signer certs
from VPN configuration
--dump-files          : dump OCSP request and response in ocsp_
req.der and ocsp_resp.der (existing files will be overwritten)
--no-nonce            : do not send a nonce in the OCSP request
--verbose             : redirect verbose to stdout
--quiet              : print result only and no extra info
--help               : this help
```

## Results

## Example

```
ocspcheck --caname "C=FR ST=STST O=OO OU=OUOU CN=SubCA" --name
"C=FR ST=STST O=OO OU=OUOU CN=VPNClient.com" --quiet
```

## OPENVPN

### Description

OpenVPN Daemon

### Command

## Results

## Example

## OPENVPN\_AUTH

### Description

Authenticate user and control his access.



## Command

```
openvpn_auth tcp|udp  
openvpn_auth tcp : Authenticate TCP user  
openvpn_auth udp : Authenticate UDP user
```

## Results

## Example

## OPENVPN\_CLEAN\_USERTABLE

### Description

Called by launchd on OpenVPN daemon shutdown and ensures to clean ASQ users table entries flagged with OPENVPN method.

## Command

```
openvpn_clean tcp|udp  
openvpn_clean tcp : Clean ASQ TCP users table entries flagged  
with OPENVPN method  
openvpn_clean udp : Clean ASQ UDP users table entries flagged  
with OPENVPN method  
openvpn_clean all : Clean ASQ TCP and UDP users table entries  
flagged with OPENVPN method
```

## Results

## Example

## OPENVPN\_CONNECT

### Description

Register user in ASQ users table.

## Command

```
openvpn_connect tcp|udp  
openvpn_connect tcp : Register TCP user in ASQ users table  
openvpn_connect udp : Register UDP user in ASQ users table
```



## Results

## Example

### OPENVPN\_DISCONNECT

#### Description

Remove user in ASQ users table.

#### Command

```
openvpn_disconnect tcp|udp  
openvpn_disconnect tcp  
openvpn_disconnect udp
```

## Results

## Example

### OPENVPN\_PROXYCTL

#### Description

OpenVPN proxy daemon controller

#### Command

```
openvpn_proxyctl [-d] [-v] [-h] command  
  
-h, --help      : show this help  
-v, --verbose: enable verbose  
  
-d, --daemon   : run in background  
commands:  
mgmt_raw <tcp|udp> command: send the given command to openvpn  
list_users [tcp|udp|both]: list users of given openvpn server
```

## Results



## Example

### OPENVPN\_PROXYD

#### Description

OpenVPN proxy daemon

#### Command

```
openvpn_proxyd [-d] [-v] [-h]
-d, --daemonize: will daemonize
-v, --verbose   : verbose mode
-h, --help     : show this help
```

#### Results

## Example

### P12IMPORT

#### Description

Import PKCS#12 file.

#### Command

```
p12import -f <file path> [-p <password>] [-P] [-v]
-v : verbose mode
-t : if specified, TPM seal is forced to ONDISK, NONE
otherwise
-p : password associated with PKCS#12 file
-P : prompt for a password
-f : import PKCS#12 file given by <file path>
```

#### Results

## Example



## PAYGPREP

### Description

PAYG template provisioning utility

### Command

```
paygprep  
This wizard provisions the virtual machine to a PAYG template.
```

### Results

### Example

## PIMCTL

### Description

Interrogates pimd for status information.

### Command

```
Usage:  
pimctl [
```

### Options

```
][
```

### Command

```
]
```

Options:

```
-m, --monitor           Run '
```

### Command

```
' every two seconds, like watch(1)
```

```
-p, --plain             Use plain table headings, no ctrl  
chars
```

```
-t, --no-heading       Skip table headings
```



-h, --help	This help text
-x, --xml cli commands)	Set output format to XML (only for cli commands)
Commands:	
help	This help text
kill	Kill running daemon, like SIGTERM
restart	Restart and reload .conf file,
like SIGHUP	
graceful	Graceful restart of all protocol
layers	
show status	Show router status
show igmp	Show interfaces and group
memberships	
show interface	Show router interface table
show mrt [detail]	Show multicast routing table
show neighbor	Show router neighbor table
show rp	Show Rendezvous-Point (RP) set
show crp	Show candidate Rendezvous-Point
(CRP) set	
show pim [detail]	Show interfaces, neighbors and
routes (default)	
show compat [detail]	Show router status, compat mode
cli igmp	Execute command cli for IGMP
table	
cli interface	Execute command cli for INTERFACE
table	
cli mrt	Execute command cli for MRT table
cli rp	Execute command cli for RP table
cli bsr	Execute command cli for BSR table
config check	Check if the configuration files
match what is currently loaded in pimd.	
config reload	Reload configuration

## Results

The information requested.

## Example

```
VMSNSX00Z0000A0>pimctl show rp
```

```

PIM Rendez-Vous Point Set Table
Group Address      RP Address      Prio  Holdtime  Type
232/8              169.254.0.1    1     Forever  Static
239/8              10.221.39.221  1     Forever  Static

```



## PIMD

### Description

Daemon that manages multicast routing using the PIM (Protocol Independent Multicast) protocol.

### Command

Usage:

```
pimd [-hnrs] [-w SEC]
```

Options:

<code>-n, --foreground</code>	Run in foreground do not detach from calling terminal
<code>-r</code>	Retry (forever) if not all configured interfaces are available when starting up, e.g. wait for DHCP lease
<code>--disable-vifs (phyint) by default</code>	Disable all virtual interfaces
<code>-h, --help</code>	Show this help text
<code>-w, --startup-delay=SEC</code>	Initial startup delay before probing interfaces

### Results

Launches the daemon. Normally launched only by `launchd`.

### Example

## PKICTL

### Description

Manage PKI content.

### Command

```
pkictl <operation> [--help] [--verbose] [--pkidir <path>|--global] [options...]
```

<operation> can be one of the following :

<code>create</code>	: create a new object into PKI
<code>import</code>	: import object(s) into PKI
<code>stage</code>	: stage PKI objects in a restricted folder



```
verify          : verify the PKI object against the
specified parent
--help          : display help for the selected operation
--verbose       : verbose mode
--pkidir <path> : PKI dir to use
--global        : shortcut to use the global PKI dir
```

## Results

## Example

## POWERSTATUS

### Description

Display status of power slots

### Command

```
powerstatus [-s <0|1>]
-s <0|1>: slot to display (if missing, display all slots)
```

## Results

## Example

```
SN6KXA04F0015A8>powerstatus
POWER0: OK
POWER1: OK
```

## PPPDOWN

### Description

Called when a PPP link is down.

### Command

```
pppdwn <dialup-interface>dialup-interface : interface name to
check
```



## Results

## Example

## PPPDOWN2

### Description

Called in background when a PPP link is down.

### Command

```
pppdwn <dialup-interface>dialup-interface : interface name to  
check
```

## Results

## Example

## PPPUP

### Description

Called when a PPP link is up.

### Command

```
pppup <interface> inet <local-ip> <remote-ip> <authname> [dns1  
ip] [dns2 ip]  
<interface> : Interface name  
<local-ip> : IP address of link's local endpoint  
<remote-ip> : IP address of link's remote endpoint  
<authname> : authentication name  
<dns1 ip> : Domain name server primary IP address  
<dns2 ip> : Domain name server secondary IP address
```

## Results

## Example



## PPPUP2

### Description

Called in background when a PPP link is up.

### Command

```
pppup <interface> inet <local-ip> <remote-ip> <authname> [dns1 ip] [dns2 ip]
<interface> : Interface name
<local-ip> : IP address of link's local endpoint
<remote-ip> : IP address of link's remote endpoint
<authname> : authentication name
<dns1 ip> : Domain name server primary IP address
<dns2 ip> : Domain name server secondary IP address
```

### Results

### Example

## PVMGENCONF

### Description

Used by autoupdate in order to generate the configuration files for pvm from the downloaded files.

### Command

```
pvmgenconf -d <autoupdate files dir> [-c <core dir>] [-s <sodb dir>] [-b <banner dir>] [-v <vuln rules file>] [-V <vuln descs file>] [-p <pof rules file>] [-l <us|fr>:<language file> [-l ...]]
-d <autoupd files dir> : Autoupdate download directory
-c <core dir> : Pvm main directory
-s <sodb dir> : Service OS Database directory
-b <banner dir> : Service Banner directory
-v <vuln rules file> : Vulnerability rules file
-V <vuln descs file> : Vulnerability description file
-p <pof rules file> : OS Signature file
-l <us|fr>:<language file> [-l ...] : language file
```

### Results

generates pvm conf files for ASQ <= "ASQ\_VERSION"



## Example

## REBOOT

### Description

Reboot the IPS-Firewall. Warning !! No confirmation is requested. This action stops the HA monitoring.

### Command

Reboot (no argument)

### Results

### Example

```
U2504C099999999999999>reboot
Shutdown NOW!
shutdown: [pid 712]
*** FINAL System shutdown message from
admin@U2504C099999999999999
***
System going down IMMEDIATELY
U2504C099999999999999>System shutdown time has arrived
```

## REMOTE\_SHELL

### Description

Shell for remote user. Redirect to nsrpc or csh given the CLIShell token in ConfigFiles/system [SSH]

### Command

remote\_shell

### Results

### Example



## ROUTERCTL

### Description

Client application used to control the routing management daemon (routerd)

### Command

```
routerctl [-h] [-v] [-B] [-o] [-b] [-4] [-6] [-f] [--refresh arg] [--router arg] [--gateway arg] [--state arg] [--dhcp dhcp-mac-ifce-name] [--dialup dialup-mac-ifce-name] [--check-config] [--dump-config] [--reload-config arg] [--host-status] [--get-history] [--dump-state] [--health]
```

Command	Args	Description
-h [ --help ]		Display a
help message		
-v [ --verbose ]		Enable
verbose mode		
-B [ --background]		Execute in
the background (nothing is printed)		
-o [ --libxo ]	(text html xml json)[,pretty]	Specify the
output format (text,pretty is used by default)		
-b		Boot mode
(won't call external scripts in case the firmware is booting up)		
-4 [ --ipv4 ]		Manage IPv4
routes or objects		
-6 [ --ipv6 ]		Manage IPv6
routes or objects		
-f		Update the
routes in the kernel even if their state has not		changed
-n		Changes are
not applied and are printed instead		
--refresh		Refresh
routes (all routes are refreshed, for both ip versions by default)		
--refresh-pbr		Refresh the
router's pbr usage.		
--router	router-object	Name of the
router object to update (which ip version to operate on must be specified with option -4 or -6)		
--gateway	gateway	Gateway of an
host to request		
--state	UP DEGRADED DOWN	New state of
the specified gateway (case insensitive)		
--dhcp	dhcp-mac-ifce-name	Name of the
DHCP interface to update, can only be used for DHCPv4 interfaces ( ex: eth0, IPv4 option -4 must be specified)		
--dialup	dialup-mac-ifce-name	Name of the
dialup interface to update ( ex: ng0, which ip version to operate on must be specified with option -4 or -6 )		



```
--check-config          Check routing
rules validity in configuration (exclusive with other queries)
--dump-config          Dump current
routerd configuration (exclusive with other queries)
--reload-config    all|verbose|objects    Reload
current routerd configuration (every kind of configuration is
refreshed by default, exclusive with other queries)
--host-status    host-name                Show the
links(gateway/ha link) status of a host (HA peer/router
object) given in parameter
--get-history    host-name                Retrieves the
measurements history of a host (HA peer/router object) given
in parameter. Can be paired with --gateway to request a
specific gateway of this host.
--dump-state          Dump the
state of the differentes routes
--health              Get the
current global status
```

## Results

## Example

```
Refresh IPv4 or IPv6 static and default routes: routerctl
[-v] [-b] [-4] [-6] [-f] --refresh
Update the state of a gateway of a given router: routerctl
[-v] [-b] [-4] [-6] [-f] --router <router-object> --gateway
<gateway-host> --state <UP|DEGRADED|DOWN>
Update the state of a generated object of type Firewall_
<dhcp-ifce>_router and all router objects using this object
as a gateway: routerctl [-v] [-b] [-6] [-f] --dhcp <dhcp-
mac-ifce-name> --state <UP|DEGRADED|DOWN>
Update the state of a generated object of type Firewall_
<dialup-ifce>_peer and all router objects using this object
as a gateway: routerctl [-v] [-b] [-6] [-f] --dialup
<dialup-mac-ifce-name> --state <UP|DEGRADED|DOWN>
```

## ROUTERD

### Description

Routing management daemon that manage static and default routes

### Command

```
routerd [-h] [-d] [-D] [-n] [-s]
```

Command	Args	Description
-h [ --help ]		Display a help message



```
-D [ --daemonize ]      Will daemonize
-d [ --debug ]         Debug mode (start routed with verbose
if not running, otherwise activate the verbose of the current
routed process)
```

## Results

## Example

## SECADM

### Description

Used to configure Hardened BSD rules

### Command

```
secadm <command> [[modifiers] args]
Command      Args                Description
show         [-f json|ucl|xml]  show loaded ruleset
list         [-f json|ucl|xml]  alias for "show" command
load         <file>             load ruleset
validate     <file>             validate ruleset
version      show version number
flush        flush ruleset
add          pax <path> <options> add PaX rule
del          <id>               del rule
enable       <id>               enable rule
disable      <id>               disable rule
set          <options>          set various secadm options
get          <options>          get various secadm options
```

## Results

## Example

## SENDALARM

### Description

Used to send alarms from shell scripts



## Command

```
sendalarm -i <id> [-b] [-m message] [-u login] [-s src_addr]
[-d -dst_addr]
-i <id> id of the alarm message.
-b store an early alarm that will be logged at next
start of asqd. -u, -s and -d cannot be used with this option.
-m <message> alarm message related to the issue.
-u <login> user login.
-s <addr> source address.
-d <addr> destination address.
```

## Results

## Example

## SENDFILE

### Description

Used to send file from shell scripts

### Command

```
sendfile -s <server> -p <port> -f <path> -t <protocol> -m
(basic|digest|post) -d <directory> -n <name> [-c
<controlname>] [-b] [-u <username>] [-a <password>] [-x
<ca:cert>] [-r <ca:cert>] [-v]
-s server : object http server
-f path : filepath on server
-t protocol : http | https
-m mode : basic | digest | post
-d directory : file directory
-n name : filename
-c controlname : http control name
-u username : username for http authentication
-a password : password for http authentication
-x ca:cert : client certificate (default : fw certificate)
-r ca:cert : reference server certificate
-b : bypass proxy server settings
-v : verbose
```

## Results

## Example



## SENDLOG

### Description

Used to write a log from shell scripts

### Command

```
sendlog [-h] -l <log id> -m <message> [--priority <priority>]  
[--service <service>]
```

Options:

```
-h [ --help ]           Display this message.  
-m [ --message ] arg   the message to send to the log  
-p [ --program ] arg   the name of the program sending the  
log  
-l [ --log id ] arg    the id of the log to send the message  
to  
--priority arg         the priority of the log message  
--service arg          the service used to send the log
```

### Results

### Example

## SERVERD

### Description

Configuration of the daemon. Configuration is set by the user with commands lines.

### Command

```
usage: serverd [<-b | -B> ipaddr] [-p port] [-r user][-d]  
-b ipaddr Bind to the specified ipaddr (ipv4).  
-B ipdaddr Bind to the specified ipaddr (ipv6).  
-p port Attach to the specified port.  
-r user Run as the specified user.  
-d debug Set or launch serverd in verbose mode.
```

### Results

### Example



## SERVICE\_CLIENT

### Description

Test binary that use the internal messaging to communicate. It will create a client, send and receive messages from a specific service.

### Command

```
service_client
-h [ --help ]: display this message
-v [ --verbose ]: Enable verbosity
-t [ --service ]: service_name Set the service name
-m [ --message ]: arg Set the message
-s [ --startup ]: arg Set the delay in seconds at startup
before the first message (default: 1 second)
-i [ --interval ]: arg Set the interval in seconds between
successive sends (default: 1 second)
-c [ --count ]: arg Set the number of times to send the
message before exiting (default: do not stop sending)
```

### Results

Responses received from the service.

### Example

```
$> service_client --message test_request --service test_
service --count 3
Received response: <test_response>Received response: <test_
response>Received response: <test_response>
```

## SERVICE\_SERVER

### Description

Test binary that use the internal messaging to communicate. It will create a server, receive and send messages to a specific service.

### Command

```
service_server
-h [ --help ] Display this message
-v [ --verbose ] service_name Enable verbosity
-s [ --service ] service_name Set the service name
-m [ --message ] arg Set the message
```



## Results

Requests received from the service.

## Example

```
$> service_server --service test_service -m test_response
Got request: "test_request"
Got request: "test_request"
Got request: "test_request"
...
```

## SETBOOT

### Description

Used to select the boot partition for the next reboot. During the boot, if you select manually the partition on which you want to boot, it has the same effect that this command.

### Command

```
setboot <Main|Backup>Main: set main partition for next reboot
Backup: set Backup partition for next reboot.
```

## Results

## Example

## SETCONF

### Description

Write a section value to a configuration file. This command is generally called from scripts.

### Command

```
setconf <file> <section> [<token>] <value> [<comment>]
    Adds <token>=<value> to <section> in configuration file
<file> If <token> is not set, the section is appended with
<value> <comment> is only available if <token> is set.
setconf
-n, --no-protect <file> <section> <value> Sets <section> to
<value> in configuration file <file> without protecting with
"\\"
setconf
-d, --delete <file> <section> [<token> [<value>]]
```



Removes section <section> from configuration file <file>  
<token> is set, removes only the token from <section> If  
<value> is set, check token value before removing

## Results

## Example

```
U2504C0999999999999>setconf /usr/Firewall/ConfigFiles/network  
Ethernet1 Address 10.x.x.x  
U2504C0999999999999>
```

## SETKEY

### Description

PFKEYv2 userland tool used to manage kernel information related to IPsec.

### Command

```
setkey [-v] file ...  
setkey [-nv] -c  
setkey [-nv] -f filename  
setkey [-Palpv] -D  
setkey [-Pv] -F  
setkey [-H] -x  
setkey [-V] [-h]
```

## Results

## Example

## SETPERMISSIONS

### Description

Used to check and repair permissions on specific files

### Command

```
setpermissions [-h] [-r] [-t] [-p] [-o] [-g]  
-h [ --help ]: Display this message  
-r [ --repair ]: Repair permissions errors if it is possible  
-t [ --ignore-type ]: Ignore the type of the file
```



```
-p [ --ignore-permissions ]: Ignore the permissions of the
file
-o [ --ignore-owner ]: Ignore the owner of the file
-g [ --ignore-group ]: Ignore the group of the file
-v [ --verbose ]: Enable verbose
```

## Results

## Example

## SETSAREPLAYCOUNTER

### Description

Userland troubleshooting tool used to change an IPSec SA replay counter.

### Command

```
setsareplaycounter <ip src> <ip dst> <spi> <replay counter>
```

## Results

## Example

## SETURL

### Description

Set the field "URLFiltering" in the file /usr/Firewall/ConfigFiles/proxy for CLOUDURL case :  
Cloudurl State is set to 1 and URLFiltering State is set to 0 for STORMSHIELD NETWORK case :  
Cloudurl State 0 URLFiltering State is set to 1 for NONE case : both Cloudurl and URLFiltering  
State are set to 0

### Command

```
seturl [SN|CLOUDURL|NONE]  
SN: set value "SN"  
CLOUDURL: set value "CLOUDURL"  
NONE: set value "SN"
```

## Results



## Example

## SFCTL

### Description

Get or set ASQ module parameters. **Warning** This command uses some advanced functions of the firewall. Its usage must be done very carefully and with some very good knowledges. Some commands can cut current network connexions.

### Command

```
sfctl
Opt  Arg          Description
-e                               set module state
                               1 = enable
                               0 = disable
-T                               top alike mode
-f                               force operation
-v                               verbose mode
-n                               disable the reverse object lookup
-O  level         optimize ruleset at level
                               0 = none
                               1 = skip rules
-F  modifier     flush one of the following
                               addrlist = flush address list
                               assoc = flush SCTP assoc information
                               filter = flush filter rules
                               state = flush state information
                               etherstate = flush all ether state
                               count = flush count rule
                               stat = flush statistics
                               fpstat = flush fastpath statistics
                               pof = flush os signature list (pof)
                               qosq = flush qos queues
                               host = flush host (see -H hstate=...)
                               sipr = flush the sip requests
                               sip = flush the sip register table
                               ipstate = flush flows managed by ipstate
                               fpstate = flush fastpath state
                               hproperties = flush hostproperties
                               assoc = flush SCTP assoc informations
                               all = all the above
-b  t,o,a[,to]   manage blacklist entry
                               t = BlackList|WhiteList...
                               o = add or delete
                               a = string identifier or '*'
                               to = timeout
-C  configdir    load and activate a ASQ configuration
```



```
-R rulefile load a filter rule file and activate it
-c commit filter rules even if equal to old
ones
-P rulefile load finger printing rule file and
activate it
-Q load QoS queues config and activate it
-q set QoS state
1 = enable
0 = disable
-s modifier dump one of the following
addrlist = show address list
assoc = show SCTP association table
content
conn = show connection table content
connstat = show TCP conn stats per state
count = show count rule
etherstate = show Ethernet connection
table content
filter = show current filter rules
fpstat = show fastpath statistics
fpstate = show fastpath state table
global = show if statistics
ha = show ha cluster info
host = show host table content
if = show interface information
ioctl = show ioctl statistics
ipstate = show flows managed by ipstate
limit = show ASQ limits
log = show last log message
mem = show memory stats
nat = show current nat rules
natpool = show reserved nat ports
pof = show os signature list (pof)
protaddr = show protected address list
qos = show QoS rule
revrt = show reverse router table
route = show route information
rulestat = show rulesmatch
sip = show sip register table (nat)
sipr = show sip request table
stat = show statistics
state = show state table content
table = show filter tables content
user = show user table content
all = all the above
-l modifier write a log entry
count = log count rule
stat = log statistics
all = all the above
-H type=modifier modify output. type can be
host = display information for host
shost = display information for client
dhost = display information for server
```



```

port = display information for port
sport = display information for source
dport = display information for
plugin = display information associated
iface = display information associated
siface = display information associated
diface = display information associated
proto = display information associated
section = filter information for show
state = display information according
hstate = display information for host
htype = display information for host
sigid = display information for host
ctype = display connections of a given
qid = display connections of a given
rtname = display connections of a given
auth = display users authenticated
name = display user table for a given
conn = all to flush all connections
rule = filter the connections by the
natrule = filter the connections by the
macaddr = display information for mac
iptype = display information by IP type
cpu = display information by CPU
bytes = display connections with total
lastuse = display connections used within
bandwidth = display host with a total
hostrep = display host with reputation
maxcount = limit number of elements

```

returned by -s

```

geo = geo location filter
iprep = iprep filter
-A <key>[=<val>]
  [, <key>[=<val>]
    [, ...]]; [...] manually add/update authenticated user(s)
  address = user address
  name = user name
  domain = user domain
  group = group membership ("g_a,g_b")
  timeout = timeout
  multiuser = adress is multi-user (no
value)
  authmethod = authentication method
  admin = user is an admin (no value)
  sslvpn = user have access to sslvpn (no
value)
  sslrdr = user have access to sslrdr (no
value)
  openvpn = user have access to openvpn (no
value)
  ipsec = user have access to ipsec (no
value)
  sponsoring = user has the rights to

```



```
sponsor (no value)      ports_add = add ports to this user (1:4-8:12), for terminal server users only (authmethod 17)
                        ports_del = delete ports from this user (1:4-8:12), for terminal server users only (authmethod 17)
                        hostchecking = user host checking state
                        sslvpnclientversion = user SN SSL VPN

client version          ostype = user operating system

-a <key>[=<val>]
  [,<key>[=<val>]
  [, ...]];[...] manually remove authenticated user(s)
                        name = user name
                        domain = user domain
                        address = user address
                        all = all authenticated user (no value)
-r old,new              rename a user domain
-t op,val               manually add/remove objects from filter
tables (experimental)  name = name of the table
                        op = add or del
                        val = addresses separated by comma
-B op,host,conn,assoc backup operation
                        op = backup or restore
                        host = host filename
                        conn = conn filename
                        assoc = assoc filename
-h modifier            HA ethernet mode
                        active = set as active mode
                        passive = set as passive mode
                        show = display current mode
                        swap = do a swap
                        bulk = send a bulk update to peer
                        <local IP>,<peer IP>,mtu = configure HA

sync in IPS
-o filename            write output data to filename (work only
with -s)
-i source              data source (work only with -s)
                        asq = use ASQ data (default)
-p <key>[=<val>]
  [,<key>[=<val>]
  [, ...]];[...] manually add or tweak a host
                        addr = mandatory address of the host
                        if = interface name
                        state = desired state
                        mac = MAC address
                        geo = geo IP ("eu:fr")
                        iprep = IP reputation ("botnet,spam")
                        hostrep = host reputation
                        dns = DNS cache
                        nogeo = remove geo IP from host (no value)
                        noiprep = remove IP reputation from host
```



(no value) nohostrep = remove reputation from host

(no value) nodns = remove DNS cache from host (no value)

--libxo params Pass params to libxo, see libxo possible parameters <http://juniper.github.io/libxo/libxo-manual.html#option-keywords>.

color = Enable colors/effects for display styles (TEXT, HTML)

colors=xxxx = Adjust color output values

dtrt = Enable "Do The Right Thing" mode

flush = Flush after every libxo function

call flush-line = Flush after every line (line-buffered)

html = Emit HTML output

indent=xx = Set the indentation level

info = Add info attributes (HTML)

json = Emit JSON output

keys = Emit the key attribute for keys (XML)

log-gettext = Log (via stderr) each gettext(3) string lookup

log-syslog = Log (via stderr) each syslog message (via xo\_syslog)

no-humanize = Ignore the {h:} modifier (TEXT, HTML)

no-locale = Do not initialize the locale setting

no-retain = Prevent retaining formatting information

no-top Do = not emit a top set of braces (JSON)

not-first = Pretend the 1st output item was not 1st (JSON)

pretty = Emit pretty-printed output

retain = Force retaining formatting information

text = Emit TEXT output

underscores = Replace XML-friendly "-"s with JSON friendly "\_"s

units (HTML) attribute units = Add the 'units' (XML) or 'data-units' (HTML) attribute

warn = Emit warnings when libxo detects bad calls

warn-xml = Emit warnings in XML

xml = Emit XML output

xpath = Add XPath expressions (HTML)

## Results





## SLD

### Description

Daemon sld.

### Command

```
sld [-d] [-i] [-s] [-v]
-d : Toogle verbose
-i : Show information
-s : Show config
-h : Help
-v : Version
```

### Results

### Example

## SLOTINFO

### Description

Manage the different slots of configuration of the firewall (filtering, translation, VPN, ...)

### Command

```
Slotinfo [-A index [-v]] [-g index] [-f] [-a] [-n] [-S] [-s
state] <slotname>-h : This help message
-A : Set Active SlotNumber / -v verify
-f : Get Current Slot Filename
-a : Get Current SlotNumber
-g : Get Slot Filename from index
-i : Get Slot index from Filename
-n : Get Current SlotName
-S : Get Sync
-s : Set Sync
The list of <slotname> =
    globalfilter
    globalvpn
    filter
    vpn
```

### Results





```
-x --xall : Show all information for device
--scan : Scan for devices
--scan-open : Scan for devices and try to open each device
-q --quietmode <TYPE> : Set smartctl quiet mode to one of:
errorsonly, silent, noserial
-d --device <TYPE> : Specify device type to one of: ata, scsi,
sat[,auto][,N][+TYPE], usbcypress[,X], usbjmicron[,p][,x][,N],
usbsunplus, 3ware,N, hpt,L/M/N, cciss,N, areca,N/E, atacam,
auto, test
-T --tolerance <TYPE> : Tolerance: normal, conservative,
permissive, verypermissive
-b --badsum <TYPE> : Set action on bad checksum to one of:
warn, exit, ignore
-r --report <TYPE> : Report transactions (see man page)
-n --nocheck <MODE> : No check if: never, sleep, standby, idle
(see man page)
-s --smart <VALUE> : Enable/disable SMART on device (on/off)
-o --offlineauto <VALUE> : Enable/disable automatic offline
testing on device (on/off)
-S --saveauto <VALUE> : Enable/disable Attribute autosave on
device (on/off)
-s --set <NAME[,VALUE]> : Enable/disable/change device
setting: aam,[N|off], apm,[N|off], lookahead,[on|off],
security-freeze, standby,[N|off|now], wcache,[on|off], rcache,
[on|off], wcreorder,[on|off]
-H --health : Show device SMART health status
-c --capabilities : Show device SMART capabilities
-A --attributes : Show device SMART vendor-specific Attributes
and values
-f --format <FORMAT> : Set output format for attributes: old,
brief, hex[,id|val]
-l --log <TYPE> : Show device log. TYPE: error, selftest,
selective, directory[,g|s], xerror[,N][,error], xselftest[,N]
[,selftest], background, sasphy[,reset], sataphy[,reset],
scttemp[sts,hist], scttempint,N[,p], scterc[,N,M], devstat
[,N], ssd, gplog,N[,RANGE], smartlog,N[,RANGE]
-v --vendorattribute <N,OPTION> : Set display OPTION for
vendor Attribute N (see man page)
-F --firmwarebug <TYPE> : Use firmware bug workaround: none,
nologdir, samsung, samsung2, samsung3, xerrorlba, swapid
-P --presets <TYPE> : Drive-specific presets: use, ignore,
show, showall
-B --drivedb <[+]FILE> : Read and replace [add] drive database
from FILE and then
/usr/local/share/smartmontools/drivedb.h]
-t --test <TEST> : Run test. TEST: offline, short, long,
conveyance, force, vendor,N, select,M-N, pending,N,
afterselect,[on|off]
-C --captive : Do test in captive mode (along with -t)
-X --abort : Abort any non-captive test on device
```

## Results



## Example

```
smartctl -a /dev/ad0
(Prints all SMART information)
smartctl --smart=on --offlineauto=on --saveauto=on
/dev/ad0
(Enables SMART on first disk)
smartctl -t long /dev/ad0
(Executes extended disk self-test)
smartctl --attributes --log=selftest --quietmode=errorsonly
/dev/ad0
(Prints Self-Test & Attribute errors)
smartctl -a --device=3ware,2 /dev/twa0
smartctl -a --device=3ware,2 /dev/twe0
(Prints all SMART information for ATA disk on third port of
first 3ware RAID controller)
smartctl -a --device=cciss,0 /dev/ciss0
(Prints all SMART information for first disk on Common
Interface for SCSI-3 Support driver)
```

## SMCROUTERD

### Description

Daemon smcrouterd.

### Command

```
smcrouterd [-v] [-i] [-f <file>]
-i: get info on the configuration and exit
-h: show this help
-f: force config file
-v: activate verbose mode
```

### Results

## Example

## SNMPD

### Description

Daemon snmp.



## Command

snmpd [

## Options

] [LISTENING ADDRESSES] -a : log addresses -A : append to the logfile rather than truncating it -c FILE[,...] : read FILE(s) as configuration file(s) -C : do not read the default configuration files (config search path: /usr/local/etc/snmp:/usr/local/share/snmp:/usr/local/lib/snmp:/usr/Firewall/.snmp) -d : dump sent and received SNMP packets -D[TOKEN[,...]] : turn on debugging output for the given TOKEN (s) (try ALL for extremely verbose output). Don't put space(s) between -D and TOKEN(s). -f : do not fork from the shell -g GID : change to this numeric gid after opening transport endpoints -h, --help : display this usage message -H : display configuration file directives understood -I [-]INITLIST : list of mib modules to initialize (or not) (run snmpd with -Dmib\_init for a list) -L <LOGOPTS> : toggle options controlling where to log to e: log to standard error o: log to standard output n: don't log at all f file: log to the specified file s facility: log to syslog (via the specified facility) (variants) [EON] pri: log to standard error, output or /dev/null for level 'pri' and above [EON] p1-p2: log to standard error, output or /dev/null for levels 'p1' to 'p2' [FS] pri token: log to file/syslog for level 'pri' and above [FS] p1-p2 token: log to file/syslog for levels 'p1' to 'p2' -m MIBLIST : use MIBLIST instead of the default MIB list -M DIRLIST : use DIRLIST as the list of locations to look for MIBs (default no) -p FILE : store process id in FILE -q : print information in a more parsable format -r : do not exit if files only accessible to root cannot be opened -u UID : change to this uid (numeric or textual) after opening transport endpoints -v, --version : display version information -V : verbose display -x ADDRESS : use ADDRESS as AgentX address -X : run as an AgentX subagent rather than as an SNMP master agent  
Deprecated options: -l FILE : use -Lf <FILE> instead -P : use -p instead -s : use -Lsd instead -S d|i|O-? : use -Ls <facility> instead

## Results

## Example

## SSLINIT

## Description

Initialize some SSL/SSH secure keys.

## Command

```
sslinit [-p | -s] [-f] [-v]
No arg : configure all required keys and Certification
Authorities
-p : only configure proxy Certification Authorities
-s : only regenerate ssh host key
-v : activate verbose mode
```



-f : Do not perform any check on CA generation conditions and force ssh host key regeneration

## Results

## Example

## SSOD

### Description

SSO agent daemon

### Command

```
ssod [-Ddh]
-D, --daemonize: run in background
-d, --dump      : dump conf
-h, --help      : show this help
```

## Results

## Example

## STATECTL

### Description

Command line utility to set state daemon parameters when firewall is in HA mode.

### Command

```
statectl
All usage:
-v : verbose mode
-t <0-9999> : timeout
-s <infos> dump information
<infos> :
cluster = show HA cluster node info
sync = show HA node sync status
interfaces = show interfaces HA status
all = all the above
```



```
(default target host: all)
-c <command> send a command to the cluster.
  <command>:
    halt                stop firewall
    reboot              reboot firewall
    force_active        force firewall to become
the active one
    force_passive       force firewall to become
the passive one
    unforce             cancel previous forcing
    relink              reactivate faulty links
    sync[,<type>[,<source>[,nowait]]] synchronize files
                                Synchronizations options (-c sync[,<type>[,<source>]]):
                                type : Type of synchronization
                                    everything (default)
                                    config
                                    ldap
                                    ssh
                                    cert
                                    ha
                                    au_Clamav
                                    au_AdvancedAV
                                    au_Antispam
                                    au_RootCertificates
                                    au_Patterns
                                    au_URLFiltering
                                    au_Vaderetro
                                    au_Pvm
                                    pvmdb
                                    utm_secrets
                                source : specify from which node the files must be
downloaded
                                <serial> = specific host
                                local = from local firewall
                                active = from an active firewall (default)
    dumproot            run dumproot
    enha                run enha
    ennetwork           run ennetwork
    pause_balancing[<,reason>[<,duration>]] will freeze HA
balancing
                                <reason> : [enha|enfilter|ennetwork|enswitch|forced]
                                <duration> : max time during which the HA will be frozen
                                (target host: all)
    resume_balancing    resume HA balancing if
frozen
    has_logdisk         indicates if the firewall
has a log disk
-w <channel> watch HA message between cluster <channel>:
'SYNC-<serial>' or 'command', or 'all' (default target host:
all)
-S <serial> specify a target cluster member
<serial>:
specific host
```



```
local = local host
all = all cluster members
-a (re)generate Corosync authentication key file
-d display Corosync statistics and diagnostics info
-W <nb fw> wait for the HA cluster to be operationnal <nb fw>
number of firewalls to wait for
```

## Results

## Example

## STATED

### Description

State daemon. Monitors various firewall states like connected host, connections in progress, connected users, HA, network interfaces, etc... Allows HA configuration synchronization.

### Command

```
stated [-d] [-t <option1>(,<option2>(, ...))] [-k]
-d Activate debugging
-t <option1>(,<option2>(, ...)) Testing options:
    'generate_events' : generate random events/connections
    'no_passive_eth' : never switch ethernet interfaces to
passive mode
    'no_asq_events' : do no get connections lists from the ASQ
    'no_asq_restoration' : do not restore peer connections into
the ASQ when becoming active
-k : Kill all SSH redirections
```

## Results

## Example

## STRONGSWAN\_AUTH

### Description

Control user access.



## Command

```
strongswan_auth [-v] <user_id>-v : verbose mode  
user_id : id of the user to be checked
```

## Results

## Example

## STRONGSWAN\_SSO

### Description

Insert/remove user from IPS.

### Command

```
strongswan_sso --add|--delete --name <name> --address <IP> [--  
domain <domain>] [--timeout <seconds>] [--group <groups>]  
--add : insert user  
--delete : delete user  
--name <name> : name of the user  
--address <IP> : IP address of the user  
--domain <domain> : domain of the user  
--timeout <seconds> : timeout in seconds of the user  
--group <groups> : comma separated list of groups of the user
```

### Results

### Example

## SWANINFO

### Description

Display current configuration and connection status in strongSwan

### Command

```
swaninfo <element> [--noresolve] [--verbose]  
<element> is one of the following:  
conn: Display configured connections  
conn-status: Display connection status  
ike-sa [--state=<value>]: Display IKE SAs and associated
```



#### CHILD SAs

`get-counters [--name=<value>]`: Display counters for all of 1 (named) connection(s)  
`stats`: Display statistics based on IKE status and all connections counters  
`logstat`: Log IKE\_SA / CHILD\_SA rekeyings counters and reset them plus ESTABLISHED/CONNECTING IKE\_SA

#### Results

#### Example

### SWITCHCTL

#### Description

Manages switch (Only models with switch).

#### Command

```
switchctl [-e "cmd"] [-s] [-r]
-e "cmd" : send cmd command to switch and display result
-r : reboot the switch
-s : spy on communications with the switch. Commands can be
input from stdin (leave with ^C)
-b : prevent network traffic from going through the switch
```

#### Results

#### Example

### SWITCHD

#### Description

Switch daemon. It is not possible to run two instances of switchd without argument. (Only models with switch)

#### Command

```
switchd [-i] [-c] [-f/-F file] [-d]
-i : create ethX interfaces (no daemon)
-c : write /var/switch (no daemon)
```



```
-f/-F <firmware> : reset switch and flash it (DANGEROUS)  
-d : run in verbose mode (no daemon)
```

## Results

## Example

## SYSDBG

### Description

Active the debugging. Launch each line from `command_list` file and log it in `/dbg/..`

### Command

```
/usr/Firewall/sbin/sysdbg [-q] [-c <commands>] [-S <hastate>]  
/usr/Firewall/sbin/sysdbg -h  
When run without arguments, simply create the /dbg directory  
and if it already exists, compress its content.  
-c <commands> : execute the commands listed in <commands>-h :  
display help and exit  
-q : quiet, no output  
-S <hastate> : expected licence HA state.
```

## Results

## Example

## SYSINFO

### Description

Displays a detailed list of the configuration and activity of the firewall.

### Command

```
sysinfo [-arp] [-ndp] [-host] [-conn] [-safety] [-proxy] [-  
global] [-ipmi] [-time] [-fastpath] [-ipstate] [-sysctl] [-  
vmstat] [-socket] [-wifi] | [-a]  
-arp: add ARP table  
-ndp: add NDP table  
-host: add ASQ host table  
-conn: add ASQ Connection table  
-safety: add Safety mode information
```





## Results

### Example

```
U2504C0999999999999>sysutil -p ufs/main  
ad0s1a
```

## TCPICK

### Description

tcpick is a textmode sniffer libpcap-based that can track, reassemble and reorder tcp streams.

### Command

```
tcpick [ -a ] [ -n ] [ -C ] [ -i interface ] [ -yH ] [ -yP ] [ -yR ] [ -yU ] [ -yx ] [ -yX ] [ -bH ] [ -bP ] [ -bR ] [ -bU ] [ -bx ] [ -bX ] [ -wH ] [ -wP ] [ -wR ] [ -wU ] [ -v [ verbosity ] ] [ -S ] [ -h ] [ --separator ] [ "filter" ] [ -r file ] [ --help ] [ --version ]
```

## Results

### Example

```
U2504C099999999999999>tcpick -i eth1 -yP -C -h "port 22"  
Starting tcpick 0.2.1 at 2011-04-11 16:54 CEST  
Timeout for connections is 600  
tcpick: listening on eth1  
ERROR: eth1: no IPv4 address assigned  
setting filter: "port 22"  
172.17.6.1:62278 AP > 172.17.6.254:ssh (48)  
|....(..'06.c.....-..`$\.{z...-.k.x(.G.  
172.17.6.254:ssh AP > 172.17.6.1:62278 (48)  
.....E...ku.w.....4.....t.u.....#yj..)...../  
^C  
2 packets captured  
0 tcp sessions detected  
U2504C099999999999999>
```

## TELEMETRYD

### Description

Telemetry daemon.



## Command

```
telemetryd [-D] [-d] [-h]  
-D: will daemonize  
-d: debug mode  
-h: show help message
```

## Results

## Example

```
U2504C099999999999999>telemetryd -d  
telemetryd (pid 2444) is already running  
Signal SIGINFO was sent to current process  
Verbose status is modified
```

## TESTLDAPBASE

### Description

Check if openldap is up and accessible.

### Command

```
testldapbase [-n number] [-t delay][ -v]  
-n: number of tests  
-t: delay in milliseconds between tests  
-v: verbose
```

## Results

## Example

```
U2504C099999999999999>testldapbase  
U2504C099999999999999>
```

## THIND

### Description

Threat intelligence daemon.



## Command

```
thind
```

## Results

## Example

## TOPIC\_MONITOR

### Description

Binary that uses the internal messaging to communicate. It will create a subscriber and receive messages from a specific topic, and then dump them in a readable format.

### Command

```
topic_monitor  
-h [ --help ]: display this message  
-v [ --verbose ]: enable verbosity  
-t [ --topic ] topic_name: set the topic name  
--dump arg: Specify the message dump format, arg may be  
"asc|hex|all" (default is "asc")  
--width arg: Specify the message dump width, arg is an integer  
(default is 16)
```

### Results

Messages from the topic.

### Example

## TOPIC\_READER

### Description

Test binary that use the internal messaging to communicate. It will create a subscriber and receive message from a specific topic.

### Command

```
topic_reader  
-h [ --help ]: Display this message  
-v [ --verbose ]: Enable verbosity  
-t [ --topic ] topic_name: Set the topic name
```



## Results

Messages from the topic.

## Example

```
$> topic_reader --topic test_topic
test
test
test
...
```

## TOPIC\_SENDER

### Description

Test binary that use the internal messaging to communicate. It will create a publisher and send messages to a specific topic.

### Command

```
topic_sender
-h [ --help ]: Display this message
-v [ --verbose ]: Enable verbosity
-t [ --topic ] topic_name: Set the topic name
-m [ --message ] arg: Set the message
-s [ --startup ] arg: Set the delay in seconds at startup
before the first message (default: 1 second)
-i [ --interval ] arg: Set the interval in seconds between
successive sends (default: 1 second)
-c [ --count ] arg: Set the number of times to send the
message before exiting (default: do not stop sending)
```

## Results

Nothing without verbose.

## Example

```
$> topic_sender --topic test_topic --message test --count 3
$>
```

## TPMCTL

### Description

Control TPM (initialization, configuration,reset).



## Command

```
tpmctl [-v] [-i [-n]|-r|-a|-f|-o|-t|-s [-g]]|-C|-c  
<newtpmpassword> [-n]] [-p <tpmpassword>] [-w]  
-v: verbose mode  
-i: initialize TPM (tpm password is mandatory)  
-n: do not derive TPM key from password  
-r: reset TPM (tpm password is mandatory)  
-C: change TPM password (prompt for newpassword, tpmpassword  
is mandatory)  
-c: change TPM password (tpmpassword is mandatory)  
-n: no decrypt (leave pkeys as is (troubleshooting only))  
-a: run TPM diagnostic  
-f: flush TPM session authentication handles  
-p: password associated with TPM (will prompt if not provided  
and tpmpassword is needed)  
-s: rehash symmetric key PCRs (tpmpassword is mandatory)  
-g: force rehash even if secureboot is disabled  
-w: enable TPM TSS verbose  
-o: check if the TPM exists  
-t: return an error code representing TPM status
```

## Results

## Example

## TPROXYD

### Description

Display information about each proxy used on the Firewall (HTTP, SMTP, POP3, FTP, SSL).

### Command

```
tproxyd [-d] [ -L | -s <opt> | -v | -h ]  
-d: debug mode  
  
-h, -?: help  
-L: shows ICAP proxy licences  
-s <http|smtp|pop3|ftp|ssl|av|antispam|rules|all>: shows  
config  
-v: version
```

## Results





## Example

```
VMSNSX08K0013A9>tsd -D
```

## UDPSYNC

### Description

Factory tool.

### Command

```
udpsync [-s] [-p <port>] [-i <phase>] [-t <timeout>] [-v]
[<host>]
-s: Server
-p <port>: host port (default: 1991)
-i <phase>: ???
-t <timeout>: time before timeout in seconds (default: 60s)
-v: verbose mode enabled
```

### Results

## Example

## URLCTL

### Description

Manages the URL classification daemon

### Command

```
urlctl [-v] [-o] [-q] [-b] [-B] [-r <reload arg>] [-R
<reason>] [-s <slotid>] [-u <URL>] [-U <arg>] [-c <CN>] [-C
<arg>] [-d] [-g <arg>]
-v Enable verbosity
-o Specify the output format, arg may be "text|html|xml|json
[,pretty]" (default is "text,pretty")
-q Do not print the results to standard output
-b Bypass CloudURL categorization (oem category will be
'Private IP Adresses')
-B Execute in background (will not print the results)
-r Make urld reload partially or totally its configuration.
arg may be "all", "engine", "filter", "verbose"
-R Text to explain why the reload was requested
-s Classify only for the categories defined in the provided
```



```
slot
-u Classify the given url
-U Classify all the URLs found in the file name given in arg
-c Classify the given CN
-C Classify all the CNs found in the file name given in arg
-d Display the current loaded configuration of urld
-g Display classification groups. arg can be "all", "url",
"cn"
```

## Results

A command is sent to urld. Execution will wait until a response is received from urld unless background execution is requested

## Example

## URLD

### Description

Url and CN classification daemon.

### Command

```
urld [-d] [-D]
-d If an other process is already running, send it a signal to
switch its verbose mode, otherwise start with verbose mode
enabled.
-D Daemonize, run in background.
```

## Results

## Example

## USERREQD

### Description

User Requests daemon.

### Command

```
userreqd [-d] [-D] [-h]
-D: will daemonize
```





## Example



**STORMSHIELD**

[documentation@stormshield.eu](mailto:documentation@stormshield.eu)

*All images in this document are for representational purposes only, actual products may differ.*

*Copyright © Stormshield 2026. All rights reserved. All other company and product names contained in this document are trademarks or registered trademarks of their respective companies.*